




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ASROCK FM2A88M EXTREME4. You'll find the answers to all your questions on the ASROCK FM2A88M EXTREME4 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual ASROCK FM2A88M EXTREME4
User guide ASROCK FM2A88M EXTREME4
Operating instructions ASROCK FM2A88M EXTREME4
Instructions for use ASROCK FM2A88M EXTREME4
Instruction manual ASROCK FM2A88M EXTREME4



[You're reading an excerpt. Click here to read official ASROCK FM2A88M EXTREME4 user guide](http://yourpdfguides.com/dref/5417320)
<http://yourpdfguides.com/dref/5417320>

Manual abstract:

In no event shall ASRock, its directors, officers, employees, or agents be liable for any indirect, special, incidental, or consequential damages (including damages for loss of profits, loss of business, loss of data, interruption of business and the like), even if ASRock has been advised of the possibility of such damages arising from any defect or error in the documentation or product. The terms HDMI™ and HDMI High-Definition Multimedia Interface, and the HDMI logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. CALIFORNIA, USA ONLY The Lithium battery adopted on this motherboard contains Perchlorate, a toxic substance controlled in Perchlorate Best Management Practices (BMP) regulations passed by the California Legislature. When you discard the Lithium battery in California, USA, please follow the related regulations in advance. "Perchlorate Material-special handling may apply, see www.dtsc.ca.gov/hazardouswaste/perchlorate" ASRock Website: <http://www.asrock.com>

Contents 1. Introduction...

.....

.....

.....

.....

.....

.....

.....

.....

.. 1 1.1 1.2 1.

3 1.4 1.5 Package Contents.....

.....

.....

.....

.....

.....

.....

.....

.....

.. Specifications.

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

Unique Features.....

.....

.....

.....

.....

.....

.....

.....

.....

... Motherboard Layout

.....

.....

.....

.....

.....

.....
.....
..... *I/O Panel* . .

.....
.....
.....
.....
.....
.....
.....
.....
.....

1 2 6 11 13 15 16 17 18 20 21 22 27 30 32 33 37 44 47 47 48 48 49 52 53 54 55 56 57 58 60 2. Installation.....

.....
.....
.....
.....
.....
.....
.....

..... *15 Pre-installation Precautions..*

.....
.....
.....
.....
.....
.....

..... *2.1 CPU Installation.*

.....
.....
.....
.....
.....
.....

..... *2.2 Installation of CPU Fan and Heatsink .*

.....
.....
.....
.....

..... *2.3 Installation of Memory Modules (DIMM)..*

.....
.....
.....

..... *2.4 Expansion Slots (PCI and PCI Express Slots)....*

.....

.....
Advanced Screen.....

.....
.....
.....

.....
.....
.....
.....

.....
. 4.4.1 CPU Configuration. .

.....
.....

.....
.....
.....
.....

.....
.....

*.. 4.4.
2 North Bridge Configuration.....*

.....

.....
.....
.....
.....

.. 4.4.3 South Bridge Configuration.....

.....
.....
.....

.....
.....
.....

4.4.4 Storage Configuration.

.....
.....
.....
.....

.....
.....

. . 4.4.5 Super IO Configuration.

.....

.....
.....
.....
.....

.....

.. 4.4.6 ACPI Configuration.

.....
.....

.....
.....
.....
.....

.....
... 4.4.
7 USB Configuration.....

.....
.....
.....

.....
.....
3. Software and Utilities Operation. ...

.....
.....
.. 32 . 4. UEFI SETUP UTILITY.

.....
.....
.....

..... 47 .
4.1 4.2 4.3 4.4 4.
4.8 Trusted Computing....

.....
.....
.....

.....
.....
61 4.5 Tool

.....
.....
.....

.....
.....
... 62 4.6 Hardware Health Event Monitoring Screen.

.....
.....
.....

. 65 4.7 Boot Screen.....

.....
.....
.....
.....
.....



[You're reading an excerpt. Click here to read official ASROCK
FM2A88M EXTREME4 user guide
http://yourpdfguides.com/dref/5417320](http://yourpdfguides.com/dref/5417320)

0 Headers (Support 6 USB 2.0 ports) - 1 x USB 3.0 Header by AMD A88X (Bolton-D4) (Supports 2 USB 3.0 ports) - 64Mb AMI UEFI Legal BIOS with GUI support - Supports "Plug and Play" - ACPI 1.1 compliance wake up events - Supports jumperfree - SMBIOS 2.3.1 support - DRAM, CPU Voltage multi-adjustment - Drivers, Utilities, AntiVirus Software (Trial Version), CyberLink MediaEspresso 6.5 Trial, Google Chrome Browser and Toolbar, Start8 (30 days trial) - CPU temperature sensing - Chassis temperature sensing - CPU Fan Tachometer - Chassis Fan Tachometer - CPU/Chassis Quiet Fan - CPU/Chassis Fan multi-speed control - CASE OPEN detection - Voltage monitoring: +12V, +5V, +3.3V, Vcore - Microsoft® Windows® 8.1 32-bit / 8.1 64-bit / 8 32-bit / 8 64-bit / 7 32-bit / 7 64-bit / XP 32-bit - FCC, CE, WHQL - ErP/EuP ready (ErP/EuP ready power supply is required) * For detailed product information, please visit our website: <http://www.asrock.com> WARNING Please realize that there is a certain risk involved with overclocking, including adjusting the setting in the BIOS, applying Untied Overclocking Technology, or using third-party overclocking tools.

Overclocking may affect your system's stability, or even cause damage to the components and devices of your system. It should be done at your own risk and expense. We are not responsible for possible damage caused by overclocking. 4 CAUTION! 1. Whether 2600/2400/2133/1866/1600MHz memory speed is supported depends on the CPU you adopt. If you want to adopt DDR3 2600/2400/2133/1866/1600 memory module on this motherboard, please refer to the memory support list on our website for the compatible memory modules. ASRock website <http://www.asrock.com> 2. Due to the operating system limitation, the actual memory size may be less than 4GB for the reservation for syBIOS files need to be placed in the root directory of your USB disk.

Only USB2.0 ports support this feature. ASRock OMG (Online Management Guard) Administrators are able to establish an internet curfew or restrict internet access at specified times via OMG. You may schedule 7 the starting and ending hours of internet access granted to other users. In order to prevent users from bypassing OMG, guest accounts without permission to modify the system time are required. ASRock Internet Flash ASRock Internet Flash searches for available UEFI firmware updates from our servers. In other words, the system can autodetect the latest UEFI from our servers and flash them without entering Windows® OS. ASRock UEFI System Browser ASRock UEFI system browser is a useful tool included in graphical UEFI. It can detect the devices and configurations that users are currently using in their PC. With the UEFI system browser, you can easily examine the current system configuration in UEFI setup.

ASRock UEFI Tech Service Contact ASRock Tech Service by sending a support request from the UEFI setup utility if you are having trouble with your PC. ASRock On/Off Play Technology ASRock On/Off Play Technology allows users to enjoy the great audio experience from the portable audio devices, such like MP3 player or mobile phone to your PC, even when the PC is turned off (or in ACPI S5 mode)! This motherboard also provides a free 3.5mm audio cable (optional) that ensures users the most convenient computing environment. ASRock Dehumidifier Function Users may prevent motherboard damages due to dampness by enabling "Dehumidifier Function". When enabling Dehumidifier Function, the computer will power on automatically to dehumidify the system after entering S4/S5 state.

8 ASRock Easy RAID Installer ASRock Easy RAID Installer can help you to copy the RAID driver from a support CD to your USB storage device. After copying the RAID driver to your USB storage device, please change "SATA Mode" to "RAID", then you can start installing the OS in RAID mode. ASRock Easy Driver Installer For users that don't have an optical disk drive to install the drivers from our support CD, Easy Driver Installer is a handy tool in the UEFI that installs the LAN driver to your system via an USB storage device, then downloads and installs the other required drivers automatically. ASRock Interactive UEFI ASRock Interactive UEFI is a blend of system configuration tools, cool sound effects and stunning visuals. The unprecedented UEFI provides a more attractive interface and brings a lot more amusing.

ASRock Fast Boot With ASRock's exclusive Fast Boot technology, it takes less than 1.5 seconds to logon to Windows® 8 from a cold boot. No more waiting! The speedy boot will completely change your user experience and behavior. ASRock X-Boost Brilliantly designed for combo overclocking, ASRock X-Boost Technology is able to unleash the hidden power of your CPUs. Simply press "X" when turning on the PC, X-Boost will automatically overclock the relative components to get up to 15.77% performance boost! With the smart X-Boost, overclocking CPU can become a near one-button process. ASRock Restart to UEFI Windows® 8 brings the ultimate boot up experience. The lightning boot up speed makes it hard to access the UEFI setup. ASRock Restart to UEFI technology is designed for those requiring frequent UEFI access. It is included in ASRock's exclusive all-in-one A-Tuning tuning program that allows users to easily enter the UEFI automatically when turning on the PC next time.

Just 9 simply enable this function; the PC will be assured to access the UEFI directly in the very beginning. ASRock USB Key In a world where time is money, why waste precious time everyday typing usernames to log in to Windows? Why should we even bother memorizing those foot long passwords? Just plug in the USB Key and let your computer log in to windows automatically! ASRock FAN-Tastic Tuning ASRock FAN-Tastic Tuning is included in A-Tuning.

Configure up to five different fan speeds using the graph. The fans will automatically shift to the next speed level when the assigned temperature is met. 10 1.4 Motherboard Layout DDR3_A2 (64 bit, 240-pin module) DDR3_A1 (64 bit, 240-pin module) DDR3_B1 (64 bit, 240-pin module) DDR3_B2 (64 bit, 240-pin module) USB3_3_4 USB 3.0 T: USB1 B: USB2 USB 2.0 T: USB1 B: USB2 Top: RJ-45 LAN CHA_FAN1 FM2A88M Extreme4+ PCIE1 Front USB 3.0 PCI Express 3.0 ATXPWR1 1 SATA3_6 SATA3_3 SATA3_8 SATA3_5 SATA3_7 SATA3_4 PS2 Keyboard/ Mouse USB 2.

0 T: USB3 B: USB4 PWR_FAN1 CPU_FAN1 CPU_FAN2 ATX12V1 VGA1 HDMI1 Bottom: Optical SPDIF Bottom: MIC IN 1 Super I/O AUDIO CODEC HD_AUDIO1 1 DVII SOCKET FM2b Top: CTR BASS Top: LINE IN IRI Center: REAR SPK Center: FRONT PCIE2 CII 1 CMOS BATTERY X Fast RAM PCIE3 1 CLRCMOS1 X Fast LAN X Fast USB AMD A88X (Bolton-D4) Chipset RoHS PCII COM1 64Mb BIOS 1 USB_9_10 SATA3_2 PLED1 LPT1 TPMS1 USB_7_8 USB_5_6 PLED PWRBTN SPEAKER1 1 1 1 1 1 1 HDLED RESET SATA3_1 PANEL 1 11 No. Description 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 Power Fan Connector (PWR_FAN1) ATX 12V Power Connector (ATX12V1) CPU Fan Connector (CPU_FAN1) CPU Fan Connector (CPU_FAN2) 2 x 240-pin DDR3 DIMM Slots (DDR3_A1, DDR3_B1) 2 x 240-pin DDR3 DIMM Slots (DDR3_A2, DDR3_B2) ATX Power Connector (ATXPWR1) USB 3.



[You're reading an excerpt. Click here to read official ASROCK FM2A88M EXTREME4 user guide](http://yourpdfguides.com/dref/5417320)
<http://yourpdfguides.com/dref/5417320>

0 Header (USB_3_4) Clear CMOS Jumper (CLRCMOS1) SATA3 Connector (SATA3_7) SATA3 Connector (SATA3_8) SATA3 Connector (SATA3_6) SATA3 Connector (SATA3_5) SATA3 Connector (SATA3_4) SATA3 Connector (SATA3_3) SATA3 Connector (SATA3_1) SATA3 Connector (SATA3_2) System Panel Header (PANEL1) Power LED Header (PLED1) Chassis Speaker Header (SPEAKER1) USB 2.0 Header (USB_5_6) USB 2.0 Header (USB_7_8) USB 2.0 Header (USB_9_10) TPM Header (TPMS1) Print Port Header (LPT1) COM Port Header (COM1) Infrared Module Header (IR1) Front Panel Audio Header (HD_AUDIO1) Chassis Intrusion Header (CII) Chassis Fan Connector (CHA_FAN1) 12 1.5 I/O Panel 1 2 3 4 5 6 7 14 No. Description 1 2 3 4 5 6 7 13 12 11 No. Description 8 9 10 11 12 13 14 10 9 8 USB 2.0 Ports (USB_3_4)* D-Sub Port LAN RJ-45 Port** Central / Bass (Orange) Rear Speaker (Black) Line In (Light Blue) Front Speaker (Lime)*** Microphone (Pink) Optical SPDIF Out Port USB 2.0 Ports (USB_1_2)* USB 3.0 Ports (USB3_1_2) (AMD A88X (Bolton-D4)) HDMI Port DVI-D Port PS/2 Mouse/Keyboard Port 13 * It is recommended to install the USB Keyboard/Mouse cable to USB 2.0 ports (USB_1_2 or USB_3_4) instead of USB 3.0 ports. ** There are two LEDs on the LAN port. Please refer to the table below for the LAN port LED indications. ACT/LINK LED SPEED LED LAN Port Activity / Link LED Status Off Blinking On Description No Link Data Activity Link Speed LED Status Off Orange Green Description 10Mbps connection 100Mbps connection 1Gbps connection *** If you use a 2-channel speaker, please connect the speaker's plug into "Front Speaker Jack". See the table below for connection details in accordance with the type of speaker you use. Audio Output Channels 2 4 6 8 Front Speaker (No. 7) V V V V Line In or Rear Speaker Central / Bass Side Speaker (No.

5) (No. 4) (No. 6) -V V V --V V --V To enable Multi-Streaming, you need to connect a front panel audio cable to the front panel audio header. After restarting your computer, you will find the "Mixer" tool on your system. Please select "Mixer ToolBox", click "Enable playback multi-streaming", and click "ok". Choose "2CH", "4CH", "6CH", or "8CH" and then you are allowed to select "Realtek HDA Primary output" to use the Rear Speaker, Central/Bass, and Front Speaker, or select "Realtek HDA Audio 2nd output" to use the front panel audio. 14 2. Installation This is a Micro ATX form factor motherboard. Before you install the motherboard, study the configuration of your chassis to ensure that the motherboard fits into it. Pre-installation Precautions Take note of the following precautions before you install motherboard components or change any motherboard settings.

Before you install or remove any component, ensure that the power is switched off or the power cord is detached from the power supply. Failure to do so may cause severe damage to the motherboard, peripherals, and/or components. 1. 2. 3.

4. 5. Unplug the power cord from the wall socket before touching any component. To avoid damaging the motherboard components due to static electricity, NEVER place your motherboard directly on the carpet or the like. Also remember to use a grounded wrist strap or touch a safety grounded object before you handle components.

Hold components by the edges and do not touch the ICs. Whenever you uninstall any component, place it on a grounded antistatic pad or in the bag that comes with the component. When placing screws into the screw holes to secure the motherboard to the chassis, please do not over-tighten the screws! Doing so may damage the motherboard. 15 2.1 CPU Installation Step 1. Unlock the socket by lifting the lever up to a 90 angle. o Step 2. Step 3. Position the CPU directly above the socket such that the CPU corner with the golden triangle matches the socket corner with a small triangle. Carefully insert the CPU into the socket until it fits in place.

The CPU fits only in one correct orientation. DO NOT force the CPU into the socket to avoid bending of the pins. Step 4. When the CPU is in place, press it firmly on the socket while you push down the socket lever to secure the CPU. The lever clicks on the side tab to indicate that it is locked. 16 2.2 Installation of CPU Fan and Heatsink After you install the CPU into this motherboard, it is necessary to install a larger heatsink and cooling fan to dissipate heat. You also need to spray thermal grease between the CPU and the heatsink to improve heat dissipation. Make sure that the CPU and the heatsink are securely fastened and in good contact with each other. Then connect the CPU fan to the CPU FAN connector (CPU_FAN1, see Page 11, No.

3 or CPU_FAN2, see Page 11, No. 4). For proper installation, please kindly refer to the instruction manuals of the CPU fan and the heatsink. 17 2.3 Installation of Memory Modules (DIMM) This motherboard provides four 240-pin DDR3 (Double Data Rate 3) DIMM slots, and supports Dual Channel Memory Technology.

1. For dual channel configuration, you always need to install identical (the same brand, speed, size and chip-type) DDR3 DIMM pairs. 2. It is unable to activate Dual Channel Memory Technology with only one or three memory module installed. 3.

It is not allowed to install a DDR or DDR2 memory module into a DDR3 slot; otherwise, this motherboard and DIMM may be damaged. 4. If you adopt DDR3 2600/2400/2133/1866/1600 memory modules on this motherboard, it is recommended to install them on DDR3_A2 and DDR3_B2 slots. Dual Channel Memory Configuration Priority 1 2 3 DDR3_A1 Populated Populated Populated Populated DDR3_A2 DDR3_B1 Populated Populated Populated Populated DDR3_B2 The DIMM only fits in one correct orientation. It will cause permanent damage to the motherboard and the DIMM if you force the DIMM into the slot at incorrect orientation. 18 1 2 3 19 2.4 Expansion Slots (PCI and PCI Express Slots) There is 1 PCI slot and 3 PCI Express slots on this motherboard. Before installing an expansion card, please make sure that the power supply is switched off or the power cord is unplugged. Please read the documentation of the expansion card and make necessary hardware settings for the card before you start the installation. PCI Slots: PCI slots are used to install expansion cards that have the 32-bit PCI interface.

PCI Express Slots: PCIE1 (PCIe 3.0 x16 slot) is used for PCI Express x16 lane width graphics cards. PCIE2 (PCIe 2.0 x1 slot) is used for PCI Express cards with x1 lane width cards. PCIE3 (PCIe 2.0 x16 slot) is used for PCI Express x4 lane width graphics cards. PCI Express Slot Configurations PCIE1 Single Graphics Card Two Graphics Cards in CrossFireX™ Mode x16 PCIE3 N/A x16 x4 For a better thermal environment, please connect a chassis fan to the motherboard's chassis fan connector (CHA_FAN1) when using multiple graphics cards. 20 2.5 Jumpers Setup The illustration shows how jumpers are setup.



[You're reading an excerpt. Click here to read official ASROCK FM2A88M EXTREME4 user guide](http://yourpdfguides.com/dref/5417320)
<http://yourpdfguides.com/dref/5417320>

When the jumper cap is placed on pins, the jumper is "Short".

If no jumper cap is placed on pins, the jumper is "Open". The illustration shows a 3-pin jumper whose pin1 and pin2 are "Short" when jumper cap is placed on these 2 pins. Jumper Setting Clear CMOS Jumper (CLRCMOS1) (see p.11, No. 9) Description Note: CLRCMOS1 allows you to clear the data in CMOS. To clear and reset the system parameters to default setup, please turn off the computer and unplug the power cord from the power supply. After waiting for 15 seconds, use a jumper cap to short pin2 and pin3 on CLRCMOS1 for 5 seconds. However, please do not clear the CMOS right after you update the BIOS. If you need to clear the CMOS when you just finish updating the BIOS, you must boot up the system first, and then shut it down before you do the clear-CMOS action. Please be noted that the password, date, time, user default profile, 1394 GUID and MAC address will be cleared only if the CMOS battery is removed. If you clear the CMOS, the case open may be detected. Please adjust the BIOS option "Clear Status" to clear the record of previous chassis intrusion status. Default Clear CMOS 21 2.6 Onboard Headers and Connectors Onboard headers and connectors are NOT jumpers. Do NOT place jumper caps over these headers and connectors. Placing jumper caps over the headers and connectors will cause permanent damage of the motherboard! Serial ATA3 Connectors (SATA3_1: see p.11, No. 16) (SATA3_2: see p.11, No. 17) (SATA3_3: see p.

11, No. 15) (SATA3_4: see p.11, No. 14) (SATA3_5: see p.11, No. 13) (SATA3_6: see p.11, No. 12) (SATA3_7: see p.11, No. 10) (SATA3_8: see p. 11, No. 11) SATA3_1 SATA3_2 These eight Serial ATA3 (SATA3) connectors support SATA data cables for internal storage devices. The current SATA3 interface allows up to 6.0 Gb/s data transfer rate. SATA3_7 SATA3_5 SATA3_4 SATA3_3 USB 2.0 Headers (9-pin USB_5_6) (see p.11 No. 21) (9-pin USB_7_8) (see p.11 No. 22) SATA3_6 SATA3_8 USB_PWR P-6 P+6 GND DUMMY 1 GND P+5 P-5 USB_PWR USB_PWR P-8 P+8 GND DUMMY Besides four default USB 2.0 ports on the I/O panel, there are three USB 2.0 headers on this motherboard. Each USB 2.0 header can support two USB 2.0 ports. 1 GND P+7 P-7 USB_PWR (9-pin USB_9_10) (see p.11 No. 23) 1 USB_PWR P-10 P+10 GND DUMMY GND P+9 P-9 USB_PWR USB 3.0 Header (19-pin USB3_3_4) (see p.11, No.

8) Vbus Vbus IntA_P3_SSRXIntA_P3_SSRX+ GND IntA_P3_SSTXIntA_P3_SSTX+ GND IntA_P3_DIntA_P3_D+ IntA_P4_SSRXIntA_P4_SSRX+ GND IntA_P4_SSTXIntA_P4_SSTX+ GND IntA_P4_DIntA_P4_D+ DUMMY Besides two default USB 3.0 ports on the I/O panel, there is one USB 3.0 header on this motherboard. This USB 3.0 header can support two USB 3.0 ports. 22 Infrared Module Header (5-pin IR1) (see p.11 No. 27) This header supports an optional wireless transmitting and receiving infrared module. Front Panel Audio Header (9-pin HD_AUDIO1) (see p. 11 No. 28) GND PRESENCE# MIC_RET OUT_RET 1 OUT2_L J_SENSE OUT2_R MIC2_R MIC2_L This is an interface for the front panel audio cable that allows convenient connection and control of audio devices. 1. High Definition Audio supports Jack Sensing, but the panel wire on the chassis must support HDA to function correctly. Please follow the instruction in our manual and chassis manual to install your system. 2. If you use AC'97 audio panel, please install it to the front panel audio header as below: A. Connect Mic_IN (MIC) to MIC2_L. B. Connect Audio_R (RIN) to OUT2_R and Audio_L (LIN) to OUT2_L. C. Connect Ground (GND) to Ground (GND). D. MIC_RET and OUT_RET are for HD audio panel only. You don't need to connect them for AC'97 audio panel. E. To activate the front mic. For Windows® 8 / 8 64-bit / 7 / 7 64-bit 64-bit OS: Go to the "FrontMic" Tab in the Realtek Control panel. Adjust "Recording Volume". System Panel Header (9-pin PANEL1) (see p.

11 No. 18) This header accommodates several system front panel functions. Connect the power switch, reset switch and system status indicator on the chassis to this header according to the pin assignments below. Note the positive and negative pins before connecting the cables. PWRBTN (Power Switch): Connect to the power switch on the chassis front panel. You may configure the way to turn off your system using the power switch. 23 RESET (Reset Switch): Connect to the reset switch on the chassis front panel. Press the reset switch to restart the computer if the computer freezes and fails to perform a normal restart. PLED (System Power LED): Connect to the power status indicator on the chassis front panel. The LED is on when the system is operating. The LED keeps blinking when the system is in S1 sleep state. The LED is off when the system is in S3/S4 sleep state or powered off (S5). HDLED (Hard Drive Activity LED): Connect to the hard drive activity LED on the chassis front panel. The LED is on when the hard drive is reading or writing data. The front panel design may differ by chassis.

A front panel module mainly consists of power switch, reset switch, power LED, hard drive activity LED, speaker and etc. When connecting your chassis front panel module to this header, make sure the wire assignments and the pin assignments are matched correctly. Chassis Speaker Header (4-pin SPEAKER 1) (see p.11 No. 20) Please connect the chassis speaker to this header.

Power LED Header (3-pin PLED1) (see p.11 No. 19) 1 PLEDPLED+ PLED+ Please connect the chassis power LED to this header to indicate system power status. The LED is on when the system is operating. The LED keeps blinking in S1 state. The LED is off in S3/S4 state or S5 state (power off). Chassis and Power Fan Connectors CHA_FAN_SPEED (4-pin CHA_FAN1) +12V FAN_SPEED_CONTROL GND (see p.11 No. 30) (3-pin PWR_FAN1) (see p.11 No.

1) +12V PWR_FAN_SPEED GND Please connect the fan cables to the fan connectors and match the black wire to the ground pin. CHA_FAN1 fan speed can be controlled through UEFI or A-Tuning. 24 CPU Fan Connectors FAN_SPEED_CONTROL CPU_FAN_SPEED (4-pin CPU_FAN1) (see p.11 No. 3) +12V GND Please connect the CPU fan cable to the connector and match the black wire to the ground pin. 1 2 3 4 Though this motherboard provides 4-Pin CPU fan (Quiet Fan) support, the 3-Pin CPU fan still can work successfully even without the fan speed control function. If you plan to connect the 3-Pin CPU fan to the CPU fan connector on this motherboard, please connect it to Pin 1-3. Pin 1-3 Connected 3-Pin Fan Installation (3-pin CPU_FAN2) (see p.11 No. 4) GND +12V CPU_FAN_SPEED ATX Power Connector (24-pin ATXPWR1) (see p.

11 No. 7) 12 24 Please connect an ATX power supply to this connector. 1 13 12 24 Though this motherboard provides 24-pin ATX power connector, it can still work if you adopt a traditional 20-pin ATX power supply. To use the 20-pin ATX power supply, please plug your power supply along with Pin 1 and Pin 13.



[You're reading an excerpt. Click here to read official ASROCK FM2A88M EXTREME4 user guide](http://yourpdfguides.com/dref/5417320)
<http://yourpdfguides.com/dref/5417320>

20-Pin ATX Power Supply Installation 1 13 ATX 12V Power Connector (8-pin ATX12V1) (see p.

11 No. 2) 4 1 8 5 Please connect an ATX 12V power supply to this connector. Though this motherboard provides 8-pin ATX 12V power connector, it can still work 4 8 if you adopt a traditional 4-pin ATX 12V power supply. To use the 4-pin ATX power supply, please plug your power supply along with Pin 1 and Pin 5. 4-Pin ATX 12V Power Supply Installation 1 5 25 Serial port Header (9-pin COM1) (see p.

11 No. 26) This COM1 header supports a serial port module. Chassis Intrusion Header (2-pin C11) (see p.11, No. 29) Print Port Header (25-pin LPT1) (see p.11, No. 25) 1 GND Signal This motherboard supports CASE OPEN detection feature that detects if the chassis cover has been removed. This feature requires a chassis with chassis intrusion detection design. This is an interface for print port cable that allows convenient connection of printer devices. AFD# ERROR# PINIT# SLIN# GND 1 SPD7 SPD6 ACK# SPD5 BUSY SPD4 PE SPD3 SLCT SPD2 SPD1 SPD0 STB# TPM Header (17-pin TPMS1) (see p.

11, No. 24) 1 This connector supports Trusted Platform Module (TPM) system, which can securely store keys, digital certificates, passwords, and data. A TPM system also helps enhance network security, protects digital identities, and ensures platform integrity. 26 2.7 CrossFireXTM and Quad CrossFireXTM Operation Guide This motherboard supports CrossFireX TM and Quad CrossFireX TM that allows you to install up to two identical PCI Express x16 graphics cards. Currently CrossFireX TM and Quad CrossFireX TM are supported with Windows® 7 / 7 64-bit / 8 / 8 64-bit OS. 1. You should only use identical CrossFireX TM -ready graphics cards that are AMD certified. @@@@It is recommended to use a AMD certified PSU. Please refer to the AMD's website for details.

@@Please check AMD's website for details. @@@@Then select Enable AMD CrossFireX and click Apply.

@@Step 3. Connect the monitor cable to the onboard VGA port. @@@@Step 4.

Boot into OS. @@@@Step 5. Install the onboard VGA driver from our support CD to your system for both the onboard VGA and the discrete graphics card. Step 6. Restart your computer.

Right-click the desktop. Click "AMD VISION Engine Control Center" to enter AMD VISION Engine Control Center. 30 Step 7. You can also click "AMD VISION Engine Control Center" on your Windows® taskbar to enter AMD VISION Engine Control Center. AMD VISION Engine Control Center Step 8. In AMD VISION Engine Control Center, please choose "Performance". Click "AMD CrossFireTM". Step 9. Click "Enable CrossFireTM" and click "Apply" to save your change. Step 10.

Reboot your system. Then you can freely enjoy the benefit of Dual Graphics feature. * Dual Graphics appearing here is a registered trademark of AMD Technologies Inc., and is used only for identification or explanation and to the owners' benefit, without intent to infringe. * For further information of AMD Dual Graphics technology, please check AMD website for up dates and details. 31 3. Software and Utilities Operation 3.1 Installing Drivers The Support CD that comes with the motherboard contains necessary drivers and useful utilities that enhance the motherboard's features. Running The Support CD To begin using the support CD, insert the CD into your CD-ROM drive. The CD automatically displays the Main Menu if "AUTORUN" is enabled in your computer. If the Main Menu does not appear automatically, locate and double click on the file "ASRSETUP.EXE" in the Support CD to display the menu. Drivers Menu The drivers compatible to your system will be auto-detected and listed on the support CD driver page. Please click Install All or follow the order from top to bottom to install those required drivers. Therefore, the drivers you install can work properly.

Utilities Menu The Utilities Menu shows the application software that the motherboard supports. Click on a specific item then follow the installation wizard to install it. 32 3.2 A-Tuning A-Tuning is ASRock's multi purpose software suite with a new interface, more new features and improved utilities, including XFast RAM, Dehumidifier, Good Night LED, FAN-Tastic Tuning, OC Tweaker and a whole lot more. 3.

2.1 Installing A-Tuning When you install the all-in-one driver to your system from ASRock's support CD, A-Tuning will be auto-installed as well. After the installation, you will find the icon "A-Tuning" on your desktop. Double-click the "A-Tuning" icon, A-Tuning main menu will pop up. 3.2.2 Using A-Tuning There are five sections in A-Tuning main menu: Operation Mode, Tools, OC Tweaker, System Info and Tech Service. Operation Mode Choose an operation mode for your computer. 33 Tools Various tools and utilities. XFast RAM Boost the system's performance and extend the HDD's or SSD's lifespan! Create a hidden partition, then assign which files should be stored in the RAM drive.

Fast Boot Fast Boot minimizes your computer's boot time. Please note that Ultra Fast mode is only supported by Windows 8 and the VBIOS must support UEFI GOP if you are using an external graphics card. OMG Schedule the starting and ending hours of Internet access granted to other users. Place X marks on the time table to disable the Internet. Good Night LED Switch off the Power/HDD/LAN LEDs when the system is on, and automatically switch off the Power and Keyboard LEDs when the system enters into Standby/Hibernation mode. 34 FAN-Tastic Tuning Configure up to five different fan speeds using the graph. The fans will automatically shift to the next speed level when the assigned temperature is met. Dehumidifier Prevent motherboard damages due to dampness. Enable this function and configure the period of time until the computer powers on, and the duration of the dehumidifying process. OC Tweaker Configurations for overclocking the system.

System Info View information about the system. 35 Tech Service Contact Tech Service. 36 3.3 Qualcomm® Atheros® Security Wake On Internet Technology Qualcomm® Atheros® Security Wake On Internet Technology allows you to wake up and remote control your home computer from energy efficient sleep mode. Before configuring this feature, make sure that the "PCI Device Power On" is enabled in UEFI SETUP UTILITY > Advanced > ACPI Configuration. 3.3.1 Configuring and Using Sunlogin Oray Sunlogin is a remote control software that lets you easily access and control the remote host that is installed with the Oray SunLogin Client software. Installing Sunlogin remote client Step 1 Login to sunlogin.oray.com. If you have not created a Sunlogin account, create one. Step 2 Download "Sunlogin Client" from the Download section of sunlogin.oray.com and execute it. 37 Step 3 Click on Remote Client and follow the onscreen instructions to complete the installation.



[You're reading an excerpt. Click here to read official ASROCK FM2A88M EXTREME4 user guide](http://yourpdfguides.com/dref/5417320)
<http://yourpdfguides.com/dref/5417320>

Step 4 Double-click the Sunlogin Remote Control icon tray. Step 5 Make sure that "Remote wakeup module" and "Remote control module" is set to On. in the Windows system 38 Installing Sunlogin control client Step 1 For Windows users: Download "Control Client" from the Download section of sunlogin.oray.

com and execute it. Log-in with your Sunlogin Account and Password. For iPad/iPhone users: Download "Sunlogin" from the App Store and install the app. Then fill in your Sunlogin Account and Password. 39 For Andriod mobile device users: Search "Sunlogin" in Google PLAY and then install the app. Then fill in your Sunlogin Account and Password. Using Remote Wakeup For Windows users: Select one Host (Offline with Gray power button) on the control client panel to wake up your home computer. For iPad/iPhone users: Tap one Host (Offline with Gray power button) on the Host List. Then tap the Power button to wakeup your home computer. 40 For Andriod mobile device users: Tap one Host (Offline with Blue power button) on the Host List.

Then tap the Power button to wakeup your home computer. 41 Using Remote Control For Windows users: Right-click on a Host (Online with Blue Windows logo) on the control client panel. Then key in your remote access password. For iPad/iPhone users: Tap one online machine on the Host List and fill in the Access password to start using remote control. 42 For Andriod mobile device users: Tap one online machine and fill in the Access password to start using remote control.

Tutorial Video 43 3.4 Start8 For those Windows 8 users who miss the Start Menu, Start8 is an ideal solution that brings back the familiar Start Menu along with added customizations for greater efficiency. 3.4.1 Installing Start8 Install

Start8 , which is located in the folder at the following path of the Support CD: \ASRock Utility > Start8.

3.4.2 Configuring Start8 Style Select between the Windows 7 style and Windows 8 style Start Menu. Then select the theme of the Start Menu and customize the style of the Start icon. 44 Configure Configure provides configuration options, including icon sizes, which shortcuts you want Start Menu to display, quick access to recently used apps, the functionality of the power button, and more. Control 45 Control lets you configure what a click on the start button or a press on the Windows key does. Desktop Desktop allows you to disable the hot corners when you are working on the desktop. It also lets you choose whether or not the system boots directly into desktop mode and bypass the Metro user interface. About Displays information about Start8. 46 4.

UEFI SETUP UTILITY 4.1 Introduction ASRock Interactive UEFI is a blend of system configuration tools, cool sound effects and stunning visuals. Not only will it make BIOS setup less difficult but also a lot more amusing. This section explains how to use the UEFI SETUP UTILITY to configure your system. The UEFI chip on the motherboard stores the UEFI SETUP UTILITY. You may run the UEFI SETUP UTILITY when you start up the computer. Please press <F2> or <Delete> during the Power-On-Self-Test (POST) to enter the UEFI SETUP UTILITY, otherwise, POST will continue with its test routines. If you wish to enter the UEFI SETUP UTILITY after POST, restart the system by pressing <Ctl> + <Alt> + <Delete>, or by pressing the reset button on the system chassis. You may also restart by turning the system off and then back on. Because the UEFI software is constantly being updated, the following UEFI setup screens and descriptions are for reference purpose only, and they may not exactly match what you see on your screen.

4.1.1 UEFI Menu Bar The top of the screen has a menu bar with the following selections: Main For setting system time/date information OC Tweaker For overclocking configurations Advanced For advanced system configurations Tool Useful tools H/W Monitor Displays current hardware status Boot For configuring boot settings and boot priority Security For security settings Exit Exit the current screen or the UEFI SETUP UTILITY Use < > key or < > key to choose among the selections on the menu bar, and use < > key or < > key to move the cursor up or down to select items, then press <Enter> to get into the sub screen. You can also navigate with a mouse. 47 4.

1.2 Navigation Keys Please check the following table for the function description of each navigation key. Navigation Key(s) // + / - <Tab> <Enter> <PGUP> <PGDN> <HOME> <END> <F1> <F7> <F9> <F10> <F12> <ESC> Function Description Moves cursor left or right to select Screens Moves cursor up or down to select items To change option for the selected items Switch to next function To bring up the selected screen Go to the previous page Go to the next page Go to the top of the screen Go to the bottom of the screen To display the General Help Screen Discard changes and exit the UEFI SETUP UTILITY Load optimal default values for all the settings Save changes and exit the UEFI SETUP UTILITY Print screen Jump to the Exit Screen or exit the current screen 4.2 Main Screen When you enter the UEFI SETUP UTILITY, the Main screen will appear and display the system overview. Active Page on Entry This allows you to select the default page when entering UEFI setup utility.

48 4.3 OC Tweaker Screen In the OC Tweaker screen, you can set up overclocking features. EZ OC Mode You can use this option to adjust EZ overclocking setting. Please note that overcloing may cause damage to your components and motherboard. It should be done at your own risk and expense. CPU Configuration Overclock Mode Use this to select Overclock Mode. Configuration options: [Auto] and [Manual]. The default value is [Auto]. APU/PCIE Frequency (MHz) This item appears only when you set the item "Overclock Mode" to [Manual]. The default value is [Disabled].

Please be noted that overclocking may reduce the D-Sub resolution and cause the display abnormal situation. It is recommended to use DVI or HDMI monitor to get better performance. Spread Spectrum This item should always be [Auto] for better system stability. AMD Turbo Core Technology This item appears only when the processor you adopt supports this feature. Use this to select enable or disable AMD Turbo Core Technology. Configuration options: [Enabled] and [Disabled]. The default value is [Enabled]. AMD Application power Management Application Power Management (APM) ensures that average power consumption over a thermally significant time period remains at or below the TDP for the CPU mode being used. If [Enabled] is selected, the power consumption is reduced when overclocking.



[You're reading an excerpt. Click here to read official ASROCK FM2A88M EXTREME4 user guide](http://yourpdfguides.com/dref/5417320)
<http://yourpdfguides.com/dref/5417320>

49 Processor Maximum Frequency It will display Processor Maximum Frequency for reference.

Processor Maximum Voltage It will display Processor Maximum Voltage for reference. Multiplier/Voltage Change This item is set to [Auto] by default. If it is set to [Manual], you may adjust the value of Processor Frequency and Processor Voltage. However, it is recommended to keep the default value for system stability. Boost Frequency Multiplier For safety and system stability, it is not recommended to adjust the value of this item.

CPU Frequency Multiplier For safety and system stability, it is not recommended to adjust the value of this item. Voltage Control Mode Use this to control voltage mode. CPU Voltage It allows you to adjust the value of CPU voltage. However, for safety and system stability, it is not recommended to adjust the value of this item. CPU Voltage Offset It allows you to adjust the value of CPU voltage offset.

However, for safety and system stability, it is not recommended to adjust the value of this item. CPU NB Frequency Multiplier For safety and system stability, it is not recommended to adjust the value of this item. APU Load-line Calibration APU Load-line Calibration helps prevent APU voltage droop when the system is under heavy load. GFX Engine Clock Use this to adjust GFX Engine Clock. The default value is [Auto]. DRAM Timing Configuration DRAM Frequency If [Auto] is selected, the motherboard will detect the memory module(s) inserted and assigns appropriate frequency automatically. 50 DRAM Timing Control DRAM Slot Use this item to view SPD data. DRAM Timing Control Use this item to control DRAM timing. Power Down Enable Use this item to enable or disable DDR power down mode. Bank Interleaving Interleaving allows memory accesses to be spread out over banks on the same node, or across nodes, decreasing access contention.

Channel Interleaving It allows you to enable Channel Memory Interleaving. Configuration options: [Disabled], [Auto]. The default value is [Auto]. Voltage Configuration DRAM Voltage Use this to select DRAM Voltage. The default value is [Auto]. APU PCIE Voltage VDDP Use this to select APU PCIE Voltage VDDP. The default value is [Auto]. SB Voltage Use this to select SB Voltage. The default value is [Auto]. 51 4.

4 Advanced Screen In this section, you may set the configurations for the following items: CPU Configuration, North Bridge Configuration, South Bridge Configuration, Storage Configuration, Super IO Configuration, ACPI Configuration, USB Configuration and Trusted Computing. Setting wrong values in this section may cause the system to malfunction. 52 4.4.1 CPU Configuration Core C6 Mode Use this item to enable or disable Core C6 mode.

The default value is [Enabled]. Package C6 Mode This item appears only when you enable the item "Core C6 Mode". Use this item to enable or disable Package C6 mode. The default value is [Disabled]. Cool 'n' Quiet Use this item to enable or disable AMD's Cool 'n' Quiet™ technology.

The default value is [Enabled]. Configuration options: [Enabled] and [Disabled]. If you install Windows® 8 / 7 and want to enable this function, please set this item to [Enabled]. Please note that enabling this function may reduce CPU voltage and memory frequency, and lead to system stability or compatibility issue with some memory modules or power supplies. Please set this item to [Disable] if above issue occurs. SVM When this option is set to [Enabled], a VMM (Virtual Machine Architecture) can utilize the additional hardware capabilities provided by AMD-V. The default value is [Enabled]. Configuration options: [Enabled] and [Disabled]. CPU Thermal Throttle Use this item to enable CPU internal thermal control mechanism to keep the CPU from overheated. The default value is [Auto].

53 4.4.2 North Bridge Configuration IOMMU This allows you to enable or disable IOMMU support. Primary Graphics Adapter This item will switch the PCI Bus scanning order while searching for video card. It allows you to select the type of Primary VGA in case of multiple video controllers. The default value of this feature is [PCI Express]. Configuration options: [Onboard], [PCI] and [PCI Express]. Share Memory This allows you to set the share memory feature.

The default value is [Auto]. Configuration options: [Auto], [32MB], [64MB], [128MB], [256MB] [512MB], [1GB] and [2GB].

Onboard HDMI HD Audio This allows you to enable or disable the "Onboard HDMI HD Audio" feature. Dual Graphics This item appears only when you install AMD RADEON graphics card on this motherboard. Use this to enable or disable Dual Graphics feature. If you enable this option, the primary monitor will be onboard VGA. If you select [Auto], Dual Graphics function will be automatically enabled when you install AMD RADEON graphics card.

The default value is [Auto]. DVI Function Use this to select DVI function when you install the DVI to HDMI adapter to DVI port. Configuration options: [as Dual Link DVI] and [as HDMI]. If you select [as Dual Link DVI], you can use Dual Link DVI monitor without audio function. If you select [as HDMI], you can use HDMI monitor with audio function.

The default value is [as Dual Link DVI]. 54 4.4.3 South Bridge Configuration Onboard HD Audio Select [Auto], [Enabled] or [Disabled] for the onboard HD Audio feature. If you select [Auto], the onboard HD Audio will be disabled when PCI Sound Card is plugged. Front Panel Select [Auto] or [Disabled] for the onboard HD Audio Front Panel. On/Off Play With ASRock On/Off Play users can connect their portable audio devices, such as an MP3 player or a mobile phone to the PC and listen to music through the computer's speakers even when the computer is turned off. Onboard LAN This allows you to enable or disable the onboard LAN feature. Good Night LED Enable this option to turn off Power LED when the system is power on. The keyboard LED will also be turned off in S1, S3 and S4 state.

The default value is [Auto]. 55 4.4.4 Storage Configuration SATA Controller Use this item to enable or disable the "SATA Controller" feature. SATA Mode Use this item to adjust SATA Mode. The default value of this option is [AHCI Mode]. Configuration options: [AHCI Mode], [RAID Mode] and [IDE Mode]. If you set this item to RAID mode, it is suggested to install SATA ODD driver on SATA3_5, SATA3_6, SATA3_7 and SATA3_8 ports. AMD AHCI BIOS ROM Use this item to enable or disable AMD AHCI BIOS ROM. The default value of this option is [Disabled].

SATA IDE Combined Mode This item is for SATA3_5, SATA3_6, SATA3_7 and SATA3_8 ports. Use this item to enable or disable SATA IDE combined mode. The default value is [Enabled]. If you want to build RAID on SATA3_5, SATA3_6, SATA3_7 and SATA3_8 ports, please disable this item. Hard Disk S.

M.A.R.T. Use this item to enable or disable the S.

M.A.R.T. (Self-Monitoring, Analysis, and Reporting Technology) feature.



[You're reading an excerpt. Click here to read official ASROCK FM2A88M EXTREME4 user guide](http://yourpdfguides.com/dref/5417320)
<http://yourpdfguides.com/dref/5417320>

Configuration options: [Disabled], [Auto], [Enabled]. 56 4.4.5 Super IO Configuration Serial Port Use this item to enable or disable the onboard serial port. Serial Port Address Use this item to set the address for the onboard serial port.

Configuration options: [3F8h / IRQ4] and [3E8h / IRQ4]. Infrared Port Use this item to enable or disable the onboard infrared port. Infrared Port Address Use this item to set the address for the onboard infrared port. Configuration options: [2F8h / IRQ3] and [2E8h / IRQ3]. Parallel Port Enable or disable the Parallel port. Device Mode Select the device mode according to your connected device. Change Settings Select the address of the Parallel port. 57 4.4.6 ACPI Configuration Suspend to RAM Use this item to select whether to auto-detect or disable the Suspend-toRAM feature.

Select [Auto] will enable this feature if the OS supports it. Check Ready Bit Enable to enter the operating system after S3 only when the hard disk is ready, this is recommended for better system stability. Deep Sleep Configure deep sleep mode for power saving when the computer is shut down. We recommend disabling Deep Sleep for better system compatibility and stability. Restore on AC/Power Loss This allows you to set the power state after an unexpected AC/power loss.

If [Power Off] is selected, the AC/power remains off when the power recovers. If [Power On] is selected, the AC/power resumes and the system starts to boot up when the power recovers. PS/2 Keyboard Power On Use this item to enable or disable PS/2 keyboard to turn on the system from the power-soft-off mode. PCI Devices Power On Use this item to enable or disable PCI devices to turn on the system from the power-soft-off mode. Ring-In Power On Use this item to enable or disable Ring-In signals to turn on the system from the power-soft-off mode.

RTC Alarm Power On Use this item to enable or disable RTC (Real Time Clock) to power on the system. 58 USB Keyboard/Remote Power On Use this item to enable or disable USB Keyboard/Remote to power on the system. USB Mouse Power On Use this item to enable or disable USB Mouse to power on the system. ACPI HPET table Use this item to enable or disable ACPI HPET Table. The default value is [Enabled]. Please set this option to [Enabled] if you plan to use this motherboard to submit Windows® certification. CSM Please disable CSM when you enable Fast Boot option. The default value is [Enabled]. 59 4.4.

7 USB Configuration USB 2.0 Controller Use this item to enable or disable the use of USB 2.0 controller. A88X USB 3.0 Controller Use this item to enable or disable the use of USB 3.0 controller. Legacy USB Support Use this option to select legacy support for USB devices. There are four configuration options: [Enabled], [Auto], [Disabled] and [UEFI Setup Only]. The default value is [Enabled]. Please refer to below descriptions for the details of these four options: [Enabled] - Enables support for legacy USB.

[Auto] - Enables legacy support if USB devices are connected. [Disabled] - USB devices are not allowed to use under legacy OS and UEFI setup when [Disabled] is selected. If you have USB compatibility issue, it is recommended to select [Disabled] to enter OS. [UEFI Setup Only] - USB devices are allowed to use only under UEFI setup and Windows / Linux OS. Legacy USB 3.

0 Support Use this option to enable or disable legacy support for USB 3.0 devices. The default value is [Enabled]. 60 4.4.

8 Trusted Computing Security Device Support Enable to activate Trusted Platform Module (TPM) security for your hard disk drives. 61 4.5 Tool System Browser System Browser can let you easily check your current system configuration in UEFI setup. OMG(Online Management Guard) Administrators are able to establish an internet curfew or restrict internet access at specified times via OMG. You may schedule the starting and ending hours of internet access granted to other users. In order to prevent users from bypassing OMG, guest accounts without permission to modify the system time are required. UEFI Tech Service Contact ASRock Tech Service if you are having trouble with your PC. Please setup network configuration before using UEFI Tech Service. Easy RAID Installer Easy RAID Installer helps you to copy the RAID driver from the support CD to your USB storage device. After copying the drivers please change the SATA mode to RAID, then you can start installing the operating system in RAID mode.

Easy Driver Installer For users that don't have an optical disk drive to install the drivers from our support CD, Easy Driver Installer is a handy tool in the UEFI that installs the LAN driver to your system via an USB storage device, then downloads and installs the other required drivers automatically. UEFI Update Utility Instant Flash Instant Flash is a UEFI flash utility embedded in Flash ROM. This convenient UEFI update tool allows you to update system UEFI without entering operating systems first like MS-DOS or Windows®. Just save the new 62 UEFI file to your USB flash drive, floppy disk or hard drive and launch this tool, then you can update your UEFI only in a few clicks without preparing an additional floppy diskette or other complicated flash utility. Please be noted that the USB flash drive or hard drive must use FAT32/16/12 file system. If you execute Instant Flash utility, the utility will show the UEFI files and their respective information. Select the proper UEFI file to update your UEFI, and reboot your system after the UEFI update process is completed. Internet Flash Internet Flash searches for available UEFI firmware updates from our servers. In other words, the system can auto-detect the latest UEFI from our servers and flash them without entering Windows OS. Network Configuration Internet Setting Use this item to set up the internet connection mode. Configuration options: [DHCP (Auto IP)] and [PPPOE]. UEFI Download Server Use this item to select UEFI firmware download server for Internet Flash. Configuration options: [Asia], [Europe], [USA] and [China]. Dehumidifier Function Users may prevent motherboard damages due to dampness by enabling "Dehumidifier Function". When enabling Dehumidifier Function, the computer will power on automatically to dehumidify the system after entering S4/S5 state.

Dehumidifier Period This allows users to configure the period of time until the computer powers on and enables "Dehumidifier" after entering S4/S5 state. 63 Dehumidifier Duration This allows users to configure the duration of the dehumidifying process before it returns to S4/S5 state. Dehumidifier CPU Fan Setting Use this setting to configure CPU fan speed while "Dehumidifier" is enabled. Would you like to save current setting user defaults? In this option, you are allowed to load and save three user defaults according to your own requirements. 64 4.

6 Hardware Health Event Monitoring Screen In this section, it allows you to monitor the status of the hardware on your system, including the parameters of the CPU temperature, motherboard temperature, CPU fan speed, chassis fan speed, and the critical voltage.



[You're reading an excerpt. Click here to read official ASROCK FM2A88M EXTREME4 user guide](http://yourpdfguides.com/dref/5417320)
<http://yourpdfguides.com/dref/5417320>

CPU Fan 1 & 2 Setting This allows you to set the CPU fan 1 & 2 speed. Configuration options: [Full On] and [Automatic Mode]. The default is value [Full On]. **Chassis Fan 1 Setting** This allows you to set the chassis fan 1 speed. Configuration options: [Full On], [Manual Mode] and [Automatic Mode]. The default is value [Full On]. **Over Temperature Protection** Use this item to enable or disable Over Temperature Protection. The default value is [Enabled]. **Case Open Feature** This allows you to enable or disable case open detection feature.

The default is value [Disabled]. **Clear Status** This option appears only when the case open has been detected. Use this option to keep or clear the record of previous chassis intrusion status. **65 4.7 Boot Screen** In this section, it will display the available devices on your system for you to configure the boot settings and the boot priority. **Fast Boot** Fast Boot minimizes your computer's boot time. The default value is [Disabled]. [Ultra Fast] - There are a few restrictions. 1. Only supports Windows® 8 UEFI operating system.

2. If you are using an external graphics card, the VBIOS must support UEFI GOP in order to boot. **Boot From Onboard LAN** Use this item to enable or disable the Boot From Onboard LAN feature. **Setup Prompt Timeout** This shows the number of seconds to wait for setup activation key.

Bootup Num-Lock If this item is set to [On], it will automatically activate the Numeric Lock function after boot-up. **Full Screen Logo** Use this item to enable or disable OEM Logo. The default value is [Enabled]. **66 Option ROM Messages [Force BIOS]** - The third-party ROM messages will be forced to display during the boot sequence. [Keep Current] - The third-party ROM messages will be displayed only if the third-party manufacturer had set the add-on device to do so.

Boot Failure Guard Enable or disable the feature of Boot Failure Guard. **Boot Failure Guard Count** Enable or disable the feature of Boot Failure Guard Count. **CSM (Compatibility Support Module)** CSM Enable to launch the Compatibility Support Module. Please do not disable unless you're running a WHCK test. If you are using Windows® 8 64-bit and all of your devices support UEFI, you may also disable CSM for faster boot speed. **Launch PXE OpROM Policy** Select UEFI only to run those that support UEFI option ROM only. Select Legacy only to run those that support legacy option ROM only. Do not launch? **Launch Storage OpROM Policy** Select UEFI only to run those that support UEFI option ROM only. Select Legacy only to run those that support legacy option ROM only. Do not launch? **Launch Video OpROM Policy** Select UEFI only to run those that support UEFI option ROM only.

Select Legacy only to run those that support legacy option ROM only. Do not launch? **67 4.8 Security Screen** In this section, you may set or change the supervisor/user password for the system. For the user password, you may also clear it. **Secure Boot** Enable to support Windows® 8 Secure Boot. **68 4.9 Exit Screen** **Save Changes and Exit** When you select this option, it will pop-out the following message, "Save configuration changes and exit setup?" Select [OK] to save the changes and exit the UEFI SETUP UTILITY. **Discard Changes and Exit** When you select this option, it will pop-out the following message, "Discard changes and exit setup?" Select [OK] to exit the UEFI SETUP UTILITY without saving any changes. **Discard Changes** When you select this option, it will pop-out the following message, "Discard changes?" Select [OK] to discard all changes. **Load UEFI Defaults** Load UEFI default values for all the setup questions.

F9 key can be used for this operation. **69 Contact Information** If you need to contact ASRock or want to know more about ASRock, you're welcome to visit ASRock's website at <http://www.asrock.com>; or you may contact your dealer for further information. For technical questions, please submit a support request form at <http://www.asrock.com/support/tsd.asp>

ASRock Incorporation 2F., No.37, Sec.

2, Zhongyang S. Rd., Beitou District, Taipei City 112, Taiwan (R.O.C.) ASRock EUROPE B.V. Bijsterhuizen 3151 6604 LV Wijchen The Netherlands Phone: +31-24-345-44-33 Fax: +31-24-345-44-38 ASRock America, Inc. 13848 Magnolia Ave, Chino, CA91710 U.S.

A. Phone: +1-909-590-8308 Fax: +1-909-590-1026 70 .



[You're reading an excerpt. Click here to read official ASROCK FM2A88M EXTREME4 user guide](http://yourpdfguides.com/dref/5417320)
<http://yourpdfguides.com/dref/5417320>