



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for CASIO CTK-240. You'll find the answers to all your questions on the CASIO CTK-240 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual CASIO CTK-240**  
**User guide CASIO CTK-240**  
**Operating instructions CASIO CTK-240**  
**Instructions for use CASIO CTK-240**  
**Instruction manual CASIO CTK-240**

ES

**CTK-240**  
**CTK-245**

**USER'S GUIDE**  
**GUÍA DEL USUARIO**

Please keep all information for future reference.  
Guarde toda información para tener como referencia futura.

English  
Español

CTK240/245E51A

**CASIO**



[You're reading an excerpt. Click here to read official CASIO CTK-240 user guide](http://yourpdfguides.com/dref/3866687)  
<http://yourpdfguides.com/dref/3866687>

**Manual abstract:**

@@@@@@@However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: · Reorient or relocate the receiving antenna. · Increase the separation between the equipment and receiver. · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. · Consult the dealer or an experienced radio/TV technician for help. FCC WARNING Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Important! Please note the following important information before using this product. @@@@Never let children use an AC adaptor that is seriously damaged. · Never attempt to recharge batteries. · Do not use rechargeable batteries. · Never mix old batteries with new ones. · Use recommended batteries or equivalent types. @@@@ · Do not short-circuit the battery terminals. · The product is not intended for children under 3 years. · Use only CASIO AD-E95100L adaptor. · The AC adaptor is not a toy. · Be sure to disconnect the AC adaptor before cleaning the product. This mark applies in EU countries only. Manufacturer: CASIO COMPUTER CO.,LTD.

6-2, Hon-machi 1-chome, Shibuya-ku, Tokyo 151-8543, Japan Responsible within the European Union: CASIO EUROPE GmbH Casio-Platz 1, 22848 Norderstedt, Germany Safety Precautions ' ! This triangle symbol (/) means that the user should be careful. (The example at left indicates electrical shock caution.) This circle with a line through it (-) means that the indicated action must not be performed. Indications within or nearby this symbol are specifically prohibited. (The example at left indicates that disassembly is prohibited.) The black dot (0) means that the indicated action must be performed. Indications within this symbol are actions that are specifically instructed to be performed. (The example at left indicates that the power plug must be unplugged from the electrical socket.) Symbols Various symbols are used in this user's guide and on the product itself to ensure that the product is used safely and correctly, and to prevent injury to the user and other persons as well as damage to property. Those symbols along with their meanings are shown below.

\* DANGER This symbol indicates information that, if ignored or applied incorrectly, creates the danger of death or serious personal injury. \* WARNING This indication stipulates matters that have the risk of causing death or serious injury if the product is operated incorrectly while ignoring this indication. \$ \* CAUTION This indication stipulates matters that have the risk of causing injury as well as matters for which there is the likelihood of occurrence of physical damage only if the product is operated incorrectly while ignoring this indication. E-1 English Before using the instrument, be sure to carefully read through the instructions contained in this manual. Symbol Examples Safety Precautions \* DANGER Alkaline Batteries Perform the following steps immediately if fluid leaking from alkaline batteries ever gets into your eyes. 1. Do not rub your eyes! Rinse them with water. 2. Contact your physician immediately. Leaving alkaline battery fluid in your eyes can lead to loss of sight.

+ \* WARNING Smoke, Strange Odor, Overheating Continued use of the product while it is emitting smoke, a strange odor, or heat creates the risk of fire and electric shock. Take the following steps immediately. 1. Turn off power. 2. If you are using the AC adaptor for power, unplug it from the wall outlet. 3. Contact your original retailer or an authorized CASIO Service Provider. AC Adaptor Misuse of the AC adaptor creates the risk of fire and electric shock. Always make sure you observe the following precautions. · Be sure to use only the AC adaptor that is specified for this product. · Use only a power source whose voltage is within the rating marked on the AC adaptor. · Do not overload electrical outlets and extension cords. Misuse of the AC adaptor's electric cord can damage or break it, creating the risk of fire and electric shock. Always make sure you observe the following precautions. · Never place heavy objects on the cord or subject it to heat. · Never try to modify the cord or subject it to excessive bending. · Never twist or stretch the cord. · Should the electric cord or plug become damaged, contact your original retailer or authorized CASIO Service Provider. Never touch the AC adaptor while your hands are wet.

Doing so creates the risk of electric shock. Use the AC adaptor where it will not be splashed with water. Water creates the risk of fire and electric shock. Do not place a vase or any other container filled with liquid on top of the AC adaptor. Water creates the risk of fire and electric shock. Batteries Misuse of batteries can cause them to leak, resulting in damage to nearby objects, or to explode, creating the risk of fire and personal injury. Always make sure you observe the following precautions. · Never try to take batteries apart or allow them to become shorted. · Never expose batteries to heat or dispose of them by incineration. · Never mix old batteries with new ones.

· Never mix batteries of different types. · Do not charge the batteries. · Make sure the positive (+) and negative (-) ends of the batteries are facing correctly. + " + % + - - E-2 Safety Precautions Do not incinerate the product. Never throw the product into fire.

Doing so can cause it to explode, creating the risk of fire and personal injury. Water and Foreign Matter Water, other liquids, and foreign matter (such as pieces of metal) getting into the product create the risk of fire and electric shock. Take the following steps immediately. 1. Turn off power. 2. If you are using the AC adaptor for power, unplug it from the wall outlet. 3. Contact your original retailer or an authorized CASIO Service Provider. Disassembly and Modification Never try to take this product apart or modify it in any way. Doing so creates the risk of electric shock, burn injury, or other personal injury. Leave all internal inspection, adjustment, and maintenance up to your original retailer or authorized CASIO Service Provider. Dropping and Impact Continued use of this product after it has been damaged by dropping or subjecting it to strong impact creates the risk of fire and electric shock. Take the following steps immediately. 1.

Turn off power. 2. If you are using the AC adaptor for power, unplug it from the wall outlet. 3. Contact your original retailer or an authorized CASIO Service Provider.



[You're reading an excerpt. Click here to read official CASIO CTK-240 user guide](http://yourpdfguides.com/dref/3866687)  
<http://yourpdfguides.com/dref/3866687>



Use the number buttons to input the two digit rhythm number for the rhythm you want to select. Example: To select "64 WALTZ", input 6 and then 4. Wa l t z  
Selecting a Rhythm This keyboard provides you with 100 exciting rhythms that you can select using the following procedure. To select a rhythm 1.  
Find the rhythm you want to use in the rhythm list and note its rhythm number. · Not all of the available rhythms are shown on the rhythm list printed on the  
keyboard console. For a complete list, see the "Rhythm List" on page A-2. · "00 CLUB POP" is the initial default rhythm setting whenever you turn on  
keyboard power. · You can also increment the displayed rhythm number by pressing [+] and decrement it by pressing [].

E-18 Auto Accompaniment POWER/MODE START/STOP TEMPO Playing a Rhythm Use the following procedure to start and stop rhythm play. To adjust the  
tempo 1. Use the TEMPO buttons (e / r) to adjust the tempo. e : Increases the tempo value. r : Decreases the tempo value. Example: Hold down the r tempo  
value 110 is on the display. To play a rhythm 1. 2. 3. Set the POWER/MODE switch to NORMAL.

Press the START/STOP button to start play of the currently selected rhythm. To stop rhythm play, press the START/ STOP button again. · All of the keyboard  
keys are melody keys while the POWER/MODE switch is set to NORMAL. · Pressing both TEMPO buttons (e and r) at the same time resets the tempo to the  
default value of the currently selected rhythm. About the Graphic Metronome Adjusting the Tempo You can adjust the tempo of rhythm play within a range of  
20 to 255 beats per minute. The tempo setting is applied to Auto Accompaniment chord play, and song bank operations. The graphic metronome appears on  
the display along with the tempo value and beat of a rhythm or built-in tune. The graphic metronome helps you keep in time as you play along with a rhythm  
or built-in tune. Beat Tempo value Graphic metronome E-19 English Auto Accompaniment Using Auto Accompaniment The following procedure describes  
how to use the keyboard's Auto Accompaniment feature. Before starting, you should first select the rhythm you want to use and set the tempo of the rhythm to  
the value you want.

CASIO CHORD Accompaniment Keyboard and Melody Keyboard Accompaniment keyboard Melody keyboard To use Auto Accompaniment 1. 2. 3. Set the  
POWER/MODE switch to CASIO CHORD or FINGERED. Press the START/STOP button to start play of the currently selected rhythm.  
Play a chord. · The actual procedure you should use to play a chord depends on the current POWER/ MODE switch position. Refer to the following pages for  
details on chord play. CASIO CHORD..

.....  
.....  
.. This page FINGERED ...  
.....  
.....

.. Page E-21 · The accompaniment keyboard can be used for playing chords only. No sound will be produced if you try playing single melody notes on the  
accompaniment keyboard. Chord Types CASIO CHORD accompaniment lets you play four types of chords with minimal fingering.  
Chord Types Major chords Major chord names are marked above the keys of the accompaniment keyboard. Note that the chord produced when you press an  
accompaniment keyboard does not change octave, regardless of which key you use to play it. Minor chords (m) To play a minor chord, keep the major chord  
key depressed and press any other accompaniment keyboard key located to the right of the major chord key. @@@@\*1: Inverted  
fingerings cannot be used. The lowest note is the root.

\*2: The same chord can be played without pressing the 5th G. @@@@\*2. Press the START/STOP button to start rhythm play. Press the  
SYNCHRO/FILL-IN button to insert a fill-in pattern for the rhythm you are using. 2. Play a chord on the accompaniment keyboard and the rhythm pattern  
starts to play automatically. Synchro Starting Accompaniment with Rhythm Play You can set up the keyboard to start rhythm play at the same time you play  
the accompaniment on the keyboard. The following procedure describes how to use synchro start. Before starting, you should first select the rhythm you want  
to use, set the tempo, and use the POWER/MODE switch to select the chord play method you want to use (CASIO CHORD, FINGERED). · If the  
POWER/MODE switch is set to NORMAL, only the rhythm plays (without a chord) when you play on the accompaniment keyboard.

· To cancel synchro start standby, press the SYNCHRO/FILL-IN button one more time. E-22 Auto Accompaniment ACCOMP VOLUME [+] / [-] Number  
buttons Adjusting the Accompaniment Volume You can adjust the volume of the accompaniment parts as a value in the range of 0 (minimum) to 9. 1. Press the  
ACCOMP VOLUME button. Current accompaniment volume setting A c c m p V o l 2. Use the number buttons or the [+] / [-] buttons to change the current  
volume setting value. Example: 5 A c c m p V o l · The current accompaniment volume value that appears in Step 1 automatically clears from the display if you  
do not input anything within about five seconds. · Pressing [+] and [-] buttons at the same time automatically sets an accompaniment volume of 7. E-23  
English Using the Song Bank POWER/MODE SONG BANK [+] / [-] Number buttons A selection of 50 Song Bank tunes comes built-in for your listening  
enjoyment or play along fun. You can turn off the melody part to practice with the remaining part.

4. Use the Song Bank list to find the tune you want to play back, and then use the number buttons to input the tune's two-digit number. Example: To select "31  
ALOHA OE", input 3 and then 1. Song Number Song Name Playing Back a Song Bank Tune To play back a Song Bank tune 1. 2.  
3. Set the POWER/MODE switch to NORMAL, FINGERED, or CASIO CHORD. Adjust the main volume and accomp volume. Press the SONG BANK button  
to enter the Song Bank Mode. Appears when SONG BANK button is pressed A l o h a O e · Not all of the available songs are shown on the song bank list  
printed on the keyboard console.

For a complete list, see the "Song List" on page A-8. · "00 TWINKLE TWINKLE LITTLE STAR" is the initial default Song Bank tune setting whenever you  
turn on keyboard power. · You can also increment the displayed tune number by pressing [+] and decrement is by pressing []. E-24 Using the Song Bank  
TEMPO STOP TONE [+] / [-] Number buttons 5. Press the PLAY/PAUSE button to start play of the tune. Appears when PLAY/PAUSE button is pressed A l o  
h a O e Chord name · Each time you select a new Song Bank tune, the tone, tempo, and rhythm that is programmed for the tune are automatically selected. You  
can change a tune's tone and tempo during playback, but you cannot change the rhythm. · You can also adjust the accompaniment volume (page E-23) for  
Song Bank tunes. Song Bank Mode Display In the Song Bank Mode, the display shows a variety of information about the tune being played.



[You're reading an excerpt. Click here to read official CASIO  
CTK-240 user guide  
http://yourpdfguides.com/dref/3866687](http://yourpdfguides.com/dref/3866687)



[Playback Display] Notes played 6.

Press the STOP button to stop playback of the Song Bank tune. To pause Song Bank tune play 1. While a Song Bank tune is playing, press the PLAY/PAUSE button to pause it. The indicator "II" appears while a tune play is paused. Tune tempo A l o h a Oe Chord name 2. To resume play, press PLAY/PAUSE again. E-25 English MELODY ON/OFF PLAY/PAUSE Using the Song Bank Adjusting the Tempo of a Song Bank Tune To change the tempo of a Song Bank tune The tempo can be set within a range of 20 to 255 beats per minute. The tempo setting can be adjusted while the tune is stopped, playing back, or paused. · Pressing both the [+] and [] buttons at the same time selects "00 PIANO 1". · To return a Song Bank tune to its original settings, simply select that tune again.

Playing Along with a Song Bank Tune Each Song Bank tune has an accompaniment part and a melody part. You can turn off the melody part of a Song Bank tune and play along with the remaining part on the keyboard. 1. Use the TEMPO buttons [e / r] to adjust the tempo. e : Increases the tempo value. r : Decreases the tempo value. To play along with a Song Bank tune 1. · Pressing both the [e] and [r] TEMPO buttons at the same time returns the tempo setting to the preset value for the currently selected tune. Perform steps 1 through 4 under "To play back a Song Bank tune" on page E-24 to select the song you want to play along with. Press the MELODY ON/OFF button to turn off the melody part. · The on/off status of the melody part is indicated by "MELODY" that appears on the display. The melody part is turned on when "MELODY" is displayed, and turned off when "MELODY" is not displayed. Changing the Tone of a Song Bank Tune's Melody You can select any one of the keyboard's 100 tones to be used to play the melody part of a Song Bank tune. The tone setting can be changed while the tune is stopped or playing back. 2. 1. While a song is playing back, press the TONE button. Gu t G t r 2. Find the tone you want in the Tone List, and then use the number buttons or the [+] and [] buttons to specify the tone number. Example: To select "30 VIOLIN", input 3 and then 0.

Indicator turns off. Viol in E-26 Using the Song Bank STOP TONE RHYTHM 3. Press the PLAY/PAUSE button to start play of the Song Bank Tune. · Only the accompaniment part is played, so you can play the melody part on the keyboard. Applause Sound Whenever you turn off the melody part of a Song Bank tune and play it back, an applause sound is produced when the tune reaches the end. A l o h a Oe 4. To end playback, press the STOP button. To turn off the applause sound 1. Press the STOP button and the MELODY ON/OFF button at the same time. A p l s =O f f · Pressing the STOP button and the MELODY ON/OFF button at the same time again turns the applause sound back on.

· The selected Song Bank tune continues to repeat until you stop playback by pressing the STOP button. E-27 English MELODY ON/OFF PLAY/PAUSE Using the Song Bank Playing Back All Song Bank Tunes in Succession 1. Use the TONE or RHYTHM button to change to any mode other than the Song Bank Mode. · Make sure a dot is not on the display next to the SONG BANK indicator. Indicator turns off.

Gu t G t r 2. 3. Press the PLAY/PAUSE button to start playback of the Song Bank tunes starting from tune 00. To stop Song Bank tune playback, press the STOP button. · Pausing playback automatically cancels consecutive playback of all Song Bank tunes.

Re-starting playback causes repeat playback of the current tune only. E-28 Keyboard Settings TRANSPOSE/TUNE [+]/[-] Transposing the Keyboard Transpose lets you raise and lower the overall key of the keyboard in semitone units. If you want to play an accompaniment for a vocalist who sings in a key that's different from the keyboard, for example, simply use transpose to change the key of the keyboard. To transpose the keyboard 1. Press the TRANSPOSE/TUNE button until the transpose screen appears on the display. · The keyboard can be transposed within a range of 6 to +5. · The default transpose setting is "0" when keyboard power is turned on. · If you leave the transpose screen on the display for about five seconds without doing anything, the screen is automatically cleared. · The transpose setting also affects Auto Accompaniment. · Playing back a Song Bank tune automatically returns the transpose setting to its standard default of "0".

Tr ans 2. Use [+] and [] to change the transpose setting of the keyboard. Example: To transpose the keyboard five semitones upwards. Tr ans ( + ) E-29 English Keyboard Settings Tuning the Keyboard The tuning feature lets you fine tune the keyboard to match the tuning of another musical instrument. To tune the keyboard 1. Press the TRANSPOSE/TUNE button twice to display the tuning screen. Tune 2. Use [+] and [] to change the tuning setting of the keyboard. Example: To lower the tuning by 20. Tune (-) · The keyboard can be tuned within a range of 50 cents to +50 cents.

\* 100 cents is equivalent to one semitone. · The default tuning setting is "00" when keyboard power is turned on. · If you leave the tuning screen on the display for about five seconds without doing anything, the screen is automatically cleared. · The tuning setting also affects Auto Accompaniment. · Playing back a Song Bank tune automatically returns the tuning setting to its standard default of "00".

E-30 Troubleshooting No keyboard Sound 1. Power supply problem. 1. Correctly attach the AC adaptor, make sure that batteries poles (+/-) are facing correctly, and check to make sure that batteries are not dead. 2.

Set the POWER/MODE switch to the NORMAL position. 3. Use the MAIN VOLUME buttons to increase volume. Pages E-13, 14 2. Power is not turned on. Page E-16 3. Volume setting is too low. 4. The POWER/MODE switch is in the CASIO CHORD or FINGERED position. Page E-16 4.

Normal play is not possible Page E-16 on the accompaniment keyboard while the POWER/ MODE switch is set to CASIO CHORD or FINGERED. Change the POWER/MODE switch setting to NORMAL. Replace the batteries with a Pages set of new ones or use the AC E-13, 14 adaptor. Any of the following symptoms Low battery power while using battery power. · Instrument does not turn on · Display that is flickering, dim, or difficult to read · Abnormally low speaker/ headphone volume · Distortion of sound output · Occasional interruption of sound when playing at high volume · Sudden power failure when playing at high volume · Flickering or dimming of the display when playing at high volume · Continued sound output even after you release a key · A tone that is totally different from the one that is selected · Abnormal rhythm pattern and Song Bank play Auto Accompaniment does not Auto accompaniment volume sound.



[You're reading an excerpt. Click here to read official CASIO CTK-240 user guide](http://yourpdfguides.com/dref/3866687)  
<http://yourpdfguides.com/dref/3866687>

@@other than 0 or 00. @@Press the MELODY ON/OFF button to turn on the melody part. @@@@ Location Avoid the following locations for this product. · Areas exposed to direct sunlight and high humidity · Areas subjected to temperature extremes · Near a radio, TV, video deck, or tuner The above devices will not cause malfunction of the product, but the product can cause interference in the audio or video of a nearby device. User Maintenance · Never use benzene, alcohol, thinner, or other chemical agents to clean the product.

· To clean the product or its keyboard, wipe with a soft cloth moistened in a weak solution of water and a mild neutral detergent. Wring all excess moisture from the cloth before wiping. Included and Optional Accessories Use only accessories that are specified for use with this product. @@@@ · The AC adaptor is intended for indoor use only. Do not use it where it might be exposed to splashing or moisture.

@@ · Store the AC adaptor in a dry place. · Use the AC adaptor in an open, well-ventilated area. @@ · Unplug the AC adaptor from the power outlet if you do not plan to use the product for a long time. · Never try to repair the AC adaptor or modify it in any way. · AC adaptor operating environment Temperature: 0 to 40°C Humidity: 10% to 90% RH · Output polarity: & Weld Lines Lines may be visible on the exterior of the product.

These are "weld lines" that result from the plastic molding process. They are not cracks or scratches. Musical Instrument Etiquette Always be aware of others around you whenever using this product. Be especially careful when playing late at night to keep the volume at levels that do not disturb others. Other steps you can take when playing late at night are closing windows and using headphones. E-34 Operating Precautions Any reproduction of the contents of this manual, either in part or its entirety, is prohibited. Except for your own, personal use, any other use of the contents of this manual without the consent of CASIO is prohibited under copyright laws. IN NO EVENT SHALL CASIO BE LIABLE FOR ANY DAMAGES WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF PROFITS, BUSINESS INTERRUPTION, LOSS OF INFORMATION) ARISING OUT OF THE USE OF OR INABILITY TO USE THIS MANUAL OR PRODUCT, EVEN IF CASIO HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. The contents of this manual are subject to change without notice. The actual appearance of the product may be different from that shown in the illustrations in this User's Guide.

Company and product names used in this manual may be registered trademarks of others. E-35 English Appendix / Apéndice Tone List / Lista de sonidos PIANO/ORGAN 00 PIANO1 01 PIANO2 02 HONKY-TONK 03 STUDIOPIANO 04 ELEC PIANO1 05 ELEC PIANO2 06 ELEC PIANO3 07 ELEC PIANO4 08 HARPSICHORD 09 CLAVELECTRO 10 ELEC ORGAN1 11 ELEC ORGAN2 12 ELEC ORGAN3 13 ELEC ORGAN4 14 CHURCH ORGAN 15 PIPE ORGAN 16 REED ORGAN 17 ACCORDION 18 BANDONEON 19 HARMONICA GUITAR/BASS/STRINGS 20 GUT GUITAR 21 ACOUS GUITAR 22 JAZZ GUITAR 23 ELEC GUITAR 24 MUTE GUITAR 25 DIST GUITAR 26 WOOD BASS 27 ELEC BASS 28 SLAP BASS 29 BANJO 30 VIOLIN 31 CELLO 32 HARP 33 STRINGS1 34 STRINGS2 35 STRINGS3 36 SYNTH-STRI 37 SYNTH-STR2 38 CHOIR 39 VOICE OOH BRASS/REED/PIPE 40 TRUMPET 41 TUBA 42 BRASS ENS 43 FR.HORN1 44 FR.HORN2 45 BRASS1 46 BRASS2 47 SYN-BRASS1 48 SYN-BRASS2 49 SYN-BRASS3 50 SOPRANO SAX 51 ALTO SAX 52 TENOR SAX 53 OBOE 54 CLARINET 55 PICCOLO 56 FLUTE 57 RECORDER 58 PAN FLUTE 59 WHISTLE SYNTH-SOUND 60 SYN-LEAD1 61 SYN-LEAD2 62 SYN-LEAD3 63 SYN-CALLIOPE 64 SYN-PAD1 65 SYN-PAD2 66 SYN-PAD3 67 GLASS HMCA 68 COUNTRY FARM 69 SYN-BASS 70 PEARL DROP 71 COSMIC SOUND 72 SOUNDTRACK 73 SPACE PAD 74 VOICE BASS 75 APPLAUSE 76 SYNTH-SFX 77 VEHICLE 78 PHONE 79 FUNNY LAYER/SPLIT/PERCUSSION 80 STR PIANO 81 STR E.PIANO 82 CHOIRE.P 83 CHOIR ORGAN 84 STR GUITAR 85 STR HARP 86 BRASS STR 87 VIB PAD 88 12 STR GTR 89 CHOIR STR 90 BASS/PIANO 91 BASS/E.PIANO 92 BASS/VIB 93 BASS/GUT GTR 94 V.BASS/OOH 95 STR/PIANO 96 STR/TRUMPET 97 VIBRAPHONE 98 MARIMBA 99 PERCUSSION A-1 Appendix / Apéndice Rhythm List / Lista de ritmos POPS I 00 CLUB POP 01 VOCAL POP 02 RAP POP 03 FUNKY POP 1 04 SOUL BALLAD 05 POP BALLAD 06 LOVE BALLAD 07 FUNKY POP 2 08 EPIC BALLAD 09 LITE POP POPS II 10 16 BEAT SHUFFLE 11 16 BEAT POP 12 16 BEAT FUNK 13 8 BEAT POP 14 8 BEAT SOUL 15 8 BEAT SHUFFLE 16 DANCE POP 1 17 DANCE POP 2 18 POP FUSION 19 FOLKIE POP ROCK 1 20 ROCK WALTZ 21 SLOW ROCK 1 22 SLOW ROCK 2 23 SOFT ROCK 1 24 SOFT ROCK 2 25 SOFT ROCK 3 26 POP ROCK 1 27 POP ROCK 2 28 50'S ROCK 29 60'S SOUL ROCK II 30 4 BEAT ROCK 31 ROCK 32 HEAVY ROCK 33 8 BEAT ROCK 34 STRAIGHT ROCK 35 HEAVY METAL 36 TWIST 37 NEW ORLNS R&R 38 CHICAGO BLUES 39 R&B JAZZ/FUSION 40 BIG BAND 41 SLOW SWING 42 SWING 43 FOX TROT 44 JAZZ WALTZ 45 MODERN JAZZ 46 COOL 47 HARD BOP 48 ACID JAZZ 49 LATIN FUSION DANCE/FUNK 50 VOCAL GROOVE 51 RAVE 52 CLUB GROOVE 53 TECHNO 54 TRANCE 55 HOUSE 56 GROOVE SOUL 57 DISCO 58 RAP 59 FUNK EUROPEAN 60 POLKA 1 61 POLKA 2 62 MARCH 1 63 MARCH 2 64 WALTZ 65 VIENNESE WALTZ 66 FRENCH WALTZ 67 SLOW WALTZ 68 SERENADE 69 TANGO 1 LATIN I 70 BOSSA NOVA 71 SAMBA 72 MAMBO 73 RHUMBA 74 CHA-CHA-CHA 75 MERENGUE 76 REGGAE 77 BOLERO 78 TANGO 2 79 LAMBADA LATIN II/VARIOUS I 80 PUNTA 81 CUMBIA 82 SKA 83 TEX-MEX 84 SALSA 85 FOLKLORE 86 PASODOBLE 87 RUMBA CATALANA 88 SEVILLANA 89 FOLK VARIOUS II 90 COUNTRY 91 BLUEGRASS 92 TOWNSHIP 93 FAST GOSPEL 94 SLOW GOSPEL 95 ADANI 96 BALADI 97 BAROQUE 98 ENKA 99 NEW AGE A-2 Appendix / Apéndice Note Table / Tabla de notas (1) 00 01 02 03 04 05 06 07 08 09 (2) 12 12 6 6 12 12 6 6 12 12 (3) A A A A A A A A A A (1) 10 11 12 13 14 15 16 17 18 19 (2) 12 12 12 6 12 6 12 6 12 12 (3) A A A A A A A A A A (1) 20 21 22 23 24 25 26 27 28 29 (2) 12 12 12 12 12 12 12 12 (3) A A A A B B B A (1) 30 31 32 33 34 35 36 37 38 39 (2) 12 12 12 12 12 6 12 6 12 12 (3) A B A A A A A A A (1) 40 41 42 43 44 45 46 47 48 49 (2) 12 12 6 12 6 12 6 12 6 6 (3) A B A B B B B B B (1) 50 51 52 53 54 55 56 57 58 59 (2) 12 12 12 12 12 12 12 12 (3) A A A A C A A A A (1) 60 61 62 63 64 65 66 67 68 69 (2) 12 6 12 6 6 6 6 6 6 12 (3) A A A A A A A A B (1) 70 71 72 73 74 75 76 77 78 79 (2) 6 6 6 6 12 12 6 6 12 6 (3) A A A B D A D D D (1) 80 81 82 83 84 85 86 87 88 89 (2) 6 6 6 6 6 6 6 6 6 (3) A A A A A B A A A (1) 90 91 92 93 94 95 96 97 98 99 (2) 12 6 12 12 12 12 12 12 (3) E E E E E E A A D (1): Tone number (2): Maximum polyphony (3): Range type (1): Número de sonido (2): Polifonía máxima (3): Tipo de gama A-3 Appendix / Apéndice · See the illustration below for a description of range types (A through E). · Vea la ilustración siguiente para una descripción de los tipos de gama (A a E). Range Type Tipo de gama C-1 C0 A0 C1 A1 C2 A2 C3 C4 C5 C6 C7 C8 C9 G9 A (Standard type) (Tipo estándar) B Low pitch instruments Instrumentos de altura tonal baja C ("55 PICCOLO" only) Solamente "55 PICCOLO" D (Sound Effect) (Efecto de sonido) No scale for tones.



[You're reading an excerpt. Click here to read official CASIO](http://yourpdfguides.com/dref/3866687)

[CTK-240 user guide](http://yourpdfguides.com/dref/3866687)

<http://yourpdfguides.com/dref/3866687>

Sin escala para los sonidos. E (SPLIT) (División) Scale changes in accordance with tone. La escala cambia de acuerdo con el sonido. ..

.....

.Range of keyboard play .....Gama de ejecución de teclado A-4 Appendix / Apéndice Fingered Chord Chart / Cuadros de acordes Fingered This table shows the left-hand fingerings (including inverted forms) for a number of often-used chords.

Esta tabla muestra las digitaciones (incluyendo las formas invertidas) para varios de los acordes más a menudo usados. · Chords marked with asterisk (\*) cannot be played in the Fingered Mode on this keyboard. · En este teclado, los acordes marcados con asterisco (\*) no pueden ejecutarse en el modo Fingered. A-5 Appendix / Apéndice Root Chord Type A-6 Appendix / Apéndice Percussion Instrument List / Lista de instrumentos de percusión · PERCUSSION (tone 99) assigns 39 percussion sound to the keyboard as illustrated below. The sound assigned to each key are indicated above the keyboard. · PERCUSSION (sonido 99) asigna 39 sonidos de percusión al teclado como se ilustra debajo. Los sonidos asignados a cada tecla se indican sobre el teclado. \* No sound is produced when the keys in this range are pressed. \* Cuando se presionan las teclas en esta gama no se produce ningún sonido. BASS DRUM SIDE STICK ACOUSTIC SNARE HAND CLAP ELECTRIC SNARE LOW TOM 2 CLOSED HI-HAT LOW TOM 1 PEDAL HI-HAT MID TOM 2 OPEN HI-HAT MID TOM 1 HIGH TOM 2 CRASH CYMBAL 1 HIGH TOM 1 RIDE CYMBAL 1 CHINESE CYMBAL RIDE BELL TAMBOURINE SPLASH CYMBAL COWBELL CRASH CYMBAL 2 CLAVES RIDE CYMBAL 2 HIGH BONGO LOW BONGO MUTE HIGH CONGA OPEN HIGH CONGA LOW CONGA HIGH TIMBALE LOW TIMBALE HIGH AGOGO LOW AGOGO CABASA MARACAS VOICE BASS DRUM VOICE SNARE VOICE CLOSED HI-HAT VOICE OPEN HI-HAT A-7 Appendix / Apéndice Song List / Lista de canciones SONG BANK / BANCO DE CANCIONES 00 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 TWINKLE TWINKLE LITTLE STAR GRANDFATHER'S CLOCK WHEN THE SAINTS GO MARCHING IN WE WISH YOU A MERRY CHRISTMAS JINGLE BELLS SILENT NIGHT O CHRISTMAS TREE GREENSLEEVES AMAZING GRACE AULD LANG SYNE ACH DU LIEBER AUGUSTIN LONDON BRIDGE J'AI PERDU LE DO DE MA CLARINETTE SUR LE PONT D'AVIGNON I'VE BEEN WORKING ON THE RAILROAD LITTLE BROWN JUG LONG LONG AGO SIPPIN' CIDER THROUGH A STRAW UNDER THE SPREADING CHESTNUT TREE SUMM SUMM SUMM DANNY BOY MY DARLING CLEMENTINE HOUSE OF THE RISING SUN AURA LEE WHEN JOHNNY COMES MARCHING HOME 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 SWANEE RIVER (OLD FOLKS AT HOME) YANKEE DOODLE HOME ON THE RANGE OH! SUSANNA BEAUTIFUL DREAMER TURKEY IN THE STRAW ALOHA OE JAMAICA FAREWELL LA CUCARACHA LA PALOMA TROIKA SZLA DZIEWECZKA WALTZING MATILDA AJO MAMMA RASA SAYANG ODE TO JOY BRIDAL MARCH FROM "LOHENGRIN" AIR FROM "SUITE no. 3" SCENE FROM "SWAN LAKE" MARCH FROM "THE NUTCRACKER" TRIUMPHAL MARCH FROM "AIDA" TOY SYMPHONY SERENADE FROM "EINE KLEINE NACHTMUSIK" CHANSON DU TOREADOR FROM "CARMEN" SPRING FROM "THE FOUR SEASONS" A-8 This recycle mark indicates that the packaging conforms to the environmental protection legislation in Germany. Esta marca de reciclaje indica que el empaquetado se ajusta a la legislación de protección ambiental en Alemania. CASIO COMPUTER CO.,LTD. 6-2, Hon-machi 1-chome Shibuya-ku, Tokyo 151-8543, Japan O MA1006-B Printed in China CTK240/245ES1A .



[You're reading an excerpt. Click here to read official CASIO](#)

[CTK-240 user guide](#)

<http://yourpdfguides.com/dref/3866687>