



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DELONGHI EC 145. You'll find the answers to all your questions on the DELONGHI EC 145 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual DELONGHI EC 145
User guide DELONGHI EC 145
Operating instructions DELONGHI EC 145
Instructions for use DELONGHI EC 145
Instruction manual DELONGHI EC 145

GB

Read this manual thoroughly before installing and using the appliance.

This is the only way to ensure best results and maximum safety for the user.

DESCRIPTION OF THE APPLIANCE

(see figure on pag. 3).

The terminology below will be used repeatedly on the following pages.

- 1 Filter holder for ground coffee
- 2 Large filter for 2 cups ground coffee
- 3 Small filter for 1 cup ground coffee
- 4 Steam knob
- 5 Presser
- 6 Cup tray
- 7 Power cable
- 8 Temperature OK light (coffee/hot water or steam)
- 9  light (appliance on)
- 10 Function selector knob
- 11  position to run off coffee/hot water
- 12 Off position
- 13 Steam position
- 14 Coffee measure
- 15 Boiler outlet
- 16 Steam/hot water tube
- 17 Cappuccino maker
- 18 Water tank
- 19 Water tank lid

SAFETY WARNINGS

- This appliance is designed to "make espresso coffee" and "heat drinks". Use with care to avoid scalds from the water and steam jets or through incorrect use.
- This appliance is intended for domestic use only. Any other use is considered improper and thus dangerous.
- The manufacturer cannot be held responsible for any damage caused through incorrect, wrong or unreasonable use.
- When using the appliance, do not touch the hot surfaces. Use the knobs or handles only.
- Do not touch the appliance with wet or damp hands or feet.
- Do not allow children or unfit persons to use the appliance unsupervised.
- Never allow children to play with the appliance.
- In the event of malfunction or faulty operation, switch off and unplug from the mains.
If it requires repair, contact an authorised service centre only and ask for original spare parts to be used.
Failure to respect the above could reduce the safety of the appliance.

IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH EC DIRECTIVE 2002/96/EC

 At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service.

Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.

INSTALLATION

- After removing the packaging, make sure the product is complete and undamaged. If in doubt, do not use the appliance and contact a qualified professional.
- The packing elements (plastic bags, polystyrene foam, etc.) should be kept out of reach of children as they are a safety hazard.
- Place the appliance on a work surface far away from water taps, basins and sources of heat.
- After positioning the appliance on the work top, leave a space of at least 5 cm between the surfaces of the appliance and the side and rear walls and at least 20 cm above the coffee maker.
- Never install the appliance in environments where the temperature may reach 0°C or lower (the appliance may be damaged if the water freezes).
- Check that the voltage of the mains power supply corresponds to the value indicated on the appliance rating plate.
Connect the appliance to an efficiently earthed socket with a minimum current rating of 10 A only. The manufacturer may not be considered liable for possible incidents caused by the failure to adequately earth the mains.
- If the plug fitted to the appliance does not match the power socket, have the socket replaced with a suitable type by a qualified professional.
- The power cable on this appliance must not be replaced by the user as this operation requires the use of special tools. If the cable is damaged or requires replacing, contact an authorised service centre only to avoid all risks.



[You're reading an excerpt. Click here to read official DELONGHI EC 145 user guide](#)

<http://yourpdfguides.com/dref/3389912>

Manual abstract:

This is the only way to ensure best results and maximum safety for the user. DESCRIPTION OF THE APPLIANCE (see figure on pag. 3). The terminology below will be used repeatedly on the following pages. 1 Filter holder for ground coffee 2 Large filter for 2 cups ground coffee 3 Small filter for 1 cup ground coffee 4 Steam knob 5 Presser 6 Cup tray 7 Power cable 8 Temperature OK light (coffee/hot water or steam) 9 light (appliance on) 10 Function selector knob 11 position to run off coffee/hot water 12 Off position 13 Steam position 14 Coffee measure 15 Boiler outlet 16 Steam/hot water tube 17 Cappuccino maker 18 Water tank 19 Water tank lid IMPORTANT INFORMATION FOR CORRECT DISPOSAL OF THE PRODUCT IN ACCORDANCE WITH EC DIRECTIVE 2002/96/EC. At the end of its working life, the product must not be disposed of as urban waste. It must be taken to a special local authority differentiated waste collection centre or to a dealer providing this service. Disposing of a household appliance separately avoids possible negative consequences for the environment and health deriving from inappropriate disposal and enables the constituent materials to be recovered to obtain significant savings in energy and resources. As a reminder of the need to dispose of household appliances separately, the product is marked with a crossed-out wheeled dustbin.

INSTALLATION · After removing the packaging, make sure the product is complete and undamaged.

If in doubt, do not use the appliance and contact a qualified professional. · The packing elements (plastic bags, polystyrene foam, etc.) should be kept out of reach of children as they are a safety hazard. · Place the appliance on a work surface far away from water taps, basins and sources of heat. · After positioning the appliance on the work top, leave a space of at least 5 cm between the surfaces of the appliance and the side and rear walls and at least 20 cm above the coffee maker.

· If the plug fitted to the appliance does not match the power socket, have the socket replaced with a suitable type by a qualified professional. · The power cable on this appliance must not be replaced by the user as this operation requires the use of special tools. If the cable is damaged or requires replacing, contact an authorised service centre only to avoid all risks. SAFETY WARNINGS · This appliance is designed to "make espresso coffee" and "heat drinks". Use with care to avoid scalds from the water and steam jets or through incorrect use.

· This appliance is intended for domestic use only. Any other use is considered improper and thus dangerous. · The manufacturer cannot be held responsible for any damage caused through incorrect, wrong or unreasonable use. · When using the appliance, do not touch the hot surfaces. Use the knobs or handles only. · Do not touch the appliance with wet or damp hands or feet. · Do not allow children or unfit persons to use the appliance unsupervised. · Never allow children to play with the appliance. · In the event of malfunction or faulty operation, switch off and unplug from the mains. If it requires repair, contact an authorised service centre only and ask for original spare parts to be used.

Failure to respect the above could reduce the safety of the appliance. 11 HOW TO MAKE ESPRESSO COFFEE FILLING THE WATER TANK 1. Open the water tank lid (fig. 1) and then take out the tank by pulling upwards (fig. 2). 2. Fill the tank with fresh clean water taking care not to exceed the MAX level (fig. 3). Replace the tank, pressing lightly to open the valve located on the bottom of the tank. 3.

More simply, the tank can also be filled without removing it, pouring the water directly from a jug. IMPORTANT: It is normal for there to be water in the space under the tank. This should therefore be dried regularly with a clean sponge. NB: Never use the appliance without water in the tank and always remember to top up when the level drops to a couple of centimetres from the bottom. PREHEATING THE COFFEE UNIT To obtain espresso coffee at the right temperature, the coffee machine must be preheated.

Turn the selector knob to the position (fig. 4) at least 15 to 30 minutes before making the coffee, making sure the filter holder is attached to the appliance (check that the steam knob is closed). To attach the filter holder, position it under the boiler outlet with the handle towards the left (see fig. 5), push it upwards and at the same time rotate the handle towards the right. Rotate firmly.

Wait for half an hour, then make the coffee as described in the following chapter. Alternatively, preheating can be achieved more rapidly proceeding as follows: 1. Turn the appliance on by rotating the selector knob to the position (fig. 4) and attach the filter holder to the appliance without adding ground coffee. 2. Place a cup under the filter holder. 3. Wait for the OK indicator light to come on (fig. 6), then immediately rotate the selector knob to the position (fig. 6).

4. Empty the cup. 8. 9. 10. 11. Rotate firmly (fig. 5) to avoid leaks of water. 11. 6. Make sure the OK light (fig. 7) until the required quantity is obtained. To interrupt, place the selector back in the position (fig. 5). (You should not delivery coffee for more than one minute at a time). 7.

To remove the filter holder, rotate the handle from right to left. 12. 13. 2. Rotate the selector knob to the position (fig. 14) and wait until the OK light comes on (fig. 6). 3. The milk must be at refrigerator temperature (not hot!). NB: YOU ARE RECOMMENDED TO USE SEMISKIMMED MILK AT REFRIGERATOR TEMPERATURE. 4. Place the recipient containing the milk under the cappuccino maker (fig. 15). 5. Immerse the cappuccino maker in the milk for about 5 mm and rotate the steam knob anticlockwise (fig. 16) (rotating the knob more or less varies the quantity of steam discharged by the cappuccino maker).

The milk now starts to increase in volume and take on a creamy appearance. 6. When the milk has doubled in volume, immerse the cappuccino maker deeply and continue heating the milk (fig. 17). When the required temperature is reached (the ideal is 60°C), interrupt steam delivery by rotating the steam knob clockwise and placing the selector in the "O" position (fig. 13). 7. Pour the frothed milk into the cups containing the espresso coffee prepared previously. The cappuccino is ready. Sweeten to taste and if desired, sprinkle the froth with a little cocoa powder.

NB: to make coffee again after the milk has been frothed, cool down the boiler first or the coffee will be burnt. To cool, place a container under the boiler outlet, turn the selector to the "coffee" position and run off the water until the OK light goes out. Turn the selector back to the position and make the coffee as described above. IMPORTANT: always clean the cappuccino maker after use. Proceed as follows: 1.

Discharge a little steam for a few seconds by rotating the steam knob (fig.



[You're reading an excerpt. Click here to read official DELONGHI EC 145 user guide](http://yourpdfguides.com/dref/3389912)
<http://yourpdfguides.com/dref/3389912>

16). 2.Wait several minutes for the steam tube to cool down. Unscrew the cappuccino maker by rotating clockwise (fig. 18) and wash thoroughly with warm water. 3.Make sure the three holes in the cappuccino maker shown in fig. 19 are not blocked. If necessary, clean with a pin. 4.Clean the steam tube, taking care to avoid burns. 5.Screw the cappuccino maker back in place. **HOT WATER PRODUCTION** 1.

Turn the appliance on by rotating the selector knob to the position (fig. 4). 2.Place a recipient under the cappuccino maker. 3.When the OK indicator light comes on, turn the selector knob to the position (fig. 8) and at the same time, rotate the steam knob anticlockwise (fig. 18). Hot water is delivered from the cappuccino maker. 4.

To interrupt delivery of hot water, rotate the steam knob clockwise and position the selector knob to "O" (fig. 14) (You should not delivery hot water for more than one minute at a time). **CLEANING AND MAINTENANCE OF THE FILTER** 1. Before performing any cleaning operations, leave the appliance to cool down and unplug from the mains socket. 2.

Do not use solvents or abrasive cleaning products to clean the appliance. A soft, damp cloth is sufficient. 3. Remove the drip tray, empty and wash frequently. 4.

Clean the water tank regularly. 5. @@If necessary, clean with a pin (see fig. @@@@21). @@Make sure the holes are not blocked. If necessary, clean with a pin (fig. 20). Failure to clean as described above invalidates the guarantee. **IMPORTANT:** during cleaning, never immerse the coffee machine in water. It is an electrical appliance.

13 DESCALING You are recommended to descale the coffee machine about every 200 coffees. You should use a commercially available product specifically for descaling espresso coffee machines. If such a product is not available, proceed as follows. 1.Fill the tank with half a litre of water. 2.Dissolve 2 spoonfuls (about 30 grams) of citric acid (obtainable from chemist's). 3.Rotate the selector knob to the position and wait until the OK indicator light comes on. 4.

Make sure the filter holder is not attached and position a recipient under the boiler se indicated in figure 19. 15 .



[You're reading an excerpt. Click here to read official DELONGHI EC](#)

[145 user guide](#)

<http://yourpdfguides.com/dref/3389912>