




# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for DELONGHI PMC 110. You'll find the answers to all your questions on the DELONGHI PMC 110 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual DELONGHI PMC 110**  
**User guide DELONGHI PMC 110**  
**Operating instructions DELONGHI PMC 110**  
**Instructions for use DELONGHI PMC 110**  
**Instruction manual DELONGHI PMC 110**



[You're reading an excerpt. Click here to read official DELONGHI PMC 110 user guide](http://yourpdfguides.com/dref/3382689)  
<http://yourpdfguides.com/dref/3382689>

**Manual abstract:**

Caution and common sense should nevertheless be used when cooking with the "Pasta Cooker", particularly in the presence of children. · Before use, make sure the mains supply voltage corresponds to the voltage indicated on the rating plate. · After removing the packaging, make sure the product is complete. If in doubt, do not use the appliance and contact a professionally qualified person. · Connect the appliance to an efficiently earthed socket with a minimum current rating of 10 A only. (If the plug fitted to the appliance does not match the power socket, have the socket replaced with a suitable type by qualified personnel). · This appliance is intended for household use only. Any other use is considered improper and thus dangerous. · Never locate the appliance near sources of heat or outdoors. · Never immerse the appliance in water.

Water infiltration could cause electrical shock. · When in use, the appliance becomes hot. **KEEP AWAY FROM CHILDREN.** · The hot water could cause serious burns. Never move the pasta cooker when the water is hot.

· Never move the bowl while in operation. · Never exceed the MAX level to avoid water or foam boiling over during cooking. · Move the appliance with the handles only. (Never lift by the basket handle). · Position the bowl only after filling it with water to the levels indicated.

If heated up without water, a thermal protection device trips and shuts the appliance down. @@@@This is normal and disappears after a few minutes. Ventilate the room. · Never insert any utensils into the appliance. The use of accessories not recommended by the manufacturer may cause fire, electric shock or injury. · If the bowl is filled beyond the maximum level indicated, the water may boil over and optimum cooking results cannot be guaranteed. Always respect the quantities and volumes recommended in this manual. · Never let children or unfit persons use the appliance without supervision. · You are recommended to keep the "Pasta Cooker" away from the edge of the work surface and out of the reach of children. · Never use the appliance as a deep fryer.

Never cook in oil · Important: do not use on sloping surfaces, make sure the appliance is resting on a stable surface before using. · The protective cover must under no circumstances be used while the "Pasta Cooker" is in operation. · Never leave the power cable dangling from the work surface as it could be grabbed by children or get in the way of the user. Do not use extensions. · If the power cable is damaged, it must be replaced by the manufacturer, an authorised service centre or a qualified electrician in order to eliminate all risk. · If the power cable requires replacing, use H05VV-F cable with a cross-section of 3x1mm<sup>2</sup> only. The replacement cable must conform to current safety standards and must have the same diameter as the original cable. · The removable bowl must be inserted and extracted with great care. When performing these operations, the water and appliance must be cold. When the removable bowl is in place, make sure it is correctly positioned as otherwise the appliance may not start up and it may be difficult to insert and move the cooking basket.

15 GB 2-07-2003 10:21 Pagina 16 STANDARD ACCESSORIES MAX MED MIN REMOVABLE BOWL (E) The bowl must ALWAYS be in place when using the Pasta Cooker. Three water levels are indicated inside the bowl MIN, MED and MAX, corresponding to 1.5 l, 2.5 l and 3.5 l.

The level of water can be adjusted according to the quantity of pasta to be cooked. · Never exceed the MAX level to avoid water or foam boiling over during cooking. The bowl can be washed in the dishwasher. BASKET (G) The basket must ALWAYS be used when cooking pasta. The only exception is fresh home-made gnocchi (for more information see tips on page 19).

The basket can be washed in the dishwasher. TRANSPARENT LID (O) When cooking whole spaghetti, use of the lid is fundamental to ensure the pasta enters the water correctly. For other types of pasta, it can be used to support the sauce warmer or separator in the special slots (P). The transparent lid can be washed in the dishwasher. MIXER (N) AND MIXER SUPPORT (M) The mixer must be used whenever cooking pasta. It is divided into two sections to facilitate removal and cleaning. The mixer and support can be washed in the dishwasher. SEPARATOR (R) The separator must ALWAYS be used when cooking broken spaghetti. This accessory may, however, be used to mix all types of pasta (even short formats) to avoid it sticking together. It is inserted in the special slot (P) in the transparent lid.

The separator can be washed in the dishwasher. SAUCE WARMER (Q) This accessory can be used to warm the sauce while cooking the pasta, exploiting the steam given off by the boiling water. The sauce warmer is inserted in the special slot (P) in the transparent lid. It cannot be used to reheat frozen sauces. The sauce warmer can be washed in the dishwasher. PROTECTIVE COVER (S) The protective cover must under no circumstances be used while the "Pasta Cooker" is in operation. After cooking, place the protective cover on the appliance to avoid dust building up inside the Pasta Cooker. 16 GB 2-07-2003 10:21 Pagina 17 HOW TO SET THE CLOCK (MODELS WITH TIMER ONLY) When the appliance is connected to the electricity supply for the first time or after it has been without power for some time, four dashes (- - - -) will flash on the display and the pasta cooking time (10) is automatically set by the appliance. 1. press the clock button (6).

(the hours flash on display 1) 12-- 15-- 2. set the hour using the - (2) and + (3) buttons (the hours flash on display 1) 15:00 3. press the clock button (6) again. (the minutes flash on display 1) 15:06 4. set the minutes using the - (2) and + (3) buttons.

(the minutes flash on display 1) 15:06 10 5. press the clock button (6) again. (the time set is displayed on display 1 together with the minutes required to cook the pasta on the right in smaller characters). · If you want to change the time set, press the CLOCK button (6) then repeat the procedure described above to set a new time (this operation must be performed only when the machine is not in operation). · The time must be set in order to use the "delayed start-up" function.

@@@@@ · Never turn the appliance on without water in the bowl. @@@@2. @@@@@@Never use with water below the minimum level indicated. @@@@place the basket in the bowl lining up the hook with the housing. Make sure the mixer is attached correctly to the support.

@@@@@the preset cooking time of 10 minutes is displayed. @@Press the START/STOP button (4) (figure 13). The Pasta Cooker starts operating and the relative LED (5) comes on. @@Countdown of the pasta cooking time begins once the basket has been lowered completely.



[You're reading an excerpt. Click here to read official DELONGHI  
PMC 110 user guide  
http://yourpdfguides.com/dref/3382689](http://yourpdfguides.com/dref/3382689)

the cooking time indicated on the display can be modified at any moment using the - (2) or + (3) buttons.

one minute before the end of the cooking time, the appliance emits a beep to warn that cooking is about to end. You can taste the pasta to check if it is cooked as you require. at the end of the cooking time, the basket is raised up automatically accompanied by a beep. if the pasta is still too hard, press the START/STOP button (4) again. The pasta will continue cooking for a further minute (this time can be increased by pressing the + (3) button) and then is drained automatically. to interrupt cooking before the end of the cooking time, just press the START/STOP BUTTON (4); after 30 seconds, the basket is raised automatically. alternatively, the basket can be raised up manually at any moment by pulling the handle lock outwards and lifting the basket up (figure 14). . . . . . 18 GB 2-07-2003 10:21 Pagina 19 · after removing the transparent lid, pour the pasta into a bowl. To facilitate this (particularly for spaghetti), the mixer can be unhooked from its support by pressing the two tabs (figures 15 and 16). · Once the appliance is turned on, if you realise it needs topping up with further water, proceed as follows: 1.

Press the START/STOP button (4) to turn off the appliance; 2. Add water, taking care not to exceed the MAX level; 3. Press the START/STOP button to turn the appliance on again. 3. IMPORTANT · When the appliance is plugged in, the automatic basket movement mechanism may come into operation to verify the position of the basket.

Wait until the handle lock is in the raised position before cooking again. · Do not touch the bowl during cooking as it becomes extremely hot. To lift it ALWAYS use the handles. You are, however, recommended to wait until the water cools down before emptying (figure 17). · Do not remove the bowl when the appliance is in operation 4.

**USEFUL TIPS FOR GETTING THE BEST FROM YOUR PASTA COOKER** The bowl has three levels marked inside (MIN - MED - MAX), corresponding to 1.5, 2.5 and 3.5 litres of water. The quantity of water can be adjusted according to the amount of pasta to be cooked. To cook one portion (up to 100 g), the minimum level of water is sufficient (this speeds up boiling times). Up to 300 g, the middle level is pressed. If this occurs, simply set the TIMER for a longer period. · there may be a maximum tolerance of about five minutes longer than the time set. · once programmed cooking has been activated (TIMER ON indicator light on), the time reappears on the display.

To display the programmed cooking time, just press the TIMER button. The setting reappears for a few seconds. 21 GB 2-07-2003 10:21 Pagina 22

**CLEANING** Before cleaning, always unplug from the mains. Do not immerse the Pasta Cooker in water and do not place under the tap. Water infiltration could cause short circuits and electric shock. After allowing the water to cool down, empty the bowl (E), lifting it out with the help of the handles (F). Never empty the Pasta Cooker by tilting it or turning it upside down. The bowl and all accessories may be washed in warm water with normal washing up liquid or in a dishwasher. When washing the bowl (E) and the basket (G), position with care to avoid scratching the non-stick coating. Do not use abrasives, steel wool or sharp metal utensils to clean the bowl (E) and basket (G).

Clean the surfaces with a soft damp cloth only. You are recommended to clean the basket each time you use it, taking care to remove all pasta deposits. To facilitate cleaning, you should remove the mixer from its support by pressing lightly with the fingers on the tabs projecting inside the basket. **MAINTENANCE** In the case of malfunction or defective operation, contact a technical service centre authorised by the manufacturer. @@@@The bowl is not in the correct place.

"EPOS" is displayed accompa- Make sure the bowl handles (F) are inserted in their panied by a warning beep. housing (C). press the START/STOP button (4) to turn the beep off. "C" is displayed accompa- "Prob" is displayed accompnied by a warning beep panied by a warning beep the temperature sensor may be faulty. try turning the appliance on again.

"F" is displayed accompa- "FCO" is displayed accompnied by a warning beep panied by a warning beep the lifting mechanism may be faulty. try turning the appliance on again. the MAX level has been exceeded press the START/STOP button (4) to turn the beep off. Water in the bowl boils Water in the bowl boils dirty starchy water from previous cooking has been used. over during cooking over during cooking turn the appliance off and dry well 22 .



[You're reading an excerpt. Click here to read official DELONGHI](http://yourpdfguides.com/dref/3382689)

[PMC 110 user guide](http://yourpdfguides.com/dref/3382689)

<http://yourpdfguides.com/dref/3382689>