



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for EPSON EXPRESSION PHOTO HD XP-950. You'll find the answers to all your questions on the EPSON EXPRESSION PHOTO HD XP-950 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual EPSON EXPRESSION PHOTO HD XP-950**

**User guide EPSON EXPRESSION PHOTO HD XP-950**

**Operating instructions EPSON EXPRESSION PHOTO HD XP-950**

**Instructions for use EPSON EXPRESSION PHOTO HD XP-950**

**Instruction manual EPSON EXPRESSION PHOTO HD XP-950**

**EPSON**  
EXCEED YOUR VISION

## User's Guide

MF080001



[You're reading an excerpt. Click here to read official EPSON EXPRESSION PHOTO HD XP-950 user guide](http://yourpdfguides.com/dref/5516370)  
<http://yourpdfguides.com/dref/5516370>

**Manual abstract:**

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions. Seiko Epson Corporation and its affiliates shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation. Seiko Epson Corporation shall not be held liable for any damage resulting from electromagnetic interference that occurs from the use of any interface cables other than those designated as Epson Approved Products by Seiko Epson Corporation. ©©©© Copyright © 2001 Seiko Epson Corporation. All rights reserved. ©©©© Epson Scan software is based in part on the work of the Independent JPEG Group. libtiff Copyright © 1988-1997 Sam Leffler Copyright © 1991-1997 Silicon Graphics, Inc. Permission to use, copy, modify, distribute, and sell this software and its documentation for any purpose is hereby granted without fee, provided that (i) the above copyright notices and this permission notice appear in all copies of the software and related documentation, and (ii) the names of Sam Leffler and Silicon Graphics may not be used in any advertising or publicity relating to the software without the specific, prior written permission of Sam Leffler and Silicon Graphics.

THE SOFTWARE IS PROVIDED "AS-IS" AND WITHOUT WARRANTY OF ANY KIND, EXPRESS, IMPLIED OR OTHERWISE, INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL SAM LEFFLER OR SILICON GRAPHICS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER OR NOT ADVISED OF THE POSSIBILITY OF DAMAGE, AND ON ANY THEORY OF LIABILITY, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE. © Microsoft, Windows, and Windows Vista are registered trademarks of Microsoft Corporation. Apple, Macintosh, Mac OS, and OS X are trademarks of Apple Inc., registered in the U.

S. and other countries. AirPrint is a trademark of Apple Inc. Google Cloud Print © © © ™ is a registered trademark of Google Inc. ABBYY and ABBYY FineReader names and logos are registered trademarks of ABBYY Software House.

© © Adobe, Adobe Reader, Acrobat, and Photoshop are trademarks of Adobe systems Incorporated, which may be registered in certain jurisdictions. General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks. © 2013 Seiko Epson Corporation. All rights reserved. The contents of this manual and the specifications of this product are subject to change without notice. 3 User's Guide Contents Contents Copyright and Trademarks Copyright and Trademarks. . . .

.....  
.....  
2 Removing a CD/DVD. ....  
.....  
... Inserting a Memory Card. ....  
.....  
.. Placing Originals. ....  
.....  
.....  
.. Scanner glass. ...  
.....  
.....  
... 35 . 35 .  
36 . 36 Introduction Where to Find Information. ...  
.....  
... Caution, Important and Note. ....  
.....  
... Operating System Versions. .  
.....  
..... Using Epson Connect Service. ....  
.....  
..... .7 .7 .8 Copying Copying Documents. .  
.....  
.....  
Basic copying. ....  
.....  
.....  
2-Sided copying. ....  
.....

.....	<i>Layout copying.</i>	.....
.....		.....
.....		.....
.....		.....
.....	<i>Copy Mode Menu List.</i>	.....
.....		.....
.....		.....
.....	<i>39 . 39 . 39 . 40 . 41 Important Instructions Safety Instructions.</i>	.....
.....		.....
.....		.....
.....		.....
.....	<i>9 Product Advisories and Warnings.</i>	.....
.....		.....
.....	<i>9 Setting up/using the product.</i>	.....
.....		.....
.....		.....
.....	<i>9 Using the product with a wireless connection.</i>	.....
.....		.....
.....		.....
.....		.....
.....	<i>11 Using memory cards.</i>	.....
.....		.....
.....		.....
.....	<i>11 Using the touchscreen.</i>	.....
.....		.....
.....	<i>11 Handling ink cartridges.</i>	.....
.....		.....
.....		.....
.....	<i>12 Restrictions on Copying.</i>	.....
.....		.....
.....		.....
.....	<i>12 Printing Basic Operation from the Control Panel.</i>	.....
.....		.....
.....	<i>Printing photos.</i>	.....
.....		.....
.....		.....
.....		.....
.....	<i>Printing photos from a digital camera.</i>	.....
.....		.....
.....	<i>Print photos mode menu list.</i>	.....
.....		.....
.....		.....
.....	<i>Basic Operation from Your Computer.</i>	.....
.....		.....
.....		.....
.....	<i>Printer driver and status monitor.</i>	.....
.....		.....
.....		.....
.....	<i>Basic Printing.</i>	.....
.....		.....
.....		.....
.....	<i>Canceling Printing.</i>	.....
.....		.....
.....		.....
.....		.....
.....	<i>Other Options.</i>	.....
.....		.....
.....		.....
.....		.....
.....	<i>Printing photos the easy way.</i>	.....
.....		.....
.....		.....
.....	<i>Printing on CD/DVD.</i>	.....
.....		.....
.....		.....
.....		.....

.. Product presets (for Windows only). . .	
..... 2-sided printing. . . . .	
.....	
.....	
.... Fit to page printing.	
.....	
.....	
Pages per sheet printing. . . . .	
.....	
..... Sharing the Product for Printing. .	
.....	
. Setup for Windows. . . . .	
.....	
.....	
.. Setup for Mac OS X. . . . .	
.....	
.....	
.... 42 . 42 . 43 . 45 . 45 . 45 .	
47 . 50 . 52 . 52 . 53 . 55 . 56 . 58 . 59 . 60 .	
60 . 62 Getting to Know Your Product Available features for your product. . . . .	
.....	
.. Product Parts. . . . .	
.....	
.....	
.... Notes regarding the control panel and the output tray.	
.....	
.....	
.....	
. Guide to the Control Panel. . . . .	
.....	
.... Button and LCD. . . . .	
.....	
.....	
..... Lights. . . . .	
.....	
.....	
.....	
..... 13 . 14 .	
16 . 17 . 17 . 19 Paper and Media Handling Introduction to Using, Loading, and Storing Media. . . . .	
.....	
.....	
.....	
..... Storing paper. . . . .	
.....	
.....	
.....	
. Selecting Paper. . . . .	
.....	
.....	
..... Paper type settings on the LCD screen. . . . .	
.... Paper type settings from the printer driver. . . . Loading Paper. .	
.....	
.....	
.....	

. . . . .	<i>Into the paper cassette. . . . .</i>	
	. . . . .	
	. . . . .	
. . . . .	<i>Into the rear paper feed slot. . . . .</i>	
	. . . . .	
	. . . . .	
. . . . .	<i>Loading a CD/DVD. . . . .</i>	
	. . . . .	
	. . . . .	
	. . . . .	
. . . . .	<i>20 . 20 . 20 . 22 . 23 . 24 . 24 . 30 .</i>	
. . . . .	<i>33 Scanning Let's Try Scanning. . . . .</i>	
	. . . . .	
	. . . . .	
. . . . .	<i>Starting a Scan. . . . .</i>	
	. . . . .	
	. . . . .	
. . . . .	<i>Image Adjustment Features. . . . .</i>	
	. . . . .	
. . . . .	<i>Basic Scanning from the Control Panel. . . . .</i>	
	. . . . .	
. . . . .	<i>Scan mode menu list. . . . .</i>	
	. . . . .	
. . . . .	<i>Basic Scanning from Your Computer. . . . .</i>	
	. . . . .	
. . . . .	<i>Scanning in Full Auto Mode. . . . .</i>	
	. . . . .	
. . . . .	<i>Scanning in Home Mode. . . . .</i>	
	. . . . .	
	. . . . .	
. . . . .	<i>Scanning in Office Mode. . . . .</i>	
	. . . . .	
. . . . .	<i>Scanning in Professional Mode. . . . .</i>	
	. . . . .	
	. . . . .	
. . . . .	<i>Previewing and Adjusting the Scan Area. . . . . 63 . 63 . 65 .</i>	
67 . 68 . 68 . 68 . 70 . 72 . 74 . 76 4	<i>User's Guide Contents Various Types of Scanning. . . . .</i>	
	. . . . .	
	. . . . .	
. . . . .	<i>Scanning a Magazine. . . . .</i>	
	. . . . .	
. . . . .	<i>Scanning Multiple Documents to a PDF File . . . . .</i>	
	. . . . .	
	. . . . .	
	. . . . .	
. . . . .	<i>Scanning a Photo. . . . .</i>	
	. . . . .	
	. . . . .	
. . . . .	<i>Software Information. . . . .</i>	
	. . . . .	
	. . . . .	
. . . . .	<i>Starting Epson Scan Driver. . . . .</i>	
	. . . . .	
. . . . .	<i>Starting Other Scanning Software. . . . .</i>	
	. . . . . 78 . 78 .	
80 . 83 . 84 . 84 . 85	<i>Maintaining Your Product and Software Checking the Print Head Nozzles. . . . .</i>	

.....  
.. 111 Using the Nozzle Check utility for Windows ...

.....

.....

.....

.....

.. 111 Using the Nozzle Check utility for Mac OS X ..



[You're reading an excerpt. Click here to read official EPSON  
EXPRESSION PHOTO HD XP-950 user guide](http://yourpdfguides.com/dref/5516370)  
<http://yourpdfguides.com/dref/5516370>

.....  
.....  
.....  
.....  
..... 111 Using the control panel. . .

.....  
.....  
.....  
.....  
..... 112 Cleaning the Print Head. . . . .

..... 112 Using the Head Cleaning utility for Windows . . . . .  
.....  
.....  
.....

..... 113 Using the Head Cleaning utility for Mac OS X .  
.....  
.....  
.....

.....  
..... 113 Using the control panel.  
.....  
.....

.. 114 Aligning the Print Head. . . . .  
.....  
.....  
.. 114 Using the Print Head Alignment utility for Windows. . . . .

.....  
.....  
.....  
.....  
114 Using the Print Head Alignment utility for Mac OS X. . . . .

.....  
.....  
..... 115 Using the control panel. .  
.....

..... 115 Saving Power. . . . .  
.....  
.....  
.....

... 116 For Windows. . . . .  
.....  
.....  
..... 116 For Mac OS X. .

.....  
.....  
.....  
..... 116 Using the control panel. . . . .

.....  
..... 117 Quieter Printer Operations. . . . .  
.....  
..... 117 For Windows. .

.....  
.....  
.....  
..... 117 For Mac OS X. . . . .





.....  
..... *Help Mode*.....

.....  
.....  
.....  
..... *Quiet Mode*.....

.. 90 . 91 . 92 . 92 . 94 . 95 . 97 . 98 *Ink Cartridge Information Replacing Ink Cartridges Ink Cartridge Safety Instructions, Precautions, and Specifications.*

.....  
.....  
.....  
..... *100 Safety instructions*.....

.....  
.....  
.....  
..... *100 Precas not feed*.....

..... *143 Multiple pages feed*.....

.....  
.....  
..... *143 Paper is improperly loaded*.....

.....  
..... *144 Paper is not ejected fully or is wrinkled*.....  
..... *144 The CD/DVD tray is ejected or not inserted correctly when sending a CD/DVD print job*.....

.....  
.....  
.....  
..... *144 The Product Does Not Print*.....

.....  
..... *144 All lights are off*.....  
.....

..... *144 Lights came on and then went out*.....  
..... *144 Only the power light is on*.....

..... *Important Instructions Important Instructions Safety Instructions Read and follow these instructions to ensure safe use of this product. Make sure you keep this guide for future reference.*

Also, be sure to follow all warnings and instructions marked on the product.  Use only the power cord supplied with the product and do not use the cord with any other equipment. Use of other cords with this product or the use of the supplied power cord with other equipment may result in fire or electric shock.  Be sure your AC power cord meets the relevant local safety standard.  Never disassemble, modify, or attempt to repair the power cord, plug, printer unit, scanner unit, or options by yourself, except as specifically explained in the product's guides.  Unplug the product and refer servicing to qualified service personnel under the following conditions: The power cord or plug is damaged; liquid has entered the product; the product has been dropped or the casing damaged; the product does not operate normally or exhibits a distinct change in performance. Do not adjust controls that are not covered by the operating instructions.  Place the product near a wall outlet where the plug can be easily unplugged.  Do not place or store the product outdoors, near excessive dirt or dust, water, heat sources, or in locations subject to shocks, vibrations, high temperature or humidity.  Take care not to spill liquid on the product and not to handle the product with wet hands.

Keep this product at least 22 cm away from cardiac pacemakers. Radio waves from this product may adversely affect the operation of cardiac pacemakers.  If the LCD screen is damaged, contact your dealer. If the liquid crystal solution gets on your hands, wash them thoroughly with soap and water. If the liquid crystal solution gets into your eyes, flush them immediately with water.

If discomfort or vision problems remain after a thorough flushing, see a doctor immediately. Note: The following provides safety instructions for ink cartridges. & "Replacing Ink Cartridges" on page 100 Product Advisories and Warnings Read and follow these instructions to avoid damaging the product or your property. Make sure you keep this guide for future reference. Setting up/using the product  Do not block or cover the vents and openings in the product.

9 User's Guide Important Instructions  Use only the type of power source indicated on the product's label.  Avoid using outlets on the same circuit as photocopiers or air control systems that regularly switch on and off.  Avoid electrical outlets controlled by wall switches or automatic timers.  Keep the entire computer system away from potential sources of electromagnetic interference, such as loudspeakers or the base units of cordless telephones.  The

power-supply cords should be placed to avoid abrasions, cuts, fraying, crimping, and kinking. Do not place objects on top of the power-supply cords and do not allow the power-supply cords to be stepped on or run over. Be particularly careful to keep all the power-supply cords straight at the ends and the points where they enter and leave the transformer. □ If you use an extension cord with the product, make sure that the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating. Also, make sure that the total ampere rating of all devices plugged into the wall outlet does not exceed the wall outlet's ampere rating. □ If you plan to use the product in Germany, the building installation must be protected by a 10 or 16 amp circuit breaker to provide adequate short-circuit protection and over-current protection for the product.

□ When connecting the product to a computer or other device with a cable, ensure the correct orientation of the connectors. Each connector has only one correct orientation. Inserting a connector in the wrong orientation may damage both devices connected by the cable. □ Place the product on a flat, stable surface that extends beyond the base of the product in all directions. If you place the product by the wall, leave more than 10 cm between the back of the product and the wall. The product will not operate properly if it is tilted at an angle. □ When storing or transporting the product, avoid tilting it, placing it vertically, or turning it upside down; otherwise ink may leak.



[You're reading an excerpt. Click here to read official EPSON  
EXPRESSION PHOTO HD XP-950 user guide  
http://yourpdfguides.com/dref/5516370](http://yourpdfguides.com/dref/5516370)

□ Allow spaces behind the product for the cables, and space above the product so that you can fully raise the document cover. □ Leave enough space in front of the product for the paper to be fully ejected. □ Avoid places subject to rapid changes in temperature and humidity.

Also, keep the product away from direct sunlight, strong light, or heat sources. □ Do not insert objects through the slots in the product. □ Do not put your hand inside the product or touch the ink cartridges during printing. □ Do not touch the white flat cable inside the product. □ Do not use aerosol products that contain flammable gases inside or around the product.

Doing so may cause fire. □ Do not move the print head by hand; otherwise, you may damage the product. □ Always turn the product off using the P button. Do not unplug the product or turn off the power at the outlet until the LCD screen has turned off completely. 10 User's Guide Important Instructions □ Before transporting the product, make sure that the print head is in the home (far right) position and the ink cartridges are in place.

□ Be careful not to trap your fingers when closing the scanner unit. □ If you are not going to use the product for a long period, be sure to unplug the power cord from the electrical outlet. □ Do not press too hard on the scanner glass when placing the originals. □ During the life of your product it may be necessary to replace the waste ink pad when it has become full. Whether and how often this is required will vary according to the number of pages you print, the type of material that you print and the number of cleaning cycles that the product performs. Epson Status Monitor, your LCD, or lights on the control panel will advise you when this part needs replacing. The need for replacement of the pad does not mean that your product has ceased to operate in accordance with its specifications. The replacement of this part is a routine product servicing activity within the product's specification and is not a problem which requires repair. The Epson warranty does not therefore cover the cost of this replacement. If your product needs the pad replacing this can be performed for you by any authorised Epson service provider.

It is not a user-serviceable part. Using the product with a wireless connection □ Do not use this product inside medical facilities or near medical equipment. Radio waves from this product may adversely affect the operation of electrical medical equipment. □ Do not use this product near automatically controlled devices such as automatic doors or fire alarms. Radio waves from this product may adversely affect these devices, and could lead to accidents due to malfunction. Using memory cards □ Do not remove a memory card or turn off the product while the memory card light is flashing. □ The methods for using memory cards vary according to card type. Be sure to refer to the documentation packaged with your memory card for details. □ Use only memory cards compatible with the product. & "Memory card" on page 158 Using the touchscreen □ The LCD screen may contain a few small bright or dark spots, and because of its features it may have an uneven brightness.

These are normal and do not indicate that it is damaged in any way. □ Only use a dry, soft cloth to clean the touchscreen. Do not use liquid or chemical cleansers. □ The exterior cover of the touchscreen could break if it receives a heavy impact. Contact your dealer if the panel surface chips or cracks, and do not touch or attempt to remove the broken pieces.

□ Press the touchscreen gently with your finger. Do not press force or operate with your nails. □ Do not operate by a sharp edge thing such as a ball point pen, sharp pencil, stylus pen and so on. 11 User's Guide Important Instructions □ Condensation inside the panel due to abrupt changes in temperature or humidity may cause performance to deteriorate. Handling ink cartridges & "Replacing Ink Cartridges" on page 100 Restrictions on Copying Observe the following restrictions in order to ensure the responsible and legal use of the product.

Copying of the following items is prohibited by law: □ Bank bills, coins, government-issued marketable securities, government bond securities, and municipal securities □ Unused postage stamps, pre-stamped postcards, and other official postal items bearing valid postage □ Government-issued revenue stamps, and securities issued according to legal procedure Exercise caution when copying the following items: □ Private marketable securities (stock certificates, negotiable notes, checks, etc.), monthly passes, concession tickets, etc. □ Passports, driver's licenses, warrants of fitness, road passes, food stamps, tickets, etc. Note: Copying these items may also be prohibited by law. Responsible use of copyrighted materials: □ Products can be misused by improperly copying copyrighted materials. Unless acting on the advice of a knowledgeable attorney, be responsible and respectful by obtaining the permission of the copyright holder before copying published material. 12 User's Guide Getting to Know Your Product Getting to Know Your Product Available features for your product Check what is available for your product. Print Copy Scan Ethernet Wi-Fi Epson Connect services Email Print Remote Print Driver Scan to Cloud iPrint\* Other companies' services AirPrint Google Cloud Print PictBridge USB LAN WLAN \* Epson iPrint is an application for iOS and Android. Using Epson iPrint, you can wirelessly print and scan from your smartphone or tablet. For more information, visit the following website.

<http://ipr.to/a> 13 User's Guide Getting to Know Your Product Product Parts Note: The illustrations in this manual are from a similar product model. Although they may differ from your actual product, the method of operation is the same. a. b. c. d. e. Rear paper feed slot cover Paper support Rear paper feed slot Edge guide CD/DVD tray a. b.

c. d. e. Document cover Paper cassette 1 (upper cassette)\*1 Paper cassette 2 (lower cassette)\*1 Front cover\*1 Control panel\*2 \*1 See the following illustration for details. \*2 The control panel raises automatically when printing starts.

Lower it manually if necessary. 14 User's Guide Getting to Know Your Product a. b. c. d.

e. Output tray\* Paper cassette 1 Paper cassette 2 Front cover Edge guides \* The output tray slides out automatically when printing starts. Close it manually if necessary. a. b. c. d. e. Document mat Scanner glass Memory card light Memory card slots External interface USB port 15 User's Guide Getting to Know Your Product a. b.

Scanner unit Print head / Ink cartridge holder a. b. c. d. AC inlet Rear cover LAN port USB port Notes regarding the control panel and the output tray The control panel raises and the output tray slides out automatically when printing starts. After printing, close the output tray and lower the control panel manually if necessary.



[You're reading an excerpt. Click here to read official EPSON EXPRESSION PHOTO HD XP-950 user guide](http://yourpdfguides.com/dref/5516370)  
<http://yourpdfguides.com/dref/5516370>



For more information, refer to the documentation that came with the Exif Print or PRINT Image Matching compatible digital camera. Note: The availability of special media varies by location. For the latest information on media available in your area, contact Epson support. & "Technical Support Web Site" on page 162 Loading Paper Into the paper cassette Note: The available paper type, size and loading capacity differs between cassette 1 and 2.

See the following section for more information on paper availability. & "Selecting Paper" on page 20 Into the paper cassette 1 A Open the front cover. Note: If the output tray has been ejected, close it before pulling out the paper cassette. B Pull out the paper cassette. 24 User's Guide Paper and Media Handling Note: If the cassette is too far inside the product, turn the product off and then back on again. C Slide the edge guides to the sides of the paper cassette. D Slide the edge guide to adjust to the paper size you will use. E Load paper toward the edge guide with printable side face-down, and check that the paper is not sticking out from the end of the cassette. Note: □ Fan and align the edges of the paper before loading. □ □ □ For Epson special media, make sure the number of sheets is less than the limit specified for the media.

& "Selecting Paper" on page 20 When you select Cassette 1->2 as the Paper Source, load the same size and type of paper in both cassettes. When loading a Photo Stickers sheet, place it face down. Do not use the loading support sheet that came with the Photo Stickers. 25 User's Guide Paper and Media Handling F Slide the edge guides to the edges of the paper. G Keep the cassette flat and insert it back into the product carefully and slowly. Note: □ Leave enough space in front of the product for the paper to be fully ejected. □ Do not remove or insert the paper cassette while the product is operating. Into the paper cassette 2 A Open the front cover. Note: If the output tray has been ejected, close it before pulling out the paper cassette. 26 User's Guide Paper and Media Handling B Pull out the paper cassette.

C Slide the edge guides to the sides of the paper cassette. Note: When using Legal-size paper, remove the CD/DVD tray, and then extend cassette 2 as shown in the illustration. D Slide the edge guide to adjust to the paper size you will use. Note: If you are loading envelopes, skip this step. 27 User's Guide Paper and Media Handling E Load paper toward the edge guide with printable side face-down, and check that the paper is not sticking out from the end of the cassette. Note: □ Fan and align the edges of the paper before loading. □ arrow mark inside the edge guide. For plain paper, do not load paper above the line just under the Epson special media, make sure the number of sheets is less than the limit specified for the media. & "Selecting Paper" on page 20 □ □ When you select Cassette 1->2 as the Paper Source, load the same size and type of paper in both cassettes. When loading a Photo Stickers sheet, place it face down. Do not use the loading support sheet that came with the Photo Stickers. Use cassette 2 when loading envelopes. Load envelopes short edge first with the flap facing up and to the left. Next, check that the envelopes are not sticking out from the end of the cassette. 28 User's Guide Paper and Media Handling Note: □ The thickness of envelopes and their ability to fold vary widely. If the total thickness of the stack of envelopes exceeds 11 mm, press down on the envelopes to flatten them before loading. If print quality declines when a stack of envelopes is loaded, load one envelope at a time. & "Selecting Paper" on page 20 □ □ Do not use envelopes that are curled or folded. Flatten the envelope and the flaps before loading. □ □ □ Flatten the leading edge of the envelope before loading.

Avoid using envelopes that are too thin, as they may curl during printing. Align the edges of the envelopes before loading. F Slide the edge guides to the edges of the paper. Slide the edge guides to the edges of the envelopes. G Keep the cassette flat and insert it back into the product carefully and slowly. 29 User's Guide Paper and Media Handling Note: □ Leave enough space in front of the product for the paper to be fully ejected. □ Do not remove or insert the paper cassette while the product is operating. Into the rear paper feed slot Note: Even though you can print on paper with a thickness of 0.05 to 0.6 mm, some hard paper may not be fed correctly even if the thickness is within this range.

A B Send your print job to the product (from your computer, or by using the control panel). Note: Before sending your print job, you cannot load paper into the rear paper feed slot. Open the rear paper feed slot cover. C Slide out the paper support, and then extend and tilt it backwards. 30 User's Guide Paper and Media Handling D Slide the edge guide.

E Insert a single sheet of paper (up to A3 size) in the center of the rear paper feed slot with the printable side face-up until you hear a beep. 31 User's Guide Paper and Media Handling Note: □ Insert the paper so that the leading edge is approximately 5 cm from the groove in the edge guides. □ Do not insert the paper at an angle. If paper is inserted at an angle, it could cause a paper jam or leave wrinkles in your printouts. □ When Button Press is set to Off, the printer does not beep when you insert paper.

To change the settings, follow the instructions below. Home > Setup > Printer Setup > Sound > Button Press Load the envelope short edge first with the flap facing down and at the center of the rear paper feed slot, and then set the edge guide. 32 User's Guide Paper and Media Handling Note: □ Do not use an envelope that is curled or folded. □ Flatten the envelope and the flaps before loading. □ □ Flatten the leading edge of the envelope before loading. Avoid using an envelope that is too thin, as it may curl during printing. F Press x. Note: The paper or envelope ejects automatically after a certain period of time.

Loading a CD/DVD Important: c □ Do not insert the CD/DVD tray while the product is operating. Otherwise, your product may be damaged or the surface of the CD/DVD may become dirty or scratched.

□ When ejecting/inserting the CD/DVD tray, make sure nothing is placed on the output tray. Note: You can also print on a Blu-ray Disc .™ A B Press on the control panel, and then select Load CD/DVD. Raise the panel as far as it will go. 33 User's Guide Paper and Media Handling Note: If the output tray has been ejected, close the tray and the front cover. C Remove the CD/DVD tray from the product. D Place a CD/DVD on the CD/DVD tray with the printable side face-up, and then insert the tray into the product. Make sure that the u marks on the tray and the d marks on the product match, so that the line on the tray aligns with the product.



[You're reading an excerpt. Click here to read official EPSON](http://yourpdfguides.com/dref/5516370)

[EXPRESSION PHOTO HD XP-950 user guide](http://yourpdfguides.com/dref/5516370)

<http://yourpdfguides.com/dref/5516370>

E Press OK on the LCD screen. Note: The CD/DVD tray ejects automatically after a certain period of time.

34 User's Guide Paper and Media Handling Removing a CD/DVD A Remove the CD/DVD tray from the product, and then remove your CD/DVD from the tray. !Caution: not to scratch the surface of the CD/DVD when removing it. Be careful B C D Press OK on the LCD screen. Lower the control panel. Insert the CD/DVD tray back into the slot on the bottom of the product.

Inserting a Memory Card You can print photos in a memory card or save a scanned data in a memory card. The following memory cards are supported. SD, miniSD, microSD, SDHC, miniSDHC, microSDHC, SDXC, microSDXC, Memory Stick Duo, Memory Stick PRO Duo, Memory Stick PRO-HG Duo, Memory Stick Micro, MagicGate Memory Stick Duo, CompactFlash, Microdrive Important c The following memory cards require an adapter. Attach it before inserting the card into the slot, otherwise the card may get stuck. □ miniSD, microSD, miniSDHC, microSDHC, microSDXC □ Memory Stick Micro 35 User's Guide Paper and Media Handling A Open the cover, and insert one card at a time.

B Check the light stays on. = on, = flashing Important c □ Do not try to force the card all the way into the slot. It should not be fully inserted. □ Do not remove the memory card while the light is flashing. The data in the memory card may be lost. Placing Originals Scanner glass A Open the document cover. 36 User's Guide Paper and Media Handling B Place your original face-down on the scanner glass, and slide it to the front-right corner. Note: See the following sections if any problems occur with the scanning area or the scanning direction when using EPSON Scan. & "The edges of your original are not scanned" on page 151 & "Multiple documents are scanned into a single file" on page 152 C Close the cover gently. Note: The folding document cover is useful for flattening documents that are curled or folded on the scanner glass.

This reduces misalignment of documents when scanning. Placing a CD Place the CD in the center. Placing photos Place photos 5 mm apart. 37 User's Guide Paper and Media Handling Note: You can copy one photo or multiple photos of different sizes at the same time, as long as they are larger than 30 x 40 mm.

Placing a book Place the first page, and then place the second page. You can print two pages of a book on a single side of one sheet of paper. Select A4, Book/2-up or Book/2-Sided as the layout and place the book. Note: Close the document cover to avoid direct light, such as fluorescent lights, when scanning. Otherwise, the light may affect the scanning result. 38 User's Guide Copying Copying Documents Basic copying Follow the steps below to copy documents.

A Load paper in the cassette 2. & "Into the paper cassette" on page 24 Note: You can also load paper in the rear paper feed slot. & "Into the rear paper feed slot" on page 30 B C D E F G Place original. & "Placing Originals" on page 36 Enter Copy mode from the Home menu. Press + or - to set the number of copies.

Set the color. Press d to make the copy settings. Select the appropriate copy settings such as paper size, paper type, and quality. Note: □ You can preview the copy results before you start copying. □ You can make various layout copies such as 2-sided copy, 2-up copy, and so on.

Change the 2-sided or layout settings as necessary. H Press x to start copying. 2-Sided copying With duplex copying, you can create double-sided or single-sided copies from single-sided originals. Follow the instructions below to perform duplex copying. 39 User's Guide Copying A Load paper in the cassette 2. & "Into the paper cassette" on page 24 Note: You can also load paper in the rear paper feed slot. & "Into the rear paper feed slot" on page 30 B C D E F G H Place original. & "Placing Originals" on page 36 Enter Copy mode from the Home menu. Press + or - to set the number of copies. Set the color.

Press d to make the copy settings. Select 2-Sided Copying. Select the type of 2-sided copying. Setting 1>1-Sided 1>2-Sided Description Normal copying. Two single-sided originals are printed onto each side of a single sheet of paper. I Make the appropriate settings for Document Orientation or Binding Margin. Setting Document Orientation Binding Margin Description Specifies the orientation of your originals. Specifies the binding direction of your prints. Note: Depending on the settings for 2-Sided Copying and Layout, these menus may not be available. J Press x to start copying.

Layout copying With the layout function, you can copy two single-sided originals onto a single page. 40 User's Guide Copying A Load paper in the cassette 2. & "Into the paper cassette" on page 24 Note: You can also load paper in the rear paper feed slot. & "Into the rear paper feed slot" on page 30 B C D E F G Place original. & "Placing Originals" on page 36 Enter Copy mode from the Home menu.

Press d to make the copy settings. Select Layout. Select A4, 2-up Copy. Press x to start copying. Copy Mode Menu List Refer to the section below for the Copy mode menu list.

& "Copy Mode" on page 90 41 User's Guide Printing Printing Basic Operation from the Control Panel Printing photos A Load photo paper in the paper cassette. & "Into the paper cassette" on page 24 Note: □ If you want to print on an A3 size paper, use the rear paper feed slot. & "Into the rear paper feed slot" on page 30 □ If you print photos larger than A4 size, Epson recommends the use of large-size Epson ink cartridges. These high-capacity cartridges reduce the probability of having to replace cartridges mid-print. Note that incomplete prints will need to be restarted. & "Ink Cartridge Information" on page 99 B Insert a memory card. & "Inserting a Memory Card" on page 35 Note: You can also print photos from an external USB device. C D Enter Print Photos mode from the Home menu. Select a photo and press + or - to set the number of copies. Note: □ You can crop and enlarge your photo.

Press Edit and Crop/Zoom, and then make the settings. □ □ □ □ To select more photos, press y and repeat step 4. If you want to correct your images, press Edit and Photo Adjustments, and then make the settings. Scroll down if necessary. If the screen display (for example, "-", "+", or menus) disappears, touch the LCD screen. To select another group, select Print Photos on the Home menu. Next, select Options, Select Location, and then Select Folder. E F Press Settings, and then make the print settings. Scroll down if necessary. Press x to start printing.

42 User's Guide Printing Note See the following sections for more information on other printing functions available from the control panel.



[You're reading an excerpt. Click here to read official EPSON EXPRESSION PHOTO HD XP-950 user guide](http://yourpdfguides.com/dref/5516370)  
<http://yourpdfguides.com/dref/5516370>

& "Print Photos Mode" on page 91 & "More Functions" on page 86 Printing photos from a digital camera Printing using a USB connection A B C D E F G Load photo paper in the paper cassette. & "Into the paper cassette" on page 24 Remove a memory card. Enter Setup mode from the Home menu. Enter External Device Setup.

Scroll down if necessary. Select Print Settings. Make the appropriate print settings. Scroll down if necessary. Connect the camera to the product with a USB cable, and then turn on the camera.

H See your camera's guide to print. Compatibility File Format Image Size PictBridge JPEG 80 × 80 pixels to 10200 × 10200 pixels 43 User's Guide Printing Note:  Depending on the settings on this printer and the digital camera, some combinations of paper type, size, and layout may not be supported.  Some of the settings on your digital camera may not be reflected in the output. Printing using a wireless connection You can print photos directly from a digital camera using a wireless connection. Make sure your digital camera can connect to a network and is PictBridge capable (DPS over IP). For more details, see the documentation provided with your camera. A B C D E F G You can check the network connection status of your products. & "Setup Mode" on page 95 Load photo paper in the paper cassette. & "Into the paper cassette" on page 24 Enter Setup mode from the Home menu. Enter External Device Setup.

Scroll down if necessary. Select Print Settings. Make the appropriate print settings. Scroll down if necessary. Configure the camera's network connection. The procedure depends on your camera. For more details, see the documentation provided with your camera. Note:  You can check the Printer Name that is connected to the network. & "Setup Mode" on page 95  Connect the camera to the same network as the product. H I Print the photo from the camera. Note: You cannot print photos or documents from other devices while the camera is connected to the product. Disconnect the camera from the network. 44 User's Guide Printing Print photos mode menu list Refer to the section below for the Print Photos mode menu list. & "Print Photos Mode" on page 91 Basic Operation from Your Computer Printer driver and status monitor The printer driver lets you choose from a wide variety of settings to get the best printing results. The status monitor and the printer utilities help you check the product and keep it in top operating condition.

Note for Windows users:  Your printer driver automatically finds and installs the latest version of the printer driver from Epson's Web site. Click the Software Update button in your printer driver's Maintenance window, and then follow the on-screen instructions. If the button does not appear in the Maintenance window, point at All Programs or Programs in the Windows Start menu, and check in the EPSON folder. \* \* For Windows 8: If the button does not appear in the Maintenance window, right-click on the Start screen, or swipe from the bottom or top edge of the Start screen, and select All apps, then select Software Update from EPSON category.  If you want to change the language of the driver, select the language you want to use from the Language setting in your printer driver's Maintenance window.

Depending on the location, this function may not be available. Accessing the printer driver for Windows You can access the printer driver from most Windows applications, the desktop, or the taskbar. To make settings that apply only to the application you are using, access the printer driver from that application. To make settings that apply to all of your Windows applications, access the printer driver from the desktop or the taskbar. Refer to the following sections to access the printer driver. Note: Screen shots of the printer driver windows in this User's Guide are from Windows 7. From Windows applications A B Click Print or Print Setup on the File menu. In the window that appears, click Printer, Setup, Options, Preferences, or Properties. (Depending on your application, you may need to click one or a combination of these buttons.) 45 User's Guide Printing From the desktop  Windows 8: Select Desktop, Settings charm, and Control Panel.

Then select Devices and Printers from the Hardware and Sound category. Right-click on the product, or press and hold the product, and select Printing preferences.  Windows 7: Click the start button, select Devices and Printers. Then right-click the product and select Printing preferences.  Windows Vista: Click the start button, select Control Panel, and then select Printer from the Hardware and Sound category. Then select the product and then click Select printing preferences.  Windows XP: Click Start, Control Panel, (Printers and Other Hardware,) then Printers and Faxes. Select the product, then click Printing Preferences on the File menu. From the shortcut icon on the taskbar Right-click the product icon on the taskbar, then select Printer Settings. To add a shortcut icon to the Windows taskbar, first access the printer driver from the desktop as described above.

Next, click the Maintenance tab, the Extended Settings button, and then the Monitoring Preferences button. In the Monitoring Preferences window, select the Shortcut Icon check box. Getting information through online help In the printer driver window, try one of the following procedures.  Right-click the item, then click Help.  Click the button at the top right of the window, then click the item (for Windows XP only).

Accessing the printer driver for Mac OS X The table below describes how to access the printer driver dialog. Dialog Box Page Setup How to Access It Click Page Setup on the File menu of your application. Note: Depending on your application, the Page Setup menu may not appear in the File menu. Print Epson Printer Utility 4 Click Print on the File menu of your application. For Mac OS X 10.

8 or 10.7, click System Preferences on the Apple menu and then click Print & Scan. Select your product from the Printers list box, click Options & Supplies, Utility, and then click Open Printer Utility. For Mac OS X 10.6, click System Preferences on the Apple menu and then click Print & Fax. Select your product from the Printers list box, click Options & Supplies, Utility, and then click Open Printer Utility. For Mac OS X 10.5, click System Preferences on the Apple menu and then click Print & Fax. Select your product from the Printers list box, click Open Print Queue and then click Utility button. 46 User's Guide Printing Basic Printing Note:  The screen shots in this manual may vary depending on the model.

Before you print, load paper properly. & "Loading Paper" on page 24 Refer to the section below for the printable area. & "Printable area" on page 155 After completing the settings, print one test copy and examine the results before printing an entire job.



[You're reading an excerpt. Click here to read official EPSON](http://yourpdfguides.com/dref/5516370)

[EXPRESSION PHOTO HD XP-950 user guide](http://yourpdfguides.com/dref/5516370)

<http://yourpdfguides.com/dref/5516370>

Basic product settings for Windows A B Open the file you want to print. Access the printer settings. & “Accessing the printer driver for Windows” on page 45 C D Click the Main tab. Select the appropriate Source setting. & “Selecting Paper” on page 20 47 User’s Guide Printing E Select the appropriate Type setting. & “Paper type settings from the printer driver” on page 23 Note: Print quality is automatically adjusted for the selected paper type setting. F G H I J Select Borderless if you want to print borderless photos.

& “Selecting Paper” on page 20 If you want to control the amount of the image that extends beyond the edges of the paper, click the Page Layout tab, select Auto Expand as the Enlargement Method, and then adjust the Expansion slider. Select the appropriate Size setting. You can also define a custom paper size. For details, see the online help. Select Portrait (tall) or Landscape (wide) to change the orientation of your printout.

Note: Select Landscape when printing on envelopes. Click OK to close the printer settings window. Note: To make changes to advanced settings, refer to the relevant section. Print your file. Basic product settings for Mac OS X Note: Screen shots of the printer driver windows in this manual are from Mac OS X 10.7. A Open the file you want to print. 48 User’s Guide Printing B Access the Print dialog box. & “Accessing the printer driver for Mac OS X” on page 46 Note: If the simplified dialog box is displayed, click the Show Details button (for Mac OS X 10.8 or 10.7) or the d button (for Mac OS X 10.6 or 10.5) to extend this dialog box. C Select the product you are using as the Printer setting. Note: Depending on your application, you may not be able to select some of the items in this dialog box.

If so, click Page Setup on the File menu of your application, and then make suitable settings. D Select the appropriate Paper Size setting. Note: Select XXX (Borderless) as the Paper Size if you want to print borderless photos. & “Selecting Paper” on page 20 E Select the appropriate Orientation setting. Note: Select landscape orientation when printing envelopes. 49 User’s Guide Printing F Select Print Settings from the pop-up menu. G H I J Select the appropriate Paper Source setting. Select the appropriate Media Type setting. & “Paper type settings from the printer driver” on page 23 Select the appropriate Expansion setting during borderless printing to control the amount of the image that extends beyond the edges of the paper. Click Print to start printing.

Canceling Printing If you need to cancel printing, follow the instructions in the appropriate section below. Using the control panel Press y to cancel a print job in progress. 50 User’s Guide Printing For Windows Note: You cannot cancel a print job that has been completely sent to the product. In this case, cancel the print job by the product. Using the progress meter When you start printing, the progress meter appears on your computer screen.

Click the Cancel button to cancel printing. Using EPSON Status Monitor 3 A B C Access the EPSON Status Monitor 3. & “For Windows” on page 130 Click the Print Queue button. The Windows Spooler appears. Right click on the job you want to cancel and then select Cancel.

For Mac OS X Follow the steps below to cancel a print job. Note: If you have sent a print job from a Mac OS X 10.6 or 10.5 through the network, you may not be able to cancel printing from the computer. Press y on the product’s control panel to cancel a print job. To solve this problem, see the online Network Guide. A B Click your product icon in the Dock. In the Document Name list, select the document which is printing. 51 User’s Guide Printing C Click the Delete button to cancel the print job. For Mac OS X 10.

8: Click the button to cancel the print job. Other Options Printing photos the easy way Epson Easy Photo Print lets you lay out and print digital images on various types of paper. The step-by-step instructions in the window let you preview the printed images and get the effects you want without having to make any difficult settings. Using the Quick Print function, you can perform one-click printing with the settings you make. 52 User’s Guide Printing Starting Epson Easy Photo Print For Windows □ Double-click the Epson Easy Photo Print icon on the desktop. □ For Windows 8: Right-click on the Start screen, or swipe from the bottom or top edge of the Start screen and select All apps, then select Easy Photo Print from Epson Software. For Windows 7 and Vista: Click the start button, point to All Programs, click Epson Software, and then click Easy Photo Print. For Windows XP: Click Start, point to All Programs, point to Epson Software, then click Easy Photo Print. For Mac OS X Double-click the Applications folder on your Mac OS X hard drive, then double-click in turn on the Epson Software and Easy Photo Print folders and finally double-click the Easy Photo Print icon. Printing on CD/DVD Epson Print CD lets you create CD/DVD labels with text and images on your computer, then print the labels directly onto 12-cm CDs and DVDs.

Note: □ Before you print, load the CD/DVD properly. & “Loading a CD/DVD” on page 33 □ □ Try to test print on a spare CD/DVD and check the printed surface after waiting for one full day, especially before printing a large amount of CD/DVDs. You can also print on CD/DVDs from the control panel. & “More Functions” on page 86 Notice for CD/DVD printing □ Print only on a circular CD/DVD. □ See the documentation provided with your CD/DVD for more information on handling the CD/DVD.

□ Do not print on the CD/DVD before writing your data to it. If you do, fingerprints, dirt, or scratches on the surface may cause errors while writing data. 53 User’s Guide Printing □ Store the CD/DVD tray in the bottom slot of the product. A warped or damaged CD/DVD tray may stop the product from operating normally. □ If the tray is ejected or not fed correctly when you start a CD/DVD print job, make sure that you inserted the tray properly.

& “Loading a CD/DVD” on page 33 □ If the tray is ejected when you start a CD/DVD print job, the product is not ready. Wait until you see a message on your computer screen asking you to insert the tray. Then reinsert the tray and press x. □ After you finish printing on a CD/DVD, remove the CD/DVD tray and press OK on the LCD screen. □ Use only CD/DVD labelled as suitable for printing, for example “Printable on the label surface” or “Printable with ink jet printers”. □ Depending on the CD/DVD type, smearing may occur depending on the level of color saturation. □ Moisture on the printable surface may cause smearing. □ If the CD/DVD tray or the internal transparent compartment are accidentally printed on, immediately wipe off the ink.



[You're reading an excerpt. Click here to read official EPSON EXPRESSION PHOTO HD XP-950 user guide](http://yourpdfguides.com/dref/5516370)  
<http://yourpdfguides.com/dref/5516370>



□ Reprinting on the same CD/DVD may not improve the print quality. □ If you select CD/DVD Premium Surface as the Media Type setting in the printer driver and use a high quality CD/DVD, you can create high quality CD/DVD labels.

□ Make sure you let CDs and DVDs dry completely out of direct sunlight before using them or touching the printed surface. □ If the printed surface is sticky even after it has dried, the color saturation level may be too high. In that case, lower the level of the color saturation in Epson Print CD. □ If the ink smears, adjust the color saturation using Epson Print CD. □ Set the printable area to fit the printable area of the CD/DVD. □ For details on the printable area, see the following section. & “Printable area” on page 155 □ Only one CD or DVD can be printed at a time. When the Copies setting is set to 2 or more, remove each CD or DVD from the tray after it has been printed, and then place the next CD or DVD on the tray. Follow the on-screen instructions. Starting Epson Print CD For Windows □ Double-click the Epson Print CD icon on the desktop.

54 User's Guide Printing □ For Windows 8: Right-click on the Start screen, or swipe from the bottom or top edge of the Start screen, select All apps, and then select Epson Print CD from Epson Software. For Windows 7 and Vista: Click the start button, point to All Programs, click Epson Software, and then click Print CD. For Windows XP: Click Start, point to All Programs, point to Epson Software, then click Print CD. For Mac OS X Double-click the Applications folder on your Mac OS X hard drive, then double-click in turn on the Epson Software and Print CD folders and finally double-click the Print CD icon. Printing on a CD/DVD with a commercially available software package When you print on a CD/DVD with a commercially available software package that supports CD/DVD printing, you have to make the following settings.

Size Orientation Source (Windows) Type Tray type\*1 A4 Portrait CD/DVD CD/DVD or CD/DVD Premium Surface Epson Tray Type 2\*2 \*1 Needs to be specified depending on the software. \*2 The name varies depending on the software. Product presets (for Windows only) Printer driver presets make printing a snap. You can also create presets of your own. Product settings for Windows A B Access the printer settings.

& “Accessing the printer driver for Windows” on page 45 Select a Printing Presets in the Shortcuts tab. Product settings are automatically set to the values displayed in the pop-up window. 55 User's Guide Printing 2-sided printing Use the printer driver to print on both sides of the paper. For Windows users: Four types of 2-sided printing are available: automatic standard, automatic folded booklet, manual standard and manual folded booklet. For Mac OS X users: Mac OS X supports automatic standard 2-sided printing only. 2-sided printing is only available for the following papers and sizes. Paper Plain paper Epson Bright White Ink Jet Paper Epson Double-Sided Matte Paper \* Manual 2-sided printing only. Size Legal\*, Letter, A4, B5, A5\*, A6\* A4 A4 Note: □ This feature is not available for rear paper feeding. □ □ □ This feature may not be available at some settings. Manual 2-sided printing may not be available when the product is accessed over a network or is used as a shared printer.

If the ink runs low during automatic 2-sided printing, the product stops printing and the ink needs to be replaced. When ink replacement is complete, the product starts printing again, but there may be some missing parts in your print. If this happens, print again the page that has missing parts. The loading capacity differs during 2-sided printing. & “Selecting Paper” on page 20 Only use papers that are suitable for 2-sided printing. Otherwise, the printout quality may deteriorate. Depending on the paper and the amount of ink used to print text and images, ink may bleed through to the other side of the paper.

The surface of the paper may be smeared during 2-sided printing. □ □ □ □ 56 User's Guide Printing Note for Windows: □ Manual 2-sided printing is available only when EPSON Status Monitor 3 is enabled. To enable the status monitor, access the printer driver and click the Maintenance tab followed by the Extended Settings button.

In the Extended Settings window, check the Enable EPSON Status Monitor 3 check box. □ When automatic 2-sided printing is performed, printing may be slow depending on the combination of options selected for Select Document Type in the Print Density Adjustment window and for Paper & Quality Options in the Advanced window. Note for Mac OS X: When automatic 2-sided printing is performed, printing may be slow depending on the combination of options selected for Document Type in the Two-sided Printing Settings and for Print Quality in the Print Settings. Product settings for Windows A B Access the printer settings. & “Accessing the printer driver for Windows” on page 45 Choose the desired 2-sided printing option in the Page Layout tab.

To print folded booklets, select Folded Booklet. Note: When using automatic printing, make sure Auto is selected. C D Click Settings, and make the appropriate settings. Check the other settings and print. Note: □ When printing automatically, and if you are printing high-density data such as photos or graphs, we recommend making the settings in the Print Density Adjustment window.

□ □ □ The actual binding margin may be different from the specified settings depending on your application. Experiment with a few sheets to examine actual results before printing the entire job. Manual 2-sided printing allows you to print the even-numbered pages first. When you print odd-numbered pages, a blank sheet of paper is output at the end of the print job. When you are printing manually, make sure that the ink is completely dry before reloading the paper. Product settings for Mac OS X A B Access the Print dialog box. & “Accessing the printer driver for Mac OS X” on page 46 Make the appropriate settings in the Two-sided Printing Settings pane. 57 User's Guide Printing C Check the other settings and print. Note: If you are printing high-density data such as photos or graphs, we recommend adjusting Print Density and Increased Ink Drying Time settings manually. Fit to page printing Lets you automatically enlarge or reduce the size of your document to fit the paper size selected in the printer driver.

Note: This feature may not be available at some settings. Product settings for Windows A B C A B C Access the printer settings. & “Accessing the printer driver for Windows” on page 45 Select Reduce/Enlarge Document and By Output Paper Size in the Page Layout tab, and then select the size of the paper you are using from the drop-down list. Check the other settings and print. Product settings for Mac OS X Access the Print dialog box. & “Accessing the printer driver for Mac OS X” on page 46 Choose Scale to fit paper size for Destination Paper Size in the Paper Handling pane, and then select the size of the paper you are using from the pop-up menu.



[You're reading an excerpt. Click here to read official EPSON  
EXPRESSION PHOTO HD XP-950 user guide  
http://yourpdfguides.com/dref/5516370](http://yourpdfguides.com/dref/5516370)