



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for EPSON EXPRESSION XP-335. You'll find the answers to all your questions on the EPSON EXPRESSION XP-335 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual EPSON EXPRESSION XP-335

User guide EPSON EXPRESSION XP-335

Operating instructions EPSON EXPRESSION XP-335

Instructions for use EPSON EXPRESSION XP-335

Instruction manual EPSON EXPRESSION XP-335



[You're reading an excerpt. Click here to read official EPSON EXPRESSION XP-335 user guide](http://yourpdfguides.com/dref/5833299)
<http://yourpdfguides.com/dref/5833299>

| | |
|--|-------|
| | |
| ... 37 Printing to Fit the Paper Size. | |
| 38 Printing Multiple Files Together (for Windows Only). | |
| | |
| 39 Printing One Image on Multiple Sheets to Create a Poster (for Windows Only). | |
| ... 40 Printing Using Advanced Features. | |
| | |
| 46 Printing Photos Using Epson Easy Photo Print. . 48 Printing from Smart Devices. . . | |
| | |
| ... 49 Using Epson iPrint. | |
| | |
| 49 Using AirPrint. . . | |
| | |
| | |
| ... 51 Canceling Printing. | |
| | |
| 51 Canceling Printing - Printer Button. . | |
| | |
| 51 Canceling Printing - Windows. | |
| | |
| ... 52 Canceling Printing - Mac OS X. | |
| | |
| 52 Important Instructions Safety Instructions. . . | |
| | |
| | |
| ... 9 Printer Advisories and Warnings. | |
| | |
| ... 9 Advisories and Warnings for Setting Up/ Using the Printer. . | |
| | |
| | |
| .. 10 Advisories and Warnings for Using the Printer with a Wireless Connection. . . | |
| | |
| ... 11 Advisories and Warnings for Using Memory Cards. | |
| | |
| | |
| 11 Advisories and Warnings for Using the LCD Screen. | |
| | |
| | |
| 11 Protecting Your Personal Information. . . | |
| | |
| 11 Printer Basics Part Names and Functions. . | |
| | |
| 12 Control Panel. . . | |
| | |
| | |
| 14 Buttons. | |

| | |
|-------|--|
| | |
| | |
| | |
| | 14 Guide to the LCD Screen. |
| | |
| | 14 Copying Menu Options for Copy Mode. |
| | |
| | |
| 53 | Loading Paper Paper Handling Precautions. |
| | |
| | 19 Available Paper and Capacities. |
| | |
| | 20 List of Paper Types. |
| | |
| | 21 Loading Paper in the Rear Paper Feed. |
| | |
| | 21 Scanning Scanning Using the Control Panel. |
| | |
| | |
| | 56 Scanning to a Computer. |
| | |
| | 56 Scanning to a Computer (WSD). |
| | |
| | 56 Scanning from a Computer. |
| | |
| | 57 Scanning Basics. |
| | |
| | |
| | 57 Scanning Using Advanced Features. |
| | |
| | 60 Scanning from Smart Devices. |
| | |
| | |
| | 63 Installing Epson iPrint. |
| | |
| | |
| | 63 Using Epson iPrint. |
| | |
| | |
| | 63 Placing Originals on the Scanner Glass Placing Other Originals. |
| | |
| | |
| | 26 Inserting a Memory Card Supported Memory Cards. |
| | |
| | 28 Inserting and Removing a Memory Card. |
| | |
| | 28 Replacing Ink Cartridges Checking the Ink Levels. |
| | |
| | |
| | 65 Checking the Ink Levels - Control Panel. |
| | |
| | 65 4 User's Guide Contents Checking the Ink Levels - Windows. |
| | |
| | 65 Checking the Ink Levels - Mac OS X. |
| | 65 Ink Cartridge Codes. |
| | |
| | |

.....
.....
.65 Ink Cartridge Handling Precautions.
... *66 Replacing Ink Cartridges.*
.....
.....
... *68 Temporarily Printing with Black Ink.*



[You're reading an excerpt. Click here to read official EPSON
EXPRESSION XP-335 user guide
http://yourpdfguides.com/dref/5833299](http://yourpdfguides.com/dref/5833299)

| | | |
|--|---|--|
| | | |
| | 91 Mac OS X Printer Driver..... | |
| | | |
| | | |
| | 91 Guide to Mac OS X Printer Driver..... | |
| | .92 Making Operation Settings for the Mac OS X Printer Driver.... | |
| | | |
| | | |
| |93 EPSON Scan (Scanner Driver). . . | |
| | | |
| | | |
| | . . . 94 Epson Event Manager..... | |
| | | |
| | | |
| | .94 Epson Easy Photo Print. . . | |
| | | |
| |95 E-Web Print (for Windows Only). . . | |
| | | |
| | | |
| | . 95 Easy Photo Scan..... | |
| | | |
| | | |
| | . . .95 EPSON Software Updater. . | |
| | | |
| |96 Uninstalling Applications. . | |
| | | |
| | | |
| |96 Uninstalling Applications - Windows. . | |
| |96 Uninstalling Applications - Mac OS X. . . | |
| | | |
| | . 97 Installing Applications. . . . | |
| | | |
| |98 Updating Applications and Firmware. . | |
| | | |
| | 98 Solving Problems Checking the Printer Status. | |
| | | |
| |99 Checking Error Codes on the LCD Screen. . . | |
| | . . . 99 Checking the Printer Status - Windows. . | |
| | | |
| | 100 Checking Printer Status - Mac OS X..... | 100 Removing Jammed Paper. |
| | | |
| | | |
| | . . . 101 Removing Jammed Paper from the Rear Paper Feed. . | |
| | | |
| | | |
| | | |
| | .101 Removing Jammed Paper from the Output Tray | 101 Removing Jammed Paper from Inside the Printer. . . . |
| | | |
| | | |
| | | |
| | . .102 Paper Does Not Feed Correctly. . . | |
| | | |
| | | |
| | . . 103 Paper Jams..... | |
| | | |

..... 121 Standards and Approvals for European Model. . 121 Restrictions on Copying. .

.....
.....

..... 121 Transporting the Printer.

.....
.....

. 122 Accessing a Memory Card From a Computer.

.123 Where to Get Help.

.....
.....

124 Technical Support Web Site.

.....

.124 Contacting Epson Support.

.....

. . 125 6 User's Guide About This Manual About This Manual Introduction to the Manuals The following manuals are supplied with your Epson printer. As well as the manuals, see the help included in the various Epson software applications. □ Start Here (paper manual) Provides you with information on setting up the printer, installing the software, using the printer, solving problems, and so on.

□ User's Guide (digital manual) This manual. Provides overall information and instructions on using the printer, and on solving problems. □ Network Guide (digital manual) Provides information on network settings and solving problems when using the printer on a network. You can obtain the latest versions of the above manuals with the following methods. □ Paper manual Visit the Epson Europe support website at <http://www.epson.eu/Support>, or the Epson worldwide support website at <http://support.epson.net/>. □ Digital manual Start EPSON Software Updater on your computer.

EPSON Software Updater checks for available updates of Epson software applications and the digital manuals, and allows you to download the latest ones.

Related Information & "EPSON Software Updater" on page 96 Marks and Symbols ! Caution: that must be followed carefully to avoid bodily injury.

Instructions c Important: that must be observed to avoid damage to your equipment. Instructions Note: Provides complementary and reference information. &

Related Information Links to related sections. 7 User's Guide About This Manual Descriptions Used in this Manual □ Screenshots of the printer driver and the EPSON Scan (scanner driver) screens are from Windows 8.1 or Mac OS X v10.10.x. The content displayed on the screens varies depending on the model and situation.

□ Illustrations of the printer used in this manual are examples only. Although there may be slight differences depending on the model, the method of operation is the same. □ Some of the menu items on the LCD screen vary depending on the model and settings. Operating System References Windows In this manual, terms such as "Windows 8.1", "Windows 8", "Windows 7", "Windows Vista", and "Windows XP" refer to the following operating systems.

Additionally, "Windows" is used to refer to all versions. ® ® ® ® □ Microsoft Windows 7 operating system ® ® □ Microsoft Windows Vista operating system ® ® □ Microsoft Windows XP operating system ® ® □ Microsoft Windows XP Professional x64 Edition operating system ® ® □ Microsoft Windows 8 operating system Mac OS X In this manual, "Mac OS X v10.10.x" refers to OS X Yosemite, "Mac OS X v10.9.x" refers to OS X Mavericks, and "Mac OS X v10.8.x" refers to OS X Mountain Lion. Additionally, "Mac OS X" is used to refer to "Mac OS X v10.10.x", "Mac OS X v10.9.x", "Mac OS X v10.8.x", "Mac OS X v10.7.x", and "Mac OS X v10.6.8". □ Microsoft Windows 8.1 operating system 8 User's Guide Important Instructions Important Instructions Safety Instructions

Read and follow these instructions to ensure safe use of this printer.



[You're reading an excerpt. Click here to read official EPSON EXPRESSION XP-335 user guide](http://yourpdfguides.com/dref/5833299)
<http://yourpdfguides.com/dref/5833299>

Make sure you keep this manual for future reference. Also, be sure to follow all warnings and instructions marked on the printer. □ Use only the power cord supplied with the printer and do not use the cord with any other equipment. Use of other cords with this printer or the use of the supplied power cord with other equipment may result in fire or electric shock.

□ Be sure your AC power cord meets the relevant local safety standard. □ Never disassemble, modify, or attempt to repair the power cord, plug, printer unit, scanner unit, or options by yourself, except as specifically explained in the printer's manuals. □ Unplug the printer and refer servicing to qualified service personnel under the following conditions: The power cord or plug is damaged; liquid has entered the printer; the printer has been dropped or the casing damaged; the printer does not operate normally or exhibits a distinct change in performance. Do not adjust controls that are not covered by the operating instructions. □ Place the printer near a wall outlet where the plug can be easily unplugged.

□ Do not place or store the printer outdoors, near excessive dirt or dust, water, heat sources, or in locations subject to shocks, vibrations, high temperature or humidity. □ Take care not to spill liquid on the printer and not to handle the printer with wet hands. □ Keep the printer at least 22 cm away from cardiac pacemakers. Radio waves from this printer may adversely affect the operation of cardiac pacemakers. □ If the LCD screen is damaged, contact your dealer.

If the liquid crystal solution gets on your hands, wash them thoroughly with soap and water. If the liquid crystal solution gets into your eyes, flush them immediately with water. If discomfort or vision problems remain after a thorough flushing, see a doctor immediately. □ Be careful when you handle used ink cartridges, as there may be some ink around the ink supply port. □ If ink gets on your skin, wash the area thoroughly with soap and water. □ If ink gets into your eyes, flush them immediately with water. If discomfort or vision problems continue after a thorough flushing, see a doctor immediately. □ If ink gets into your mouth, see a doctor right away. □ Do not disassemble the ink cartridge; otherwise ink may get into your eyes or on your skin. □ Do not shake ink cartridges too vigorously and do not drop them.

Also, be careful not to squeeze them or tear their labels. Doing so may cause ink leakage. □ Keep ink cartridges out of the reach of children. Printer Advisories and Warnings Read and follow these instructions to avoid damaging the printer or your property. Make sure you keep this manual for future reference. 9 User's Guide Important Instructions Advisories and Warnings for Setting Up/Using the Printer □ Do not block or cover the vents and openings in the printer. □ Use only the type of power source indicated on the printer's label. □ Avoid using outlets on the same circuit as photocopiers or air control systems that regularly switch on and off. □ Avoid electrical outlets controlled by wall switches or automatic timers. □ Keep the entire computer system away from potential sources of electromagnetic interference, such as loudspeakers or the base units of cordless telephones.

□ The power-supply cords should be placed to avoid abrasions, cuts, fraying, crimping, and kinking. Do not place objects on top of the power-supply cords and do not allow the power-supply cords to be stepped on or run over. Be particularly careful to keep all the power-supply cords straight at the ends and the points where they enter and leave the transformer. □ If you use an extension cord with the printer, make sure that the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating. Also, make sure that the total ampere rating of all devices plugged into the wall outlet does not exceed the wall outlet's ampere rating.

□ If you plan to use the printer in Germany, the building installation must be protected by a 10 or 16 amp circuit breaker to provide adequate short-circuit protection and over-current protection for the printer. □ When connecting the printer to a computer or other device with a cable, ensure the correct orientation of the connectors. Each connector has only one correct orientation. Inserting a connector in the wrong orientation may damage both devices connected by the cable. □ Place the printer on a flat, stable surface that extends beyond the base of the printer in all directions.

The printer will not operate properly if it is tilted at an angle. □ When storing or transporting the printer, avoid tilting it, placing it vertically, or turning it upside down; otherwise ink may leak. □ Allow space above the printer so that you can fully raise the document cover. □ Leave enough space in front of the printer for the paper to be fully ejected. □ Avoid places subject to rapid changes in temperature and humidity. Also, keep the printer away from direct sunlight, strong light, or heat sources. □ Do not insert objects through the slots in the printer. □ Do not put your hand inside the printer during printing. □ Do not touch the white flat cable inside the printer. □ Do not use aerosol products that contain flammable gases inside or around the printer.

Doing so may cause fire. □ Do not move the print head by hand; otherwise, you may damage the printer. □ Be careful not to trap your fingers when closing the scanner unit. □ Do not press too hard on the scanner glass when placing the originals. □ Always turn the printer off using the P button. Do not unplug the printer or turn off the power at the outlet until the P light stops flashing. □ Before transporting the printer, make sure that the print head is in the home (far right) position and the ink cartridges are in place. □ If you are not going to use the printer for a long period, be sure to unplug the power cord from the electrical outlet. 10 User's Guide Important Instructions Advisories and Warnings for Using the Printer with a Wireless Connection □ Radio waves from this printer may negatively affect the operation of medical electronic equipment, causing them to malfunction. When using this printer inside medical facilities or near medical equipment, follow directions from the authorized personnel representing the medical facilities, and follow all posted warnings and directions on the medical equipment.

□ Radio waves from this printer may negatively affect the operation of automatically controlled devices such as automatic doors or fire alarms, and could lead to accidents due to malfunction. When using this printer near automatically controlled devices, follow all posted warnings and directions on these devices. Advisories and Warnings for Using Memory Cards □ Do not remove a memory card or turn off the printer while the memory card light is flashing. □ The methods for using memory cards vary according to card type.



[You're reading an excerpt. Click here to read official EPSON
EXPRESSION XP-335 user guide
http://yourpdfguides.com/dref/5833299](http://yourpdfguides.com/dref/5833299)

Be sure to refer to the manual packaged with your memory card for details.

□ Use only memory cards compatible with the printer. Related Information & “Supported Memory Card Specifications” on page 118 Advisories and Warnings for Using the LCD Screen □ The LCD screen may contain a few small bright or dark spots, and because of its features it may have an uneven brightness. These are normal and do not indicate that it is damaged in any way. □ Only use a dry, soft cloth for cleaning. Do not use liquid or chemical cleaners.

□ The exterior cover of the LCD screen could break if it receives a heavy impact. Contact your dealer if the screen's surface chips or cracks, and do not touch or attempt to remove the broken pieces. Protecting Your Personal Information When you give the printer to someone else or dispose of it, erase all the personal information stored in the printer's memory by selecting Setup > Restore Default Settings > All Settings on the control panel. 11 User's Guide Printer Basics Printer Basics Part Names and Functions A B C D E F Edge guide Rear paper feed Paper support Feeder guard Feeds the paper straight into the printer. Slide to the edges of the paper. Loads paper. Supports loaded paper. Prevents foreign substance from entering the printer. Usually keep this guard closed. Holds the ejected paper.

Before printing, raise the stopper to prevent the ejected paper from falling off the tray. Operates the printer. Output tray Control panel B A 12 User's Guide Printer Basics A B Memory card slot Ink cartridge holder Insert a memory card. Install the ink cartridges. Ink is ejected from the print head nozzles underneath. A B C Document cover Scanner glass Scanner unit Blocks external light while scanning. Place the originals. Scans placed originals. Open when replacing ink cartridges or removing jammed paper inside the printer. A B A B AC inlet USB port Connects the power cord.

Connects a USB cable. 13 User's Guide Printer Basics Control Panel You can change the angle of the control panel. To lower the control panel, squeeze the lever on the back of the panel as shown below. Buttons A Turns the printer on or off. Do not turn off while the power light is flashing (while the printer is operating or processing data).

Unplug the power cord when the power light is off. B C D E Displays the home screen. u d l r OK Use the u d l r buttons to select a menu, and press the OK button to run the selected menu. Stops the current operation or returns to the previous screen. Starts an operation such as printing or copying.

Guide to the LCD Screen Menus and messages are displayed on the LCD screen. Select a menu or setting by pressing the u d l r buttons. 14 User's Guide Printer Basics Guide to the Home Screen The following icons and menus are displayed on the home screen. A Icons that show the network status are displayed. Indicates a problem with the printer's wireless (Wi-Fi) network connection, or that the printer is searching for a wireless (Wi-Fi) network connection. Indicates that the printer is connected to a wireless (Wi-Fi) network. The number of bars indicates the signal strength of the connection. The more bars there are, the stronger the connection. Indicates that the printer is connected to a wireless (Wi-Fi) network in Ad Hoc mode Indicates that a wireless (Wi-Fi) network is disabled, or that the printer is processing a wireless network connection. Indicates that the printer is connected to a wireless (Wi-Fi) network in Simple AP mode.

Indicates that the printer is connected to a wireless (Wi-Fi) network in Wi-Fi Direct mode. Indicates that Wi-Fi Direct is disabled, or that the printer is processing a wireless network connection. B When l and r are displayed, you can scroll right or left by pressing the l or r button. 15 User's Guide Printer Basics C Function icons and names are displayed as mode icons. Copy Print Photos Scan Personal Stationery Quiet Mode Enters Copy mode that allows you to copy a document. Enters Print Photos mode that allows you to print photos on your memory card. Enters Scan mode that allows you to scan a document or a photo. Enters Personal Stationery mode that allows you to print original items, such as ruled paper and calendars, using the photos on your memory card.

Displays Quiet Mode setting that allows you to reduce the noise the printer makes. However, enabling this may reduce print speed.

Depending on the paper type and print quality settings you selected, there may be no difference in the printer's noise level. This is a shortcut to the following menu. Setup > Printer Setup > Quiet Mode Setup Wi-Fi Setup Enters Setup mode that allows you to make maintenance, printer setup, and network settings.

Displays menus that allow you to set up the printer for use on a wireless network. This is a shortcut to the following menu.

Setup > Network Settings > Wi-Fi Setup D Available buttons are displayed. In this example, you can proceed to the selected menu by pressing the OK button.

Entering Characters To enter characters and symbols for network settings from the control panel, use the u, d, l, and r buttons. Press the u or d button to select the character you want to enter, and then press the r button to move the cursor to the next input position. When you have finished entering characters, press the OK button.

The displayed screen varies depending on the settings items. The following is the screen to enter a password of your Wi-Fi network. Icons Descriptions Switches the character type. ABC: Uppercase characters abc: Lowercase characters 123: Numbers and symbols ud Selects the character to be entered. 16 User's Guide Printer Basics Icons Descriptions r l OK Moves the cursor to the right. Deletes a character to the left (backspace). Enters the selected characters. Returns to the previous screen. Entering the Practice String "13By" 1. Press the button twice to switch the character type to 123.

2. 3. Press the u button twice to select "1". Press the r button once to move the cursor, and then press the u button four times to select "3". 17 User's Guide Printer Basics 4. Press the r button once to move the cursor, and then press the ABC. Press the u button twice to select "B". button to switch the character type to 5. Press the r button once to move the cursor, and then press the Press the d button twice to select "y". button to switch the character type to abc.

6. Press the OK button. 18 User's Guide Loading Paper Loading Paper Paper Handling Precautions □ Read the instruction sheets supplied with the paper. □ Fan and align the edges of the paper before loading. Do not fan or curl photo paper.

Doing so may damage the printable side. □ If the paper is curled, flatten it or curl it slightly in the opposite direction before loading. Printing on curled paper may cause paper jams and smears on the printout. □ Do not use paper that is wavy, torn, cut, folded, damp, too thick, too thin, or paper that has stickers stuck to it.



[You're reading an excerpt. Click here to read official EPSON
EXPRESSION XP-335 user guide
http://yourpdfguides.com/dref/5833299](http://yourpdfguides.com/dref/5833299)

Using these types of paper causes paper jams and smears on the printout.

□ Fan and align the edges of the envelopes before loading. When the stacked envelopes are puffed up with air, press them down to flatten them before loading. □ Do not use envelopes that are curled or folded. Using these envelopes causes paper jams and smears on the printout. □ Do not use envelopes with adhesive surfaces on the flaps or window envelopes. □ Avoid using envelopes that are too thin, as they may curl during printing. Related Information & “Printer Specifications” on page 116 19 User's Guide Loading Paper Available Paper and Capacities Epson recommends using genuine Epson paper to ensure high-quality printouts. Genuine Epson Paper Media Name Size Loading Capacity (Sheets) 80* 20 Manual 2Sided Printing □ Borderless Printing Epson Bright White Ink Jet Paper Epson Ultra Glossy Photo Paper Epson Premium Glossy Photo Paper A4 – □ □ A4, 13 × 18 cm (5 × 7 in.), 10 × 15 cm (4 × 6 in.) A4, 13 × 18 cm (5 × 7 in.)

), 16:9 wide size (102 × 181 mm), 10 × 15 cm (4 × 6 in.) A4, 10 × 15 cm (4 × 6 in.) – 20 – Epson Premium Semigloss Photo Paper Epson Photo Paper Glossy 20 – □ □ □ A4, 13 × 18 cm (5 × 7 in.), 10 × 15 cm (4 × 6 in.) A4 20 – Epson Matte Paper Heavyweight Epson Photo Quality Ink Jet Paper * 20 – A4 80 – – For manual 2-sided printing, you can load up to 30 sheets for paper with one side already printed. Note: The availability of paper varies by location.

For the latest information on paper available in your area, contact Epson support. Commercially Available Paper Media Name Size Loading Capacity (Sheets) Up to the line indicated by the triangle symbol on the edge guide. *3 1 Manual 2-Sided Printing □ Borderless Printing – Plain paper*1 Letter*2, A4, B5*2, A5*2, A6*2 Legal*2 User Defined*2 Envelope*2 Envelope #10, Envelope DL, Envelope C6 10 – – *1 *2 The loading capacity for pre-punched paper is one sheet. Only printing from computer is available.

20 User's Guide Loading Paper *3 For manual 2-sided printing, you can load up to 30 sheets for paper with one side already printed. Related Information & “Technical Support Web Site” on page 124 List of Paper Types To obtain optimum printing results, select the paper type that suits the paper. Media Name Media Type Control Panel Epson Bright White Ink Jet Paper*1 Epson Ultra Glossy Photo Paper*1 Epson Premium Glossy Photo Paper*1 Epson Premium Semigloss Photo Paper*1 Epson Photo Paper Glossy*1 Epson Matte Paper-Heavyweight*1 Epson Photo Quality Ink Jet Paper*1 Plain paper*1 Envelope *1 *2 plain papers Ultra Glossy Prem. Glossy Prem. Semigloss Printer Driver, Smart device*2 plain papers Epson Ultra Glossy Epson Premium Glossy Epson Premium Semigloss Glossy Matte Matte plain papers Envelope Photo Paper Glossy Epson Matte Epson Matte plain papers Envelope These paper types are compatible with Exif Print and PRINT Image Matching when printed by the printer driver.

For more information, see the documentation that came with the Exif Print or PRINT Image Matching compatible digital camera. For smart devices, these media types can be selected when printing using Epson iPrint. Loading Paper in the Rear Paper Feed 1. Open the feeder guard, extend the paper support, and then tilt it backwards. 21 User's Guide Loading Paper 2.

Slide the edge guide to the left. 3. Load paper vertically along the right side of the rear paper feed with the printable side facing up. c Important: more than the maximum number of sheets specified for the paper. For plain paper, do not load Do not load above the line indicated by the triangle symbol on the edge guide. □ Envelopes 22 User's Guide Loading Paper □ Pre-punched paper Note: □ Load a single sheet of paper without binding holes at the top or the bottom. □ Adjust the print position of your file to avoid printing over the holes. 4. Slide the edge guide to the edge of the paper, and then close the feeder guard. 5.

Check the paper size and paper type settings displayed on the control panel. To use the settings, select Confirm using the u or d button, press the OK button, and then go to step 7. To change the settings, select Change using the u or d button, press the OK button, and then go to the next step. c Important: setting screen is not displayed if the paper is not loaded along the right side of the rear paper feed. An The paper error occurs when you start printing. Note: The paper setting screen is not displayed if you have disabled Paper Configuration in the following menus. Go to step 7. Setup > Printer Setup > Paper Source Settings > Paper Configuration 6. On the paper size setting screen, select the paper size using the l or r button, and then press the OK button. On the paper type setting screen, select the paper type in the same way, and then press the OK button.

Confirm the settings, and then press the OK button. Note: You can also display the paper size and paper type settings screen by selecting the following menus. Setup > Printer Setup > Paper Source Settings > Paper Setup 23 User's Guide Loading Paper 7. Slide out the output tray and then raise the stopper. Note: Return the remaining paper to its package.

If you leave it in the printer, the paper may curl or the print quality may decline. Related Information & “Paper Handling Precautions” on page 19 & “Available Paper and Capacities” on page 20 24 User's Guide Placing Originals on the Scanner Glass Placing Originals on the Scanner Glass c Important: bulky originals such as books, prevent exterior light from shining directly onto the scanner glass. When placing 1. Open the document cover. 2.

3. Remove any dust or stains on the scanner glass. Place the original face-down and slide it to the corner mark. Note: The area 1.5 mm from the edges of the scanner glass is not scanned. 25 User's Guide Placing Originals on the Scanner Glass If you are scanning using Full Auto Mode or a thumbnail preview of EPSON Scan, place the original 4.5 mm away from the horizontal and vertical edges of the scanner glass. Note: □ Place multiple photos at least 20 mm apart from each other. □ The photos should be larger than 15 x 15 mm. 4.

Close the cover gently. Note: Remove the originals after scanning or copying. If you leave the originals on the scanner glass for a long time, they may stick to the surface of the glass. Placing Other Originals When copying a double-page spread 26 User's Guide Placing Originals on the Scanner Glass When copying into 2-up layout 27 User's Guide Inserting a Memory Card Inserting a Memory Card Supported Memory Cards miniSD* miniSDHC* microSD* microSDHC* microSDXC* SD SDHC SDXC * Attach an adapter to fit the memory card slot. Otherwise, the card may get stuck.



[You're reading an excerpt. Click here to read official EPSON EXPRESSION XP-335 user guide](http://yourpdfguides.com/dref/5833299)
<http://yourpdfguides.com/dref/5833299>

Related Information & "Supported Memory Card Specifications" on page 118 Inserting and Removing a Memory Card 1. Insert a memory card into the printer. The printer starts reading the data and the light flashes. When reading is complete, the light stops flashing and remains on. c Important: to force the card all the way into the slot.

It should not be fully inserted. Do not try 28 User's Guide Inserting a Memory Card 2. When you have finished using the memory card, make sure the light is not flashing, and then remove the card. c Important: the memory card while the light is flashing, the data in the memory card may be lost. If you remove Note: If you access the memory card from a computer, you need to operate the computer to safely remove the removable device.

Related Information & "Accessing a Memory Card From a Computer" on page 123 29 User's Guide Printing Printing Printing from the Control Panel Printing Photos by Selecting from a Memory Card 1. Load paper in the printer. c Important: settings on the control panel. Make the paper 2. Insert a memory card into the printer.

c Important: the memory card until you have finished printing. Do not remove 3. 4. Enter Print Photos from the home screen using the l or r button, and then press the OK button. Use the l or r button to select a photo, and use the u or d button to set the number of copies. When printing more than one photo, repeat this procedure. Press the OK button to display the print settings confirmation screen. To change the print settings, press the d button to display the setting screen. Use the u or d button to select setting items such as the paper size and the paper type, and change the settings using the l or r button. When you have finished, press the OK button.

7. Press the x button. 5. 6. Related Information & "Loading Paper in the Rear Paper Feed" on page 21 & "List of Paper Types" on page 21 & "Inserting a Memory Card" on page 28 & "Menu Options for Printing Photos" on page 32 30 User's Guide Printing Printing Original Writing Paper and Calendars You can easily print lined paper, calendars, and original writing paper using the Personal Stationery menu. 1. Load paper in the printer. c Important: settings on the control panel. Make the paper 2. 3.

4. 5. To print writing paper using a photo on your memory card, insert the memory card into the printer. Enter Personal Stationery from the home screen using the l or r button, and then press the OK button. Select a menu item using the l or r button, and then press the OK button.

Follow the on-screen instructions to print. Related Information & "Loading Paper in the Rear Paper Feed" on page 21 & "List of Paper Types" on page 21 & "Inserting a Memory Card" on page 28 & "Menu Options for Printing Original Writing Paper and Calendars" on page 31 & "Menu Options for Printing Photos" on page 32 Menu Options for Printing Original Writing Paper and Calendars Lined Papers Prints some types of lined paper, graph paper, or music paper on A4 size paper. Writing Papers Prints some types of writing paper on A4 size paper with a photo from the memory card set as the background. The photo is printed lightly so that it can be easily written on. Calendar 31 User's Guide Printing Prints a weekly or monthly calendar.

Select the year and the month for the monthly calendar. DPOF Printing This printer is compatible with DPOF (Digital Print Order Format) Ver. 1.10. DPOF is a format that stores additional information for photos such as the date, time, user name, and printing information. DPOF-compatible cameras allow you to set which image on a memory card to print and the number of copies. When the memory card is inserted into the printer, the photos selected by the camera are printed. Note: For information on making print settings on your camera, see the documentation provided with your camera. When you insert a memory card into the printer, a confirmation screen is displayed. Press the OK button to display the print start screen.

Press the x button to start printing. If you want to change the print settings, press the d button. Setting items are the same as in Print Photos mode. Related Information & "Printing Photos by Selecting from a Memory Card" on page 30 & "Menu Options for Printing Photos" on page 32 Menu Options for Printing Photos Paper Size Select the paper size you loaded. Paper Type Select the paper type you loaded. Borderless To print without margins around the edges, select Borderless. The image is enlarged a little to remove margins from the edges of the paper. To print with margins around the edges, select With Border.

Quality Select the print quality. Selecting Best provides higher quality printing, but the printing speed may be slower.

Printing from a Computer Printing Basics - Windows Note: See the online help for explanations of the setting items. Right-click an item, and then click Help. Operations differ depending on the application. See the application's help for details. 32 User's Guide Printing 1.

Load paper in the printer. c Important: settings on the control panel. Make the paper 2. 3. 4.

5. Open the file you want to print. Select Print or Print Setup from the File menu. Select your printer. Select Preferences or Properties to access the printer driver window. 6. Make the following settings. Document Size: Select the paper size you loaded in the printer. Borderless: Select to print with no margins around the image. In borderless printing, the print data is enlarged slightly more than the paper size so that no margins are printed around the edges of the paper.

Click Settings to select the amount of enlargement. Orientation: Select the orientation you set in the application. Paper Type: Select the type of paper you loaded. Color: Select Grayscale when you want to print in black or shades of gray. Note: When printing on envelopes, select Landscape as the Orientation setting. 33 User's Guide Printing 7. 8. Click OK to close the printer driver window. Click Print. Related Information & "Available Paper and Capacities" on page 20 & "Loading Paper in the Rear Paper Feed" on page 21 & "Guide to Windows Printer Driver" on page 88 & "List of Paper Types" on page 21

Printing Basics - Mac OS X Note: Explanations in the section use TextEdit as an example.

Operations and screens differ depending on the application. See the application's help for details. 1. Load paper in the printer. c Important: settings on the control panel.

Make the paper 2. 3. Open the file you want to print. Select Print from the File menu or another command to access the print dialog. If necessary, click Show Details or d to expand the print window.

4. Make the following settings. Printer: Select your printer.



[You're reading an excerpt. Click here to read official EPSON
EXPRESSION XP-335 user guide
http://yourpdfguides.com/dref/5833299](http://yourpdfguides.com/dref/5833299)

Presets: Select when you want to use the registered settings. Paper Size: Select the paper size you loaded in the printer. When printing with no margins, select a "borderless" paper size. 34 User's Guide Printing Orientation: Select the orientation you set in the application. Note: If the above setting menus are not displayed, close the print window, select Page Setup from the File menu, and then make settings. When printing on envelopes, select landscape orientation. 5.

Select Print Settings from the pop-up menu. Note: On Mac OS X v10.8.x or later, if the Print Settings menu is not displayed, the Epson printer driver has not been installed correctly. Select System Preferences from the menu > Printers & Scanners (or Print & Scan, Print & Fax), remove the printer, and then add the printer again. See the following to add a printer. <http://epson.sn> 6. Make the following settings. Media Type: Select the type of paper you loaded. Expansion: Available when selecting a borderless paper size. In borderless printing, the print data is enlarged slightly more than the paper size so that no margins are printed around the edges of the paper. Select the amount of enlargement. Grayscale: Select to print in black or shades of gray. 7. Click Print. Related Information & "Available Paper and Capacities" on page 20 & "Loading Paper in the Rear Paper Feed" on page 21 & "Guide to Mac OS X Printer Driver" on page 92 35 User's Guide Printing & "List of Paper Types" on page 21 Printing on 2-Sides (for Windows only) The printer driver prints automatically separating even pages and odd pages. When the printer has finished printing the odd pages, flip the paper over following the instructions to print the even pages. You can also print a booklet that can be created by folding the printout. Note: This feature is not available for borderless printing. If you do not use paper that is suitable for 2-sided printing, the print quality may decline and paper jams may occur. Depending on the paper and the data, ink may bleed through to the other side of the paper. If EPSON Status Monitor 3 is disabled, access the printer driver, click Extended Settings on the Maintenance tab, and then select Enable EPSON Status Monitor 3. 2-sided printing may not be available when the printer is accessed over a network or is used as a shared printer. 1. 2. 3. 4. Load paper in the printer. Open the file you want to print.

Access the printer driver window. Select Manual (Long-edge binding) or Manual (Short-edge binding) from 2-Sided Printing on the Main tab. Click Settings, make the appropriate settings, and then click OK. Note: To print as a booklet, select Booklet. 5. 6. 7. @@Click Print. When the first side has finished printing, a pop-up window is displayed on the computer. Follow the on-screen instructions.

36 User's Guide Printing Related Information & "Available Paper and Capacities" on page 20 & "Loading Paper in the Rear Paper Feed" on page 21 & "Printing Basics - Windows" on page 32 Printing Several Pages on One Sheet You can print two or four pages of data on a single sheet of paper. Printing Several Pages on One Sheet - Windows Note: This feature is not available for borderless printing. 1. 2. 3. 4. 5. 6. 7. Load paper in the printer.

Open the file you want to print. Access the printer driver window. Select 2-Up or 4-Up as the Multi-Page setting on the Main tab. Click Page Order, make the appropriate settings, and then click OK to close the window. @@Click Print. Related Information & "Loading Paper in the Rear Paper Feed" on page 21 & "Printing Basics - Windows" on page 32 37 User's Guide Printing Printing Several Pages on One Sheet - Mac OS X 1. 2. 3. 4. 5.

6. 7. Load paper in the printer. Open the file you want to print. Access the print dialog. Select Layout from the pop-up menu. Set the number of pages in Pages per Sheet, the Layout Direction (page order), and Border. Set the other items as necessary. Click Print. Related Information & "Loading Paper in the Rear Paper Feed" on page 21 & "Printing Basics - Mac OS X" on page 34 Printing to Fit the Paper Size You can print to fit the paper size you loaded in the printer.

Printing to Fit the Paper Size - Windows Note: This feature is not available for borderless printing. 1. 2. 3. 4.

Load paper in the printer. Open the file you want to print. Access the printer driver window. Make the following settings on the More Options tab. Document Size: Select the paper size you set in the application.

Output Paper: Select the paper size you loaded in the printer. 38 User's Guide Printing Fit to Page is selected automatically. Note: If you want to print a reduced image at the center of the page, select Center. 5. 6. @@Click Print. Related Information & "Loading Paper in the Rear Paper Feed" on page 21 & "Printing Basics - Windows" on page 32 Printing to Fit the Paper Size - Mac OS X 1. 2. 3. 4.

5. 6. 7. 8. 9. Load paper in the printer. Open the file you want to print. Access the print dialog. Select the size of the paper you set in the application as the Paper Size setting. Select Paper Handling from the pop-up menu.

Select Scale to fit paper size. Select the paper size you loaded in the printer as the Destination Paper Size setting. Set the other items as necessary. Click Print. Related Information & "Loading Paper in the Rear Paper Feed" on page 21 & "Printing Basics - Mac OS X" on page 34 Printing Multiple Files Together (for Windows Only) Job Arranger Lite allows you to combine several files created by different applications and print them as a single print job.

You can specify the print settings for combined files, such as layout, print order, and orientation. 39 User's Guide Printing Note: To open a Print Project saved in Job Arranger Lite, click Job Arranger Lite on the printer driver's Maintenance tab. Next, select Open from the File menu to select the file. The extension of the saved files is ".ecl". 1.

2. 3. 4. 5. 6. Load paper in the printer. Open the file you want to print. Access the printer driver window. Select Job Arranger Lite on the Main tab. Click OK to close the printer driver window.

Click Print. The Job Arranger Lite window is displayed and the print job is added to the Print Project. 7. With the Job Arranger Lite window opened, open the file that you want to combine with the current file, and then repeat steps 3 to 6. Note: If you close the Job Arranger Lite window, the unsaved Print Project is deleted. To print later, select Save from the File menu. 8. 9. Select the Layout and Edit menus in Job Arranger Lite to edit the Print Project as necessary.

Select Print from the File menu.

Related Information & "Loading Paper in the Rear Paper Feed" on page 21 & "Printing Basics - Windows" on page 32 Printing One Image on Multiple Sheets to Create a Poster (for Windows Only) This feature allows you to print one image on multiple sheets of paper.



[You're reading an excerpt. Click here to read official EPSON EXPRESSION XP-335 user guide](http://yourpdfguides.com/dref/5833299)
<http://yourpdfguides.com/dref/5833299>

You can create a larger poster by taping them together. Note: This feature is not available for borderless printing. 1. Load paper in the printer.

40 User's Guide Printing 2. 3. 4. 5. 6.

7. Open the file you want to print. Access the printer driver window. Select 2x1 Poster, 2x2 Poster, 3x3 Poster, or 4x4 Poster from Multi-Page on the Main tab. Click Settings, make the appropriate settings, and then click OK. @Click Print. Related Information & "Loading Paper in the Rear Paper Feed" on page 21 & "Printing Basics - Windows" on page 32 Making Posters Using Overlapping Alignment Marks Here is an example of how to make a poster when 2x2 Poster is selected, and Overlapping Alignment Marks is selected in Print Cutting Guides. 41 User's Guide Printing 1. Prepare Sheet 1 and Sheet 2. Cut off the margins of Sheet 1 along the vertical blue line through the center of the top and bottom cross marks.

2. Place the edge of Sheet 1 on top of Sheet 2 and align the cross marks, then temporarily tape the two sheets together from the back. 42 User's Guide Printing 3. Cut the taped sheets in two along the vertical red line through the alignment markers (this time, the line to the left of the cross marks). 4. Tape the sheets together from the back. 5. Repeat steps 1 to 4 to tape Sheet 3 and Sheet 4 together. 43 User's Guide Printing 6. Cut off the margins of Sheet 1 and Sheet 2 along the horizontal blue line through the center of the left and right side cross marks.

7. Place the edge of Sheet 1 and Sheet 2 on top of Sheet 3 and Sheet 4 and align the cross marks, and then temporarily tape them together from the back. 44 User's Guide Printing 8. Cut the taped sheets in two along the horizontal red line through the alignment markers (this time, the line above the cross marks). 9. Tape the sheets together from the back. 45 User's Guide Printing 10. Cut off the remaining margins along the outer guide. Printing Using Advanced Features This section introduces a variety of additional layout and printing features available on the printer driver. Related Information & "Windows Printer Driver" on page 88 & "Mac OS X Printer Driver" on page 91 Adding a Printing Preset to Print Easily If you create your own preset of frequently used print settings on the printer driver, you can print easily by selecting the preset from the list.

46 User's Guide Printing Windows To add your own preset, set items such as the Document Size and Paper Type on the Main or More Options tab, and then click Add/Remove Presets in Printing Presets. Note: To delete an added preset, click Add/Remove Presets, select the preset name you want to delete from the list, and then delete it. Mac OS X Access the print dialog. To add your own preset, set items such as the Paper Size and Media Type, and then save the current settings as the preset in the Presets setting. Note: To delete an added preset, click Presets > Show Presets, select the preset name you want to delete from the list, and then delete it. Printing a Reduced or Enlarged Document You can reduce or enlarge the size of a document by a specific percentage. Windows Note: This feature is not available for borderless printing. Set the Document Size on the More Options tab. Select Reduce/Enlarge Document, Zoom to, and then enter a percentage. Mac OS X Note: Operations differ depending on the application.

See the application's help for details. Select Page Setup (or Print) from the File menu. Select the printer from Format For, select the paper size, and then enter a percentage in Scale. Close the window, and then print following the basic printing instructions. Adjusting the Print Color You can adjust the colors used in the print job. PhotoEnhance produces sharper images and more vivid colors by automatically adjusting the contrast, saturation, and brightness of the original image data. Note: These adjustments are not applied to the original data. PhotoEnhance adjusts the color by analyzing the location of the subject.

Therefore, if you have changed the location of the subject by reducing, enlarging, cropping, or rotating the image, the color may change unexpectedly.

Selecting the borderless setting also changes the location of the subject resulting in changes in color.

If the image is out of focus, the tone may be unnatural. If the color is changed or becomes unnatural, print in a mode other than PhotoEnhance. Windows Select the method of color correction from Color Correction on the More Options tab. If you select Automatic, the colors are automatically adjusted to match the paper type and print quality settings. If you select Custom and click Advanced, you can make your own settings.

47 User's Guide Printing Mac OS X Access the print dialog. Select Color Matching from the pop-up menu, and then select EPSON Color Controls. Select Color Options from the pop-up menu, and then select one of the available options. Click the arrow next to Advanced Settings and make the appropriate settings. Printing a Watermark (for Windows Only) You can print a watermark such as "Confidential" on your printouts.

You can also add your own watermark. Note: This feature is not available with borderless printing. Click Watermark Features on the More Options tab, and then select a watermark. Click Settings to change details such as the density and position of the watermark. Printing a Header and Footer (for Windows Only)

You can print information such as a user name and printing date as headers or footers. Click Watermark Features in the More Options tab, and then select Header/Footer. Click Settings and select necessary items from the drop-down list. Printing Photos Using Epson Easy Photo Print Epson Easy Photo Print lets you lay out and print photos easily on various types of paper. See the application's help for details. Note: By printing on genuine Epson photo paper, the ink quality is maximized and the printouts are vivid and clear.

To perform borderless printing using a commercially available application, make the following settings. Create the image data to fully fit the paper size and if a margin setting is available in the application you are using, set the margin to 0 mm. Enable the borderless printing setting in the printer driver.

Related Information & "Epson Easy Photo Print" on page 95 48 User's Guide Printing Printing from Smart Devices Using Epson iPrint Epson iPrint is an application that allows you to print photos, documents, and web pages from a smart device such as a smartphone or tablet. You can use local print, printing from a smart device that is connected to the same wireless network as your printer, or remote print, printing from a remote location over the Internet. To use remote print, register your printer in the Epson Connect service. Related Information & "Epson Connect Service" on page 86 Installing Epson iPrint You can install Epson iPrint on your smart device from the following URL or QR code.



[You're reading an excerpt. Click here to read official EPSON EXPRESSION XP-335 user guide](http://yourpdfguides.com/dref/5833299)
<http://yourpdfguides.com/dref/5833299>

<http://ipr.to/a> Printing Using Epson iPrint Start Epson iPrint from your smart device and select the item you want to use from the home screen. 49 User's Guide Printing The following screens are subject to change without notice.

A B C D E F G H Home screen displayed when the application is started. Displays information on how to setup the printer and a FAQ. Displays the screen where you can select the printer and make printer settings. Once you have selected the printer, you do not need to select it again from the next time. Select what you want to print such as photos, documents, and web pages.

Displays the screen to make print settings such as paper size and paper type. Displays the paper size. When this is displayed as a button, press it to display the paper settings currently set on the printer. Displays photos and documents you selected. Starts printing.

Note: To print from the document menu using iPhone, iPad, and iPod touch running iOS, start Epson iPrint after transferring the document you want to print using the file sharing function in iTunes. 50 User's Guide Printing Using AirPrint AirPrint allows you to wirelessly print to your product from your Apple device running the latest version of iOS. Note: AirPrint also allows you to wirelessly print to your product from your Mac running OS X 10.7 or later. If you disabled paper configuration messages on your product control panel, you cannot use AirPrint. See the link below to enable the messages, if necessary. 1. 2. Load paper in your product. Set up your product for wireless printing.

See the link below. <http://epson.sn> 3. 4. Connect your Apple device to the same wireless network that your product is using. Print from your device to your product. Note: For details, see the AirPrint page on the Apple website. Related Information & "Cannot Use AirPrint" on page 105 & "Loading Paper in the Rear Paper Feed" on page 21 Canceling Printing Note: In Windows, you cannot cancel a print job from the computer once it has been completely sent to the printer. In this case, cancel the print job by using the printer's control panel. When printing several pages from Mac OS X, you cannot cancel all of the jobs by using the control panel.

In this case, cancel the print job from the computer. If you have sent a print job from Mac OS X v10.6.8 through the network, you may not be able to cancel printing from the computer. In this case, cancel the print job by using the printer's control panel.

Canceling Printing - Printer Button Press the y button to cancel the print job in progress. 51 User's Guide Printing Canceling Printing - Windows 1. 2. 3. 4. Access the printer driver window. Select the Maintenance tab. Click Print Queue. Right-click on the job you want to cancel and then select Cancel. Related Information & "Windows Printer Driver" on page 88 Canceling Printing - Mac OS X 1. 2. 3. Click the printer icon in the Dock. Select the job you want to cancel. Cancel the job.

Mac OS X v10.8.x or later Click next to the progress meter. Mac OS X v10.6.8 to v10.7.x Click Delete. 52 User's Guide Copying Copying 1. Load paper in the printer.

c Important: settings on the control panel. Make the paper 2. 3. 4. 5.

6. Place the originals. Enter Copy from the home screen using the l or r button, and then press the OK button. Set the number of copies using the u or d button. Select color copy or monochrome copy using the l or r button.

Press the OK button to display and check the print settings. To change the settings, press the d button, select the setting items using the u or d button and change settings using the l or r button. When you have finished, press the OK button. Note: If you want to copy by reducing or enlarging the size of a document by a specific percentage, select any item other than Auto Fit as the Reduce/Enlarge setting, and then press the OK button. Specify a percentage in Custom Size. You can change the percentage in increments of 10% by holding down the l or r button. 7. Press the x button. Related Information & "Loading Paper in the Rear Paper Feed" on page 21 & "Placing Originals on the Scanner Glass" on page 25 & "Menu Options for Copy Mode" on page 53 Menu Options for Copy Mode Note: Available menus vary depending on the layout you selected. The number of copies Enter the number of copies.

Color Copies the original in color. B&W Copies the original in black and white (monochrome). Layout 53 User's Guide Copying With Border Copies with margins around the edges. Borderless Copies without margins around the edges. The image is enlarged a little to remove margins from the edges of the paper. A4, 2-up Copy Copies two A4 single-sided originals onto a single sheet of A4 size paper in 2-up layout. A4, Book/2-up Copies two A4 facing pages of a book and so on onto a single sheet of A4 size paper in 2-up layout. Reduce/Enlarge Enlarges or reduces the originals. Actual Size Copies at 100 % magnification. Auto Fit Detects the scan area and automatically enlarges or reduces the original to fit to the paper size you selected.

When there are white margins around the original, the white margins from the corner mark of the scanner glass are detected as the scan area, but the margins at the opposite side may be cropped. Custom Select to specify the magnification to enlarge or reduce the original. Custom Size Specifies the magnification used to enlarge or reduce the original within a range of 25 to 400%. Paper Size Select the paper size you loaded. Paper Type Select the paper type you loaded.

Quality 54 User's Guide Copying Select the print quality. Draft provides faster printing, but the printouts may be faint. Best provides higher quality printing, but the printing speed may be slower. For users in Belgium, the draft mode is not available. Density Increase the level of density by pressing the r button when the copying results are faint.

Decrease the level of density by pressing the l button when ink smears. 55 User's Guide Scanning Scanning Scanning Using the Control Panel Scanning to a Computer You can save the scanned image to a computer. c Important: you have installed EPSON Scan and Epson Event Manager on your computer before using this feature. Make sure 1. 2. 3. Place the originals. Enter Scan from the home screen using the l or r button, and then press the OK button. Select how to save the scanned image to a computer from the following menus using the l or r button, and then press the OK button. To Computer (JPEG): Saves the scanned image in JPEG format.

To Computer (PDF): Saves the scanned image in PDF format. To Computer (Email): Starts the email client on your computer, and then automatically attaches it to an email. 4. Select the computer to which you want to save the scanned images. Note: You can change to frequently-used scan settings such as the document type, folder to save, or save format by using Epson Event Manager.



[You're reading an excerpt. Click here to read official EPSON EXPRESSION XP-335 user guide](http://yourpdfguides.com/dref/5833299)
<http://yourpdfguides.com/dref/5833299>