



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for FRIGIDAIRE FFEF3015LW. You'll find the answers to all your questions on the FRIGIDAIRE FFEF3015LW in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual FRIGIDAIRE FFEF3015LW
User guide FRIGIDAIRE FFEF3015LW
Operating instructions FRIGIDAIRE FFEF3015LW
Instructions for use FRIGIDAIRE FFEF3015LW
Instruction manual FRIGIDAIRE FFEF3015LW



[You're reading an excerpt. Click here to read official FRIGIDAIRE FFEF3015LW user guide](http://yourpdfguides.com/dref/3258583)
<http://yourpdfguides.com/dref/3258583>

Manual abstract:

.....
.....
.....
.....
.....
.....
6 Before Setting Oven Controls

.....
.....
.....
.....
.....
.....
..... 7-8 Before Setting Surface Controls ...

.....
.....
.....
.....
.....
.....
8-9 Setting Surface Controls (Coil cooktop)

.....
.....
.....
.....
.....
.....
..... 10 Oven Control Functions (200) .

.....
.....
.....
.....
.....
.....
.. 11 Setting Oven Controls ...

.....
.....
.....
.....
.....
.....
. @22-23 Major Appliance Warranty

.....
.....
.....
.....
.....
.....
... @2 Important Safety Instructions ..

.....
.....
.....
.....
.....
.....
. @6 Before Setting Oven Controls

.....
.....
.....
.....
.....
.....
.. 7-8 Removing, replacing & arranging oven racks ...

.....
.....
.....
.....
.....
.....
... 7 Before Setting Surface Controls

.....
.....
.....
.....
.....
.....
8-9 Cookware material types

.....
.....
.....
.....
.....
.....
.... 9 Home Canning .

.....
.....
.....
.....
.....
.....

.....
.. 9 Setting Surface Controls ...

.....
.....

.....
.....
.....

. 10 Operating surface elements

.....
.....
.....

..... 10 Oven Control Functions .

.....
.....
.....
.....

.....
11 Setting Oven Controls

.....
.....

.....
.....

... 11-15 Setting the clock ..

.....
.....
.....
.....
.....

.....
.. 11 Changing oven temperature display (F° or C°) ...

.....
.....

.... 11 Setting the minute timer

.....
.....
.....
.....

..... @@@@ @14 Adjusting the oven temperature ...

.....
.....
.....

..... 15 Setting oven lockout feature .

.....
.....
.....

.....
.....

. @15 Self-Cleaning

.....
.....
.....
.....
.....

..... 16-17 Care & Cleaning ..

.....

.....
.....
.....
.....
.....
..... 18-21 Cleaning recommendation table

.....
.....
.....
..... 18 Surface elements and drip bowls ...

.....
.....
.....
..... 19 Cautions for aluminum use ...

.....
.....
.....
.....
..... 20 Replacing the oven light

.....
.....
.....
.....
..... 20 Removing & replacing oven door .

.....
.....
.....
.....
.....
..... 21 Before You Call Solutions to common problems

.....
.....
..... 22-23 Appliance Warranty .

.....
.....
.....
.....
.....

..... 24 Thank you for choosing Frigidaire. This Use & Care Guide is part of our commitment to customer satisfaction and product quality throughout the service life of your new appliance. We view your purchase as the beginning of a relationship. To ensure our ability to continue serving you, please use this page to record important product information. Need help?? Visit the Frigidaire web site at www.frigidaire.com

Before you call for service, there are a few things you can do to help us serve you better. Read this Use & Care manual. It contains instructions to help you use and maintain your range properly. If you received a damaged range .

.. immediately contact the dealer (or builder) that sold you the range. Save time and money. Check the section titled "Before you call".

This section helps step you through some common problems that might occur. If you do need service, help is only a phone call away. Call Frigidaire Customer Services at 1-800-944-9044. Product Registration Registering your product with Frigidaire enhances our ability to serve you. You can register online at www.frigidaire.com or by dropping your Product Registration Card in the mail. Serial plate location Serial plate location: open storage drawer (some models) or remove lower front panel (some models). Record model & serial numbers here Purchase date Model number Serial number 2 ©2009

Electrolux Home Products, Inc. All rights reserved.

Printed in the USA **IMPORTANT SAFETY INSTRUCTIONS** Read all instructions before using this appliance. Do not attempt to install or operate your appliance until you have read the safety precautions in this manual. Safety items throughout this manual are labeled with a **WARNING** or **CAUTION** statement based on the risk type. Ask your dealer to recommend a qualified technician and an authorized repair service. Know how to disconnect the power to the range at the circuit breaker or fuse box in case of an emergency. Definitions This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death. **WARNING** · All ranges can tip. · Injury to persons could result.

· Install anti-tip device packed with range. · See Installation Instructions. To reduce the risk of tipping, the range must be secured by properly installed anti-

tip bracket provided with the range. To check if the bracket is installed properly, visually check that rear leveling leg is inserted into and fully secured by the anti-tip bracket by removing lower front panel or storage drawer from the range. For models equipped with a warmer drawer or lower oven, grasp the top rear edge of the range and carefully attempt to tilt it forward.

Refer to the installation instructions for proper anti-tip bracket installation. · Never modify or alter the construction of a range by removing the leveling legs, panels, wire covers, anti-tip brackets/screws, or any other part of the range. · Remove the oven door from any unused range if it is to be stored or discarded. **WARNING WARNING** indicates a potentially hazardous situation which, if not avoided, may result in death or serious injury. **CAUTION CAUTION** indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

IMPORTANT IMPORTANT indicates installation, operation, maintenance or valuable information that is not hazard related. **Important Safety Instructions** · Remove all tape and packaging before using the range. Destroy the carton and plastic bags after unpacking the range. Never allow children to play with packaging material. · Proper installation--Be sure your appliance is properly installed and grounded by a qualified technician in accordance with the National Electrical Code ANSI/NFPA No. 70 latest edition and local electrical code requirements. Install only per installation instructions provided in the literature package for this range. · User servicing--Do not repair or replace any part of the appliance unless specifically recommended in the manuals. All other servicing should be done only by a qualified technician. This may reduce the risk of personal injury and damage to the range.

WARNING Stepping, leaning or sitting on the door or drawers of a range can result in serious injuries and also cause damage to the appliance. **DO NOT** allow children to climb or play around the range. The weight of a child on an open oven door may cause the range to tip, resulting in serious burns or other injury. Never use your appliance for warming or heating the room. Do not use the oven, warmer drawer or lower oven (if equipped) for storage. Save these instructions for future reference. **3 IMPORTANT SAFETY INSTRUCTIONS WARNING** · Storage in or on appliance--flammable materials should not be stored in an oven, warmer drawer, near surface units or in the storage drawer. This includes paper, plastic and cloth items, such as cookbooks, plasticware and towels, as well as flammable liquids. Do not store explosives, such as aerosol cans, on or near the range. · **DO NOT LEAVE CHILDREN ALONE** --children should not be left alone or unattended in the area where appliance is in use.

They should never be allowed to sit or stand on any part of the appliance, including the storage drawer, lower broiler drawer, warmer drawer or lower double oven. · Do not use water or flour on grease fires-- smother the fire with a pan lid, or use baking soda, a dry chemical or foam-type extinguisher. · When heating fat or grease, watch it closely. Fat or grease may catch fire if allowed to become too hot. · Use dry potholders - moist or damp potholders on hot surfaces may result in burns from steam.

Do not let potholders touch hot heating elements. Do not use a towel or other bulky cloth instead of a potholder. · Do not heat unopened food containers - buildup of pressure may cause container to burst and result in injury.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FFEF3015LW user guide](http://yourpdfguides.com/dref/3258583)
<http://yourpdfguides.com/dref/3258583>

CAUTION · Do not store items of interest to children in the cabinets above a range or on the backguard of the range. Children climbing on the range to reach items could be seriously injured.

· Do not touch surface heating units or surface cooking elements, areas near these units or elements, or interior surface of the oven. Both surface heating and oven heating elements may be hot even though they are dark in color. Areas near surface cooking units may become hot enough to cause burns. During and after use, do not touch, or let clothing or other flammable materials touch these areas until they have had sufficient time to cool. Among these areas are the cook top, surfaces facing the cook top, the oven vent openings and surfaces near these openings, oven door and oven door window. · Wear proper apparel--loose-fitting or hanging garments should never be worn while using the appliance. Do not let clothing or other flammable materials contact hot surfaces. **IMPORTANT INSTRUCTIONS FOR USING YOUR OVEN** · Use care when opening oven door, lower oven door or warmer drawer (if equipped)--Stand to the side of the range when opening the door of a hot oven. Let hot air or steam escape before you remove or replace food in the oven. · Keep oven vent ducts unobstructed.

The oven vent is located under the left rear surface element if your model is equipped with coil elements. The oven vent is located below the backguard for models equipped with ceramic-glass cook tops. Touching the surfaces in this area when the oven is operating may cause severe burns. Also, do not place plastic or heat-sensitive items on or near the oven vent. These items could melt or ignite. · Placement of interior oven racks. Always place oven racks in desired location while oven is cool. If rack must be moved while oven is hot use extreme caution. Use potholders and grasp the rack with both hands to reposition. Do not let potholders contact the hot heating elements in the oven.

Remove all utensils from the rack before moving. · Do not use the broiler pan without its insert. The broiler pan and its insert allow dripping fat to drain and be kept away from the high heat of the broiler. Do not cover the broiler insert with aluminum foil. Exposed fat and grease could ignite. · Protective liners--Do not use aluminum foil to line the oven bottom. Only use aluminum foil as recommended in this manual. Improper installation of these liners may result in risk of electric shock, or fire. **IMPORTANT** Do not attempt to operate the range during a power failure. If the power fails, always turn off the range.

If the range is not turned off and the power resumes, the range will begin to operate again. Once the power resumes, reset the clock and oven function. **4 IMPORTANT SAFETY INSTRUCTIONS SELF-CLEANING OVENS** · Clean in the self-cleaning cycle only the parts listed in this Use & Care Manual. Before self-cleaning the oven, remove the broiler pan and any utensils or foods from the oven. · Do Not Use Oven Cleaners--No commercial oven cleaner or oven liner protective coating of any kind should be used in or around any part of the oven. · Do Not Clean Door Gasket--The door gasket is essential for a good seal. Care should be taken not to rub, damage or move the gasket. · The health of some birds is extremely sensitive to the fumes given off during the self-cleaning cycle of any range. Move birds to another well-ventilated room. **IMPORTANT INSTRUCTIONS FOR USING YOUR COOKTOP** · Know which knob controls each surface heating unit.

Place a pan of food on the unit before turning it on, and turn the unit off before removing the pan. · Use proper pan size--This appliance is equipped with (included). 22 Be sure to visit us online at www.frigidaire.com for a complete line of accessories. 20 21 10 9 17 12 11 13 14 15 16 24 21 19 21 20 23 18 19 21 6 **BEFORE SETTING OVEN CONTROLS** Oven vent location The oven vent is located under the left rear surface element (See Fig. 1). When the oven is on, warm air passes through the vent. This venting is necessary for proper air circulation in the oven and good baking results. Do not block the oven vent. oven vent located under left rear element Recommended rack positions by food type Food type Broiling meats Cookies, cakes, pies, biscuits & muffins Refrigerators for home canning procedures. · Use only quality flat bottom canners when home canning. Use a straight-edge to check canner bottom (see "Cookware material types" in the Before setting surface controls section). · Use only a completely flat bottom canner with no ridges that radiate from the bottom center when home canning using a ceramic cooktop. · Make sure the diameter of the canner does not exceed 1 inch beyond the surface element markings or burner.

It is recommended to use smaller diameter canners on electric coil and ceramic glass cooktops. · Start with hot tap water to bring water to boil more quickly. Use the highest heat setting when first bringing the water to a boil. Once boiling is achieved, reduce heat to lowest possible setting to maintain that boil. Element on indicator lights Your range is equipped with one or more element on indicator lights located on the control panel just above the surface control knobs (See Fig.

1). The element on indicator light will glow when a surface element is turned ON. A quick glance at this indicator light after cooking is an easy check to be sure ALL surface controls are turned OFF. element on indicator light **IMPORTANT NEVER** place or straddle a cooking utensil over 2 different surface cooking elements at the same time. This can cause uneven heating results. This can also cause the ceramic cooktop to fracture (for Ceramic cooktop models only). Fig. 1 9 **SETTING SURFACE CONTROLS** Operating surface elements **CAUTION** · Surface elements may appear to have cooled after they have been turned off. The element surface may still be hot and burns may occur if the element or the area surrounding the element is touched before it has cooled sufficiently. · Do not place flammable items such as plastic salt and pepper shakers, spoon holders or plastic wrappings on top of the range when it is in use.

These items could melt or ignite. Potholders, towels or wooden spoons could catch fire if placed too close to the surface elements. · Protective liners--Do not use aluminum foil to line surface drip bowls, or reflector pans. Improper installation of these liners may result in risk of electric shock, or fire. Only use aluminum foil as recommended in this manual. To operate surface elements: 1. Place correctly sized cooking utensil on surface element. 2. Push in and turn the surface control knob in either direction to the desired setting. Start most surface cooking on a higher setting and then turn to a lower setting to finish. The surface control knobs do not have to be set exactly on a particular spot.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FFEF3015LW user guide](http://yourpdfguides.com/dref/3258583)
<http://yourpdfguides.com/dref/3258583>

Use the graphics provided as a guide and adjust the control knob as needed (Fig. 1). Each surface element provides a constant amount of heat at each setting. For more information see the Suggested surface element settings table (Fig.

2). 3. When cooking is complete, turn the surface element OFF before removing the cookware. Fig. 1 Suggested surface element settings The suggested settings table provided below are based when cooking with medium-weight aluminum pans with lids.

Settings may vary when using other types of pans. Suggested surface element settings table Settings High (HI - 9) Type of cooking Start most foods, bring water to a boil, pan broiling Continue a rapid boil, fry, deep fat fry Maintain a slow boil, thicken sauces and gravies or steam vegetables Keep foods cooking, poach, stew Keep warm, melt, simmer Fig. 2 Medium high (7 - 8) Medium (5 - 6) Medium Low (2 - 4) Low (LO - 1) NOTES · The element on indicator light(s) will glow when one or more surface elements are turned ON. A quick glance at this indicator light when finished surface cooking is an easy check to be sure all surface controls are turned OFF. · The size and type of utensil used, and the amount and type of food being cooked will influence the surface setting needed for best cooking results. IMPORTANT Do not allow aluminum foil, or ANY material that can melt to make contact with the surface element. 10 OVEN CONTROL FUNCTIONS READ THE INSTRUCTIONS CAREFULLY BEFORE USING THE OVEN. For satisfactory use of your oven, become familiar with the various pad features and functions of the oven as described below. Feature indicator lights-- These indicator lights show which feature is active. Broil pad-- Use to select the variable broil feature.

Up and down arrow pads-- Use to adjust the oven temperature, clean time and when adjusting the clock or minute timer. Also used with many feature or function pads to make adjustments. Bake pad--Use to select the bake feature. Clock pad-- Use to set the time of day. Timer on-off pad-- Use to set or cancel the minute timer. The minute timer does not start or stop cooking. Timer on-off pad is used to set the continuous bake function. Clean pad-- Use to set a Self-Clean cycle. Oven, preheat & door locked lights -- The "oven" light will glow each time the oven turns on to maintain the set oven temperature. The "preheat" light will glow when the oven is first set to operate, or if the desired temperature is reset higher than the actual oven temperature.

The "door locked" light will flash when the oven door locks and unlocks, the oven door lockout is active or when the self-clean cycle feature is active. Clear off pad-- Use to clear any feature previously entered except the time of day and minute timer. Press clear off to stop cooking. Also use clear off to activate oven lockout feature. SETTING OVEN CONTROLS Setting the clock When the appliance is first plugged in or when the power supply to the appliance has been interrupted, the display will flash "12:00".

It is recommended to always set the clock for the correct time of day before using the appliance. To set the clock: 1. Press clock once (do not hold key pad down). 2. Within 5 seconds, press and hold the or until Changing temperature display (°F or °C) The electronic oven control is set to display °F (Fahrenheit) when shipped from the factory.

The display may be changed to show either Fahrenheit or Celsius oven temperatures. NOTE The temperature display feature cannot be changed when the oven is set for cooking or clean is active. To change the temperature to display °C (Celsius) or from °C to °F: 1. Press broil. "-- --" appears in the display. 2. Press and hold the until "HI" appears in the display. 3. Press and hold broil until °F or °C appears in the display. 4.

Press the or to change °F to °C or °C to °F. 5. Press any control pad to return to normal operating mode. the correct time of day appears in the display. NOTE The clock cannot be changed when the oven is set for cooking or clean is active. 11 SETTING OVEN CONTROLS Setting the minute timer 1. Press timer on-off. 2. Press the to increase the time in one minute to increase the Changing between continuous bake setting or 12-Hour Energy Saving feature The oven control has a built-in 12-Hour Energy Saving feature that will shut off the oven if the oven is left on for more than 12 hours. The oven control can be programmed to override this feature for continuous baking.

Changing to continuous bake setting: 1. Press and hold timer on-off down for 6 seconds until a tone sounds. " -- -- hr" will appear in display for continuous cooking. The current time of day will return to the display. 2.

To cancel the continuous bake setting, press timer on-off and hold for 6 seconds until a tone sounds. "12hr" will appear in display indicating that the control has returned to the 12-Hour Energy Saving feature. increments. Press and hold the time in 10 minute increments. The timer can be set for any amount of time from 1 minute to 11 hours and 59 minutes.

Note: If the pad is pressed first, the timer will advance to 11 hours and 59 minutes. 3. When the set time has run out, the timer will beep 3 times and will continue to beep 3 times every 60 seconds until timer on-off is pressed. To change the timer while it is in use While the timer is active and shows in the display, press and hold the remaining. To cancel the minute timer before the set time has run out Press timer on-off once . or to increase or decrease the time IMPORTANT This feature does not change how the cooktop controls operate. NOTES · The indicator light located above the timer on-off pad will glow while the minute timer is active. · The minute timer will display hours and minutes until 1 hour remains on the timer. @@@@· The minute timer will not start or stop the cooking process. @@@@To set bake 1.

Press bake. "-- -- --" appears in the display. 2. Within 5 seconds, press the the or or . @@@3. @@@@To change the oven temperature after bake has started 1. Press bake. Visually check the bake temperature and that it needs to be changed. 2. @@@@Dark pans are recommended for pies.

@@@Position the rack as suggested in the broil settings table (See Figs. 1 & 3). To set Broil 1. Arrange the oven rack while oven is still cool. 2.

Press broil. " -- -- "will appear in display. 3. @@2 setting level appears in the display. Press the broil or the Fig.

1 for LO broil. Most foods may be broiled 4. 5. 6. 7. 8. 9. at the HI broil setting. @@For optimum results, preheat oven for 5 minutes before adding food. @@Place the broiler pan and insert on the oven rack (See Figs.

1 & 2). Open the oven door to the broil stop position when broiling. Broil on one side until food is browned. Turn and broil food on other side. @@If the fire continues, use a fire extinguisher.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FFEF3015LW user guide](http://yourpdfguides.com/dref/3258583)
<http://yourpdfguides.com/dref/3258583>

DO NOT put water or flour on the fire. DO NOT use the pan without the insert. To adjust oven temperature: 1. Press bake. 2. Within 2 seconds, press and hold bake until numeric digit(s) appear. Release bake keypad. Adjust until the desired amount of offset appears in the display. 5.

When you have made the desired adjustment, press clear off to go back to the time of day display. Setting oven lockout The control can be programmed to lock the oven door and lockout the oven control pads. To set the oven lockout feature 1. Press clear off and hold for 3 seconds. "Loc" will appear in display, the "Door Locked" indicator light will flash and the motor driven door lock will begin to close automatically.

Allow about 15 seconds for the oven door to lock. Once the oven door is locked, the current time of day will appear in the display. 2. To cancel the Oven Lockout feature, press clear off and hold for 3 seconds. The control will unlock the oven door and resume normal operation. NOTES DO NOT open the oven door while the indicator light is flashing. Allow about 15 seconds for the oven door to lock. Once the oven door is locked, the current time of day will appear in the display. If any control pad is pressed with the oven lockout feature active, "Loc" will appear in the display until the control pad is released. Operating oven light (some models) The interior oven light will automatically turn ON when the oven door is opened.

Press the oven light switch located on the upper left control panel to turn the interior oven light ON and OFF whenever the oven door is closed. The interior oven light is located at the upper left rear wall of the oven interior and is covered with a glass shield held by a wire holder. The glass shield must be in place whenever the oven is in use. To change the interior oven light, see "Changing the oven light" in the Care & Cleaning section. oven light switch NOTES Oven temperature adjustments made will not affect the broil or self-cleaning feature temperatures. If the display is set for Celsius, adjustments made will be in 1°C increments each press of the or keys. DO NOT USE oven thermometers such as those found in grocery stores to check the temperature settings inside your oven. These oven thermometers may vary as much as 20 to 40 degrees from actual temperatures. 15 SELF-CLEANING Self-Cleaning A self-cleaning oven cleans itself with high temperatures (well above normal cooking temperatures) which eliminate soils completely or reduces them to a fine powdered ash you can wipe away with a damp cloth. CAUTION During the self-cleaning cycle, the outside of the range can become very hot to the touch.

DO NOT leave small children unattended near the appliance. The health of some birds is extremely sensitive to the fumes given off during the self-cleaning cycle of any range. Move birds to another well-ventilated room. DO NOT force the oven door open. This can damage the automatic door locking system. Use caution when opening the door after the self-cleaning cycle is complete. The oven may still be VERY HOT. IMPORTANT Adhere to the following self-clean precautions: · DO NOT use oven cleaners or oven protective coatings in or around any part of the oven interior. DO NOT clean the oven door gasket (See Fig. 1).

The woven material of the oven door gasket is essential for a good seal. Care should be taken not to rub, damage or remove the gasket. DO NOT use any cleaning materials on the oven door gasket. Doing so could cause damage. Remove the broiler pan and insert, all utensils and ANY ALUMINUM FOIL. These items cannot withstand high cleaning temperatures and will melt. Completely remove ALL OVEN RACKS and ANY ACCESSORIES. If the oven racks are not removed they will lose their special coating properties and no longer slide in and out of the oven cavity easily. Remove any excessive spillovers. Any spills on the oven bottom should be wiped-up and removed before starting the self-cleaning cycle.

To clean, use hot, soapy water and a cloth. Large spillovers can cause heavy smoke or fire when subjected to high temperatures. These areas heat sufficiently to burn soil on. Clean with soap and water. These areas are shown in white (See Fig. 1). Fig. Remove the bottom oven rack before raising the element. Press clear off. 2.

DO NOT force the oven door open. This can damage the automatic door locking system. The oven may still be VERY HOT. Setting a self-clean cycle 1.

Press clean. "---" appears in the display. 2. Press the or pad once. You will need to add about 1 hour to the time displayed before you can use the range for cooking.

When the oven is cool, wipe away any residue or powdered ash with a damp cloth or paper towel. the display indicating that a 3 hour self-clean time is set. To change to a 2 hour self-clean time press once (2:00 appears in the display). 3. "CLn" will appear in the display during the self-clean cycle and the "LOCK" light will glow until the selfcleaning cycle is complete or cancelled and the oven temperature has cooled. NOTE As soon as the controls are set, the motor driven lock will begin to close automatically and the "LOCK" indicator light will flash. DO NOT open the oven door while the light is flashing (allow about 15 seconds for the oven door to lock). When the self-clean cycle has completed: 1. The time of day will appear in the display window and the "Clean" and "LOCK" light will continue to glow. 2.

Once the oven has cooled down for about 1 HOUR and the "LOCK" light has gone out, the oven door can be opened. 17 CARE & CLEANING Cleaning recommendation table Surface type · · · Control knobs Painted body parts Painted decorative trim Aluminum, plastic or vinyl trim pieces Recommendation Use hot, soapy water and a cloth. Dry with a clean cloth. For general cleaning, use hot, soapy water and a cloth. For more difficult soils and built-up grease, apply a liquid detergent directly onto the soil. Leave on soil for 30 to 60 minutes. Rinse with a damp cloth and dry. Do not use abrasive cleaners on any of these materials; they can scratch. To remove control knobs, turn to the OFF position; grasp firmly and pull straight off the shaft. To replace knobs after cleaning, line up the flat sides of both the knob and the shaft; then push the knob into place.

Before cleaning the control panel, turn all controls OFF and if needed remove any knobs from the panel. Clean using hot, soapy water and a dishcloth. Be sure to squeeze excess water from the dishcloth before wiping the control panel; especially when wiping around the controls area. Excess water in or around the controls may cause damage to the appliance. When rinsing, use clean water and a dishcloth and be sure to squeeze excess water from dishcloth before wiping the control panel.

Clean heavier soils with hot, soapy water and a dishcloth.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FFEF3015LW user guide](http://yourpdfguides.com/dref/3258583)
<http://yourpdfguides.com/dref/3258583>

Rinse with clean water and a cloth. Do not use cleaners with high concentrations of chlorides or chlorine. Do not use harsh scrubbing cleaners. Only use kitchen cleaners that are especially made for cleaning stainless steel.

Always be sure to rinse the cleaners off from the surface as bluish stains may occur during heating that cannot be removed. Gentle scouring with a soapy non-abrasive scouring pad will remove most spots. Rinse with a 1:1 solution of clear water and ammonia. If necessary, cover difficult spots with an ammonia-soaked paper towel for 30 to 40 minutes. Rinse with clean water and a damp cloth, and then scrub with a soap-filled non-abrasive scouring pad. Rinse and wipe dry with a clean cloth. Remove all cleaners or the porcelain may become damaged during future heating. Oven racks must be removed from oven cavity. Clean by using a mild, abrasive cleaner following manufacturer's instructions. Rinse with clean water and dry.

Use soap & water to thoroughly clean the top, sides and front of the oven door. Rinse well. You may use a glass cleaner on the outside glass of the oven door. Do not immerse the door in water. Do not spray or allow water or the glass cleaner to enter the door vents. Do not use oven cleaners, cleaning powders or any harsh abrasive cleaning materials on the outside of the oven door. Do not clean the oven door gasket. On self-cleaning models the oven door gasket is made of a woven material which is essential for a good seal. Care should be taken not to rub, damage or remove this gasket. · Control panel · Decorative trim (some models) · Stainless steel (some models) · Porcelain enamel broiler pan and broiler pan insert (if equipped) · Door liner & body parts · Oven racks · Oven door · Surface elements and drip bowls Do not use spray oven cleaners on the cooktop.

See "Surface elements and drip bowls" in the Care & Cleaning section. 18 CARE & CLEANING Surface elements and drip bowls Cleaning drip bowls Wash in hot, soapy water or in the dishwasher. Rinse and dry while still warm. Hard to remove, burned on soil can be removed by soaking the drip bowls for about 20 minutes in a lightly diluted liquid cleanser or a solution of ammonia and water (1/2 cup ammonia to 1 gallon of water). A nylon scrubber may be used after soaking.

DO NOT use abrasive cleaners or steel wool, they will scratch the surface. Always rinse with clean water and polish dry with a soft cloth. To replace drip bowls and surface elements 1. Slide the terminal end on the element through the opening in the drip bowl (See Fig. 1). 2. Align the element support to rest on the rim inside the drip bowl. If your drip bowl is equipped with a hold down clip, align the element support opposite the terminal end with the slot in the hold down clip, and snap into place. 3. After the element is positioned in the drip bowl, line up the terminal end with the terminal plug as shown. 4. Hold the surface element and drip bowl together as level as possible and firmly push the terminal end into the terminal plug. Make sure element terminal is seated properly into terminal plug. Make sure the surface element is level to reduce the hazard of pans sliding off the element. CAUTION · Make sure drip bowls are in place - Absence of these bowls during cooking may subject wiring or components underneath to damage.

· Never immerse a surface element in water. · Be sure the range is cool before removing surface elements or drip bowls. Be careful not to bend terminal ends when replacing surface elements after cleaning. · Protective liners--Do not use aluminum foil to line surface drip bowls, or reflector pans. Only use aluminum foil as recommended in this manual. Improper installation of these liners may result in risk of electric shock, or fire. Surface elements may be unplugged and removed to make cleaning the drip pans easier. The surface elements clean themselves when they are turned on. Food spilled on a hot element will burn off.

Food spilled on a COOL element may be cleaned with a damp cloth--any remaining soil will burn off the next time the element is used.

To remove the surface elements and drip bowls 1. Lift the edge of the drip bowl across from the terminal end. Lift the surface element and drip bowl together just enough to clear the cooktop. 2. While holding the drip bowl and surface element, gently pull the terminal end out from terminal plug.

DO NOT remove hold down clip (if equipped) from the drip bowl. CAUTION · When lowering the lift-up range cooktop, grasp the sides with finger-tips only. Be careful not to pinch fingers. DO NOT drop or bend the range cooktop when raising or lowering. This could damage the cooktop surface.

Hold down clip (if equipped) Element support Allow element support to rest on drip pan inside rim. Terminal end Fig. 2 Terminal plug Fig. 1 To raise the cooktop for cleaning 1. Grasp the sides and lift from the front (See Fig. 2). Lift-up rods will support the top in a raised position. Only lift the top far enough to allow the support rods to snap into place. 2. Clean underneath using a clean cloth and hot, soapy water 3.

To lower the top, gently push back on each rod to release the notched support. Hold the range top and slide the lift rods down into the range frame. 19 CARE & CLEANING Caution for aluminum use on the cooktop · Aluminum Foil - Use of aluminum foil on a hot cooktop can damage the cooktop. Do not use thin aluminum cooking utensils or allow aluminum foil to touch the surface elements under ANY circumstances. · Aluminum utensils - The melting point of aluminum is much lower than that of other metals. Care must be taken when aluminum pots or pans are used on the cooktop. If aluminum pans are allowed to boil dry when using the cooktop, the utensil may be damaged or destroyed. To replace the interior oven light bulb 1. Turn electrical power off at the main source or unplug the range. 2.

Open oven door for access to interior oven light. Once located, press wire holder to one side to release the glass shield (See Fig.1). 3. Replace bulb with a new 40 watt appliance bulb.

4. Replace glass shield over bulb and snap wire holder into place. 5. Turn power back on again at the main source (or plug the range back in). 6. The clock will then need to be set with the correct time of day. To reset, see "Setting the Clock" in this Use & Care Guide. Replacing the oven light CAUTION Be sure the range is unplugged and all parts are COOL before replacing oven light. Wear a leather-faced glove for protection against possible broken glass.

IMPORTANT The glass shield and wire holder must be in place whenever the oven is in use. This shield helps protect the appliance bulb from high temperatures. The interior oven light bulb is located on the rear wall of the oven and is covered with a glass shield held by a wire holder. Fig.1 20 CARE & CLEANING Removing and replacing the lift-off oven door CAUTION The door is heavy.



[You're reading an excerpt. Click here to read official FRIGIDAIRE](http://yourpdfguides.com/dref/3258583)

[FFEF3015LW user guide](http://yourpdfguides.com/dref/3258583)

<http://yourpdfguides.com/dref/3258583>

For safe, temporary storage, lay the door flat with the inside of the door facing down.

To remove oven door: 1. Open oven door completely (horizontal with floor - See Fig. 1). 2. Pull the door hinge locks on both left and right door hinges down from the oven frame completely towards the oven door (See Fig. 2). A tool such as a small flatblade screwdriver may be required. 3. Firmly grasp both sides of oven door along the door sides (Do not use the oven door handle - See Fig. 3). 4. Close the door to the broil stop position (the oven door will stop into this position just before fully closing). 5. With the oven door in the broil stop position, lift the oven door hinge arms over the roller pins located on each side of the oven frame (See Fig. 4).

To replace oven door: 1. Firmly grasp both sides of oven door along the door sides (Do not use the oven door handle - See Fig. 3). 2. Holding the oven door at the same angle as the removal position, seat the hook of the hinge arm over the roller pins located on each side of the oven door frame (See Fig. 4). 3. The hook of the hinge arms must be fully seated onto the roller pins. 4. Fully open the oven door (horizontal with floor - See Fig. 1). 5. Push the door hinge locks up towards and into the oven frame on both left and right oven door hinges (See Fig. 2) to the locked position. 6. Close the oven door.

Special door care instructions - Most oven doors contain glass that can break. Read the following recommendations: 1. Do not close the oven door until all the oven racks are fully in place. 2. Do not hit the glass with pots, pans, or any other object. 3. Scratching, hitting, jarring or stressing the glass may weaken its structure causing an increased risk of breakage at a later time. Fig. 3 Oven door hinge locations with oven door fully open. Fig. 4

Fig. 2 Fig. 4 21 BEFORE YOU CALL Problem Poor baking results. · Solutions to common problems Solution · Many factors affect baking results. Make sure the proper oven rack position is used.

Center food in the oven and space pans to allow air to circulate. Allow the oven to preheat to the set temperature before placing food in the oven. Try adjusting the recipe's recommended temperature or baking time. If you feel the oven is too hot or cool, see "Adjusting Oven Temperature" section in this Use & Care Guide. · Be sure floor is level, strong & stable enough to adequately support range.

· If floor is sagging or sloping, contact a carpenter to correct the situation. · Poor installation. Place oven rack in center of oven. Place a level on the oven rack. Adjust leveling legs at base of appliance until the rack is level. · Kitchen cabinet alignment may make range appear not level. Be sure cabinets are square & have sufficient room for appliance clearance. Appliance is not level. Cannot move appliance easily. Appliance must be accessible for service.

· Cabinets not square or are built in too tightly. Contact builder or installer to make appliance accessible. · Carpet interferes with appliance. Provide sufficient space so appliance can be lifted over carpet. Surface element too hot or not hot enough. Surface element does not heat. · Incorrect control setting. Be sure the correct control is ON for the element that you are attempting to use. · Lightweight or warped pans used. Use only flat, evenly balanced, medium or heavyweight cookware.

Flat pans heat better than warped pans. Cookware materials and weight of the material affect heating. Heavy & medium-weight pans heat evenly. Because lightweight pans heat unevenly, foods may burn easily. · The time of day is not set.

The time of day must first be set in order to operate the oven. See "Setting the clock" in the Setting Oven Controls section. · Make sure cord/plug is plugged correctly into outlet. · Service wiring is not complete. Contact your dealer, installing agent or authorized service agent.

· Electrical power outage. Check house lights to be sure. Call your local electric company for service. Entire appliance does not operate. Oven portion of appliance does not operate. Oven light does not work. · Be sure the oven controls are set properly for the desired cooking feature. See Setting Oven Controls in this manual or read the instructions "Entire appliance does not operate" in this checklist. · Be sure the light is secure in the socket. Also see "Replacing the oven light" section.

· Oven control not set properly. Follow instructions under Self-Clean. · Self-cleaning cycle was interrupted. Follow steps under "Stopping or interrupting a self-cleaning cycle" under Self-Cleaning. Self-clean cycle does not work. 22 Solutions to common problems · Problem Soil not completely removed after selfcleaning cycle. Solution BEFORE YOU CALL · Failure to clean bottom, front top of oven, frame of oven or door area outside oven seal. These areas are not in the self-cleaning area, but get hot enough to burn on residue. Clean these areas before the self-cleaning cycle is started. Burned-on residue can be cleaned with a stiff nylon brush and water or a nylon scrubber.

Be careful not to damage the oven gasket. · Incorrect setting. Follow broiling instructions in Setting Oven Controls. · Make sure oven door is opened to broil stop position. · Meat too close to the broil element.

Reposition the oven rack to provide proper clearance between the meat & the element. Preheat the broil element for searing. · Meat not properly prepared. Remove excess fat from meat. @@@@ · Grease has built up on oven surfaces.

Regular cleaning is necessary when broiling frequently. @@For example this will happen for pie spillovers or large amounts of grease left on the oven bottom. Wipe up excessive spillovers before starting oven. If flames or excessive smoke are present see "Broiling" in the Setting Oven Controls section. · Oven control has detected a fault or error condition. Press clear off to clear the display & stop beeping. Try the bake or broil feature again. If the F code error repeats, remove power from appliance, wait 5 minutes and then repower appliance and set clock for the time of day. Try the bake or broil feature again. If the fault recurs, record fault and call for service.

· Foods with acids, such as tomatoes, if allowed to stand in/on bowls will cause corrosion. Remove and wash drip bowls as soon as possible after a spill over. · Normal environment. Houses located along sea coasts are exposed to salt air. @@This can cause high enough temperatures to discolor the drip bowls. DO NOT use cookware of this type. Pan sizes should be matched to the size of the element. @@@@2. 3. 4.

5. 6. 7. 8. 9.

10. 11. 12. 13. @@Product that has been transferred from its original owner to another party or removed outside the USA or Canada. Rust on the interior or exterior of the unit. Products purchased "as-is" are not covered by this warranty.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FFEF3015LW user guide](http://yourpdfguides.com/dref/3258583)
<http://yourpdfguides.com/dref/3258583>

Food loss due to any refrigerator or freezer failures. Products used in a commercial setting. Service calls which do not involve malfunction or defects in materials or workmanship, or for appliances not in ordinary household use or used other than in accordance with the provided instructions. Service calls to correct the installation of your appliance or to instruct you how to use your appliance. Expenses for making the appliance accessible for servicing, such as removal of trim, cupboards, shelves, etc., which are not a part of the appliance when it is shipped from the factory. Service calls to repair or replace appliance light bulbs, air filters, water filters, other consumables, or knobs, handles, or other cosmetic parts. Surcharges including, but not limited to, any after hour, weekend, or holiday service calls, tolls, ferry trip charges, or mileage expense for service calls to remote areas, including the state of Alaska.

Damages to the finish of appliance or home incurred during installation, including but not limited to floors, cabinets, walls, etc. Damages caused by: services performed by unauthorized service companies; use of parts other than genuine Electrolux parts or parts obtained from persons other than authorized service companies; or external causes such as abuse, misuse, inadequate power supply, accidents, fires, or acts of God. DISCLAIMER OF IMPLIED WARRANTIES; LIMITATION OF REMEDIES CUSTOMER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPAIR OR REPLACEMENT AS PROVIDED HEREIN. CLAIMS BASED ON IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR OR THE SHORTEST PERIOD ALLOWED BY LAW, BUT NOT LESS THAN ONE YEAR. ELECTROLUX SHALL NOT BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES SUCH AS PROPERTY DAMAGE AND INCIDENTAL EXPENSES RESULTING FROM ANY BREACH OF THIS WRITTEN LIMITED WARRANTY OR ANY IMPLIED WARRANTY. SOME STATES AND PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, OR LIMITATIONS ON THE DURATION OF IMPLIED WARRANTIES, SO THESE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WRITTEN WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE. If You Need Service Keep your receipt, delivery slip, or some other appropriate payment record to establish the warranty period should service be required. If service is performed, it is in your best interest to obtain and keep all receipts.

Service under this warranty must be obtained by contacting Electrolux at the addresses or phone numbers below. This warranty only applies in the USA and Canada. In the USA, your appliance is warranted by Electrolux Major Appliances North America, a division of Electrolux Home Products, Inc. In Canada, your appliance is warranted by Electrolux Canada Corp. Electrolux authorizes no person to change or add to any obligations under this warranty.

Obligations for service and parts under this warranty must be performed by Electrolux or an authorized service company. Product features or specifications as described or illustrated are subject to change without notice. USA 1.800.944.

9044 Electrolux Major Appliances North America P.O. Box 212378 Augusta, GA 30907 Canada 1.800.265.8352 Electrolux Canada Corp. 5855 Terry Fox Way Mississauga, Ontario, Canada L5V 3E4 24 .



[You're reading an excerpt. Click here to read official FRIGIDAIRE FFEF3015LW user guide](http://yourpdfguides.com/dref/3258583)
<http://yourpdfguides.com/dref/3258583>