



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for FRIGIDAIRE FGF328GS. You'll find the answers to all your questions on the FRIGIDAIRE FGF328GS in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual FRIGIDAIRE FGF328GS
User guide FRIGIDAIRE FGF328GS
Operating instructions FRIGIDAIRE FGF328GS
Instructions for use FRIGIDAIRE FGF328GS
Instruction manual FRIGIDAIRE FGF328GS

Use & Care Manual
Gas Range
ES100 Control with Gas Sealed Burners & Broiler Drawer

Visit the Frigidaire Web Site at: <http://www.frigidaire.com>

Welcome.....	2	
Important Safety Instructions.....	2-4	
Setting Surface Controls.....	5	
Before Setting Oven Controls.....	6	
Oven Control Functions.....	6-7	
Setting Oven Controls.....	8-9	
Adjusting Your Oven Temperature (some models).....	10	
General Care & Cleaning.....	11-13	
Before You Call Solutions to Common Problems.....	14	
Warranty.....	Back Page	

Questions or for Service Call:
1-800-944-9044 (U.S.)
1-800-668-4606 (Canada)

READ AND SAVE THESE INSTRUCTIONS p/n 316417114 Rev A (0605)



[You're reading an excerpt. Click here to read official FRIGIDAIRE FGF328GS user guide](http://yourpdfguides.com/dref/3258663)
<http://yourpdfguides.com/dref/3258663>

Manual abstract:

..... @@10 General Care & Cleaning
.... @@14 Warranty .
.....
.....

..... Back Page Questions or for Service Call: 1-800-944-9044 (U.

S.) 1-800-668-4606 (Canada) READ AND SAVE THESE INSTRUCTIONS p/n 316417114 Rev A (0605) Welcome & Congratulations Congratulations on your purchase of a new range! At Electrolux Home Products, we are very proud of our product and are completely committed to providing you with the best service possible. Your satisfaction is our number one priority. We know you'll enjoy your new range and Thank You for choosing our product. We hope you consider us for future purchases.

PLEASE CAREFULLY READ AND SAVE THESE INSTRUCTIONS This Use & Care Manual provides specific operating instructions for your model. Use your appliance only as instructed in this manual. @@@@ Your range may not have all the described features. The graphics shown are representative. The graphics on your range may not look exactly like those shown.

Product Registration Be sure to register your product. The self-addressed PRODUCT REGISTRATION CARD should be filled in completely, signed and returned to Electrolux Home Products. Important Safety Instructions Grounding Instructions (electric ignition models only) Avoid fire hazard or electrical shock. Do not use an adapter plug, an extension cord, or remove grounding prong from electrical power cord. Failure to follow this warning can cause serious injury, fire or death. This appliance is equipped with a 3-prong grounding plug for your protection against shock hazard and should be plugged directly into a properly grounded receptacle. DO NOT cut or REMOVE the grounding prong from this plug. For personal safety this appliance must be properly grounded. For maximum safety, the power cord must be plugged into an electrical outlet that is correctly polarized and properly grounded. If a 2-prong wall receptacle is the only available outlet, it is the personal responsibility of the consumer to have it replaced with a properly grounded 3-prong wall receptacle installed by a qualified electrician.

© 2006 Electrolux Home Products, Inc. All rights reserved. See the INSTALLATION INSTRUCTIONS packaged with this appliance for complete installation & grounding instructions. 2 Important Safety Instructions Read all instructions before using this appliance. Save these instructions for future reference. This manual contains important safety symbols and instructions. Please pay attention to these symbols and follow all instructions given. This symbol will help alert you to situations that may cause serious bodily harm, death or property damage. This symbol will help alert you to situations that may cause bodily injury or property damage. If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury or death.

FOR YOUR SAFETY: -- Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance. -- WHAT TO DO IF YOU SMELL GAS: · Do not try to light any appliance. · Do not touch any electrical switch; do not use any phone in your building. · Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.

· If you cannot reach your gas supplier, call the fire department. -- Installation and service must be performed by a qualified installer, servicer or the gas supplier. · Remove all tape and packaging before using the range. Destroy the carton and plastic bags after unpacking the range. Never allow children to play with packaging material.

· Proper Installation--Be sure your appliance is properly installed and grounded by a qualified technician in accordance with the National Fuel Gas Code ANSI Z223.- latest edition, or in Canada CAN/CGA B149.1, and CAN/CGA B149.2, and the the National Electrical Code ANSI/NFPA No.70-latest edition, or in Canada CSA Standard C22.1, Canadian Electrical Code, Part 1, and local code requirements. Install only per installation instructions provided in the literature package for this range. Ask your dealer to recommend a qualified technician and an authorized repair service. Know how to disconnect the power to the range at the circuit breaker or fuse box in case of an emergency. · User servicing--Do not repair or replace any part of the appliance unless specifically recommended in the manuals.

All other servicing should be done only by a qualified technician, This may reduce the risk of personal injury and damage to the range. · Never modify or alter the construction of a range by removing leveling legs, panels, wire covers, anti-tip brackets/screws, or any other part of the product. Do not use the oven or warmer drawer (if equipped) for storage. 3 NEVER use this appliance as a space heater to heat or warm the room. Doing so may result in carbon monoxide poisoning. NEVER cover any slots, holes or passages in the oven bottom or cover an entire rack with materials such as aluminum foil. Doing so blocks air flow through the oven and may cause carbon monoxide poisoning. Aluminum foil linings may trap heat, causing a fire hazard. Stepping, leaning or sitting on the doors or drawers of this range can result in serious injuries and also cause damage to the range. Do not allow children to climb or play around the range.

The weight of a child on an open door may cause the range to tip, resulting in serious burns or other injury. Do not store items of interest to children in the cabinets above a range or on the backguard of a range. Children climbing on the range to reach items could be seriously injured. · Storage in or on Appliance--Flammable materials should not be stored in an oven, warmer drawer, near surface burners or in the storage drawer. This includes paper, plastic and cloth items, such as cookbooks, plasticware and towels, as well as flammable liquids.

Do not store explosives, such as aerosol cans, on or near the range. Important Safety Instructions · Do Not Leave Children Alone--Children should not be left alone or unattended in the area where appliance is in use. They should never be allowed to sit or stand on any part of the appliance. · DO NOT TOUCH SURFACE BURNERS, AREAS NEAR THESE BURNERS, OVEN BURNERS OR INTERIOR SURFACES OF THE OVEN. Both surface and oven burners may be hot even though flames are not visible.

Areas near surface burners may become hot enough to cause burns. During and after use, do not touch, or let clothing or other flammable materials touch these areas until they have had sufficient time to cool. Among these areas are the cook top, surfaces facing the cook top, the oven vent openings and surfaces near these openings, oven door and window. · Wear Proper Apparel--Loose-fitting or hanging garments should never be worn while using the appliance. Do not let clothing or other flammable materials contact hot surfaces. · Do Not Use Water or Flour on Grease Fires--Smother the fire with a pan lid, or use baking soda, a dry chemical or foam-type extinguisher.



[You're reading an excerpt. Click here to read official FRIGIDAIRE](http://yourpdfguides.com/dref/3258663)

[FGF328GS user guide](http://yourpdfguides.com/dref/3258663)

<http://yourpdfguides.com/dref/3258663>

· When heating fat or grease, watch it closely. Fat or grease may catch fire if allowed to become too hot. · Use Only Dry Potholders--Moist or damp potholders on hot surfaces may result in burns from steam. Do not let potholders touch hot heating burners.

Do not use a towel or other bulky cloth instead of a potholder. · Do Not Heat Unopened Food Containers--Buildup of pressure may cause container to burst and result in injury. · Remove the oven door from any unused range if it is to be stored or discarded. **IMPORTANT--ELECTRIC IGNITION MODELS ONLY:** Do not attempt to operate the oven during a power failure. If the power fails, always turn off the oven. If the oven is not turned off and the power resumes, the oven will begin to operate again. Once the power resumes, reset the clock and oven function. **IMPORTANT INSTRUCTIONS FOR USING YOUR COOKTOP**

Use Proper Flame Size--Adjust flame size so it does not extend beyond the edge of the utensil. The use of undersized utensils will expose a portion of the burner flame to direct contact and may result in ignition of clothing. Proper relationship of utensil to flame will also improve efficiency.

· Know which knob controls each surface burner. Place a pan of food on the burner before turning it on, and turn the burner off before removing the pan. · Always turn knob to the full LITE position when igniting top burners. Visually check that burner has lit. Then adjust the flame so it does not extend beyond the edge of the utensil.

· Utensil Handles Should Be Turned Inward and Not Extend Over Adjacent Surface Burners--To reduce the risk of burns, ignition of flammable materials, and spillage due to unintentional contact with the utensil, the handle of the utensil should be positioned so that it is turned inward, and does not extend over adjacent surface burners. · Never Leave Surface Burners Unattended at High Heat Settings--Boilovers cause smoking and greasy spillovers that may ignite, or a pan that has boiled dry may melt. · Protective Liners--Do not use aluminum foil to line surface burner pans, or oven bottom, except as suggested in this manual. Improper installation of these liners may result in risk of electric shock, or fire. · Glazed Cooking Utensils--Only certain types of glass, glass/ceramic, ceramic, earthenware, or other glazed utensils are suitable for cooktop service without breaking due to the sudden change in temperature. Check the manufacturer's recommendations for cooktop use. **IMPORTANT INSTRUCTIONS FOR USING YOUR OVEN** · Use Care When Opening Oven Door or Warmer Drawer-- Stand to the side of the range when opening the door of a hot oven. Let hot air or steam escape before you remove or replace food in the oven. · Keep Oven Vent Ducts Unobstructed. The oven vent is located below the backguard. Touching the surfaces in this area when the oven is operating may cause severe burns. Also, do not place plastic or heat-sensitive items on or near the oven vent. These items could melt or ignite. · Placement of Oven Racks. Always place oven racks in desired location while oven is cool.

If rack must be moved while oven is hot use extreme caution. Use potholders and grasp the rack with both hands to reposition. Do not let potholders contact the hot heating elements in the oven. Remove all utensils from the rack before moving. · Do not use the broiler pan without its insert. The broiler pan and its insert allow dripping fat to drain and be kept away from the high heat of the broiler. · Do not cover the broiler insert with aluminum foil. Exposed fat and grease could ignite. · Cold temperatures can damage the electronic control. When using the appliance for the first time, or when the appliance has not been used for an extended period of time, be certain the unit has been in temperatures above 32°F (0°C) for at least 3 hours before turning on the power to the appliance.

IMPORTANT INSTRUCTIONS FOR CLEANING YOUR RANGE · Clean the range regularly to keep all parts free of grease that could catch fire. Pay particular attention to the area underneath each surface element. Do not allow grease to accumulate. Refer to the range manufacturer's instructions for cleaning. · Kitchen cleaners and aerosols--Always follow the manufacturer's recommended directions for use.

Be aware that excess residue from cleaners and aerosols may ignite causing damage and injury. **IMPORTANT SAFETY NOTICE** The California Safe Drinking Water and Toxic Enforcement Act requires the Governor of California to publish a list of substances known to the state to cause cancer, birth defects or othe circulation in the oven and good baking results. **DO NOT BLOCK THE OVEN VENT. Arranging Oven Racks ALWAYS ARRANGE OVEN RACKS WHEN THE OVEN IS COOL (PRIOR TO OPERATING THE OVEN).** Always use oven mitts when using the oven.

Removing & Replacing Oven Racks To remove, pull the rack forward until it stops. Lift up front of rack and slide out. To replace, fit the rack onto the guides on the oven walls. Tilt the front of the rack upward and slide the rack back into place. Arranging Ovenl the process. 5. The control will beep once. The display will then return to the time of day with any temperature display mode change you may have requested. 7 Setting Oven Controls Note: The time of day must first be set in order to operate the oven. To Set or Change the Temperature for Baking The oven can be programmed to bake at any temperature from 170°F to 500°F.

To Set the Controls for Baking: 1. Press . "-- -- °" appears in the display. or . @@@@3. @@@@4. @@Press 2. Press the and make sure the bake temperature is displayed. @@2. 3.

4. Slide broiler drawer out to the stop position. Remove broiler pan & insert (See Fig. 1). Position rack before setting control; while range is cool. @@@@2). @@For medium foods use middle position. @@2 5. Place insert on broiler pan, then place meat on insert. **DO NOT** use the broiler pan without the insert.

DO NOT cover the insert with aluminum foil. The exposed fat could ignite. 6. @@Be sure front of pan is positioned correctly in rack. 7. Slide the broiler drawer all the way into the range. Press on Oven Control. 8. Press and hold the broil or the or Fig. 1 Fig.

@@3). **DO NOT** use the pan without the insert. @@Press the for HI (high) for LO (low) broil. Most foods can be broiled at the HI broil setting. @@9. @@@@10. When broiling is finished, press . 11. When removing broiler pan from broiler drawer always use pot holders. **DO NOT** use the broiler drawer for storage.

Items placed in the broiler drawer will catch fire. Should an oven fire occur, close the oven door and turn off the oven. If the fire continues, use a fire extinguisher. **DO NOT** put water or flour on the fire. @@@@@@@Press & hold the 00.

@@2. @@@@@@@3. @@4. @@This will cancel the temperature adjustment procedure. To start this procedure over again begin with step 1 above OR; 5.

@@6. @@@@@@@For more difficult soils and built-up grease, apply a liquid detergent directly onto the soil.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FGF328GS user guide](http://yourpdfguides.com/dref/3258663)
<http://yourpdfguides.com/dref/3258663>

Leave on soil for 30 to 60 minutes. Rinse with a damp cloth and dry. **DO NOT** use abrasive cleaners on any of these materials; they can scratch. Before cleaning the control panel, turn all controls to OFF and remove the control knobs. To remove, pull each knob straight off the shaft. Clean as instructed above. Squeeze excess water from the cloth before wiping the panel; especially when wiping around the controls. Excess water in or around the controls may cause damage to the appliance.

To replace knobs after cleaning, line up the flat sides of both the knob and the shaft, then push the knob(s) into place. Clean burner grates, broiler pan & insert in the dishwasher and dry upon removal. If soils are not removed, follow the cooktop cleaning instructions below. Gentle scouring with a soapy scouring pad will remove most spots. Rinse with a 1:1 solution of clean water and ammonia. If necessary, cover difficult spots with an ammonia-soaked paper towel for 30 to 40 minutes. Rinse with clean water and a damp cloth, then scrub with a soapfilled scouring pad. Rinse and wipe dry with a clean cloth.

Remove all cleaners or the porcelain may become damaged during future heating. **DO NOT** use spray oven cleaners on the range top.

Remove racks. See "Removing & Replacing Oven Racks" under Before Setting Oven Controls. Use a mild, abrasive cleaner, following the cleaner's recommendations. Rinse with clean water & let dry. After cleaning the racks, rub the sides of the racks with wax paper or a cloth containing a small amount of salad oil (this will make the racks glide easier into the oven rack positions).

Use soap & water to thoroughly clean the top, sides & front of the oven door. Rinse well. You may use a glass cleaner on the outside glass of the oven door.

DO NOT immerse the door in water. **DO NOT** spray or allow water or the glass cleaner to enter the door vents.

DO NOT use oven cleaners, cleaning powders or any harsh abrasive cleaning materials on the outside of the oven door. **DO NOT** clean the oven door gasket.

The oven door gasket is made of a woven material, on Self-Cleaning models, which is essential for a good seal. Care should be taken not to rub, damage or remove this gasket. Painted Control Panels Porcelain Enamel Burner Grates, Cooktop Surface, Below Cooktop, Broiler Pan & Insert, Broiler Drawer, Door Liner & Oven Bottom Oven Racks Oven Door 11 General Care & Cleaning (Cleaning Chart cont'd) Surfaces Stainless Steel (some models) How to Clean

Clean stainless steel with a dishcloth using hot, soapy water. Rinse with clean water & a cloth. Do not use cleaners with high concentrations of chlorides or chlorines. Do not use harsh scrubbing cleaners. Only use kitchen cleaners that are especially made for cleaning stainless steel. Always be sure to rinse the cleaners from the surface as bluish stains may occur during heating that cannot be removed.

Cleaning the Cooktop The cooktop is designed to make cleaning easier. Because the four burners are sealed, cleanups are easy when spillovers are cleaned up immediately. @@@@Refer to the following section for instructions. NOTE: THE COOKTOP IS NOT REMOVABLE. Do not attempt to remove or lift the cooktop. @@Rinse with a clean, damp cloth and wipe dry. @@@@ALWAYS keep the surface burner cap and surface burner head in place whenever a surface burner is in use. Use caution when replacing the burner cap so the electrode is not damaged. This may cause a delayed ignition or prevent the burner from igniting. Any additions, changes or conversions required in order for this appliance to satisfactorily meet the application needs must be made by an authorized Electrolux Distributor or Qualified Agency.

12 General Care & Cleaning Removing & Replacing the Oven Door (all models) The door is heavy. For safe, temporary storage, lay the door flat with the inside of the door facing down. To Remove Oven Door: 1. Open oven door completely (horizontal with floor - See Fig. 1).

2. Remove 2 screws located on the inside of the oven door liner (See A Fig. 2). 3. Insert the 2 screws into the door hinge holes located on the side of the hinge arm, one into each hinge (See B Fig.

2). 4. Close oven door until the door stops, (Do not force the door to close any further). The placement of these screws should keep door open in about a 45 degree position. 5. Grasp oven door firmly on both sides and slide door up and off hinges at the same angle. (See Fig. 3) 6. To clean oven door, follow the instructions provided in the Cleaning Chart at the beginning of the Care & Cleaning section (See Door Liner). To Replace Oven Door: 1.

Be sure the hinge arms remain at the 45 degree angle position. Be sure the screws are still locking the hinge arms from moving. If the screws fall out of the hinge holes, the hinge(s) may snap back against the oven frame and could pinch fingers or chip the porcelain finish on the oven front frame. 2. Hold door at the sides near the top while resting the lower front of door on your knee. Insert the door channels at the bottom of door over the door hinges, (See Fig. 3). 3. Allow the door to slide down into the door hinges evenly at the same 45 degree angle. The hinge arms should be inserted into the bottom corners as far as they can go.

4. Open door completely (horizontal with floor) and remove both screws from holes in door hinges. 5. Reinstall the 2 screws into the door liner (See C Fig. 2). 6. If the door is not in alignment with the oven frame, remove door and repeat the above steps. Fig. 1 Fig. 2 Fig.

3 Changing the Oven Light (some models) On some models, the oven light automatically turns on when the door is opened. Some models have a switch located on the control panel to turn on the light. The oven light is located at the rear of the oven. To 1. 2. 3. 4. replace the oven light: Turn electrical power off at the main source or unplug the range. Replace bulb with a new 40 watt appliance bulb. Turn power back on again at the main source (or plug the range back in).

The clock will then need to be reset. To reset, see "Setting the Clock" and "Setting the Minute Timer" under Setting Oven Controls in this Use & Care Manual. Be sure the range is unplugged and all parts are COOL before replacing oven light. Wear a leather-faced glove for protection against possible broken glass.

13 Before You Call Solutions to Common Problems Before you call for service, review the following list. It may save you time & expense. The list includes common occurrences (shown in bold) that are not the result of defective workmanship or materials in this appliance. The possible corrections to these problems are provided with the problem listed: Range is not level - (1) Poor installation. Place oven rack in center of oven. Place a level on the oven rack. Adjust leveling legs at base of range until the oven rack is level. (2) Be sure floor is level, strong & stable enough to adequately support range. (3) If floor is sagging or sloping, contact a carpenter to correct the situation.



[You're reading an excerpt. Click here to read official FRIGIDAIRE FGF328GS user guide](http://yourpdfguides.com/dref/3258663)
<http://yourpdfguides.com/dref/3258663>

(4) Kitchen cabinet alignment may make range appear not level. Be sure cabinets are square & have sufficient room for range clearance. Cannot move appliance easily. Appliance must be accessible for service - (1) Cabinets not square or are built in too tightly. Contact builder or installer to make appliance accessible. (2) Carpet interferes with range. Provide sufficient space so range can be lifted over carpet.

Surface Burners do not light - (1) Surface Control knob was not completely turned to LITE. Push in & turn the Surface Control knob to LITE until burner ignites and then turn control knob to desired flame size. (2) Burner ports are clogged. With the burner OFF, use a small-gauge wire or needle to clean ports. See "Cleaning the Contoured Well Areas, Burner Caps, Head & Drip Pans" in the General Care & Cleaning section for additional cleaning instructions. (3) Range power cord is disconnected from outlet (electric ignition models only). Be sure power cord is securely plugged into the outlet. (4) Electrical power outage (electric ignition models only). Burners can be lit manually. See section on Setting Surface Controls.

Surface burner flame burns only part way around burner cap - (1) Burner ports are clogged. With the gas burner OFF, clean ports with a small-gauge wire or needle. (2) Moisture is present after cleaning. Lightly fan the flame & allow burner to operate until flame is full. Dry the burners thoroughly following the instructions under "Cleaning the Contoured Well Areas, Burner Caps, Head & Drip Pans" in the General Care & Cleaning section. Surface burner flame is orange - (1) Dust particles in gas main line. Allow the gas burner to operate a few minutes until flame turns blue in color. (2) In coastal areas a slightly orange flame may be unavoidable due to salt in air. Oven does not operate - (1) Be sure the oven controls are set properly for the desired function. See Setting Oven Controls in this Use & Care Manual or read the instructions for "Entire appliance does not operate" listed below.

(2) Be sure the Gas Regulator Valve is in the "ON" position. Refer to the Installation Instructions to for more information. Entire appliance does not operate - (1) The time of day is not set. The time of day must first be set in order to operate the oven. See "To Set the Clock" in the Setting Oven Controls section.

(2) Make sure cord/plug is plugged correctly into outlet. (3) Service wiring is not complete. Contact your dealer, installing agent or authorized service agent. (4) Electrical power outage (electric ignition models only). Check house lights to be sure.

Call your local electric company for service. Surface gas burners can be lit manually. See Setting Surface Controls in this Use & Care Manual. Poor baking results - Many factors affect baking results. Make sure the proper oven rack position is used. Center food in the oven & space pans to allow air to circulate. Allow the oven to preheat to the set temperature before placing food in the oven. Try adjusting the recipe's recommended temperature or baking time. Oven light does not work (some models) - Replace or tighten bulb. See Changing Oven Light section in this Use & Care Manual.

Oven smokes excessively during broiling - (1) Control(s) not set properly. Follow Broil instructions under Setting Oven Controls. (2) Broiler Drawer is open. The Broiler Drawer should be closed while broiling. (3) Meat too close to the broil element. Reposition the broil rack to provide proper clearance between the meat & the element. Preheat the broil element for searing. (4) Meat not properly prepared. Remove excess fat from meat. Cut remaining fatty edges to prevent curling, but do not cut into lean.

(5) Insert on broiler pan wrong side up & grease not draining. Always place grid on the broiler pan with ribs up & slots down to allow grease to drip into pan (some models). (6) Grease has built up on oven surfaces. Regular cleaning is necessary when broiling frequently. Old grease or food spatters cause excessive smoking.

Flames inside oven or smoking from oven vent - Excessive spillovers in oven. @@Wipe up excessive spillovers before starting oven. @@@@Press CLEAR/OFF to clear the display & stop beeping. Try the Bake or Broil function again. @@Try the Bake or Broil function again.

If the fault recurs, record fault number, press CLEAR/OFF & contact an authorized service agent. Oven control beeps and displays any "F" code error (for example F3; some models) - Electronic control has detected a fault condition. Press CLEAR/OFF to clear the display & stop beeping. Reprogram oven. If fault recurs, record fault number. Press CLEAR/OFF & contact your authorized service agent. Poor baking results - Many factors affect baking results. Make sure the proper oven rack position is used. Center food in the oven & space pans to allow air to circulate. Allow the oven to preheat to the set temperature before placing food in the oven.

Try adjusting the recipe's recommended temperature or baking time. @@@@2. 3. 4. 5. 6. 7. 8. 9. @@@@Rust on the interior or exterior of the unit.

Products purchased "as-is" are not covered by this warranty. Food loss due to any refrigerator or freezer failures. Products used in a commercial setting. Service calls which do not involve malfunction or defects in materials or workmanship, or for appliances not in ordinary household use or used other than in accordance with the provided instructions. Service calls to correct the installation of your appliance or to instruct you how to use your appliance.

Expenses for making the appliance accessible for servicing, such as removal of trim, cupboards, shelves, etc., which are not a part of the appliance when it is shipped from the factory. 10. Service calls to repair or replace appliance light bulbs, air filters, water filters, other consumables, or knobs, handles, or other cosmetic parts. 11.

Surcharges including, but not limited to, any after hour, weekend, or holiday service calls, tolls, ferry trip charges, or mileage expense for service calls to remote areas, including the state of Alaska. 12. Damages to the finish of appliance or home incurred during installation, including but not limited to floors, cabinets, walls, etc. 13. Damages caused by: services performed by unauthorized service companies; use of parts other than genuine Electrolux parts or parts obtained from persons other than authorized service companies; or external causes such as abuse, misuse, inadequate power supply, accidents, fires, or acts of God. **DISCLAIMER OF IMPLIED WARRANTIES; LIMITATION OF REMEDIES CUSTOMER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPAIR OR REPLACEMENT AS PROVIDED HEREIN. CLAIMS BASED ON IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR OR THE SHORTEST PERIOD ALLOWED BY LAW, BUT NOT LESS THAN ONE YEAR. ELECTROLUX SHALL NOT BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES SUCH AS PROPERTY DAMAGE AND INCIDENTAL EXPENSES RESULTING FROM ANY BREACH OF THIS WRITTEN LIMITED WARRANTY OR ANY IMPLIED WARRANTY.**



[You're reading an excerpt. Click here to read official FRIGIDAIRE FGF328GS user guide](http://yourpdfguides.com/dref/3258663)
<http://yourpdfguides.com/dref/3258663>

SOME STATES AND PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, OR LIMITATIONS ON THE DURATION OF IMPLIED WARRANTIES, SO THESE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WRITTEN WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS.

YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE. If You Need Service Keep your receipt, delivery slip, or some other appropriate payment record to establish the warranty period should service be required. If service is performed, it is in your best interest to obtain and keep all receipts. Service under this warranty must be obtained by contacting Electrolux at the addresses or phone numbers below. This warranty only applies in the USA and Canada. In the USA, your appliance is warranted by Electrolux Major Appliances North America, a division of Electrolux Home Products, Inc.

In Canada, your appliance is warranted by Electrolux Canada Corp. Electrolux authorizes no person to change or add to any obligations under this warranty. Obligations for service and parts under this warranty must be performed by Electrolux or an authorized service company. Product features or specifications as described or illustrated are subject to change without notice.

USA 1.800.944.9044 Electrolux Major Appliances North America P.O.

Box 212378 Augusta, GA 30907 Canada 1.800.668.4606 Electrolux Canada Corp. 5855 Terry Fox Way Mississauga, Ontario, Canada L5V 3E4 .



[You're reading an excerpt. Click here to read official FRIGIDAIRE FGF328GS user guide](#)

<http://yourpdfguides.com/dref/3258663>