



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for GIGABYTE GA-Z97MX-GAMING 5. You'll find the answers to all your questions on the GIGABYTE GA-Z97MX-GAMING 5 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual GIGABYTE GA-Z97MX-GAMING 5
User guide GIGABYTE GA-Z97MX-GAMING 5
Operating instructions GIGABYTE GA-Z97MX-GAMING 5
Instructions for use GIGABYTE GA-Z97MX-GAMING 5
Instruction manual GIGABYTE GA-Z97MX-GAMING 5

GA-Z97MX-Gaming 5

User's Manual
Rev. 1001
12M E-Z97MGM5-1001R



[You're reading an excerpt. Click here to read official GIGABYTE GA-Z97MX-GAMING 5 user guide](http://yourpdfguides.com/dref/5585592)
<http://yourpdfguides.com/dref/5585592>

Manual abstract:

© 2014 Apr. 3, 2014 Copyright © 2014 GIGA-BYTE TECHNOLOGY CO., LTD. All rights reserved. For detailed product information, carefully read the User's Manual. For product-related information, check on our website at: <http://www.gigabyte.com> Identifying Your Motherboard Revision
The revision number on your motherboard looks like this: "REV: X.X." For example, "REV: 1.0" means the revision of the motherboard is 1.0. Check your motherboard revision before updating motherboard BIOS, drivers, or when looking for technical information. Example: Table of Contents Box Contents..

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....6 Optional Items.

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

...6 GA-Z97MX-Gaming 5 Motherboard Layout.....

.....

.....

.....

.....

.....

.....

.....

..7 GA-Z97MX-Gaming 5 Motherboard Block Diagram...

.....

.....

.....

.....

.....

.....

.....8 Chapter 1 Hardware Installation..

.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

....9 1-1 1-2 1-3 Installation Precautions.....

.....
.....
.....
.....
.....
.....
.....
.....

..... 9 Product Specifications..

.....
.....
.....
.....
.....
.....
.....
.....

.. 10 Installing the CPU and CPU Cooler.....

.....
.....
.....
.....
.....
.....
.....

..... 13 1-3-1 Installing the CPU.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....
.....
.....
.....
.....
.....
.....
.....

... 34 2-2 *The Main Menu*.....

.....
.....
.....
.....
.....
.....
.....
.....

..... 35 2-3 *M.
I.T.*.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

... 38 2-4 *System Information*.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.. 50 2-5 *BIOS Features*.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... *51 2-6 Peripherals..*

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

55 2-7 Power Management.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

... 58 2-8 Save & Exit..

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

..... *60 Chapter 3 Configuring SATA Hard Drive(s).*

.....
.....
.....
.....

.....
.....

.....
.....

.....61 3-1 3-2 Configuring SATA Controllers....

.....
.....
.....

.....
.....
.....

.....
.....

.... 61 Installing the SATA RAID/AHCI Driver and Operating System.

.....

. 73 -4- Chapter 4 Drivers Installation....

.....
.....

.....
.....
.....

.....
.....
.....

.....77 4-1 Chipset Drivers.

.....
.....
.....

.....
.....
.....

.....
.....
.....

.... 77 4-2 Application Software.

.....
.....

.....
.....
.....

.....
.....
.....

. 78 4-3 Information....

.....
.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

... 78 Chapter 5 Unique Features.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

....79 5-1 BIOS Update Utilities.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

79 Updating the BIOS with the Q-Flash Utility.....

.....
.....
.....

.....
.....
.....

79 Updating the BIOS with the @BIOS Utility.....

.....
.....
.....

.....
.....
.....

.82 5-1-1 5-1-2 5-2 APP Center.....

.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.. 83 5-2-1 EasyTune.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.... 84 5-2-2 System Information Viewer.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

... 85 5-2-3 EZ Setup..

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

86 5-2-4 Fast Boot.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

...91 5-2-5 Smart TimeLock.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

92 5-2-6 Smart Recovery 2.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

....93 5-2-7 USB Blocker.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....
..95 5-2-8 Smart Switch....

.....
.....

.....
.....
.....

.....
.....
.....

.....
.....

..... 96 5-2-9 Game Controller...

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....97 Chapter 6 Appendix.

.....
.....

.....
.....
.....

.....
.....
.....

.....
.....

..99 6-1 Qualcomm® Atheros Killer Network Manager.....

.....
.....
.....

99 6-2 Configuring Audio Input and Output.....

.....
.....
.....
.....

.....
.....
.....
.....
. 100 6-2-1 6-2-2 6-2-3 6-2-4 6-2-5 Configuring 2/4/5.1/7.1-Channel Audio..
.....
.....
.....
.....
.....
.....
.....
.....

.....
.....
.. 100 Configuring S/PDIF Out...
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....
.....
102 Configuring Microphone Recording.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....
.....
.....103 Using the Sound Recorder.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....
.....
...105 Creative Software Suite..
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....
.....
106 6-3 Troubleshooting.....

.....
.....
.....

.....
.....
.....

.....
.....
.. 109 6-3-1 Frequently Asked Questions..

.....
.....
.....

.....
.....
.....

.....109 6-3-2 Troubleshooting Procedure...

.....
.....

.....
.....
.....

.....
.....

.....110 Regulatory Statements.

.....
.....
.....

.....
.....
.....

.....
.....
.....

..112 Contact Us.....

.....
.....
.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

....115 -5- Box Contents 55 55 55 55 55 55 55 55 GA-Z97MX-Gaming 5 motherboard Motherboard driver disk User's Manual Quick Installation Guide Four SATA cables I/O Shield One 2-Way SLI bridge connector The box contents above are for reference only and the actual items shall depend on the product package you obtain. The box contents are subject to change without notice. Optional Items □□ □□ □□ □□ 2-port USB 2.0 bracket (Part No. 12CR1-1UB030-6*R) eSATA bracket (Part No. 12CF1-3SATPW-4*R) 3.

5" Front Panel with 2 USB 3.0/2.0 ports (Part No. 12CR1-FPX582-2*R) HDMI-to-DVI adapter (Part No. 12CT2-HDMI01-1*R) -6- GA-Z97MX-Gaming 5 Motherboard Layout DDR3_4 DDR3_2 DDR3_3 KB_MB ATX_12V_2X4 CPU_FAN CPU_OPT SYS_FAN3 B_BIOS M_BIOS M.2 PCIEX16 TI Burr Brown® OPA2134 GAIN CODEC Intel® Z97 iTE® Super I/O CLR_CMOS F_AUDIO SPDIF_O SYS_FAN2 F_USB2 F_USB1 F_PANEL VGA DVI LGA1150 DDR3_1 ATX R_USB30 HDMI R_USB Qualcomm® Atheros Killer E2201 LAN USB30_LAN GA-Z97MX-Gaming 5 SYS_FAN1 AUDIO F_USB30 SATA_EXPRESS SATA3 2 4 3 5 SATA3 1 0 PCIEX1 BAT PCIEX8 PCIEX4 -7- GA-Z97MX-Gaming 5 Motherboard Block Diagram PCIe CLK (100 MHz) 1 PCI Express x16 or 2 PCI Express x8 CPU CLK+/- (100 MHz) DDR3 1600/1333 MHz LGA1150 CPU Dual Channel Memory x16 Switch x8 DVI-D HDMI DMI 2.0 FDI PCI Express Bus 1 PCI Express x4 1 PCI Express x1 PCIe CLK (100 MHz) x4 PCI Express Bus x1 D-Sub LAN RJ45 or Switch or Dual BIOS M.2 SATA Express 2 SATA 6Gb/s Qualcomm® Atheros Killer E2201 LAN x1 Intel® Z97 4 SATA 6Gb/s 6 USB 3.0/2.0 CODEC 8 USB 2.0/1.1 MIC Line Out Line In Rear Speaker Out Center/Subwoofer Speaker Out Side Speaker Out S/PDIF Out LPC Bus iTE® Super I/O PS/2 KB/Mouse For detailed product information/limitation(s), refer to "1-2 Product Specifications." -8- Chapter 1 Hardware Installation 1-1 Installation Precautions The motherboard contains numerous delicate electronic circuits and components which can become damaged as a result of electrostatic discharge (ESD). Prior to installation, carefully read the user's manual and follow these procedures: • Prior to installation, make sure the chassis is suitable for the motherboard. •

Prior to installation, do not remove or break motherboard S/N (Serial Number) sticker or warranty sticker provided by your dealer. These stickers are required for warranty validation. • Always remove the AC power by unplugging the power cord from the power outlet before installing or removing the motherboard or other hardware components. • When connecting hardware components to the internal connectors on the motherboard, make sure they are connected tightly and securely. • When handling the motherboard, avoid touching any metal leads or connectors. • It is best to wear an electrostatic discharge (ESD) wrist strap when handling electronic components such as a motherboard, CPU or memory. If you do not have an ESD wrist strap, keep your hands dry and first touch a metal object to eliminate static electricity. • Prior to installing the motherboard, please have it on top of an antistatic pad or within an electrostatic shielding container. • Before unplugging the power supply cable from the motherboard, make sure the power supply has been turned off. • Before turning on the power, make sure the power supply voltage has been set according to the local voltage standard. • Before using the product, please verify that all cables and power connectors of your hardware components are connected. • To prevent damage to the motherboard, do not allow screws to come in contact with the motherboard circuit or its components. • Make sure there are no leftover screws or metal components placed on the motherboard or within the computer casing. • Do not place the computer system on an uneven surface. • Do not place the computer system in a high-temperature environment. • Turning on the computer power during the installation process can lead to damage to system components as well as physical harm to the user.

• If you are uncertain about any installation steps or have a problem related to the use of the product, please consult a certified computer technician. -9 Hardware Installation Hardware Monitor □□ □□ □□ □□ □□ System voltage detection CPU/System/Chipset temperature detection CPU/CPU OPT/System fan speed detection CPU/System overheating warning CPU/CPU OPT/System fan fail warning CPU/CPU OPT/System fan speed control 2 x 64 Mbit flash Use of licensed AMI UEFI BIOS Support for DualBIOS™ PnP 1.



[You're reading an excerpt. Click here to read official GIGABYTE GA-Z97MX-GAMING 5 user guide](http://yourpdfguides.com/dref/5585592)
<http://yourpdfguides.com/dref/5585592>

0a, DMI 2.7, SM BIOS 2.7, ACPI 2.0 Support for APP Center * Whether the fan speed control function is supported will depend on the cooler you will install. BIOS Unique Features * Available applications in APP Center may differ by motherboard model. Supported A functions of each application may also differ depending on motherboard specifications. Bundled Software Operating System Form Factor @BIOS - EasyTune - EZ Setup - Fast Boot - Game Controller - ON/OFF Charge - Smart TimeLock - Smart Recovery 2 - System Information Viewer - USB Blocker Support for Q-Flash Support for Smart Switch Support for Xpress Install Norton® Internet Security (OEM version) Intel® Rapid Start Technology Intel® Smart Connect Technology Intel® Smart Response Technology Support for Windows 8.1/8/7 Micro ATX Form Factor; 24.4cm x 24.4cm * GIGABYTE reserves the right to make any changes to the product specifications and product-related information without prior notice. * Please visit the Support & Downloads/Utility page on GIGABYTE's website to check the supported operating system(s) for the software listed in the "Unique Features" and "Bundled Software" columns. Hardware Installation - 12 - 1-3 Installing the CPU and CPU Cooler Read the following guidelines before you begin to install the CPU: • Make sure that the motherboard supports the CPU. (Go to GIGABYTE's website for the latest CPU support list.) • Always turn off the computer and unplug the power cord from the power outlet before installing the CPU to prevent hardware damage. • Locate the pin one of the CPU. The CPU cannot be inserted if oriented incorrectly. (Or you may locate the notches on both sides of the CPU and alignment keys on the CPU socket.) • Apply an even and thin layer of thermal grease on the surface of the CPU. • Do not turn on the computer if the CPU cooler is not installed, otherwise overheating and damage of the CPU may occur. • Set the CPU host frequency in accordance with the CPU specifications. It is not recommended that the system bus frequency be set beyond hardware specifications since it does not meet the standard requirements for the peripherals. If you wish to set the frequency beyond the standard specifications, please do so according to your hardware specifications including the CPU, graphics card, memory, hard drive, etc. 1-3-1 Installing the CPU A. Locate the alignment keys on the motherboard CPU socket and the notches on the CPU. LGA1150 CPU Socket Alignment Key Alignment Key Pin One Corner of the CPU Socket LGA1150 CPU Notch Notch Triangle Pin One Marking on the CPU - 13 - Hardware Installation B. Follow the steps below to correctly install the CPU into the motherboard CPU socket. • Before installing the CPU, make sure to turn off the computer and unplug the power cord from the power outlet to prevent damage to the CPU. • To protect the socket contacts, do not remove the protective plastic cover unless the CPU is inserted into the CPU socket.

Save the cover properly and replace it if the CPU is removed. Step 1: Gently press the CPU socket lever handle down and away from the socket with your finger. Then completely lift the CPU socket lever and the metal load plate/plastic cover will be lifted as well. Step 2: Hold the CPU with your thumb and index fingers. Align the CPU pin one marking (triangle) with the pin one corner of the CPU socket (or you may align the CPU notches with the socket alignment keys) and gently insert the CPU into position. Step 3: Once the CPU is properly inserted, carefully replace the load plate. When replacing the load plate, make sure the front end of the load plate is under the shoulder screw. Then press the CPU socket lever. The protective plastic cover may pop off from the load plate during the process of engaging the lever. Remove the cover.

(Save the cover properly and always replace it when the CPU is not installed.) Step 4: Finally, secure the lever under its retention tab to complete the installation of the CPU. NOTE: Hold the CPU socket lever by the handle, not the lever base portion. Hardware Installation - 14 - 1-3-2 Installing the CPU Cooler Follow the steps below to correctly install the CPU cooler on the motherboard. (The following procedure uses Intel® boxed cooler as the example cooler.

) Male Push Pin The Top of Female Push Pin Direction of the Arrow Sign on the Male Push Pin Female Push Pin Step 1: Apply an even and thin layer of thermal grease on the surface of the installed CPU. Step 2: Before installing the cooler, note the direction of the arrow sign on the male push pin. (Turning the push pin along the direction of arrow is to remove the cooler, on the contrary, is to install.) Step 3: Place the cooler atop the CPU, aligning the four push pins through the pin holes on the motherboard. Push down on the push pins diagonally.

Step 4: You should hear a "click" when pushing down each push pin. Check that the Male and Female push pins are joined closely. (Refer to your CPU cooler installation manual for instructions on installing the cooler.) Step 5: After the installation, check the back of the motherboard. If the push pin is inserted as the picture above shows, the installation is complete. Step 6: Finally, attach the power connector of the CPU cooler to the CPU fan header (CPU_FAN) on the motherboard. Use extreme care when removing the CPU cooler because the thermal grease/tape between the CPU cooler and CPU may adhere to the CPU. Inadequately removing the CPU cooler may damage the CPU. - 15 Hardware Installation 1-4 Installing the Memory Read the following guidelines before you begin to install the memory: • Make sure that the motherboard supports the memory. It is recommended that memory of the same capacity, brand, speed, and chips be used.

(Go to GIGABYTE's website for the latest supported memory speeds and memory modules.) • Always turn off the computer and unplug the power cord from the power outlet before installing the memory to prevent hardware damage. • Memory modules have a foolproof design. A memory module can be installed in only one direction. If you are unable to insert the memory, switch the direction. 1-4-1 Dual Channel Memory Configuration This motherboard provides four DDR3 memory sockets and supports Dual Channel Technology. After the memory is installed, the BIOS will automatically detect the specifications and capacity of the memory. Enabling Dual Channel memory mode will double the original memory bandwidth. The four DDR3 memory sockets are divided into two channels and each channel has two memory sockets as following: Channel A: DDR3_2, DDR3_4 Channel B: DDR3_1, DDR3_3 Dual Channel Memory Configurations Table DDR3_4 DDR3_2 DDR3_3 -DS/SS -DS/SS -DS/SS Four Modules DS/SS DS/SS DS/SS (SS=Single-Sided, DS=Double-Sided, "-"=No Memory) Two Modules DDR3_1 DS/SS -DS/SS Due to CPU limitations, read the following guidelines before installing the memory in Dual Channel mode.



[You're reading an excerpt. Click here to read official GIGABYTE GA-Z97MX-GAMING 5 user guide](http://yourpdfguides.com/dref/5585592)
<http://yourpdfguides.com/dref/5585592>

1.

Dual Channel mode cannot be enabled if only one DDR3 memory module is installed. 2. When enabling Dual Channel mode with two or four memory modules, it is recommended that memory of the same capacity, brand, speed, and chips be used and installed in the same colored DDR3 sockets. For optimum performance, when enabling Dual Channel mode with two memory modules, we recommend that you install them in the DDR3_1 and DDR3_2 sockets. Hardware Installation DDR3_4 DDR3_2 DDR3_3 DDR3_1 - 16 - 1-4-2 Installing a Memory Before installing a memory module, make sure to turn off the computer and unplug the power cord from the power outlet to prevent damage to the memory module.

DDR3 and DDR2 DIMMs are not compatible to each other or DDR DIMMs. Be sure to install DDR3 DIMMs on this motherboard. Notch DDR3 DIMM A DDR3 memory module has a notch, so it can only fit in one direction. Follow the steps below to correctly install your memory modules in the memory sockets.

Step 1: Note the orientation of the memory module.

Spread the retaining clips at both ends of the memory socket. Place the memory module on the socket. As indicated in the picture on the left, place your fingers on the top edge of the memory, push down on the memory and insert it vertically into the memory socket. Step 2: The clips at both ends of the socket will snap into place when the memory module is securely inserted. - 17 - Hardware Installation 1-5 Installing an Expansion Card Read the following guidelines before you begin to install an expansion card: • Make sure the motherboard supports the expansion card. Carefully read the manual that came with your expansion card. • Always turn off the computer and unplug the power cord from the power outlet before installing an expansion card to prevent hardware damage. PCI Express x1 Slot PCI Express x16 Slot Follow the steps below to correctly install your expansion card in the expansion slot. 1. Locate an expansion slot that supports your card.

Remove the metal slot cover from the chassis back panel. 2. Align the card with the slot, and press down on the card until it is fully seated in the slot. 3. Make sure the metal contacts on the card are completely inserted into the slot. 4. Secure the card's metal bracket to the chassis back panel with a screw. 5. After installing all expansion cards, replace the chassis cover(s). 6.

Turn on your computer. If necessary, go to BIOS Setup to make any required BIOS changes for your expansion card(s). 7. Install the driver provided with the expansion card in your operating system. Example: Installing and Removing a PCI Express Graphics Card: • Installing a Graphics Card: Gently push down on the top edge of the card until it is fully inserted into the PCI Express slot.

Make sure the card is securely seated in the slot and does not rock. • Removing the Card: Gently push back on the lever on the slot and then lift the card straight out from the slot. Hardware Installation - 18 - 1-6 Setting up AMD CrossFire™/NVIDIA® SLI™ Configuration A. System Requirements -- Windows 8.1/8/7 operating system -- A CrossFire/SLI-supported motherboard with two or more PCI Express x16 slots and correct driver -- CrossFire/SLI-ready graphics cards of identical brand and chip and correct driver -- CrossFire(Note)/SLI bridge connectors -- A power supply with sufficient power is recommended (Refer to the manual of your graphics cards for the power requirement) B.

Connecting the Graphics Cards Step 1: Observe the steps in "1-5 Installing an Expansion Card" and install CrossFireX/SLI graphics cards on the PCI Express x16 slots. Step 2: Insert the CrossFire(Note)/SLI bridge connectors in the CrossFire/SLI gold edge connectors on top of the cards. Step 3: Plug the display cable into the graphics card on the PCIEX16 slot. C. Configuring the Graphics Card Driver C-1. To Enable CrossFire Function After installing the graphics card driver in the operating system, go to the AMD Catalyst Control Center. Browse to Performance\AMD CrossFireX™ and ensure the Enable AMD CrossFireX check box is selected and click Apply. C-2. To Enable SLI Function After installing the graphics card driver in the operating system, go to the NVIDIA Control Panel. Browse to the Configure SLI, Surround, Physx screen and ensure Maximize 3D performance is enabled.

(Note) The bridge connector(s) may be needed or not depending on your graphics cards. Procedure and driver screen for enabling CrossFire/SLI technology may differ by graphics cards and driver version. Refer to the manual that came with your graphics cards for more information about enabling CrossFire/SLI technology. - 19 Hardware Installation 1-7 Back Panel Connectors PS/2 Keyboard/Mouse Port D-Sub Port Use the upper port (green) to connect a PS/2 mouse and the lower port (purple) to connect a PS/2 keyboard. The D-Sub port supports a 15-pin D-Sub connector and supports a maximum resolution of 1920x1200@60Hz (the actual resolutions supported depend on the monitor being used). Connect a monitor that supports D-Sub connection to this port. DVI-

D Port (Note) The DVI-D port conforms to the DVI-D specification and supports a maximum resolution of 1920x1200@60Hz (the actual resolutions supported depend on the monitor being used). Connect a monitor that supports DVI-D connection to this port. USB 3.0/2.0 Port HDMI Port (Note) The USB 3.0 port supports the USB 3.0 specification and is compatible to the USB 2.0/1.1 specification.

Use this port for USB devices such as a USB keyboard/mouse, USB printer, USB flash drive and etc. The HDMI port is HDCP compliant and supports Dolby True HD and DTS HD Master Audio formats. It also supports up to 192KHz/24bit 8-channel LPCM audio output. You can use this port to connect your HDMI-supported monitor. The maximum supported resolution is 4096x2160@24Hz or 2560x1600@60Hz, but the actual resolutions supported are dependent on the monitor being used.

After installing the HDMI device, make sure to set the default sound playback device to HDMI. (The item name may differ depending on your operating system. The screenshot below is from Windows 8.1.) In Windows 8.1, select Apps>Control Panel>Hardware and Sound>Sound>Playback, set Intel(R) Display Audio to the default playback device. (Note) The DVI-D port does not support D-Sub connection by adapter. • When removing the cable connected to a back panel connector, first remove the cable from your device and then remove it from the motherboard. • When removing the cable, pull it straight out from the connector. Do not rock it side to side to prevent an electrical short inside the cable connector.

Hardware Installation - 20 - Triple-Display Configurations for the Onboard Graphics: Triple-display configurations are supported after you install motherboard drivers in OS. Only dual-display configurations are supported during the BIOS Setup or POST process. USB 2.0/1.1 Port The USB port supports the USB 2.



[You're reading an excerpt. Click here to read official GIGABYTE GA-Z97MX-GAMING 5 user guide](http://yourpdfguides.com/dref/5585592)
<http://yourpdfguides.com/dref/5585592>

0/1.1 specification. You can connect a USB DAC to this port or use this port for USB devices such as a USB keyboard/mouse, USB printer, USB flash drive and etc. Use this port for USB devices such as a USB keyboard/mouse, USB printer, USB flash drive and etc. RJ-45 LAN Port The Gigabit Ethernet LAN port provides Internet connection at up to 1 Gbps data rate.

The following describes the states of the LAN port LEDs. Connection/ Speed LED Activity LED Connection/Speed LED: State Orange Green Off Description 1 Gbps data rate 100 Mbps data rate 10 Mbps data rate Activity LED: State Blinking Off Description Data transmission or receiving is occurring No data transmission or receiving is occurring LAN Port Center/Subwoofer Speaker Out Jack Rear Speaker Out Use this audio jack to connect center/subwoofer speakers in a 5.1/7.1-channel audio configuration. This jack can be used to connect front speakers in a 4/5.

1/7.1-channel audio configuration. Optical SPDIF Out Connector Line In This connector provides digital audio out to an external audio system that supports digital optical audio. Before using this feature, ensure that your audio system provides an optical digital audio in connector. The line in jack.

Use this audio jack for line in devices such as an optical drive, walkman, etc. Line Out The line out jack. This jack supports audio amplifying function. For better sound quality, it is recommended that you connect your headphone/speaker to this jack (actual effects may vary by the device being used). Use this audio jack for a headphone or 2-channel speaker. This jack can be used to connect front speakers in a 4/5.1/7.1-channel audio configuration. Mic In The Mic in jack. Microphones must be connected to this jack.

The audio jacks can be reconfigured to perform different functions via the audio software (supported functions may vary based on hardware specification). If you install a Side Speaker, you need to retask other audio jack to be Side Speaker out. Only microphones still MUST be connected to the default Mic in jack.

Refer to the instructions on setting up a 2/4/5.1/7.1-channel audio configuration in Chapter 6, "Configuring 2/4/5.1/7.1-Channel Audio." •• When removing the cable connected to a back panel connector, first remove the cable from your device and then remove it from the motherboard. •• When removing the cable, pull it straight out from the connector.

Do not rock it side to side to prevent an electrical short inside the cable connector. - 21 - Hardware Installation 1-8 Changing the Operational Amplifier Step 1: Use an IC extractor to carefully grip the IC's sides and extract it from the socket. Step 2: Align the notch on your OP chip with the notch on the socket and gently press the chip into the socket until seated. For purchasing the IC extractor and OP Chip, please contact the local dealer. Hardware Installation - 22 -

1-9 Internal Connectors 1 5 3 4 2 8 4 14 15 12 7 6 7 10 11 4 13 9 16 1) 2) 3) 4) 5) 6) 7) 8) ATX_12V_2X4 ATX CPU_FAN SYS_FAN1/2/3 CPU_OPT SATA_EXPRESS SATA3 0/1/2/3/4/5 M.

2 9) 10) 11) 12) 13) 14) 15) 16) F_PANEL F_AUDIO SPDIF_O F_USB30 F_USB1/F_USB2 GAIN BAT CLR_CMOS Read the following guidelines before connecting external devices: •• First make sure your devices are compliant with the connectors you wish to connect. •• Before installing the devices, be sure to turn off the devices and your computer. Unplug the power cord from the power outlet to prevent damage to the devices. •• After installing the device and before turning on the computer, make sure the device cable has been securely attached to the connector on the motherboard. - 23 Hardware Installation 1/2)

ATX_12V_2X4/ATX (2x4 12V Power Connector and 2x12 Main Power Connector) With the use of the power connector, the power supply can supply enough stable power to all the components on the motherboard.

Before connecting the power connector, first make sure the power supply is turned off and all devices are properly installed. The power connector possesses a foolproof design. Connect the power supply cable to the power connector in the correct orientation. The 12V power connector mainly supplies power to the CPU. If the 12V power connector is not connected, the computer will not start. To meet expansion requirements, it is recommended that a power supply that can withstand high power consumption be used (500W or greater). If a power supply is used that does not provide the required power, the result can lead to an unstable or unbootable system. ATX_12V_2X4: 5 1 ATX_12V_2X4 8 4 Pin No. 1 2 3 4 5 6 7 8 Definition GND (Only for 2x4-pin 12V) GND (Only for 2x4-pin 12V) GND +12V (Only for 2x4-pin 12V) +12V (Only for 2x4-pin 12V) +12V +12V ATX: 12 24 Pin No. 1 2 3 4 5 6 7 8 9 10 11 12 1 ATX 13 Definition Pin No.

3.3V 13 3.3V 14 GND 15 +5V 16 GND 17 +5V 18 GND 19 Power Good 20 5VSB (stand by +5V) 21 +12V 22 +12V (Only for 2x12-pin 23 ATX) 3.3V (Only for 2x12-pin 24 ATX) Definition 3.3V -12V GND PS_ON (soft On/Off) GND GND GND -5V +5V +5V +5V (Only for 2x12-pin ATX) GND (Only for 2x12-pin ATX) Hardware Installation - 24 - 3/4) CPU_FAN/SYS_FAN1/SYS_FAN2/SYS_FAN3 (Fan Headers) All fan headers on this motherboard are 4-pin. Most fan headers possess a foolproof insertion design. When connecting a fan cable, be sure to connect it in the correct orientation (the black connector wire is the ground wire). The speed control function requires the use of a fan with fan speed control design. For optimum heat dissipation, it is recommended that a system fan be installed inside the chassis. CPU_FAN: 1 CPU_FAN Pin No.

1 2 3 4 Pin No. 1 2 3 4 Definition GND +12V Sense Speed Control Definition GND +12V/Speed Control Sense VCC 1 SYS_FAN1/2 SYS_FAN1/2/3 1 SYS_FAN3 5) CPU_OPT (Water Cooling CPU Fan Header) The fan header is 4-pin and possesses a foolproof insertion design. When connecting a fan cable, be sure to connect it in the correct orientation (the black connector wire is the ground wire). The speed control function requires the use of a fan with fan speed control design. Pin No.

1 2 3 4 Definition GND +12V/Speed Control Sense VCC 1 •• Be sure to connect fan cables to the fan headers to prevent your CPU and system from overheating. Overheating may result in damage to the CPU or the system may hang. •• These fan headers are not configuration jumper blocks. Do not place a jumper cap on the headers. - 25 Hardware Installation 1 2 3 S 6) SATA_EXPRESS (SATA Express Connector) S The SATA Express connector supports a single SATA Express device.

_ S 3 B SS S S _ S F S _ 7) SATA3 0/1/2/3/4/5 (SATA 6Gb/s Connectors) S The SATA connectors conform to SATA 6Gb/s standard and are compatible with SATA 3Gb/s and SATA 1.5Gb/s standard. Each SATA connector supports a single SATA device. The Intel® Chipset supports RAID 0, RAID 1, RAID 5, and RAID 10. Refer to Chapter 3, "Configuring SATA Hard Drive(s)," for instructions on configuring a RAID array.



[You're reading an excerpt. Click here to read official GIGABYTE GA-Z97MX-GAMING 5 user guide](http://yourpdfguides.com/dref/5585592)
<http://yourpdfguides.com/dref/5585592>

SATA3 7 7 1 0 SATA3 3 2 5 4 1 1 _ S _ Pin No. 1 2 3 4 5 6 7 Definition GND TXP TXN GND RXN RXP GND •• A RAID 0 or RAID 1 configuration requires at least two hard drives. If more than two hard drives are to be used, the total number of hard drives must be an even number. •• A RAID 5 configuration requires at least three hard drives. (The total number of hard drives does not have to be an even number.)

) •• A RAID 10 configuration requires four hard drives. •• To enable hot-plugging for the SATA ports, refer to Chapter 2, "BIOS Setup," "Peripherals\SATA Configuration," for more information. •• M.2, SATA Express, and SATA3 4/5 connectors can only be used one at a time. The SATA3 4/5 connectors will become unavailable when an M.2 SSD is installed. Hardware Installation - 26 - 1 2 _ B B S _ B 8) M.2 (M.2 Connector) You can insert an M.2 SSD into this connector.

S B _ B _ S S _ _ B _ Follow the steps below to correctly install an M.2 SSD in the M.2 connector. B _ U F _ USB3 F Step 1: Use a screw driver to unfasten the screw and nut from the motherboard. Locate the proper mounting hole for the M.2 SSD to be installed and then screw the nut first. Step 2: Slide the M.2 SSD into the connector at an oblique angle. Step 3: Press the M.2 SSD down and then secure it with the screw.

Step 4: The installation is completed, as shown in the picture above. •• On the motherboard there are three length adjustment holes for the M.2 SSD. Select the proper hole for the M.2 SSD to be installed and refasten the screw and nut. •• M.2, SATA Express, and SATA3 4/5 connectors can only be used one at a time. The SATA3 4/5 connectors will become unavailable when an M.2 SSD is installed. - 27 Hardware Installation 9) F_PANEL (Front Panel Header) Connect the power switch, reset switch, speaker, chassis intrusion switch/sensor and system status indicator on the chassis to this header according to the pin assignments below.

Note the positive and negative pins before connecting the cables. Power LED Power Switch Speaker PLED+ PLEDPW+ PW- SPEAK+ 2 1 HD+ HDRESRES+ CICI+ PWR_LED+ PWR_LED PWR_LED- SPEAK20 19 Power LED Hard Drive Activity LED Reset Switch Chassis Intrusion Header •• PLED/PWR_LED (Power LED, Yellow/Purple): Connects to the power status indicator on the chassis front panel. The LED System Status LED is on when the system is operating. The LED is off when the system is in S3/S0 On S4 sleep state or powered off (S5). S3/S4/S5 Off •• PW (Power Switch, Red): Connects to the power switch on the chassis front panel. You may configure the way to turn off your system using the power switch (refer to Chapter 2, "BIOS Setup," "Power Management," for more information). •• SPEAK (Speaker, Orange): Connects to the speaker on the chassis front panel. The system reports system startup status by issuing a beep code. One single short beep will be heard if no problem is detected at system startup. •• HD (Hard Drive Activity LED, Blue): Connects to the hard drive activity LED on the chassis front panel.

The LED is on when the hard drive is reading or writing data. •• RES (Reset Switch, Green): Connects to the reset switch on the chassis front panel. Press the reset switch to restart the computer if the computer freezes and fails to perform a normal restart. •• CI (Chassis Intrusion Header, Gray): Connects to the chassis intrusion switch/sensor on the chassis that can detect if the chassis cover has been removed. This function requires a chassis with a chassis intrusion switch/sensor.

The front panel design may differ by chassis. A front panel module mainly consists of power switch, reset switch, power LED, hard drive activity LED, speaker and etc. When connecting your chassis front panel module to this header, make sure the wire assignments and the pin assignments are matched correctly. Hardware Installation - 28 - 10) F_AUDIO (Front Panel Audio Header) The front panel audio header supports Intel High Definition audio (HD).

You may connect your chassis front panel audio module to this header.

Make sure the wire assignments of the module connector match the pin assignments of the motherboard header. Incorrect connection between the module connector and the motherboard header will make the device unable to work or even damage it. Pin No. 1 2 F _ 3 4 5 6 7 8 9 10 Definition MIC2_L GND MIC2_R -ACZ_DET LINE2_R GND FAUDIO_JD No Pin LINE2_L GND 9 F _ U 10 1 F _ 2 11) SPDIF_O (SPDIF Out Header) 1 2 3 •• The front panel audio header supports HD audio by default. If your chassis provides an AC'97 B SS B _ front panel audio module, refer to the instructions on how to activate AC'97 functionality via the audio software in Chapter 6, "Configuring 2/4/5.1/7.1-Channel Audio." •• Audio signals will be present on both of the front and back panel audio connections simultaneously. _ S If you want to mute the back panel audio (only supported when using an HD front panel audio module), refer to Chapter 6, "Configuring 2/4/5.1/7.1-Channel Audio."

•• Some chassis provide a front panel audio module that has separated connectors on each wire instead of a single plug. For information about connecting the front panel audio module that has S different wire assignments, please contact the chassis manufacturer. 1 1 This header supports digital S/PDIF Out and connects a S/PDIF digital audio cable (provided by expansion S cards) for digital audio output from your motherboard to certain expansion cards like graphics cards and sound cards. For example, some graphics cards may require you to use a S/PDIF digital audio cable for digital audio output from your motherboard to your graphics card if you wish to connect an HDMI display to the graphics card and have digital audio output from the HDMI display at the same time. For information about connecting the S/PDIF digital audio cable, carefully read the manual for your expansion card. 1 2 3 S 3 B SS S 1 U S _ S F - 29 - 1 2 3 1 1 _ B 1 2 3 S B _ B _ S S _ _ B Pin No. 1 2 _ _ Definition SPDIF_O GND 3 _ U _ B F _ USB3 F Hardware Installation 12)

F_USB30 (USB 3.0/2.0 Header) F_USB30 F _ U F _ The header conforms to USB 3.

0/2.0 specification and can provide two USB ports. For purchasing the optional 3.5" front panel that provides two USB 3.0/2.

0 ports, please contact the local dealer. Pin No. 1 2 3 4 5B_ 6 7 8 9 10 Definition VBUS SSRX1SSRX1+ GND SSTX1SSTX1+ GND DID1+ NC Pin No. 11 12 13 14 15 16 17 18 19 20 Definition D2+ D2GND SSTX2+ B SS SSTX2GND SSRX2+ SSRX2VBUS No Pin S 1 2 3 1 2 3 20 1 1 S 13) F_USB1/F_USB2 (USB 2.0/1.

1 Headers) The header conforms to USB 2.0/1.1 specification. Each USB header can provide two USB ports via an optional USB bracket. For purchasing the optional USB bracket, please contact the local dealer. Pin No. Definition 1 Power (5V) S 2B S S Power (5V) 3 USB DX4 USB DY5 USB DX+ 6 USB DY+ 7 GND S F 8 GND 9 No Pin 10 NC 9 S 10 3 1 2 S _ •• Do not plug the IEEE 1394 bracket (2x5-pin) cable into the USB 2.



[You're reading an excerpt. Click here to read official GIGABYTE GA-Z97MX-GAMING 5 user guide](http://yourpdfguides.com/dref/5585592)
<http://yourpdfguides.com/dref/5585592>

0/1.1 header. •• Prior to installing the USB bracket, be sure to turn off your computer and unplug the power cord from the power outlet to prevent damage to the USB bracket.

S _ Hardware Installation - 30 - 1 11 10 1 _S 1 2 3 1 1 2 3 U _S B _S 14) GAIN (Audio Gain Control Switches) S 3 This switch allows for audio gain control for the line-out jack on the back panel. Please make sure all of the dips are set in the same position and are set according to your headphone specification (actual effects may vary by the device being used). _ U B SS S U __ 3 _ B S _ B Gain Ratio 2.5x 6x S F DIP 1 OFF ON DIP Setting DIP 2 DIP 3 DIP 4 OFF OFF F _USB3 OFF F ON ON ON 15) BAT (Battery) The battery provides power to keep the values (such as BIOS configurations, date, and time information) in the CMOS when the computer is turned off. Replace the battery when the battery voltage drops to a low level, or the CMOS values may not be accurate or may be lost. You may clear the CMOS values by removing the battery: 1. Turn off your computer and unplug the power cord. 2. Gently remove the battery from the battery holder and wait for one minute. (Or use a metal object like a screwdriver to touch the positive and negative terminals of the battery holder, making them short for 5 seconds.

) 3. Replace the battery. 4. Plug in the power cord and restart your computer. •• Always turn off your computer and unplug the power cord before replacing the battery.

•• Replace the battery with an equivalent one. Danger of explosion if the battery is replaced with an incorrect model. •• Contact the place of purchase or local dealer if you are not able to replace the battery by yourself or uncertain about the battery model. •• When installing the battery, note the orientation of the positive side (+) and the negative side (-) of the battery (the positive side should face up). •• Used batteries must be handled in accordance with local environmental regulations.

- 31 Hardware Installation 16) CLR_CMOS (Clear CMOS Jumper) Use this jumper to clear the BIOS configuration and reset the CMOS values to factory defaults. To clear the CMOS values, use a metal object like a screwdriver to touch the two pins for a few seconds. Open: Normal Short: Clear CMOS Values

•• Always turn off your computer and unplug the power cord from the power outlet before clearing the CMOS values. •• After system restart, go to BIOS Setup to load factory defaults (select Load Optimized Defaults) or manually configure the BIOS settings (refer to Chapter 2, "BIOS Setup," for BIOS configurations).

Hardware Installation - 32 - Chapter 2 BIOS Setup BIOS (Basic Input and Output System) records hardware parameters of the system in the CMOS on the motherboard. Its major functions include conducting the Power-On Self-Test (POST) during system startup, saving system parameters and loading operating system, etc. BIOS includes a BIOS Setup program that allows the user to modify basic system configuration settings or to activate certain system features. When the power is turned off, the battery on the motherboard supplies the necessary power to the CMOS to keep the configuration values in the CMOS. To access the BIOS Setup program, press the <Delete> key during the POST when the power is turned on. To upgrade the BIOS, use either the GIGABYTE Q-Flash or @BIOS utility.

•• Q-Flash allows the user to quickly and easily upgrade or back up BIOS without entering the operating system. •• @BIOS is a Windows-based utility that searches and downloads the latest version of BIOS from the Internet and updates the BIOS. •• Because BIOS flashing is potentially risky, if you do not encounter problems using the current version of BIOS, it is recommended that you not flash the BIOS. To flash the BIOS, do it with caution. Inadequate BIOS flashing may result in system malfunction. •• It is recommended that you not alter the default settings (unless you need to) to prevent system instability or other unexpected results. Inadequately altering the settings may result in system's failure to boot. If this occurs, try to clear the CMOS values and reset the board to default values. (Refer to the "Load Optimized Defaults" section in this chapter or introductions of the battery/clear CMOS jumper in Chapter 1 for how to clear the CMOS values.)

- 33 - BIOS Setup 2-1 Startup Screen The following startup Logo screen will appear when the computer boots.

Function Keys Function Keys: : BIOS SETUP\Q-FLASH Press the <Delete> key to enter BIOS Setup or to access the Q-Flash utility in BIOS Setup. <F9>: SYSTEM INFORMATION Press the <F9> key to display your system information. <F12>: BOOT MENU Boot Menu allows you to set the first boot device without entering BIOS Setup. In Boot Menu, use the up arrow key <h> or the down arrow key <i> to select the first boot device, then press <Enter> to accept. The system will boot from the device immediately.

Note: The setting in Boot Menu is effective for one time only. After system restart, the device boot order will still be based on BIOS Setup settings. <END>: Q-

FLASH Press the <End> key to access the Q-Flash utility directly without having to enter BIOS Setup first. BIOS Setup - 34 - 2-2 The Main Menu A. Startup Guide (Default) The Startup Guide screen simplifies conventional complicated BIOS setup menus and presents only the most frequently used options in the easy-to-use interface.

It helps first-time users to perform basic system setups more quickly and easily. B. ST Mode (Smart Tweak Mode) Differing from traditional UEFI interface, the ST Mode provides a fancy and user-friendly BIOS environment where users can easily point and click through various settings and make adjustments for optimum performance. In ST Mode, you can use your mouse to move through the option menus for quick configuration or press <F2> to switch to the traditional BIOS Setup screen. •• When the system is not stable as usual, select the Load Optimized Defaults item to set your system to its defaults. •• The BIOS Setup menus described in this chapter are for reference only and may differ by BIOS version.

- 35 BIOS Setup C. Classic Setup Classic Setup is the conventional BIOS Setup interface where you can press the arrow keys on your keyboard to move among the items and press <Enter> to accept or enter a submenu. Or you can use your mouse to select the item you want. (Sample BIOS Version: F1) Setup Menu Switch to ST Mode Enter Q-Flash Select Default Language Help Function Keys Configuration Items Current Settings Classic Setup Function Keys <f><g> <h><i> <Enter> <+>/<Page Up> <->/<Page Down> <F2> <F5> <F7> <F8> <F9> <F10> <F12> <Esc> Move the selection bar to select a setup menu Move the selection bar to select an

configuration item on a menu Execute command or enter a menu Increase the numeric value or make changes Decrease the numeric value or make changes Switch to ST Mode or Startup Guide screen Restore the previous BIOS settings for the current submenus Load the Optimized BIOS default settings for the current submenus Access the Q-Flash utility Display system information Save all the changes and exit the BIOS Setup program Capture the current screen as an image and save it to your USB drive Main Menu: Exit the BIOS Setup program Submenus: Exit current submenu BIOS Setup - 36 - BIOS Setup Menus □□

M.



[You're reading an excerpt. Click here to read official GIGABYTE GA-Z97MX-GAMING 5 user guide](http://yourpdfguides.com/dref/5585592)
<http://yourpdfguides.com/dref/5585592>

I.T. System Information Use this menu to configure the clock, frequency, and voltages of your CPU and memory, etc. Or check the system/CPU temperatures, voltages, and fan speeds. Use this menu to configure the default language used by the BIOS and system time and date. Use this menu to configure the device boot order and advanced features available on the CPU. BIOS Features Peripherals Power Management Use this menu to configure all peripheral devices, such as SATA, USB, integrated audio, and integrated LAN, etc. Use this menu to configure all the power-saving functions. Save & Exit Save all the changes made in the BIOS Setup program to the CMOS and exit BIOS Setup. You can save the current BIOS settings to a profile or load optimized defaults for optimal-performance system operations.

- 37 - BIOS Setup 2-3 M.I.T. Whether the system will work stably with the overclock/overvoltage settings you made is dependent on your overall system configurations. Incorrectly doing overclock/overvoltage may result in damage to CPU, chipset, or memory and reduce the useful life of these components.

This page is for advanced users only and we recommend you not to alter the default settings to prevent system instability or other unexpected results. (Inadequately altering the settings may result in system's failure to boot. If this occurs, clear the CMOS values and reset the board to default values.) This section provides information on the BIOS version, CPU base clock, CPU frequency, memory frequency, total memory size, CPU temperature, Vcore, and memory voltage. BIOS Setup - 38 - ``M.

I.T. Current Status This screen provides information on CPU/memory frequencies/parameters. ``Advanced Frequency Settings && Performance Upgrade (Note) && CPU Base Clock Provides you with five different overclocking configurations. Options are: 20% Upgrade, 40% Upgrade, 60% Upgrade, 80% Upgrade, 100% Upgrade. (Default: Auto) Allows you to manually set the CPU base clock in 0.01 MHz increments. (Default: Auto) Important: It is highly recommended that the CPU frequency be set in accordance with the CPU specifications. Allows you to manually set the host clock frequency (which controls CPU, PCIe, and memory frequencies) in 0.01 MHz increments.

This item is configurable only when CPU Base Clock is set to Manual. Allows you to configure the Processor Base Clock by multiplying the Host/PCIe Clock Frequency by several preset host clock multipliers. This item is configurable only when CPU Base Clock is set to Manual. Enables or disables CPU/PCIe Spread Spectrum. (Default: Auto) && Host/PCIe Clock Frequency (Note) && Processor Base Clock (Gear Ratio) (Note) && Spread Spectrum Control (Note) && Host Clock Value && Processor Graphics Clock This value is determined by multiplying the Host/PCIe Clock Frequency value by the Processor Base Clock (Gear Ratio) value. Allows you to set the onboard graphics clock. The adjustable range is from 400 MHz to 4000 MHz. (Default: Auto) This item is present only when you install a CPU that supports this feature. For more information about Intel® CPUs' unique features, please visit Intel's website. - 39 BIOS Setup (Note) && CPU Upgrade (Note) && CPU Clock Ratio Allows you to set the CPU frequency.

Options may vary depending on the CPU being used. (Default: Auto) && CPU Frequency Allows you to alter the clock ratio for the installed CPU. The adjustable range is dependent on the CPU being installed. Displays the current operating CPU frequency. ``Advanced CPU Core Settings && CPU Clock Ratio, CPU Frequency && K OC (Note) The settings above are synchronous to those under the same items on the Advanced Frequency Settings menu. Allows for increased performance by using certain CPUs. (Default: Auto) Allows you to set the CPU PLL. Auto lets the BIOS automatically configure this setting. (Default: Auto) Allows you to set the Filter PLL. Auto lets the BIOS automatically configure this setting.

(Default: Auto) Allows you to set the CPU Uncore ratio. The adjustable range is dependent on the CPU being used. Displays the current CPU Uncore frequency. && CPU PLL Selection && Filter PLL Level && Uncore Ratio && Uncore Frequency && Intel(R) Turbo Boost Technology (Note) Allows you to determine whether to enable the Intel CPU Turbo Boost technology. Auto lets the BIOS automatically configure this setting. (Default: Auto) (Note) This item is present only when you install a CPU that supports this feature. For more information about Intel® CPUs' unique features, please visit Intel's website. - 40 - BIOS Setup && Turbo Ratio (1-Core Active~4-Core Active) (Note) && Turbo Power Limit (Watts) Allows you to set the CPU Turbo ratios for different number of active cores. Auto sets the CPU Turbo ratios according to the CPU specifications. (Default: Auto) Allows you to set a power limit for CPU Turbo mode.

When the CPU power consumption exceeds the specified power limit, the CPU will automatically reduce the core frequency in order to reduce the power. Auto sets the power limit according to the CPU specifications. (Default: Auto) Allows you to set a current limit for CPU Turbo mode. When the CPU current exceeds the specified current limit, the CPU will automatically reduce the core frequency in order to reduce the current. Auto sets the power limit according to the CPU specifications. (Default: Auto) Allows you to select the number of CPU cores to enable in an Intel® multi-core CPU (the number of CPU cores may vary by CPU). Auto lets the BIOS automatically configure this setting. (Default: Auto) Allows you to determine whether to enable multi-threading technology when using an Intel® CPU that supports this function. This feature only works for operating systems that support multi-processor mode. Auto lets the BIOS automatically configure this setting.

(Default: Auto) Enables or disables Intel® CPU Enhanced Halt (C1E) function, a CPU power-saving function in system halt state. When enabled, the CPU core frequency and voltage will be reduced during system halt state to decrease power consumption. Auto lets the BIOS automatically configure this setting. (Default: Auto) Allows you to determine whether to let the CPU enter C3 mode in system halt state. When enabled, the CPU core frequency and voltage will be reduced during system halt state to decrease power consumption.

The C3 state is a more enhanced power-saving state than C1. Auto lets the BIOS automatically configure this setting. (Default: Auto) Allows you to determine whether to let the CPU enter C6/C7 mode in system halt state. When enabled, the CPU core frequency and voltage will be reduced during system halt state to decrease power consumption. The C6/C7 state is a more enhanced power-saving state than C3.

Auto lets the BIOS automatically configure this setting.



[You're reading an excerpt. Click here to read official GIGABYTE GA-Z97MX-GAMING 5 user guide](http://yourpdfguides.com/dref/5585592)
<http://yourpdfguides.com/dref/5585592>

(Default: Auto) Enables or disables Intel® Thermal Monitor function, a CPU overheating protection function. When enabled, the CPU core frequency and voltage will be reduced when the CPU is overheated. Auto lets the BIOS automatically configure this setting. (Default: Auto) Enables or disables Enhanced Intel® Speed Step Technology (EIST). Depending on CPU loading, Intel EIST technology can dynamically and effectively lower the CPU voltage and core frequency to decrease average power consumption and heat production. Auto lets the BIOS automatically configure this setting. (Default: Auto) && Core Current Limit (Amps) && No. of CPU Cores Enabled (Note) && Hyper-Threading Technology (Note) && CPU Enhanced Halt (C1E) (Note) && C3 State Support (Note) && C6/C7 State Support (Note) && CPU Thermal Monitor (Note) && CPU EIST Function (Note) (Note) This item is present only when you install a CPU that supports this feature. For more information about Intel® CPUs' unique features, please visit Intel's website.

- 41 BIOS Setup && Extreme Memory Profile (X.M.P.) (Note) && System Memory Multiplier Allows the BIOS to read the SPD data on XMP memory module(s) to enhance memory performance when enabled. Disabled Disables this function. (Default) Profile1 Uses Profile 1 settings. Profile2 (Note) Uses Profile 2 settings. Allows you to set the system memory multiplier. Auto sets memory multiplier according to memory SPD data. (Default: Auto) The first memory frequency value is the normal operating frequency of the memory being used; the second is the memory frequency that is automatically adjusted according to the System Memory Multiplier settings.

&& Memory Frequency (MHz) ``Advanced Memory Settings && Extreme Memory Profile (X.M.P.) (Note), System Memory Multiplier, Memory Frequency(MHz) && Memory Overclocking Profiles (Note) The settings above are synchronous to those under the same items on the Advanced Frequency Settings menu. Allows you to set the memory frequency.

Options may vary depending on the memory being used. (Default: Disabled) Provides memory detection and training methods. Auto Lets the BIOS automatically configure this setting. (Default) Enable Fast Boot kip memory detection and training in some specific criteria for faster memory S boot. Disable Fast Boot Detect and train memory at every single boot.

&& Memory Boot Mode (Note) This item is present only when you install a CPU and a memory module that support this feature. - 42 - BIOS Setup && Memory Enhancement Settings && Memory Timing Mode Provides three different memory performance enhancement settings: Normal (basic performance), Enhanced Stability, and Enhanced Performance. (Default: Normal) Manual and Advanced Manual allows the Channel Interleaving, Rank Interleaving, and memory timing settings below to be configurable. Options are: Auto (default), Manual, Advanced Manual. When using a non-XMP memory module or Extreme Memory Profile (X.M.P.) is set to Disabled, the value is displayed according to your memory specification. When Extreme Memory Profile (X.M.

P.) is set to Profile1 or Profile2, the value is displayed according to the SPD data on the XMP memory. Enables or disables memory channel interleaving. Enabled allows the system to simultaneously access different channels of the memory to increase memory performance and stability. Auto lets the BIOS automatically configure this setting. (Default: Auto) Enables or disables memory rank interleaving. Enabled allows the system to simultaneously access different ranks of the memory to increase memory performance and stability. Auto lets the BIOS automatically configure this setting. (Default: Auto) Channel A/B Memory Sub Timings && Profile DDR Voltage && Channel Interleaving && Rank Interleaving ``This sub-menu provides memory timing settings for each channel of memory. This sub-menu provides memory timing settings for each channel of memory.

The respective timing setting screens are configurable only when Memory Timing Mode is set to Manual or Advanced Manual. Note: Your system may become unstable or fail to boot after you make changes on the memory timings. If this occurs, please reset the board to default values by loading optimized defaults or clearing the CMOS values. - 43 - BIOS Setup ``Advanced Voltage Settings ``Advanced Power Settings && CPU VRIN Loadline Calibration Allows you to set the Load-Line Calibration level for the CPU VRIN. The levels are (from highest to lowest): Extreme, Turbo, High, Medium, Low, and Standard.

Selecting a higher level keeps the Vcore more consistent with what is set in BIOS under heavy load. Auto lets the BIOS automatically configure this setting and sets the voltage following Intel's specifications. (Default: Auto) BIOS Setup - 44 - && CPU VRIN Protection && CPU VRIN Current Protection Allows you to set the voltage limit on the CPU VRIN voltage for over-voltage protection. The adjustable range is from 150.0mV to 500.

0mV. Auto lets the BIOS automatically configure this setting. (Default: Auto) Allows you to set the over-current protection level for the CPU VRIN voltage. Auto Lets the BIOS automatically configure this setting. (Default) Standard-Extreme Selects Standard, Low, Medium, High, Turbo, or Extreme which represents different level of over-current protection for the Vcore. Displays the PWM thermal protection threshold for the CPU VRIN area. Displays the CPU VRIN PWM frequency. && CPU VRIN PWM Thermal Protection && CPU VRIN PWM Switch Rate && PWM Phase Control Allows you to automatically change the PWM phase according to the CPU load. The power-saving levels are (from lowest to highest): eXm Perf (Extreme Performance), High Perf (High Performance), Perf (Performance), Balanced, Mid PWR (Mid Power), and Lite PWR (Light Power). Auto lets the BIOS automatically configure this setting.

(Default: Auto) ``CPU Core Voltage Control ``Chipset Voltage Control ``DRAM Voltage Control This section provides CPU voltage control options. This section provides Chipset voltage control options. This section provides memory voltage control options. - 45 - BIOS Setup ``PC Health Status && Reset Case Open Status && Case Open Disabled Keeps or clears the record of previous chassis intrusion status. (Default) Enabled Clears the record of previous chassis intrusion status and the Case Open field will show "Close" at next boot. Displays the detection status of the chassis intrusion detection device attached to the motherboard CI header. If the system chassis cover is removed, this field will show "Yes", otherwise it will show "No". To clear the chassis intrusion status record, set Reset Case Open Status to Enabled, save the settings to the CMOS, and then restart your system.



[You're reading an excerpt. Click here to read official GIGABYTE GA-Z97MX-GAMING 5 user guide](http://yourpdfguides.com/dref/5585592)
<http://yourpdfguides.com/dref/5585592>

BIOS Setup - 46 - && CPU Vcore/CPU VRIN/DRAM Voltage/+3.3V/+5V/+12V/CPU VAXG && CPU/System/PCH Temperature Displays the current system voltages.

&& CPU/CPU OPT/System Fan Speed Displays current CPU/Chipset/System temperature. Displays current CPU/CPU_OPT/system fan speeds. && CPU/System Temperature Warning && CPU/CPU OPT/System Fan Fail Warning Sets the warning threshold for CPU/system temperature. When temperature exceeds the threshold, BIOS will emit warning sound. Options are: Disabled (default), 60oC/140oF, 70oC/158oF, 80oC/176oF, 90oC/194oF. && CPU Fan Speed Control (CPU_FAN Connector) Allows the system to emit warning sound if the fan is not connected or fails. Check the fan condition or fan connection when this occurs. (Default: Disabled) Allows you to determine whether to enable the fan speed control function and adjust the fan speed. Normal Allows the fan to run at different speeds according to the CPU temperature. You can adjust the fan speed with EasyTune based on your system requirements.

(Default) Silent Allows the fan to run at slow speeds. Manual Allows you to control the fan speed under the Fan Speed Percentage item. Full Speed Allows the fan to run at full speeds. Allows you to control the fan speed. This item is configurable only when CPU Fan Speed Control is set to Manual. Options are: 0.75 PWM value /oC ~ 2.50 PWM value /oC. Allows you to determine whether to enable the fan speed control function and adjust the fan speed. Normal Allows the fan to run at different speeds according to the CPU temperature.

You can adjust the fan speed with EasyTune based on your system requirements. (Default) Silent Allows the fan to run at slow speeds. Manual Allows you to control the fan speed under the Slope PWM item. Full Speed Allows the fan to run at full speeds. Allows you to control the fan speed. This item is configurable only when CPU OPT Fan Speed Control is set to Manual. Options are: 0.75 PWM value /oC ~ 2.50 PWM value /oC. Allows you to determine whether to enable the fan speed control function and adjust the fan speed.

Normal Allows the fan to run at different speeds according to the system temperature. You can adjust the fan speed with EasyTune based on your system requirements. (Default) Silent Allows the fan to run at slow speeds. Manual Allows you to control the fan speed under the Fan Speed Percentage item. Full Speed Allows the fan to run at full speeds.

Allows you to control the fan speed. This item is configurable only when 1st System Fan Speed Control is set to Manual. Options are: 0.75 PWM value /oC ~ 2.50 PWM value /oC.

&& Fan Speed Percentage && CPU OPT Fan Speed Control (CPU_OPT Connector) && Fan Speed Percentage && 1st System Fan Speed Control (SYS_FAN1 Connector) && Fan Speed Percentage - 47 - BIOS Setup && 2nd System Fan Speed Control (SYS_FAN2 Connector) && Fan Speed Percentage Allows you to determine whether to enable the fan speed control function and adjust the fan speed. Normal Allows the fan to run at different speeds according to the system temperature. You can adjust the fan speed with EasyTune based on your system requirements. (Default) Silent Allows the fan to run at slow speeds. Manual Allows you to control the fan speed under the Fan Speed Percentage item. Full Speed Allows the fan to run at full speeds. Allows you to control the fan speed. This item is configurable only when 2nd System Fan Speed Control is set to Manual. Options are: 0.75 PWM value /oC ~ 2.50 PWM value /oC. Allows you to determine whether to enable the fan speed control function and adjust the fan speed. Normal Allows the fan to run at different speeds according to the system temperature. You can adjust the fan speed with EasyTune based on your system requirements. (Default) Silent Allows the fan to run at slow speeds. Manual Allows you to control the fan speed under the Fan Speed Percentage item. Full Speed Allows the fan to run at full speeds. Allows you to control the fan speed. This item is configurable only when 3rd System Fan Speed Control is set to Manual. Options are: 0.75 PWM value /oC ~ 2.50 PWM value /oC. && 3rd System Fan Speed Control (SYS_FAN3 Connector) && Fan Speed Percentage BIOS Setup - 48 - ``

Miscellaneous Settings && PCIe Slot Configuration && DMI Gen2 Speed Allows you to set the operation mode of the PCI Express slots to Gen 1, Gen 2, or Gen 3. Actual operation mode is subject to the hardware specification of each slot. Auto lets the BIOS automatically configure this setting. (Default: Auto) Allows you to configure the DMI link speed. Auto Lets the BIOS automatically configure this setting. Enabled Sets the DMI link speed to Gen 2. (Default) Disabled Sets the DMI link speed to Gen 1. Allows you to determine whether to enhance some legacy benchmark performance. (Default: Disabled) && 3DMark01 Boost - 49 - BIOS Setup 2-4 System Information This section provides information on your motherboard model and BIOS version. You can also select the default language used by the BIOS and manually set the system time. && System Language && System Date Selects the default language used by the BIOS. && System Time Sets the system date. The date format is week (read-only), month, date, and year. Use <Enter> to switch between the Month, Date, and Year fields and use the <Page Up> or <Page Down> key to set the desired value. Sets the system time. The time format is hour, minute, and second. For example, 1 p.m.

is 13:0:0. Use <Enter> to switch between the Hour, Minute, and Second fields and use the <Page Up> or <Page Down> key to set the desired value. Displays the current access level depending on the type of password protection used. (If no password is set, the default will display as Administrator.) The Administrator level allows you to make changes to all BIOS settings; the User level only allows you to make changes to certain BIOS settings but not all. && Access Level BIOS Setup - 50 - 2-5 BIOS Features && Boot Option Priorities && Bootup NumLock State Specifies the overall boot order from the available devices. Removable storage devices that support GPT format will be prefixed with "UEFI:" string on the boot device list. To boot from an operating system that supports GPT partitioning, select the device prefixed with "UEFI:" string. Or if you want to install an operating system that supports GPT partitioning such as Windows 7 64-bit, select the optical drive that contains the Windows 7 64-bit installation disk and is prefixed with "UEFI:" string. Enables or disables Numlock feature on the numeric keypad of the keyboard after the POST. (Default: Enabled) - 51 BIOS Setup && Security Option && Full Screen LOGO Show Specifies whether a password is required every time the system boots, or only when you enter BIOS Setup.



[You're reading an excerpt. Click here to read official GIGABYTE GA-Z97MX-GAMING 5 user guide](http://yourpdfguides.com/dref/5585592)
<http://yourpdfguides.com/dref/5585592>