



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HITACHI DESKSTAR 120GXP. You'll find the answers to all your questions on the HITACHI DESKSTAR 120GXP in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HITACHI DESKSTAR 120GXP
User guide HITACHI DESKSTAR 120GXP
Operating instructions HITACHI DESKSTAR 120GXP
Instructions for use HITACHI DESKSTAR 120GXP
Instruction manual HITACHI DESKSTAR 120GXP

Hitachi Global Storage Technologies

Quick installation guide Hitachi Deskstar 120GXP Ultra ATA/100 Hard disk drive



Models: IC35L020AVVN07
IC35L020AVVA07
IC35L040AVVN07
IC35L040AVVA07
IC35L060AVVA07
IC35L080AVVA07
IC35L100AVVA07
IC35L120AVVA07

System requirements for Ultra ATA/100

If you do not have the components listed below, your drive will function but at speeds lower than 100 MB/s.

- 40-pin, 80-conductor cable
- A controller card or motherboard chipset with Ultra ATA/100 capability
- Ultra ATA/100 compatible BIOS or driver

Handling precautions

- Set the drive down gently to prevent damage from impact or vibration.
- Do not open the ESD bag containing the drive until needed.
- Handle the drive carefully by the edges. Do not touch the exposed printed circuit board or any electronic components.
- Do not press on the top or bottom of the drive.
- Do not cover the drive breather hole.
- Before handling the drive, discharge any static electricity from yourself and your clothing. With one hand touch an unpainted metal surface on your computer chassis, then touch the ESD bag with the other hand. Remain in contact with the chassis and the bag for a minimum of two seconds.

Quick installation procedure

Note: Back up all data before installing drive!

1. Turn off the computer.
2. Remove the computer cover as instructed by the computer system manual.
3. Discharge static electricity (see Handling precautions).
4. Unplug the computer.
5. Note the mounting position of existing drives and cables. If you are replacing a drive or any cable, remove it now.
6. Remove the drive from the ESD bag.
7. Record the model, the part number, and the serial number of the drive for future reference.
8. Insert the required jumpers. Refer to the jumper block diagram below.
 - If the drive is the only drive on a cable or the master drive on a two-drive cable, leave the jumpers as set at A-B and G-H for 16-head logical architecture. The jumpers are factory-set to Master-16 heads.
 - If the drive is the slave drive on a two-drive cable, set the jumpers at A-B and C-D for 16-head logical architecture.



[You're reading an excerpt. Click here to read official HITACHI DESKSTAR 120GXP user guide](http://yourpdfguides.com/dref/2839504)
<http://yourpdfguides.com/dref/2839504>

Manual abstract:

2. 3. 4. 5. Turn off the computer. Remove the computer cover as instructed by the computer system manual. Discharge static electricity (see Handling precautions). Unplug the computer. Note the mounting position of existing drives and cables. If you are replacing a drive or any cable, remove it now. Remove the drive from the ESD bag. Record the model, the part number, and the serial number of the drive for future reference. Insert the required jumpers. Refer to the jumper block diagram below. · If the drive is the only drive on a cable or the master drive on a two-drive cable, leave the jumpers as set at A-B and G-H for 16 head logical architecture.

The jumpers are factory-set to Master-16 heads. · If the drive is the slave drive on a two-drive cable, set the jumpers at A-B and C-D for 16-head logical architecture. I G H E F C D A B Handling precautions Set the drive down gently to prevent damage from impact or vibration. Do not open the ESD bag containing the drive until needed. Handle the drive carefully by the edges.

Do not touch the exposed printed circuit board or any electronic components. Do not press on the top or bottom of the drive. Do not cover the drive breather hole. Before handling the drive, discharge any static electricity from yourself and your clothing. @@@@6. 7. @@@@The pin 1 side of the IDE cable is marked with a stripe. The connector can only be inserted one way. @@@@Actual results may vary. This publication is for general guidance only.

Photographs may show design models. 11 June 2003 10. Attach the power supply cable to the drive. Match the connector bevels. 11. Mount the drive securely. 12. Verify all attachments. 13. Replace the computer cover.

14. Plug in the computer. 15. @@16. Verify that the hard disk is recognized by the BIOS and is reporting the full capacity of the drive.

Instructions for accessing your BIOS can be found in the computer system manual or in the motherboard manufacturer documentation. If the drive is not recognized in the BIOS, set the BIOS options of your computer system to Auto Detection and LBA mode if available. Once the drive is recognized correctly in the BIOS, it is ready to be partitioned and formatted. 17. @@For additional information, see: www.

hgst.com/support 18. Once the operating system is installed, reboot the system. If the system does not boot up, check all the settings and try again. .



[You're reading an excerpt. Click here to read official HITACHI](http://yourpdfguides.com/dref/2839504)

[DESKSTAR 120GXP user guide](http://yourpdfguides.com/dref/2839504)

<http://yourpdfguides.com/dref/2839504>