



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HUSQVARNA 333 R. You'll find the answers to all your questions on the HUSQVARNA 333 R in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HUSQVARNA 333 R
User guide HUSQVARNA 333 R
Operating instructions HUSQVARNA 333 R
Instructions for use HUSQVARNA 333 R
Instruction manual HUSQVARNA 333 R

Operator's manual (EPA)
333R 335FR 335RX-series

Please read the operator's manual carefully and make sure you understand the instructions before using the machine.



English



[You're reading an excerpt. Click here to read official HUSQVARNA 333 R user guide](http://yourpdfguides.com/dref/4739217)
<http://yourpdfguides.com/dref/4739217>

Manual abstract:

e. @@@@speed of output shaft, rpm Other symbols/decals on the machine refer to special certification requirements for certain markets. The engine is switched off by moving the stop switch to the stop position. CAUTION! The stop switch automatically returns to the start position. In order to prevent unintentional starting, the spark plug cap must be removed from the spark plug when assembling, checking and/or performing maintenance. Watch out for thrown objects and ricochets. The operator of the machine must ensure, while working, that no persons or animals come closer than 15 metres. 15 m 50FT 15 m 50FT Machines fitted with saw blades or grass blades can be thrown violently to the side when the blade comes into contact with a fixed object. The blade is capable of amputating an arm or leg. Always keep people and animals at least 15 metres from the machine.

Arrows which show limits for handle positioning. Always wear approved protective gloves. Regular cleaning is required. Visual check. Always wear approved protective gloves.

Approved eye protection must always be used. Wear sturdy, non-slip boots. The engine exhaust from this product contains chemical known to the State of California to cause cancer, birth defects or other reproductive harm. 2 – English CONTENTS Contents KEY TO SYMBOLS Symbols CONTENTS Contents

Note the following before starting: INTRODUCTION Dear customer! WHAT IS WHAT? What is what on the clearing saw? GENERAL SAFETY PRECAUTIONS Important Personal protective equipment Machine's safety equipment Cutting equipment ASSEMBLY Assembling the handlebar and throttle

Assembling the cutting equipment Fitting the guard extension Fitting a blade guard, grass blade and grass cutter Fitting the blade guard and saw blade Fitting other guards and cutting attachments Adjusting the harness and clearing saw Standard harness Triobalance harness FUEL HANDLING Fuel safety

Fuel Fueling STARTING AND STOPPING Check before starting Starting and stopping WORKING TECHNIQUES General working instructions MAINTENANCE Carburetor Muffler Cooling system Bevel gear Air filter Spark plug Maintenance schedule TECHNICAL DATA Technical data FEDERAL

AND CALIFORNIA EMISSIONS CONTROL WARRANTY STATEMENT YOUR WARRANTY RIGHTS AND OBLIGATIONS 2 3 3 4 5 6 7 10 13 13 13 14 14 15 16 16 18 18 19 20 20 22 26 28 29 29 29 30 31 32 The Emissions Compliance Period referred to on the emissions compliance label indicates the number of operating hours for which the engine has shown to meet Federal and Californian emission requirements. Note the following before starting: Please read

the operator's manual carefully.

Maintenance, replacement, or repair of the emission control devices and system may be performed by any nonroad engine repair establishment or individual.

!! WARNING! Long-term exposure to noise can result in permanent hearing impairment. So always use approved hearing protection. WARNING! Under no circumstances may the design of the machine be modified without the permission of the manufacturer. Always use genuine accessories. Non-authorized modifications and/or accessories can result in serious personal injury or the death of the operator or others. Your warranty may not cover damage or liability

caused by the use of nonauthorized accessories or replacement parts. WARNING! A clearing saw, brushcutter or trimmer can be dangerous if used incorrectly or carelessly, and can cause serious or fatal injury to the operator or others. It is extremely important that you read and understand the contents of this operator's manual. ! 34 English – 3 INTRODUCTION Dear customer! Congratulations on your choice to buy a Husqvarna product! Husqvarna is

based on a tradition that dates back to 1689, when the Swedish King Karl XI ordered the construction of a factory on the banks of the Huskvarna River, for production of muskets.

The location was logical, since water power was harnessed from the Huskvarna River to create the waterpowered plant. During over 300 years of continuous operation, the Husqvarna factory has produced a lot of different products, from wood stoves to modern kitchen appliances, sewing machines, bicycles, motorcycles etc. In 1956, the first motor driven lawn mowers appeared, followed by chain saws in 1959, and it is within this area Husqvarna is working today.

Today Husqvarna is one of the leading manufacturers in the world of forest and garden products, with quality as our highest priority. We develop, manufacture and market high quality motor driven products for forestry and gardening as well as for building and construction industry. Your purchase gives you access to professional help with repairs and service whenever this may be necessary. If the retailer who sells your machine is not one of our authorized dealers, ask for the address of your nearest servicing dealer. It is our wish that you will be satisfied with your product and that it will be your companion for a long time. Think of this operator's manual as a valuable document. By following its' content (using, service, maintenance etc) the life span and the second-hand value of the machine can be extended.

If you ever lend or sell this machine, make sure that the borrower or buyer gets the operator's manual, so they will also know how to properly maintain and use it. Thank you for using a Husqvarna product. Husqvarna AB has a policy of continuous product development and therefore reserves the right to modify the design and appearance of products without prior notice. For customer assistance, contact us at our website: www.usa.husqvarna.com

4 – English WHAT IS WHAT? 8 3 1 2 7 9 17 4 5 33 19 20 22 21 21 4 25 24 4 28 32 27 23 26 33 13 15 18 6 1 31 10 29 14 11 12 16 30 17 335FR 333R What is what on the clearing saw? 1 2 3 4 5 6 7 8 9 Trimmer head Grease filler cap, bevel gear Bevel gear Cutting attachment guard Shaft Handlebar Throttle control Stop switch Throttle lockout 18 Locking nut 19 Support flange 20 Support cup 21 Drive disc 22 Blade 23 Socket spanner 24 Operator's manual 25 Transport guard 26 Allen key 27 Locking pin 28 Harness 29 Spark plug cap and spark plug 30 Start throttle button 31 Adjusting screw for throttle cable 32 Spark plug spanner 33 Guard extension 10 Suspension 11 Cylinder cover 12 Starter handle 13 Fuel tank 14 Choke control 15 Air purge 16 Air filter cover 17 Handle adjustment English – 5 GENERAL SAFETY PRECAUTIONS Important IMPORTANT! The machine is only designed for trimming grass, grass clearing and/or forestry clearing. The only accessories you can operate with this engine unit are the cutting attachments we recommend in the chapter on Technical data. Never use the machine if you are tired, if you have drunk alcohol, or if you are taking medication that could affect your vision, your judgement or your co-ordination. Wear personal protective equipment.

See instructions under the heading Personal protective equipment. Never use a machine that has been modified in any way from its original specification.



[You're reading an excerpt. Click here to read official HUSQVARNA](#)

[333 R user guide](#)

<http://yourpdfguides.com/dref/4739217>

Never use a machine that is faulty. Carry out the checks, maintenance and service instructions described in this manual. Some maintenance and service measures must be carried out by trained and qualified specialists. See instructions under the heading Maintenance. All covers, guards and handles must be fitted before starting. Ensure that the spark plug cap and ignition lead are undamaged to avoid the risk of electric shock. The machine operator must ensure that no people or animals come closer than 15 metres while working. When several operators are working in the same area the safety distance should be at least twice the tree height and no less than 15 metres.

WARNING! The ignition system of this machine produces an electromagnetic field during operation. This field may under some circumstances interfere with pacemakers. To reduce the risk of serious or fatal injury, we recommend persons with pacemakers to consult their physician and the pacemaker manufacturer before operating this machine. **WARNING!** Running an engine in a confined or badly ventilated area can result in death due to asphyxiation or carbon monoxide poisoning. **WARNING!** Never allow children to use or be in the vicinity of the machine. As the machine is equipped with a springloaded stop switch and can be started by low speed and force on the starter handle, even small children under some circumstances can produce the force necessary to start the machine. This can mean a risk of serious personal injury. Therefore remove the spark plug cap when the machine is not under close supervision. **GLOVES**

Gloves should be worn when necessary, e.g.

, when fitting cutting attachments. Personal protective equipment **IMPORTANT!** A clearing saw, brushcutter or trimmer can be dangerous if used incorrectly or carelessly, and can cause serious or fatal injury to the operator or others. It is extremely important that you read and understand the contents of this operator's manual. You must use approved personal protective equipment whenever you use the machine. Personal protective equipment cannot eliminate the risk of injury but it will reduce the degree of injury if an accident does happen.

Ask your dealer for help in choosing the right equipment. **WARNING!** Listen out for warning signals or shouts when you are wearing hearing protection.

Always remove your hearing protection as soon as the engine stops. ! **HELMET** A helmet should be worn if the trees being cleared are taller than 2 m.

HEARING PROTECTION Wear hearing protection that provides adequate noise reduction.

! **EYE PROTECTION** Always wear approved eye protection. If you use a visor then you must also wear approved protective goggles. Approved protective goggles must comply with standard ANSI Z87.1 in the USA or EN 166 in EU countries. ! ! 6 – English **GENERAL SAFETY PRECAUTIONS BOOTS** Wear boots with steel toe-caps and non-slip sole. the throttle control is automatically locked at the idle setting. A **B CLOTHING** Wear clothes made of a strong fabric and avoid loose clothing that can catch on twigs and branches. Always wear heavy, long pants. Do not wear jewellery, shorts sandals or go barefoot.

Secure hair so it is above shoulder level.

FIRST AID KIT Always have a first aid kit nearby. Make sure the throttle control is locked at the idle setting when the throttle lockout is released. Press the throttle lockout and make sure it returns to its original position when you release it. Machine's safety equipment This section describes the machine's safety equipment, its purpose, and how checks and maintenance should be carried out to ensure that it operates correctly. See the "What is what?" section to locate where this equipment is positioned on your machine. **IMPORTANT!** All servicing and repair work on the machine requires special training. This is especially true of the machine's safety equipment. If your machine fails any of the checks described below you must contact your service agent. When you buy any of our products we guarantee the availability of professional repairs and service. If the retailer who sells your machine is not a servicing dealer, ask him for the address of your nearest service agent.

WARNING! Never use a machine with faulty safety equipment. The machine's safety equipment must be checked and maintained as described in this section. If your machine fails any of these checks contact your service agent to get it repaired. Check that the throttle control and throttle lockout move freely and that the return springs work properly. ! See instructions under the heading Start.

Start the machine and apply full throttle. Release the throttle and check that the cutting attachment stops and remains at a standstill. If the cutting attachment rotates with the throttle in the idle position then the carburettor idle setting must be checked. See instructions under the heading Maintenance. Throttle lockout The throttle lockout is designed to prevent accidental operation of the throttle control.

When you press the lock (A) (i.e. when you grasp the handle) it reler start the machine indoors or near combustible material! ! For mufflers it is very important that you follow the instructions on checking, maintaining and servicing your machine. ! English – 9 **GENERAL SAFETY PRECAUTIONS Locking nut** ! A locking nut is used to secure some types of cutting attachment. **WARNING!** Always stop the engine before doing any work on the cutting attachment. This continues to rotate even after the throttle has been released. Ensure that the cutting attachment has stopped completely and disconnect the HT lead from the spark plug before you start to work on it. **WARNING!** Using an incorrect cutting attachment or an incorrectly sharpened blade increases the risk of blade thrust. ! When fitting, tighten the nut in the opposite direction to the direction of rotation of the cutting attachment. To remove it, undo the nut in the same direction as the cutting attachment rotates.

(**CAUTION!** The nut has a left-hand thread.) Tighten the nut using the socket spanner. Cutting equipment Saw blades are intended for cutting fibrous types of wood. Grass blades and grass cutters are intended for cutting coarse grass. The nylon lining inside the locking nut must not be so worn that you can turn it by hand. The lining should offer a resistance of at least 1.5 Nm. The nut should be replaced after it has been put on approx. 10 times. A trimmer head is intended for trimming grass.

Cutting equipment This section describes how to choose and maintain your cutting equipment in order to: ••• Reduce the risk of blade thrust. Obtain maximum cutting performance. Extend the life of cutting equipment. **IMPORTANT!** Only use cutting attachments with the guards we recommend! See the chapter on Technical data. Refer to the instructions for the cutting attachment to check the correct way to load the cord and the correct cord diameter.

Keep the teeth of the blade correctly sharpened! Follow our recommendations. Also refer to the instructions on the blade packaging.



[You're reading an excerpt. Click here to read official HUSQVARNA 333 R user guide](http://yourpdfguides.com/dref/4739217)
<http://yourpdfguides.com/dref/4739217>

Maintain the correct blade setting! Follow our instructions and use the recommended file gauge. Keep the teeth of the blade correctly sharpened! Follow our instructions and use the recommended file gauge. An incorrectly sharpened or damaged blade increases the risk of accidents.

Only use cutting attachments with the guards we recommend! See the chapter on Technical data. General rules 10 – English GENERAL SAFETY PRECAUTIONS Keep the correct setting on the saw blade! Follow our instructions and use the recommended setting tool. An incorrectly set saw blade increases the risk of jamming and blade thrust, and damage to the saw blade. A correctly sharpened blade is essential for working efficiently and to avoid unnecessary wear to the blade and clearing saw. Check the cutting attachment for damage or cracks. A damaged cutting attachment should always be replaced. • Make sure that the blade is well supported when you file it. Use a 5.5 mm round file with a file holder. Sharpening grass cutters and grass blades • See the cutting attachment packaging for correct sharpening instructions.

Sharpen blades and cutters using a single-cut flat file. Sharpen all edges equally to maintain the balance of the blade. The filing angle is 15°. File alternate teeth to the right and those in between to the left. If the blade has been heavily pitted by stones it may be necessary to dress the top edges of the teeth with a flat file, in exceptional cases. If so, this should be done before filing with a round file. The top edges must be filed down by the same amount for all the teeth. •! WARNING! Always discard a blade that is bent, twisted, cracked, broken or damaged in any other way. Never attempt to straighten a twisted blade so that it can be reused. Only use original blades of the specified type.

• Adjust the blade setting. This should be 1 mm. Sharpening the saw blade • See the cutting attachment packaging for correct sharpening instructions. English – 11 GENERAL SAFETY PRECAUTIONS Trimmer head IMPORTANT! Always ensure the trimmer cord is wound tightly and evenly around the drum, otherwise the machine will generate harmful vibration. • Only use the recommended trimmer heads and trimmer cords.

These have been tested by the manufacturer to suit a particular engine size. This is especially important when a fully automatic trimmer head is used. Only use the recommended cutting attachment. See the chapter on Technical data. • Smaller machines generally require small trimmer heads and vice versa. This is because when clearing using a cord the engine must throw out the cord radially from the trimmer head and overcome the resistance of the grass being cleared. The length of the cord is also important. A longer cord requires greater engine power than a shorter cord of the same diameter. Make sure that the cutter on the trimmer guard is intact. This is used to cut the cord to the correct length. To increase the life of the cord it can be soaked in water for a couple of days. This will make the line tougher so that it lasts longer. ••• 12 – English ASSEMBLY Assembling the handlebar and throttle Assembling the cutting equipment! •• Remove the screw at the rear of the throttle handle. Slide the throttle handle onto the right side of the handlebar, (see diagram). WARNING! When fitting the cutting attachment it is extremely important that the raised section on the drive disc/support flange engages correctly in the centre hole of the cutting attachment.

If the cutting attachment is fitted incorrectly it can result in serious and/or fatal personal injury. ••• Align the screw hole in the throttle handle with the hole in the handlebar. Refit the screw in the hole in the rear of the throttle handle. Screw the screw through the handle and handlebar. Tighten it. ! WARNING! Never use a cutting attachment without an approved guard. See the chapter on Technical data. If an incorrect or faulty guard is fitted this can cause serious personal injury. RX,FR R IMPORTANT! If a saw blade or grass blade are to be used the machine must be equipped with the correct handlebar, blade guard and harness. Fitting the guard extension ••• Fit the mounting components as shown.

Loosely tighten the four screws. (R) Put on the harness and hang the machine from the support hook. Now make a final adjustment so that the machine is in a comfortable working position when it hangs from the harness. Tighten the knob. (FR, RX) CAUTION! The guard extension shall always be fitted when using the trimmer head/plastic blades and combination guard.

The guard extension shall always be removed when using the grass blade and combination guard. Enter the guard extension guide in the slot of the combination guard. Then click the guard extension into position on the guard with the four quick-fasteners. • English – 13 ASSEMBLY The guard extension is removed easily using the spark plug spanner, see illustration. the spanner in the opposite direction to the direction of rotation (Caution! left-hand thread). Fitting a blade guard, grass blade and grass cutter Fitting the blade guard and saw blade F E K G D A B C H J A • Hook the blade guard/combination guard (A) onto the fitting on the shaft and secure with the bolt. CAUTION! Ensure that the guard extension is removed. Use the recommended blade guard. See the Technical data section. •• Fit the drive disc (B) on the output shaft. Turn the blade shaft until one of the holes in the drive disc aligns with the corresponding hole in the gear housing. Insert the locking pin (C) in the hole to lock the shaft. Place the blade (D), support cup (E) and support flange (F) on the output shaft. Fit the nut (G). The nut must be tightened to a torque of 35-50 Nm (3.5-5 kpm).

5-5 kpm). Use the socket spanner in the tool kit. Hold the shaft of the spanner as close to the blade guard as possible. To tighten the nut, turn the spanner in the opposite direction to the direction of rotation (Caution! left-hand thread). Fitting other guards and cutting attachments • Fit the trimmer guard/combination guard (A) intended for use with the trimmer head/plastic blades.

14 – English ASSEMBLY ••• Insert the locking pin (C) in the hole to lock the shaft. Place the blade (D) and support flange (F) on the output shaft. Fit the nut (G). The nut must be tightened to a torque of 35-50 Nm (3.5-5 kpm).

Use the socket spanner in the tool kit. Hold the shaft of the spanner as close to the blade guard as possible. To tighten the nut, turn the spanner in the opposite direction to the direction of rotation (Caution! left-hand thread). Fitting other guards and cutting attachments • Fit the trimmer guard/combination guard (A) intended for use with the trimmer head/plastic blades.



[You're reading an excerpt. Click here to read official HUSQVARNA](http://yourpdfguides.com/dref/4739217)

[333 R user guide](http://yourpdfguides.com/dref/4739217)

<http://yourpdfguides.com/dref/4739217>

CAUTION! Ensure that the guard extension is fitted.

Hang the trimmer guard/combination guard (A) on the two hooks on the plate holder (M). Bend the guard around the shaft and tighten it with the bolt (L) on the opposite side of the shaft. Use the locking pin (C). Place the locking pin in the groove on the screw head and tighten. See diagram. L M • When loosening and tightening the saw blade nut, there is a risk of injury from the teeth of the saw blade. You should therefore always ensure that your hand is shielded by the blade guard when doing this. Always use a socket spanner with a shaft that is long enough to allow this. The arrow in the diagram shows the area where you should operate the socket spanner when loosening or tightening the nut. C A • Fit the drive disc (B) on the output shaft.

H B C M • A L Turn the blade shaft until one of the holes in the drive disc aligns with the corresponding hole in the gear housing. Insert the locking pin (C) in the hole to lock the shaft. Screw on the trimmer head/plastic blades (H) in the opposite direction to the direction of rotation. • • H H • To dismantle, follow the instructions in the reverse order. English – 15 ASSEMBLY Adjusting the harness and clearing saw height using the strap on the harness for the support hook.

! **WARNING!** When using a clearing saw it must always be hooked securely to the harness. Otherwise you will be unable to control the clearing saw safely and this can result in injury to yourself or others. Never use a harness with a defective quick release. Standard harness 2 Grass clearing The machine should be supported in a harness when grass clearing so that the cutting equipment is parallel to the ground. Quick release At the front is an easily accessible, quick release.

Use this if the engine catches fire or in any other emergency situation that requires you to free yourself from the machine and harness. Triobalance harness Spreading the load on your shoulders A well-adjusted harness and machine makes work much easier. Adjust the harness for the best working position. Tension the side straps so that the weight is evenly distributed across both shoulders. Quick release Push down the red release lever to release the machine from the harness.

Adjusting the harness Correct height 1 Forestry clearing The machine should be supported in a harness when forestry clearing so that the cutting equipment is angled slightly forwards in relation to the ground. Adjust the 1 Tighten the hip strap so that it sits securely. 16 – English ASSEMBLY 2 Tighten the chest strap under your left arm so that it fits closely around your body. Correct balance 1 Forestry clearing The machine is balanced by moving the suspension ring on the machine forwards or backwards. On some models the suspension ring is fixed, however, this will then have a number of holes for the support hook.

The machine is correctly balanced when it freely hangs horizontally from the support hook. In this way the risk of hitting stones is reduced if you need to release the handlebar. 3 Adjust the shoulder strap to distribute the load evenly across your shoulders. Press downwards on the suspension hook to load the harness. 2 Grass clearing Let the blade balance at a comfortable cutting height, i.e. close to the ground. 4 Adjust the height of the suspension hook as described in the instructions for the standard harness. (Forestry clearing) 5 If you need to lower the suspension hook, for trimming for example, move the suspension strap (A) to the lower mounting point on the backplate. The elastic strap (B) can be tightened to transfer more load from the shoulder straps to the hip strap.

6 A B English – 17 FUEL HANDLING Fuel safety Never start the machine: 1 2 If you have spilled fuel on it. Wipe off the spillage and allow remaining fuel to evaporate. If you have spilled fuel on yourself or your clothes, change your clothes. Wash any part of your body that has come in contact with fuel. Use soap and water. If the machine is leaking fuel. Check regularly for leaks from the fuel cap and fuel lines. Gasoline 3 **CAUTION!** Always use a quality gasoline/oil mixture with an octane rating of at least 87 octane ((RON+MON)/2). If your machine is equipped with a catalytic converter (see chapter on Technical data) always use a good quality unleaded gasoline/oil mixture. Leaded gasoline will destroy the catalytic converter.

Use low-emission gasoline, also known as alkylate gasoline, if it is available. Transport and storage • Store and transport the machine and fuel so that there is no risk of any leakage or fumes coming into contact with sparks or naked flames, for example, from electrical machinery, electric motors, electrical relays/switches or boilers. When storing and transporting fuel always use approved containers intended for this purpose. When storing the machine for long periods the fuel tank must be emptied. Contact your local gas station to find out where to dispose of excess fuel.

Ensure the machine is cleaned and that a complete service is carried out before long-term storage. The transport guard must always be fitted to the cutting attachment when the machine is being transported or in storage. In order to prevent unintentional starting of the engine, the spark plug cap must always be removed during long-term storage, if the machine is not under close supervision and when performing all service measures. • • This engine is certified to operate on unleaded gasoline. • The lowest recommended octane grade is 87 ((RON+MON)/2).

If you run the engine on a lower octane grade than 87 so-called knocking can occur. This gives rise to a high engine temperature and increased bearing load, which can result in serious engine damage. When working at continuous high revs a higher octane rating is recommended. • • • • Two-stroke oil • For best results and performance use HUSQVARNA two-stroke engine oil, which is specially formulated for our air-cooled two stroke-engines. Never use two-stroke oil intended for water-cooled engines, sometimes referred to as outboard oil (rated TCW). Never use oil intended for four-stroke engines. Mixing ratio 1:50 (2%) with HUSQVARNA two-stroke oil. Gasoline, litre 5 Two-stroke oil, litre 2% (1:50) 0,10 0,20 0,30 0,40 US fl. oz. 2 1/2 6 1/2 12 7/8 ! Fuel **WARNING!** Take care when handling fuel.

Bear in mind the risk of fire, explosion and inhaling fumes. • **CAUTION!** The machine is equipped with a two-stroke engine and must always been run using a mixture of gasoline and two-stroke engine oil. It is important to accurately measure the amount of oil to be mixed to ensure that the correct mixture is obtained. When mixing small amounts of fuel, even small inaccuracies can drastically affect the ratio of the mixture. • • ! **WARNING!** Fuel and fuel fumes are highly inflammable and can cause serious injury when inhaled or allowed to come in contact with the skin. For this reason observe caution when handling fuel and make sure there is adequate ventilation.



[You're reading an excerpt. Click here to read official HUSQVARNA 333 R user guide](http://yourpdfguides.com/dref/4739217)

<http://yourpdfguides.com/dref/4739217>

10 15 20 US gallon 1 2 1/2 5 18 – English FUEL HANDLING Mixing •• Always mix the gasoline and oil in a clean container intended for fuel. Always start by filling half the amount of the gasoline to be used. Then add the entire amount of oil. Mix (shake) the fuel mixture.

Add the remaining amount of gasoline. Mix (shake) the fuel mixture thoroughly before filling the machine's fuel tank. Fueling ! WARNING! Taking the following precautions, will lessen the risk of fire: Do not smoke or place hot objects near fuel. Always shut off the engine before refuelling. Always stop the engine and let it cool for a few minutes before refuelling.

When refuelling, open the fuel cap slowly so that any excess pressure is released gently. Tighten the fuel cap carefully after refuelling. Always move the machine away from the refuelling area before starting. ••• Do not mix more than one month's supply of fuel at a time. If the machine is not used for some time the fuel tank should be emptied and cleaned.

•• Clean the area around the fuel cap. Contamination in the tank can cause operating problems. Ensure that the fuel is well mixed by shaking the container before filling the tank. ! WARNING! The catalytic converter muffler gets very hot during and after use. This also applies during idling. Be aware of the fire hazard, especially when working near flammable substances and/ or vapours. English – 19 STARTING AND STOPPING Check before starting trimmer guard if they have been exposed to impact or are cracked. • Check the blade to ensure that no cracks have formed at the bottom of the teeth or by the centre hole. The most common reason why cracks are formed is that sharp corners have been formed at the bottom of the teeth while sharpening or that the blade has been used with dull teeth. Discard a blade if cracks are found.

•• Never use the machine without a guard nor with a defective guard. All covers must be correctly fitted and undamaged before you start the machine. Starting and stopping • Check that the support flange is not cracked due to fatigue or due to being tightened too much. Discard the support flange if it is cracked. ! • Ensure the locking nut has not lost its captive force. The nut lock should have a locking force of at least 1.5 Nm. The tightening torque of the locking nut should be 35-50 Nm. WARNING! The complete clutch cover and shaft must be fitted before the machine is started, otherwise the clutch can come loose and cause personal injury. Always move the machine away from the refuelling area before starting.

Place the machine on a flat surface. Ensure the cutting attachment cannot come into contact with any object. Make sure no unauthorised persons are in the working area, otherwise there is a risk of serious personal injury. The safety distance is 15 metres. • Check that the blade guard is not damaged or cracked. Replace the blade guard if it is exposed to impact or is cracked. Starting Choke: Set the choke control in the choke position. • Check that the trimmer head and trimmer guard are not damaged or cracked. Replace the trimmer head or 20 – English STARTING AND STOPPING Primer bulb: Press the air purge repeatedly until fuel begins to fill the bulb. The bulb need not be completely filled.

For throttle handles with a start throttle lock: Set the throttle to the start position by first pressing the throttle lockout and the throttle trigger, then pressing the start throttle button (A). Then release the throttle lockout and the throttle trigger, followed by the start throttle button. The throttle function is now activated. @@@@Not with your foot!). @@@@When the engine starts. @@CAUTION! @@@@The stop switch automatically returns to the start position. @@Do not put any part of your body in marked area. @@Always use gloves. @@@@Contact your dealer or your service workshop. Avoid all usage which you consider to be beyond your capability.

@@cause you to lose control. @@Always hold the machine with both hands. @@@@CAUTION! @@Inspect the working area. @@@@Make sure you can move and stand safely. @@Take great care when working on sloping ground. 8 9 Keep the cutting attachment below waist level. Switch off the engine before moving to another area. Fit the transport guard before carrying or transporting the equipment any distance. 10 Never put the machine down with the engine running unless you have it in clear sight. The ABC of clearing •••••••• Always use the correct equipment.

Make sure the equipment is well adjusted. Follow the safety precautions. Organise your work carefully. Always use full throttle when starting to cut with the blade. Always use sharp blades.

Avoid stones. Control the felling direction (take advantage of the wind). ! WARNING! Neither the operator of the machine nor anyone else may attempt to remove the cut material while the engine is running or the cutting equipment is rotating, as this can result in serious injury. Stop the engine and cutting equipment before you remove material that has wound around the blade shaft as otherwise there is a risk of injury. The bevel gear can get hot during use and may remain so for a while afterwards.

You could get burnt if you touch it. 5 Take great care when cutting a tree that is under tension. A tree that is under tension may spring back to its normal position before or after being cut. If you position yourself incorrectly or make the cut in the wrong place the tree may hit you or the machine and 22 – English WORKING TECHNIQUES ! WARNING! Watch out for thrown objects. Always wear approved eye protection. Never lean over the cutting attachment guard.

Stones, rubbish, etc. can be thrown up into the eyes causing blindness or serious injury. Keep unauthorised persons at a distance. Children, animals, onlookers and helpers should be kept outside the safety zone of 15 m.

Stop the machine immediately if anyone approaches. Never swing the machine around without first checking behind you to make sure no one is within the safety zone. • WARNING! Sometimes branches or grass get caught between the guard and cutting attachment. Always stop the engine before cleaning, and gives the operator a convenient and varied working area to work in. Clear a strip around 75 m long. Move your fuel can as work progresses. On sloping ground you should work along the slope. It is much easier to work along a slope than it is to work up and down it. You should plan the strip so that you avoid going over ditches or other obstacles on the ground.

You should also orient the strip to take advantage of wind conditions, so that cleared stems fall in the cleared area of the stand. ! • Working methods • ! WARNING! Machines fitted with saw blades or grass blades can be thrown violently to the side when the blade comes into contact with a fixed object. This is called blade thrust. A blade thrust can be violent enough to cause the machine and/or operator to be propelled in any direction, and possibly lose control of the machine.



[You're reading an excerpt. Click here to read official HUSQVARNA 333 R user guide](http://yourpdfguides.com/dref/4739217)
<http://yourpdfguides.com/dref/4739217>

Blade thrust can occur without warning if the machine snags, stalls or binds.

Blade thrust is more likely to occur in areas where it is difficult to see the material being cut. Avoid cutting with the area of the blade between the 12 o'clock and 3 o'clock positions. Because of the speed of rotation of the blade, blade thrust can occur if you attempt to cut thick stems with this area of the blade.

Forestry clearing using a saw blade • Before you start clearing, check the clearing area, the type of terrain, the slope of the ground, whether there are stones, hollows etc. Start at whichever end of the area is easiest, and clear an open space from which to work.

Work systematically to and fro across the area, clearing a width of around 4-5 m on each pass. This exploits the full reach of the machine in both directions •

• • The risk of blade thrust increases with increasing stem size. You should therefore avoid cutting with the area of the blade between 12 o'clock and 3 o'clock.

• To fell to the left, the bottom of the tree should be pushed to the right. Tilt the blade and bring it diagonally down to the right, exerting firm pressure. At English – 23 WORKING TECHNIQUES the same time push the stem using the blade guard. Cut with the area of the blade between 3 o'clock and 5 o'clock.

Apply full throttle before advancing the blade. wood. Small stems require more pressure, while large stems require less pressure.

• To fell to the right, the bottom of the tree should be pushed to the left. Tilt the blade and bring it diagonally up to the right. Cut with the area of the blade between 3 o'clock and 5 o'clock so that the direction of rotation of the blade pushes the bottom of the tree to the left. • • If the stems are tightly packed, adapt your walking pace to suit. If the blade jams in a stem, never jerk the machine free. If you do this the blade, bevel gear, shaft or handlebar may be damaged.

Release the handles, grip the shaft with both hands and gently pull the machine free. Brush cutting with a saw blade • To fell a tree forwards, the bottom of the tree should be pulled backwards. Pull the blade backwards with a quick, firm movement. • • • Thin stems and brush are mown down.

Work with a sawing movement, swinging sideways. Try to cut several stems in a single sawing movement. With groups of hardwood stems, first clear around the group. Start by cutting the stems high up around the outside of the group to avoid jamming. Then cut the stems to the required height.

Now try to reach in with the blade and cut from the centre of the group. If it is still difficult to gain access, cut the stems high up and let them fall. This will reduce the risk of jamming. • Large stems must be cut from two sides. First determine which direction the stem will fall.

Make the first cut on the felling side. Then finish cutting the stem from the other side. Adjust the cutting pressure to match the size of the stem and the hardness of the 24 – English WORKING TECHNIQUES Grass clearing using a grass blade • • • • Grass blades and grass cutters must not be used on woody stems. A

grass blade is used for all types of tall or coarse grass. The grass is cut down with a sideways, swinging movement, where the movement from right-to-left is the clearing stroke and the movement from left-to-right is the return stroke. Let the left-hand side of the blade (between 8 and 12 o'clock) do the cutting. can

also damage sensitive bark on trees and bushes, and damage fence posts. Reduce the risk of damaging plants by shortening the cord to 10-12 cm and reducing the engine speed. Clearing • The clearing technique removes all unwanted vegetation. Keep the trimmer head just above the ground and tilt it.

Let the end of the cord strike the ground around trees, posts, statues and the like. CAUTION! This technique increases the wear on the cord. • The cord wears quicker and must be fed forward more often when working against stones, brick, concrete, metal fences, etc., than when coming into contact with trees and wooden fences. When trimming and clearing you should use less than full throttle so that the cord lasts longer and to reduce the wear on the trimmer head. • •

• • • If the blade is angled to the left when clearing grass, the grass will collect in a line, which makes it easier to collect, e.g. by raking. Try to work rhythmically. Stand firmly with your feet apart.

Move forward after the return stroke and stand firmly again. Let the support cup rest lightly against the ground. It is used to protect the blade from hitting the ground. Reduce the risk of material wrapping around the blade by following these instructions: 1 Always work at full throttle. 2 Avoid the previously cut material during the return stroke.

Stop the engine, unclip the harness and place the machine on the ground before you start to collect the cut material. • Cutting • The trimmer is ideal for cutting grass that is difficult to reach using a normal lawn mower. Keep the cord parallel to the ground when cutting. Avoid pressing the trimmer head against the ground as this can ruin the lawn and damage the tool. • Grass trimming with a trimmer head • Trimming • Hold the trimmer head just above the ground at an angle.

It is the end of the cord that does the work. Let the cord work at its own pace. Never press the cord into the area to be cut. Do not allow the trimmer head to constantly come into contact with the ground during normal cutting. Constant contact of this type can cause damage and wear to the trimmer head. Sweeping The fan effect of the rotating cord can be used for quick and easy clearing up. Hold the cord parallel to and above the area to be swept and move the tool to and fro. • The cord can easily remove grass and weeds up against walls, fences, trees and borders, however it • When cutting and sweeping you should use full throttle to obtain the best results. English – 25 MAINTENANCE Carburetor Your Husqvarna product has been designed and manufactured to specifications that reduce harmful emissions. After the engine has used 8-10 tanks of fuel the engine will be run-in.

To ensure that it continues to run at peak performance and to minimise harmful exhaust emissions after the running-in period, ask your dealer/ service workshop (who will have a rev counter at their disposal) to adjust your carburettor. Basic setting • The basic carburetor settings are adjusted during testing at the factory. The basic setting is richer than the optimal setting and should be maintained for the first few hours the machine is in use. The carburettor should then be finely adjusted. Fine adjustment should be carried out by a skilled technician. CAUTION! If the cutting attachment rotates when the engine is idling the idle adjustment screw T should be turned anti-clockwise until the cutting attachment stops.



[You're reading an excerpt. Click here to read official HUSQVARNA](#)

[333 R user guide](#)

<http://yourpdfguides.com/dref/4739217>

Rec. idle speed: See the Technical data section. Recommended max. speed: See the Technical data section.

! Function WARNING! The complete clutch cover and shaft must be fitted before the machine is started, otherwise the clutch can come loose and cause personal injury. **! WARNING!** If the idle speed cannot be adjusted so that the cutting attachment stops, contact your dealer/service workshop. Do not use the machine until it has been correctly adjusted or repaired. • The carburetor governs the engine's speed via the throttle control. Air and fuel are mixed in the carburetor.

The air/fuel mixture is adjustable. Correct adjustment is essential to get the best performance from the machine. The setting of the carburetor means that the engine is adapted to local conditions, for example, the climate, altitude, fuel and the type of 2-stroke oil. The carburetor has three adjustment controls: L = Low speed jet H = High speed jet T = Idle adjustment screw Fine adjustment • When the machine has been "run-in" the carburetor should be finely adjusted.

The fine adjustment should be carried out by a qualified person.

First adjust the L-jet, then the idling screw T and then the H-jet. • • Conditions • Before any adjustments are made, make sure that the air filter is clean and the air filter cover is fitted. If you adjust the carburetor when the air filter is dirty it will result in a leaner mixture when the filter is finally cleaned. This can lead to serious engine damage. Carefully turn both jets, L and H, so that they are midway between fully screwed in and fully screwed out. Do not attempt to adjust the L and H jets beyond either stop as this could cause damage. Now start the machine according to the starting instructions and let it warm up for 10 minutes. CAUTION! If the cutting attachment rotates when the engine is idling the idle adjustment screw T should be turned anti-clockwise until the cutting attachment stops. L H T • The L and H-jets are used to adjust the supply of fuel to match the rate that air is admitted, which is controlled with the throttle. If they are screwed clockwise the air/fuel ratio becomes leaner (less fuel) and if they are turned anti-clockwise the ratio becomes richer (more fuel).

A lean mixture gives a higher engine speed and a rich mixture gives a lower engine speed. The T-screw regulates the throttle setting at idle speed. If the T-screw is turned clockwise this gives a higher idle speed; turning it anti-clockwise gives a lower idle speed. • • • • 26 – English MAINTENANCE Low speed jet L Try to find the highest idling speed, turning the low speed needle L clockwise respectively counter-clockwise. When the highest speed has been found, turn the low speed needle L 1/4 turn counter-clockwise. High speed jet H The high speed jet H affects the engine power, speed, temperature and fuel consumption. If the high speed jet H is set too lean (screwed in too far) the engine speed will be too high and cause engine damage. Do not let the engine run at full speed for more than 10 seconds. L H CAUTION! If the cutting attachment rotates when the engine is idling the idle adjustment screw T should be turned anti-clockwise until the cutting attachment stops. Fine adjustment of the idle speed T Adjust the idle speed using the idle adjustment screw T, if it is necessary to readjust.

First turn the idle adjustment screw T clockwise until the cutting attachment starts to rotate. Then turn the screw anticlockwise until the cutting attachment stops. The idle speed is correctly adjusted when the engine will run smoothly in every position. The idle speed should also be well below the speed at which the cutting attachment starts to rotate. Note that the engine should be loaded when you adjust the high speed jet H.

You should therefore fit the trimmer head T35 (2.7 mm cord) before adjusting the high speed jet. The cord length should be standard, i.e. to the knife on the trimmer guard.

Apply full throttle and turn the high speed jet H very slowly clockwise until the engine slows down. Then turn the high speed jet H very slowly anticlockwise until the engine starts to run unevenly. Now turn the high speed jet H slowly clockwise a little way until the engine runs smoothly. T H CAUTION! For optimum adjustment of the carburetor, contact a qualified dealer/service workshop that has a revolution counter at their disposal. **! WARNING!** If the idle speed cannot be adjusted so that the cutting attachment stops, contact your dealer/service workshop. Do not use the machine until it has been correctly adjusted or repaired. Correctly adjusted carburetor When the carburetor is correctly adjusted the machine will accelerate without hesitation and burble a little at maximum speed. It is also important that the cutting attachment does not rotate at idle. If the low speed jet L is set too lean it may cause starting difficulties and poor acceleration. If the high speed jet H is set too lean it will result in less power, less performance, poor acceleration and/or damage to the engine.

If both the L and H jets are set too rich it will result in acceleration problems or too low a working speed. English – 27 MAINTENANCE Adjusting the start throttle speed The correct start throttle speed is set by means of an adjuster on the rear of the handle next to the cable. Use this screw (4 mm Allen screw) to increase or decrease the start throttle speed. Muffler CAUTION! Some mufflers are fitted with a catalytic converter. See chapter on Technical data to see whether your machine is fitted with a catalytic converter. The muffler is designed to reduce the noise level and to direct the exhaust gases away from the operator. The exhaust gases are hot and can contain sparks, which may cause fire if directed against dry and combustible material. 5 mm Proceed as follows: 1 2 3 Run the machine at idle. Press the start throttle lock as described under the heading Starting and stopping. If the start throttle speed is too low (below 4000 rpm), turn the adjuster screw A clockwise until the cutting attachment starts to rotate.

Then turn A clockwise a further 1/2 turn. If the start throttle speed is too high, turn the adjuster screw A anticlockwise until the cutting attachment stops. Then turn adjuster screw A clockwise a further 1/2 turn. Some mufflers are equipped with a special spark arrestor screen. If your machine has this type of muffler, you should clean the screen at least once a week.

This is best done with a wire brush. On mufflers without a catalytic converter the screen should be cleaned weekly, or replaced if necessary. On mufflers fitted with a catalytic converter the screen should be checked, and if necessary cleaned, monthly. If the screen is damaged it should be replaced. If the screen is frequently blocked, this can be a sign that the performance of the catalytic converter is impaired.

Contact your dealer to inspect the muffler. A blocked screen will cause the machine to overheat and result in damage to the cylinder and piston.



[You're reading an excerpt. Click here to read official HUSQVARNA](#)

[333 R user guide](#)

<http://yourpdfguides.com/dref/4739217>

4 ! **WARNING!** If the idle speed cannot be adjusted so that the cutting attachment stops, contact your dealer/service workshop. Do not use the machine until it has been correctly adjusted or repaired. **CAUTION!** Never use a machine with a defective muffler. ! **WARNING!** Mufflers fitted with catalytic converters get very hot during use and remain so for some time after stopping. This also applies at idle speed. Contact can result in burns to the skin. Remember the risk of fire! 28 – English **MAINTENANCE** Cooling system Air filter To keep the working temperature as low as possible the machine is equipped with a cooling system. 3 2 The air filter must be regularly cleaned to remove dust and dirt in order to avoid: • Carburettor malfunctions • Starting problems • Loss of engine power • Unnecessary wear to engine parts • Excessive fuel consumption.

1 The cooling system consists of: 1 2 3 Air intake on the starter. Cooling fins on the cylinder. Cylinder cover (directs cold air over the cylinder). Clean the filter every 25 hours, or more regularly if conditions are exceptionally dusty. Clean the cooling system with a brush once a week, more often in demanding conditions. A dirty or blocked cooling system results in the machine overheating which causes damage to the piston and cylinder. Cleaning the air filter Remove the air filter cover and take out the filter. Wash it clean in warm, soapy water. Ensure that the filter is dry before refitting it. An air filter that has been in use for a long time cannot be cleaned completely.

The filter must therefore be replaced with a new one at regular intervals. A damaged air filter must always be replaced. If the machine is used in dusty conditions the air filter should be soaked in oil. See instructions under the heading Oiling the air filter. Bevel gear The bevel gear is filled with the right quantity of grease at the factory.

However, before using the machine you should check that the bevel gear is filled three-quarters full with grease. Use HUSQVARNA special grease. Oiling the air filter The grease in the bevel gear does not normally need to be changed except if repairs are carried out. Always use HUSQVARNA filter oil, art. no. 531 00 92-48. The filter oil contains a solvent to make it spread evenly through the filter. You should therefore avoid skin contact. Put the filter in a plastic bag and pour the filter oil over it. Knead the plastic bag to distribute the oil. Squeeze the excess oil out of the filter inside the plastic bag and pour off the excess before fitting the filter to the machine. Never use common engine oil. This would drain through the filter quite quickly and collect in the bottom. English – 29 **MAINTENANCE** Spark plug The spark plug condition is influenced by: ••• Incorrect carburettor adjustment. An incorrect fuel mixture (too much or incorrect type of oil).

A dirty air filter. These factors cause deposits on the spark plug electrodes, which may result in operating problems and starting difficulties. If the machine is low on power, difficult to start or runs poorly at idle speed: always check the spark plug first before taking any further action. If the spark plug is dirty, clean it and check that the electrode gap is 0.020 inch (0.5 mm). The spark plug should be replaced after about a month in operation or earlier if necessary.

CAUTION! Always use the recommended spark plug type! Use of the wrong spark plug can damage the piston/ cylinder. Note: Use only HUSQVARNA replacement parts. Use of other brands of replacement parts can cause damage to your unit or injury to the operator or others.

Your warranty does not cover damage or liability caused by the use of accessories and/or attachments not specifically recommended by HUSQVARNA. 30 – English **MAINTENANCE** Maintenance schedule The following is a list of the maintenance that must be performed on the machine. Most of the items are described in the Maintenance section. The user must only carry out the maintenance and service work described in this manual. More extensive work must be carried out by an authorised service workshop.

Maintenance Clean the outside of the machine. Check that the harness is not damaged. Check that the suspension ring is not damaged. Make sure the throttle trigger lock and the throttle function correctly from a safety point of view. Check that the stop switch works correctly.

Check that the handle and handlebar are undamaged and secured correctly. Check that the cutting attachment does not rotate at idle. Clean the air filter. Replace if necessary. Check that the guard is undamaged and not cracked. Replace the guard if it has been exposed to impact or is cracked. Check that the blade is correctly centred, is sharp, and is not cracked. An off-centre blade will cause vibration that could result in damage to the machine. Check that the trimmer head is undamaged and not cracked. Replace the trimmer head if necessary.

Check that the locking nut of the cutting equipment is tightened correctly. Check that nuts and screws are tight. Check that there are no fuel leaks from the engine, tank or fuel lines. Check that the transport guard for the blade is intact and that it can be secured correctly. Check the starter and starter cord. Check that the vibration damping elements are not damaged. Clean the outside of the spark plug. Remove it and check the electrode gap. Adjust the gap to 0.5 mm (.020"), or replace the spark plug. Check that the spark plug is fitted with a suppressor. Clean the machine's cooling system. Clean or replace the spark arrestor screen on the muffler (only applies to mufflers without a catalytic converter). Clean the outside of the carburettor and the space around it.

Check that the bevel gear is filled three-quarters full with lubricant. Fill if necessary using special grease. Check that the safety release on the harness is not damaged and works. Check the fuel filter from contamination and the fuel hose from cracks or other defects. Replace if necessary.

Check all cables and connections. Check the clutch, clutch springs and the clutch drum for wear. Replace if necessary by an authorized service workshop.

Replace the spark plug. Check that the spark plug is fitted with a suppressor. Check and clean the spark arrestor screen on the muffler (only applies to mufflers fitted with a catalytic converter). Daily maintenance X X X X X X X X Weekly maintenance Monthly maintenance X X X X X X X X X X X X X X X X X X English – 31 **TECHNICAL DATA** Technical data Technical data Engine Cylinder displacement, cu.in/cm³ Cylinder bore, inch/mm Stroke, inch/mm Idle speed, rpm Recommended max. fast idle speed, rpm Speed of output shaft, rpm Max. engine output, acc.

to ISO 8893, kW/ rpm Catalytic converter muffler Speed-regulated ignition system Ignition system Manufacturer/type of ignition system Spark plug Electrode gap, inch/mm Fuel and lubrication system Manufacturer/type of carburettor Fuel tank capacity, US pint/litre Weight Weight without fuel, cutting attachment and guard, Lbs/kg Sound levels (see note 1) Equivalent sound pressure level at the user's ear, measured according to ANSI B175.



[You're reading an excerpt. Click here to read official HUSQVARNA](http://yourpdfguides.com/dref/4739217)

[333 R user guide](http://yourpdfguides.com/dref/4739217)

<http://yourpdfguides.com/dref/4739217>

3-1997, dB(A), min/max: Vibration levels Vibration levels at handles, measured according to ANSI B175.3-1997, m/s2 At idle, left/right handles, min.: At idle, left/right handles, max.: At max. speed, left/right handles, min.: At max. speed, left/right handles, max.: 3,0/2,8 3,2/3,1 2,9/3,4 4,2/5,1 2,1/2,0 2,1/2,0 2,7/3,2 2,9/3,8 2,0/1,9 2,7/2,3 2,4/1,8 2,7/2,7 96/102 95/102 95/102 13,4/6,1 13,4/6,1 13,7/6,2 Zama C1Q 1,27/0,6 Zama C1Q 1,27/0,6 Zama C1Q 1,27/0,6 Walbro MB Champion RCJ 6Y 0,02/0,5 Walbro MB Champion RCJ 6Y 0,02/0,5 Walbro MB Champion RCJ 6Y 0,02/0,5 2,11/34,6 1,50/38,0 1,20/30,5 2900 11500 8220 1,6/8400 Yes Yes 2,11/34,6 1,50/38,0 1,20/30,5 2900 11500 8220 1,6/8400 Yes Yes 333R 335FR 335RX Note 1: Equivalent noise pressure level is calculated as the time-weighted energy total for noise pressure levels under various working conditions with the following time distribution: 1/2 idle and 1/2 max. speed.

NOTE! Noise pressure at the user's ear and vibration on the handles are measured with all the machine's approved cutting equipment fitted. The table indicates the highest and lowest values. 32 – English TECHNICAL DATA Approved accessories Centre hole in blades/cutters, Ø 25,4 mm Output shaft thread M12 Multi 255-3 (Ø 255 3 teeth) Grass blade/grass cutter Grass 255-4 (Ø 255 4 teeth) Multi 275-4 (Ø 275 4 teeth) Multi 300-3 (Ø 300 3 teeth) Saw blade Plastic blades Scarlet 200-22 (Ø 200 22 teeth) Tricut Ø 300 mm T35, T35x S35 Trimmer head T45x Auto 55 Trimmer S II Support cup 503 89 01-02 537 33 16-01 537 33 16-01 537 33 16-01 537 38 77-01 537 33 16-01 / 537 34 94-01 537 33 16-01 / 537 34 94-01 537 33 16-01 / 537 34 94-01 537 33 16-01 / 537 34 94-01 537 33 16-01 / 537 34 94-01 Type Cutting attachment guard, Art. no. English – 33 FEDERAL AND CALIFORNIA EMISSIONS CONTROL WARRANTY STATEMENT YOUR WARRANTY RIGHTS AND OBLIGATIONS The EPA (U.

S. Environmental Protection Agency), CARB (California Air Resources Board), Environment Canada and Husqvarna Forest & Garden are pleased to explain the emissions control system's warranty on your 2009 and later small off-road engine. In U.S. and Canada, new equipment that use small off-road engines must be designed, built, and equipped to meet the applicable Federal or Californian stringent anti-smog standards.

Husqvarna Forest & Garden must warrant the emissions control system on your small off-road engine for the period listed below provided there has been no abuse, neglect or improper maintenance of your equipment. Your emissions control system may include parts such as the carburetor, ignition system, catalytic converter, fuel tank, filters and other associated components. Also, included may be hoses, belts, connectors, sensors, and other emission-related assemblies.

Where a warrantable condition exists, Husqvarna Forest & Garden will repair your small off-road engine at no cost to you including diagnosis, parts and labor. WARRANTY COMMENCEMENT DATE The warranty period begins on the date the engine or equipment is delivered to an ultimate purchaser.

LENGTH OF COVERAGE Husqvarna Forest & Garden warrants to the ultimate purchaser and each subsequent owner that the engine or equipment is designed, built, and equipped so as to conform with all applicable regulations adopted by EPA and CARB, and is free from defects in materials and workmanship that causes the failure of a warranted part for a period of two years. WHAT IS COVERED REPAIR OR REPLACEMENT OF PARTS Repair or replacement of any warranted part under the warranty must be performed at no charge to the owner at a warranty station. @@@@Any such part repaired or replaced under warranty is warranted for the remainder of the period prior to the first scheduled replacement point for the part. Any warranted part that is not scheduled for replacement as required in the maintenance schedule, is warranted for two years. If any such part fails during the period of warranty coverage, it will be repaired and replaced by Husqvarna Forest & Garden at no cost.

Any such part repaired or replaced under the warranty is warranted for the remaining warranty period. Any warranted part that is scheduled only for regular inspection in the maintenance schedule will be warranted for a period of two years. A statement in such written instructions to the effect of "repair or replace as necessary" will not reduce the period of warranty coverage. Any such part repaired or replaced under warranty will be warranted for the remaining warranty period. DIAGNOSIS The owner must not be charged for diagnostic labor that leads to the determination that a warranted part is in fact defective, provided that such diagnostic work is performed at a warranty station. CONSEQUENTIAL DAMAGES Husqvarna Forest & Garden is liable for damages to other engine components proximately caused by a failure under warranty of any warranted part. MANUFACTURER'S WARRANTY COVERAGE The emissions control system is warranted for two years. If any emissions-related part on your equipment is defective, the part will be repaired or replaced by Husqvarna Forest & Garden. OWNER'S WARRANTY RESPONSIBILITIES • As the small off-road engine owner, you are responsible for performance of the required maintenance listed in your operator's manual. Husqvarna Forest & Garden recommends that you retain all receipts covering maintenance on your small off-road engine, but Husqvarna Forest & Garden cannot deny warranty solely for the lack of receipts or your failure to ensure the performance of all scheduled maintenance.

As the small off-road engine owner, you should however be aware that Husqvarna Forest & Garden may deny you warranty coverage if your small off-road engine or a part has failed due to abuse, neglect, or improper maintenance or unapproved modifications. You are responsible for presenting your small off-road engine to a Husqvarna Forest & Garden distribution center or service center as soon as the problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days. If you have any questions regarding your warranty rights and responsibilities, you should contact your nearest authorized servicing dealer or call Husqvarna Forest & Garden at 1-800-487-5951 or visit www.usa.husqvarna.com.

34 – English FEDERAL AND CALIFORNIA EMISSIONS CONTROL WARRANTY STATEMENT EMISSION WARRANTY PARTS LIST 1 2 3 4 5 6 7 Carburetor and internal parts Intake pipe, airfilter holder and carburetor bolts. Airfilter and fuelfilter covered up to maintenance schedule. Spark Plug, covered up to maintenance schedule Ignition Module Muffler with catalytic converter Fuel tank WHAT IS NOT COVERED All failures caused by abuse, neglect or improper maintenance are not covered.

ADD-ON OR MODIFIED PARTS Add-on or modified parts that are not exempted by CARB or EPA may not be used.



[You're reading an excerpt. Click here to read official HUSQVARNA 333 R user guide](http://yourpdfguides.com/dref/4739217)
<http://yourpdfguides.com/dref/4739217>