



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for INDESIT IDF125. You'll find the answers to all your questions on the INDESIT IDF125 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual INDESIT IDF125**  
**User guide INDESIT IDF125**  
**Operating instructions INDESIT IDF125**  
**Instructions for use INDESIT IDF125**  
**Instruction manual INDESIT IDF125**

## Operating instructions

DISHWASHER

EN

English, 1

IDF 125

### Contents

#### Installation, 2-3-4

Positioning and levelling  
Connecting the water and electricity supplies  
Advice regarding the first wash cycle  
Technical data  
Electrical connection

#### Description of the appliance, 5

Overall view  
Control panel

#### Loading the racks, 6

Lower rack  
Cutlery basket  
Upper rack

#### Start-up and use, 7

Starting the dishwasher  
Measuring out the detergent  
Wash options

#### Wash cycles, 8

Table of wash cycles

#### Rinse aid and refined salt, 9

Measuring out the rinse aid  
Measuring out the refined salt

#### Care and maintenance, 10

Shutting off the water and electricity supplies  
Cleaning the dishwasher  
Preventing unpleasant odours  
Cleaning the spray arms  
Cleaning the water inlet filter  
Cleaning the filters  
Leaving the machine unused for extended periods

#### Precautions and advice, 11

General safety  
Disposal  
Saving energy and respecting the environment

#### Troubleshooting, 12

 INDESIT



[You're reading an excerpt. Click here to read official INDESIT IDF125 user guide](http://yourpdfguides.com/dref/5489042)  
<http://yourpdfguides.com/dref/5489042>

#### Manual abstract:

Screw the hose to the tap as described for connection to a cold water supply. If the inlet hose is not long enough, contact a specialist store or an authorised technician (see Assistance). The water pressure must be within the values indicated in the Technical data table (see adjacent information). The hose should not be bent or compressed. Positioning and levelling 1. Remove the appliance from all packaging and check that it has not been damaged during transportation. If it has been damaged, contact the retailer and do not proceed any further with the installation process. 2. Check the dishwasher by placing it so that its sides or back panel are in contact with the adjacent cabinets or even with the wall. This appliance can also be recessed under a single worktop\* (see the Assembly instruction sheet).

3. Position the dishwasher on a level and sturdy floor. If the floor is uneven, the front feet of the appliance may be adjusted until it reaches a horizontal position. If the appliance is levelled correctly, it will be more stable and much less likely to move or cause vibrations and noise while it is operating. 4\*. Adjust the height of the rear foot from the front of the appliance\* on the central lower part of the dishwasher, turning a hexagonal spanner (red color) with an opening of 8 mm in a clockwise direction to increase the height or in an anticlockwise direction to decrease the height. Anti-flooding protection To ensure floods do not occur, the dishwasher: - is provided with a special system which blocks the water supply in the event of anomalies or leaks from inside the appliance. Some models are also equipped with the supplementary safety device New Acqua Stop\*, which guarantees antiflooding protection even in the event of a supply hose rupture. Connecting the water and electricity supplies Connection to the water and electricity supplies should only be performed by a qualified technician. The dishwasher should not stand on top of the water hoses or the electricity supply cable.

The appliance must be connected to the water supply network using new hoses. Do not use old hoses. The water inlet (A) and outlet (B) hoses and the electricity supply cable may be positioned towards the right or the left in order to achieve the best possible installation (see figure). **WARNING: HAZARDOUS VOLTAGE!** Under no circumstance should the water inlet hose be cut as it contains live electrical parts. \* Only available in selected models. 2 Connecting the water outlet hose Connect the outlet hose (without bending it) to a drain duct with a minimum diameter of 4 cm. Alternatively, rest it over a sink or tub; the free end of the hose should not remain immersed in water. The special plastic elbow\* makes it easier to find the best layout: fix the elbow to the wall securely in order to prevent the outlet hose from moving and spilling the dirty water. The part of the hose marked with the letter A should be between 40 and 100 cm above the ground (see figure). Anti-condensation strip\* After installing the dishwasher, open the door and stick the adhesive transparent strip under the wooden shelf in order to protect it from any condensation which may form.

EN A After the appliance has been installed, immediately before running the first wash cycle, completely fill the salt dispenser with water and add only then approximately 1 kg of salt (see chapter entitled Rinse aid and refined salt). The water may overflow: this is normal and is not a cause for concern. Select the water hardness value (see chapter entitled Rinse aid and refined salt). - After the salt has been poured into the machine, the LOW SALT indicator light\* switches off. If the salt container is not filled, the water softener and the heating element may be damaged as a result. Advice regarding the first wash cycle We advise against the use of hose extensions. Electrical connection Technical data Before inserting the plug into the electrical socket, make sure that:  The socket is earthed and complies with current regulations.  The socket can withstand the maximum load of the appliance, which is indicated on the data plate located on the inside of the door (see chapter entitled Description of the appliance).  The power supply voltage falls within the values indicated on the data plate on the inside of the door.  The socket is compatible with the plug of the appliance.

If this is not the case, ask an authorised technician to replace the plug (see Assistance); do not use extension cables or multiple sockets. Once the appliance has been installed, the power supply cable and the electrical socket should be easily accessible. The cable should not be bent or compressed. If the power supply cable is damaged, it must be replaced by the manufacturer or its Technical Assistance Service in order to prevent all potential hazards. (See Assistance) The Company shall not be held responsible for any incidents that occur if these regulations are not observed.

Dimensions Capacity Water supply pressure Power supply voltage width 60 cm height 85 cm depth 60 cm 12 standard place-settings 0,05 ÷ 1MPa (0.5 ÷ 10 bar) 4.3 psi – 145 psi See appliance data plate Total absorbed See appliance data plate power Fuse See appliance data plate This dishwasher conforms to the following European Community Directives: -2006/95/CE dated 16/01/2007 (Low Voltage) and subsequent modifications -89/336/EEC dated 03/05/89 (Electromagnetic Compatibility) and subsequent modifications -97/17/EC (Labelling) -2002/96/ CE Waste Electrical and Electronic Equipment (WEEE) \* Only available in selected models. 3 Electrical Connection EN Electrical Connection If your appliance is supplied with a 13 amp. fused plug it can be plugged into a 13 amp socket for immediate use.

Before using the appliance please read the instruction below. **WARNING: THIS APPLIANCE MUST BE EARTHED. THE FOLLOWING OPERATIONS SHOULD BE CARRIED OUT BY A QUALIFIED ELECTRICIAN.** Replacing the fuse: When replacing a faulty fuse, a 13 amp ASTA approved fuse to BS 1362 should always be used, and the fuse cover re-fitted. If the fuse cover is lost, the plug must not be used until a replacement is obtained. Replacemete fuse covers: If a replacement fuse cover is fitted, it must be of the correct colours as indicated by the coloured marking or the colour that is embossed in words on the base of the plug. Replacements can be obtained directly from your nearest Service Depot. Removing the plug: If your appliance has a non-rewireable moulded plug and you should wish to remove it to re-route the mains cable through partitions, units etc., please ensure that either: - the plug is replaced by a fused 13 amp re-wireable plug bearing the BSI mark of approval - or: - the mains cable is wired directly into a 13 amp cable outlet, controlled by a switch, (in compliance with BS 5733) which is accessible without moving the appliance. Disposing of the plug: Ensure that before disposing of the plug itself, you make the pins unusable so that it cannot be accidentally inserted into a socket.



[You're reading an excerpt. Click here to read official INDESIT](http://yourpdfguides.com/dref/5489042)

[IDF125 user guide](http://yourpdfguides.com/dref/5489042)

<http://yourpdfguides.com/dref/5489042>

*Instruction for connecting cable to an alternative plug: Important: the wires in the mains lead are coloured in accordance with the following code: Green & Yellow - Earth Blue - Neutral Brown - Live - Once the appliance has been installed, the electrical plug and socket should remain accessible. - The Company shall not be held responsible for any incidents that occur if these regulations are not observed. Disposing of the appliance: When disposing of the appliance please remove the plug by cutting the mains cable as close as possible to the plug body and dispose of it as described above. As the colours of the wires in the*

*mains lead may not correspond with the coloured markings identifying the terminal in your plug, proceed as follows: connect Green & Yellow wire to terminal marked E or coloured Green or Green & Yellow. Connect Brown wire to terminal marked L or coloured Red. Connect Blue wire to terminal marked N or coloured Black. If a 13 amp plug (BS 1363) is used it must be fitted with a 13 amp fuse. A15 amp plug must be protected by a 15 amp fuse, either in the plug or adaptor or at the distribution board. If you are in any doubt about the electrical supply to your machine, consult a qualified electrician before use. How to connect an alternative plug: The wires in this mains lead are coloured in accordance with the following code: BLUE BROWN GREEN AND YELLOW NEUTRAL (N) LIVE (L) EARTH (E) or GREEN & YELLOW BROWN 13 amp fuse BLUE CROSS-BAR CORD GRIP CAUTION: 4 Description of the appliance Overall view 1.*

*2. 3. 4. 5. 6.*

*7. 8. 9. 10. 11.*

*12. Upper rack Upper sprayer arm Tip-up compartments Rack height adjuster Lower rack Lower sprayer arm Cutlery basket Washing filter Salt dispenser Detergent and rinse aid dispensers Data plate Control Panel\*\*\* EN Control panel Start/Pause button and indicator light \* Select wash cycle knob ON/OFF/RESET button Washing indicator light \* Drying indicator light \* End indicator light\* Low Salt indicator light \* \*\*\*Only in completely built-in models. \* Only available in selected models. The number and type of wash cycles and options may vary depending on the dishwasher model. 5 Loading the racks EN Before loading the racks, remove all food residues from the crockery and empty liquids from glasses and cups. After loading the appliance, check that the sprayer arms can rotate freely. Adjusting the height of the upper rack In order to make it easier to arrange the crockery, the upper rack may be moved to a higher or lower level. (in models which The height of the upper rack should ideally be adjusted WHEN THE RACK IS EMPTY. Never lift or lower the rack on one side only. Open the left and right guide rail stops and pull out the rack; position it higher or lower as required, slide it along the guide rails until the front wheels are in place and close the stops (see figure).*

*If the rack is fitted with Dual Space handles\* (see figure), pull out the upper rack until it reaches its stop point, grip the handles at the sides of the rack and move it upwards or downwards, then slowly let it fall back into place. Lower rack The lower rack can hold pans, lids, plates, salad bowls, cutlery, etc. as seen in the Loading examples. Plates and large covers should be placed at the sides of the rack, ensuring that they do not block the rotation of the upper sprayer arm. Some dishwasher models are fitted with tip-up sections\*, which can be used in a vertical position when arranging plates or in a horizontal position when arranging pans and salad bowls. Cutlery basket The type of cutlery basket may vary according to the dishwasher model: it may be modular, non-modular or a sliding version. The non-modular basket must only be positioned at the front of the lower rack. The modular basket may be separated into a wash cycle in progress If a mistake was made during the wash cycle selection process it is possible to change the cycle, provided that it has only just begun: once the wash cycle has started, switch off the machine by pressing and holding the ON/ OFF/Reset button. Switch it back on using the same button and select the desired wash cycle and options. Adding extra crockery Press the Start/Pause button (the corresponding indicator light will flash).*

*Open the door, taking care to avoid the escaping steam, and place the crockery inside the appliance. Press the Start/Pause button (fixed light): the cycle starts from the point at which it was interrupted. If the Start/Pause button is pressed so as to pause the machine, the wash cycle or the Delayed Start\* function (if selected) is interrupted. At this stage it is not possible to change the wash cycle. Accidental interruptions If the door is opened during the wash cycle, or if there is a power cut, the cycle stops.*

*It starts again from the point at which it was interrupted once the door has been shut or once the electricity supply is restored. \* Only available in selected models. 7 Wash cycles EN If the crockery is only lightly soiled or if it has been rinsed with water before being placed in the dishwasher, reduce the amount of detergent used accordingly. The number and type of wash cycles and options may vary depending on the dishwasher model. Wash cycle selection instructions Wash cycle Detergent (A) = compartment A (B) = compartment B Powder Liquid Tablets Wash cycles which include drying Wash cycle duration (tolerance  $\pm 10\%$ ) Hrs.*

*Min. Heavily soiled dishes and pans (not to be used for delicate items). Normally soiled pans and dishes. Standard daily wash cycle. Pre-wash for dishes while awaiting completion of the load with the dishes from the next meal. Environmentally-friendly wash cycle with low energy consumption levels, suitable for pans and dishes. Economic and fast wash to be used for lightly soiled dishes. (Run cycle immediately after use) (2 plates + 2 glasses + 4 pieces of cutlery + 1 saucepan + 1 small frying pan). 1.Intensive 30 g (A) 30 ml (A) 1 (A) Yes 2:15' 2.*

*@@Soak No No No No 0:08' 4. @@@@ of powder = approximately 15 ml of liquid - 1 teaspoon = 5 gr. @@@@Do not use table salt or industrial salt, or washing up liquid. @@Follow the instructions given on the packaging. @@It is now possible to select the water hardness level. @@etc., up to a maximum of 5\* levels. (The default water softener setting is level 3). @@@@ @@@2. @@If this happens, clean F the spill immediately with a dry G cloth.*

*3. Screw the lid back on. @@@@- Switch the machine off using the ON/OFF button and open the door. @@@@The salt dispenser is located in the lower part of the dishwasher (see Description) and should be filled:  When the green float\* cannot be seen by simply looking at the cap of the salt dispenser.  When the LOW SALT\* indicator light on the control panel is illuminated; 1.*

*Remove the lower rack and unscrew the container cap (anticlockwise). 2. The first time you do this: fill the water tank right up to its edge. 3. Position the funnel\* (see figure) and fill the salt container right up to its edge (this should hold approximately 1 kg); it is not unusual for a little water to leak out.*



[You're reading an excerpt. Click here to read official INDESIT](#)

[IDF125 user guide](#)

<http://yourpdfguides.com/dref/5489042>

4. Remove the funnel\* and wipe any salt residue away from the opening; rinse the cap under running water and then screw it on, the head facing downwards so as to let the water flow out of the four cracks which are arranged in a star shape on the lower part of the cap. (Salt cap with green float\*) It is advisable to perform this procedure every time you add salt to the container. Make sure the cap is screwed on tightly, so that no detergent can get into the container during the wash cycle (this could damage the water softener beyond repair). When necessary, measure out the salt before a wash cycle so that any saline solution which has leaked out of the salt dispenser is removed. Measuring out the refined salt \* Only available in selected models. 9 Care and maintenance EN  Turn off the water tap after every wash cycle to avoid leaks.  Always unplug the appliance when cleaning it and when performing maintenance work.  The external surfaces of the machine and the control panel may be cleaned using a non-abrasive cloth which has been dampened with water. Do not use solvents or abrasive products.

Any marks on the inside of the appliance may be removed using a cloth dampened with water and a little vinegar. Shutting off the water and electricity supplies Clean the water inlet filter at the tap outlet regularly. - Turn off the water tap. - Unscrew the end of the water inlet hose, remove the filter and clean it carefully under running water. - Replace the filter and screw the water hose back into position. Cleaning the dishwasher Cleaning the filters The filter assembly consists of three filters which remove food residues from the washing water and then recirculate the water. They should be cleaned if you wish to achieve the best results in every wash. Clean the filters regularly. The dishwasher should not be used without filters, or if the filter is loose.  After several washes, check the filter assembly and if necessary clean it thoroughly under running water, using a non-metallic brush and following the instructions below:

1.

Turn the cylindrical filter C in an anti-clockwise direction and pull it out (fig. 1). 2. Remove the cup filter B by exerting a slight pressure on the side flaps (fig. 2).

3. Slide out the stainless steel plate filter A (fig. 3). 4. Inspect the trap and remove any food residue.

NEVER REMOVE the wash cycle pump (black detail) (fig. 4).  Always keep the door of the appliance ajar in order to avoid moisture from forming and being trapped inside the machine.  Clean the seals around the door and detergent dispensers regularly using a damp sponge. This will avoid food becoming trapped in the seals, which is the main cause behind the formation of unpleasant odours. Preventing unpleasant odours Food residue may become encrusted onto the sprayer arms and block the holes used to spray the water. It is therefore recommended that the arms are checked from time to time and cleaned with a small non-metallic brush. The two sprayer arms may both be removed. To remove the upper sprayer arm, rotate the locking ring in an anti-clockwise direction. The upper sprayer arm should be replaced with the holes facing upwards.

The lower sprayer arm can be removed by pressing on the side tabs and pulling it upwards. Cleaning the sprayer arms C 1 2 C B A 3 4 After cleaning the filters, replace the filter assembly and fix it in position correctly; this is essential for maintaining the efficient operation of the dishwasher. Leaving the machine unused for extended periods If the water hoses are new or have not been used for an extended period of time, let the water run to make sure it is clear and free of impurities before performing the necessary connections. If this precaution is not taken, the water inlet could become blocked and damage the dishwasher. Cleaning the water inlet filter\*  Disconnect the appliance from the electricity supply and shut off the water tap.  Leave the door of the appliance ajar.  When you return, run a wash cycle when the dishwasher is empty. 10 \* Only available in selected models. Precautions and advice This appliance was designed and manufactured in compliance with current international safety standards. The following information has been provided for safety reasons and should therefore be read carefully.

Saving energy and respecting the environment Saving water and energy  Only begin a wash cycle when the dishwasher is full. While waiting for the dishwasher to be filled, prevent unpleasant odours using the Soak cycle (see Wash cycles).  Select a wash cycle which is suited to the type of crockery and to the soil level of the crockery using the Table of wash cycles: - For dishes with a normal soil level, use the Eco wash cycle, which guarantees low energy and water consumption levels. - If the load is smaller than usual activate the Half load option\* (see Start-up and use).  If your electricity supply contract gives details of electricity saving time bands, run wash cycles during the periods when a lower tariff is applied.

The Delayed start\* button (see Start-up and use) helps you organise the wash cycles accordingly. EN General safety  The appliance was designed for domestic use inside the home and is not intended for commercial or industrial use.  The appliance must be used by adults only, to wash domestic crockery in accordance with the instructions in this manual.  The appliance must not be installed outdoors, even in covered areas. It is extremely dangerous to leave the machine exposed to rain and storms.

Do not touch the appliance when barefoot.  When unplugging the appliance always pull the plug from the mains socket, do not pull on the cable.  The water supply tap must be shut off and the plug should be removed from the electrical socket before cleaning the appliance or carrying out any maintenance work.  If the appliance breaks down, do not under any circumstances touch the internal parts in an attempt to perform the repair work yourself.  Never touch the heating element.  Do not lean or sit on the open door of the appliance; this may cause the appliance to overturn.  The door should not be left open as it may create a dangerous obstacle.  Keep detergent and rinse aid out of reach of children.  The packaging material should not be used as a toy.

Phosphate-free and chlorine-free detergents containing enzymes  We strongly recommend that you use detergents that do not contain phosphates or chlorine, as these products are harmful to the environment.

Enzymes provide a particularly effective action at temperatures around 50°C, and as a result detergents containing enzymes can be used in conjunction with lowtemperature wash cycles in order to achieve the same results as a normal 65°C wash cycle. @@@@The crossed-out dustbin is marked on all products to remind the owner of their obligations regarding separated waste collection. For further information relating to the correct disposal of household appliances, owners may contact the relevant public authority or the local appliance dealer.



[You're reading an excerpt. Click here to read official INDESIT](http://yourpdfguides.com/dref/5489042)

[IDF125 user guide](http://yourpdfguides.com/dref/5489042)

<http://yourpdfguides.com/dref/5489042>

\* Only available in selected models. 11 Troubleshooting EN 06/2008- Xerox Business Services 195071957.00 Whenever the appliance fails to work, check for a solution from the following list before calling for Assistance. Problem: The dishwasher does not start. Possible causes / Solutions: ••• The plug has not been inserted into the electrical socket properly, or there is no power in the house. The dishwasher door has not been shut properly. A delayed start has been programmed (see Start-up and use).

The The The The dishwasher cycle has not yet finished. Water inlet hose is bent (see Installation). Drain duct is blocked. Filter is clogged up with food residues. No water drains out from the dishwasher.

••••• The dishwasher makes excessive noise. The dishes are rattling against each other or against the spray arms. An excessive amount of foam has been produced: the detergent has not been measured out correctly or it is not suitable for use in dishwashers (see Start-up and use). The level of the refined salt is low or the dosage setting is not suited to the hardness of the water (see Rinse aid and salt). The lid on the salt dispenser is not closed properly.

The rinse aid has been used up or the dosage is too low. The crockery is made from non-stick material. The rinse aid dosage is too high. A wash cycle without a drying programme has been selected. The rinse aid has been used up or the dosage is too low (see Rinse aid and salt). The rinse aid dispenser setting is not high enough. The racks are overloaded (see Loading the racks). The crockery has not been arranged well. The spray arms cannot move freely. The wash cycle is too gentle (see Wash cycles).

An excessive amount of foam has been produced: the detergent has not been measured out correctly or it is not suitable for use in dishwashers (see Start-up and use). The lid on the rinse aid compartment has not been shut correctly. The filter is dirty or blocked (see Care and maintenance). The refined salt level is low (see Rinse aid and salt). There is no water in the mains supply. The water inlet hose is bent (see Installation). Turn on the tap and the appliance will start after a few minutes. The appliance is locked because no action was taken when the indicator lights were flashing.

Switch off the machine using the ON/OFF button, turn on the tap and switch the machine back on after 20 seconds by pressing the same button. Re-programme the machine and restart the wash cycle.

Switch off the appliance by pressing the ON/OFF button and switch it back on after a minute. If the alarm continues, shut off the water tap to eliminate the risk of flooding, remove the plug from the electrical socket and contact Assistance. The dishes and glasses are covered in a white film or limescale deposits. •••• The dishes and glasses are • streaked or have a bluish tinge. The crockery has not been dried properly.

••• The dishes are not clean. •••••••• The dishwasher does not take any water in/Tap shut-off alarm (the Drying and End indicator lights flash). •••• Water loading solenoid valve malfunction alarm (the Drying indicator light flash). • Water inlet hose alarm/Water inlet filter blocked. (the Salt, Washing, Drying and End indicator lights flashes).

• Switch off the appliance by pressing in the ON/OFF button. Shut off the water tap to eliminate the risk of flooding and remove the plug from the electrical socket. Make sure the water inlet filter has not become blocked by various impurities. (see "Care and maintenance" chapter). 12 \* Only available in selected models. .



[You're reading an excerpt. Click here to read official INDESIT](#)

[IDF125 user guide](#)

<http://yourpdfguides.com/dref/5489042>