



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for INDESIT IWDC6125. You'll find the answers to all your questions on the INDESIT IWDC6125 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual INDESIT IWDC6125
User guide INDESIT IWDC6125
Operating instructions INDESIT IWDC6125
Instructions for use INDESIT IWDC6125
Instruction manual INDESIT IWDC6125

Instructions for use

WASHER-DRYER

GB
English, 1

IWDC 6125

 This symbol reminds you to read this booklet.

GB

Contents

Installation, 2-3-4-5

Unpacking and leveling
Connecting the electricity and water supplies
The first wash cycle
Technical data

Description of the washer-dryer and starting a wash cycle, 6-7

Control panel
Indicator lights
Starting a wash cycle

Wash cycles, 8

Table of wash cycles

Personalisation, 9

Setting the temperature
Setting the drying cycle
Functions

Detergents and laundry, 10

Detergent dispenser drawer
Preparing the laundry
Garments requiring special care
Load balancing system

Precautions and tips, 11

General safety
Disposal

Care and maintenance, 12

Cutting off the water or electricity supply
Cleaning the washer-dryer
Cleaning the detergent dispenser drawer
Caring for the door and drum of your appliance
Cleaning the pump
Checking the water inlet hose

Troubleshooting, 13-14

Assistance, 15-16

 INDESIT

1



[You're reading an excerpt. Click here to read official INDESIT IWDC6125 user guide](http://yourpdfguides.com/dref/547772)
<http://yourpdfguides.com/dref/547772>

Manual abstract:

Connecting the electricity and water supplies Connecting the water inlet hose Unpacking and levelling Unpacking 1. Remove the washer-dryer from its packaging. 2. Make sure that the washer-dryer has not been damaged during the transportation process. If it has been damaged, contact the retailer and do not proceed any further with the installation process. 3. Remove the 4 protective screws (used during transportation) and the rubber washer with the corresponding spacer, located on the rear part of the appliance (see figure). 1. @@@@Close off the holes using the plastic plugs provided. 5. @@@@Make sure that the hose is not folded over or bent. ! Packaging materials should not be used as toys for children. Levelling ! The water pressure at the tap must fall within the values indicated in the Technical details table (see page 5). ! If the inlet hose is not long enough, contact a specialised shop or an authorised technician. ! Never use second-hand hoses.

! Use the ones supplied with the machine. 1. Install the washer-dryer on a flat sturdy floor, without resting it up against walls, furniture cabinets or anything else. 2. If the floor is not perfectly level, compensate for any unevenness by tightening or loosening the adjustable front feet (see figure); the angle of inclination, measured in relation to the worktop, must not exceed 2°.

2 Connecting the drain hose 65 - 100 cm Connect the drain hose, without bending it, to a draining duct or a wall drain situated between 65 and 100 cm from the floor; •the supply voltage is included within the values indicated on the Technical Data Plate fixed on the machine; •the socket is compatible with the washing machine's plug. If this is not the case, replace the socket or the plug. Your appliance is now supplied with a 13 amp fused plug it can be plugged into a 13 amp socket for immediate use. Before using the appliance please read the instructions below. **WARNING - THIS APPLIANCE MUST BE EARTHED. THE FOLLOWING OPERATIONS SHOULD BE CARRIED OUT BY A QUALIFIED ELECTRICIAN.** Replacing the fuse: When replacing a faulty fuse, a 13 amp ASTA approved fuse to BS 1362 should always be used, and the fuse cover re-fitted. If the fuse cover is lost, the plug must not be used until a replacement is obtained. Replacement fuse covers: If a replacement fuse cover is fitted, it must be of the correct colour as indicated by the coloured marking or the colour that is embossed in words on the base of the plug. Replacements can be obtained directly from your nearest Service Depot.

Removing the plug: If your appliance has a non-rewireable moulded plug and you should wish to re-route the mains cable through partitions, units etc., please ensure that either: the plug is replaced by a fused 13 ampere rewireable plug bearing the BSI mark of approval. or: the mains cable is wired directly into a 13 amp cable outlet, controlled by a switch, (in compliance with BS 5733) which is accessible without moving the appliance. Disposing of the plug: Ensure that before disposing of the plug itself, you make the pins unusable so that it cannot be accidentally inserted into a socket. Instructions for connecting cable to an alternative plug: Important: the wires in the mains lead are coloured in accordance with the following code: Green & Yellow Earth Blue Neutral Brown Live GB Where it connects to the waste water pipe cut end off spigot or remove the blanking cap The drain hose may be connected to an undersink trap. Before connecting the drain hose from the machine ensure that any blanks or removable ends have been taken off the spigot. If it is placed over the edge of a basin or sink be sure the free end of the hose should not be underwater. ! We advise against the use of hose extensions; in case of absolute need, the extension must have the same diameter as the original hose and must not exceed 150 cm in length. Ensure that if the drain hose is pushed into a standpipe, that the end does not go down more than 15cms (6 inches). If the hose is pushed down too far, this may cause the machine to self-siphon ie. continuously empty as it is filling. Electric connection Before plugging the appliance into the mains socket, make sure that: •the socket is earthed and in compliance with the applicable law; •the socket is able to sustain the appliance's maximum power load indicated on the Technical Data Plate fixed on the machine; 3 GB As the colours of the wires in the lead may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows: Connect Green & Yellow wire to terminal marked E or or coloured Green or Green & Yellow. Connect Brown wire to terminal marked L or coloured Red. Connect Blue wire to terminal marked N or coloured Black. If a 13 amp plug (BS 1363) is used it must be fitted with a 13 amp fuse, either in the plug or adaptor or at the distribution board.

If you are in any doubt regarding on the electrical supply to your machine, consult a qualified electrician before use. How to connect an alternative plug: The wires in this mains lead are coloured in accordance with the following code: BLUE NEUTRAL (N) BROWN LIVE (L) GREEN & YELLOW EARTH (E) The first wash cycle Once the appliance has been installed, and before you use it for the first time, run a wash cycle with detergent and no laundry, setting the 90°C programme. GREEN & YELLOW 13 ampere fuse BROWN BLUE CROSS-BAR CORD GRIP Disposing of the appliance: When disposing of the appliance please remove the plug by cutting the mains cable as close as possible to the plug body and dispose of it as described above. ! The washing machine should not be installed in an outdoor environment, not even where the area is sheltered, because it may be very dangerous to leave it exposed to damp, rain and thunderstorms. ! When the washing machine is installed, the mains socket must be within easy reach.

! Do not use extensions or multiple sockets. ! The power supply cable must never be bent or dangerously compressed. ! The power supply cable must only be replaced by an authorised serviceman. Warning! The company denies all liability if and when these norms are not respected. 4 Technical data Model IWDC 6125 width 59.5 cm height 85 cm depth 53.5 cm from 1 to 6 kg for the wash programme from 1 to 5 kg for the drying programme please refer to the technical data plate fixed to the machine maximum pressure 1 MPa (10 bar) minimum pressure 0.05 MPa (0.5 bar) drum capacity 52 litres up to 1200 rotations per minute Wash: programme 1; temperature 60°C; using a load of 6 kg. Drying: first drying cycle performed with 1 kg load, by selecting a drying time of 60 min.

; the second drying cycle performed with 5 kg load, by selecting the dryness level. GB Dimensions Capacity Electrical connections Water connections Spin speed Energy rated programmes according to regulation EN 50229 This appliance conforms to the following EC Directives: - 2004/108/EC (Electromagnetic Compatibility) - 2006/95/EC (Low Voltage) - 2002/96/EC 5 Description of the washer-dryer and starting a wash cycle GB Control panel WASH CYCLE PROGRESS/ DELAY TIMER indicator lights ON/OFF button FUNCTION buttons with indicator lights button with indicator light START/PAUSE TEMPERATURE Detergent dispenser drawer WASH CYCLE knob knob DRYING knob indicator light DOOR LOCKED Detergent dispenser drawer: used to dispense detergents and washing additives (see "Detergents and laundry").



[You're reading an excerpt. Click here to read official INDESIT IWDC6125 user guide](http://yourpdfguides.com/dref/547772)
<http://yourpdfguides.com/dref/547772>

ON/OFF button: switches the washer-dryer on and off. WASH CYCLE knob: programmes the wash cycles. During the wash cycle, the knob does not move. FUNCTION buttons with indicator light: used to select the available functions. The indicator light corresponding to the selected function will remain lit. TEMPERATURE knob: sets the temperature or the cold wash cycle (see "Personalisation"). DRYING knob: used to set the desired drying programme (see "Personalisation"). WASH CYCLE PROGRESS/DELAY TIMER indicator lights: used to monitor the progress of the wash cycle.

The illuminated indicator light shows which phase is in progress. If the Delay Timer function has been set, the time remaining until the wash cycle starts will be indicated (see next page). DOOR LOCKED indicator light: indicates whether the door may be opened or not (see next page). START/PAUSE button with indicator light: starts or temporarily interrupts the wash cycles. N.

B. To pause the wash cycle in progress, press this button; the corresponding indicator light will flash orange, while the indicator light for the current wash cycle phase will remain lit in a fixed manner. If the DOOR LOCKED indicator light is switched off, the door may be opened. To start the wash cycle from the point at which it was interrupted, press this button again. Standby mode This washing machine, in compliance with new energy saving regulations, is fitted with an automatic standby system which is enabled after about 30 minutes if no activity is detected.

Press the ON-OFF button briefly and wait for the machine to start up again. 6 Indicator lights The indicator lights provide important information.

@@@@@@@@@@@@@@@@@@@@The temperature may be lowered, or even set to a cold wash. @@@@There are two options: Fabric Max.

Cupboard Hanger Iron Load type type load (kg) dry dry dry A - Based on time: From 40 minutes to 180. Clothing of diffeB - Based on the desired laundry dryness level: Cotton rent sizes, Terry 5 180 170 140 Iron dry : suitable for clothes which will need ironing towels afterwards. the remaining dampness softens creases, making them easier to remove. : ideal for clothes which do not need to be Synthe- Sheets, Shirts, PyHanger dry 3 140 120 100 jamas, socks, etc. tics dried fully. Cupboard dry : suitable for laundry which can be put back in a cupboard without being ironed.

If your laundry load to be washed and dried is much greater than the maximum stated load (see adjacent table), perform the wash cycle, and when the cycle is complete, divide the garments into gt or with wet or damp hands or feet. •Do not pull on the power supply cable when unplugging the appliance from the electricity socket. Hold the plug and pull. •Do not open the detergent dispenser drawer while the machine is in operation. •Do not touch the drained water as it may reach extremely high temperatures. •Never force the porthole door. This could damage the safety lock mechanism designed to prevent accidental opening. •If the appliance breaks down, do not under any circumstances access the internal mechanisms in an attempt to repair it yourself. •Always keep children well away from the appliance while it is operating. Disposal •Disposing of the packaging materials: observe local regulations so that the packaging may be re-used.

•The European Directive 2002/96/EC on Waste Electrical and Electronic Equipment, requires that old household electrical appliances must not be disposed of in the normal unsorted municipal waste stream. Old appliances must be collected separately in order to optimise the recovery and recycling of the materials they contain and reduce the impact on human health and the environment. The crossed out "wheeled bin" symbol on the product reminds you of your obligation, that when you dispose of the appliance it must be separately collected. Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliance. 11 Care and maintenance GB Cutting off the water and electricity supplies •Turn off the water tap after every wash cycle.

This will limit wear on the hydraulic system inside the washerdryer and help to prevent leaks. •Unplug the washer-dryer when cleaning it and during all maintenance work. Cleaning the pump The washer-dryer is fitted with a self-cleaning pump which does not require any maintenance. Sometimes, small items (such as coins or buttons) may fall into the pre-chamber which protects the pump, situated in its bottom part. ! Make sure the wash cycle has finished and unplug the appliance.

To access the pre-chamber: 1. using a screwdriver, remove the cover panel on the lower front part of the washer-dryer (see figure); Cleaning the washer-dryer The outer parts and rubber components of the appliance can be cleaned using a soft cloth soaked in lukewarm soapy water. Do not use solvents or abrasives. Cleaning the detergent dispenser drawer Remove the dispenser by raising it and pulling it out (see figure). Wash it under running water; this operation should be repeated frequently. 2. unscrew the lid by rotating it anti-clockwise (see figure): a little water may trickle out. @@@3. clean the inside thoroughly; 4. screw the lid back on; 5.

@@@@@@@@@@@@•The door is not closed properly. •The ON/OFF button has not been pressed. •The START/PAUSE button has not been pressed. @@•A delayed start has been set. •Check the 2 sections above. •The 'DRYING' selector knob is in the 0 position. @@@@wash cycle stage flashes rapidly. •The water pressure is too low. @@•There is no water supply to the house. •The inlet valve filter is blocked.

•The START/PAUSE button has not been pressed. The machine continuously fills with water and continually drains away or Water left in the drum or Stuck on wash. •The top of the drain hose is too low - It must be fitted at a height between 65 and 100 cm from the floor (see "Installation"). •The drain hose is connected incorrectly to the sink trap allowing water to run into the machine, the drain hose must be positioned higher than the bottom of the sink to prevent water flowing down the drain hose. •The end of the drain hose has been pushed too far down the standpipe, the 'U' bracket should be fitted 100 mm from the end of the drain hose.

•The Pump filter is blocked. •The drain hose is kinked (see "Installation"). •New Installation - The blanking cap or spigot has not been removed if connected under a sink. •The drain hose or sink trap is blocked. •Programme times will vary due to water pressure, the incoming water temperature and if the wash load goes out of balance.

This will increase the programme times accordingly (see 'The machine wont spin properly' below) - (Most Common Cause!).



[You're reading an excerpt. Click here to read official INDESIT](#)

[IWDC6125 user guide](#)

<http://yourpdfguides.com/dref/5477772>

• The feet have not been adjusted, enabling the machine to rock. • New Installation - Either the Transit Bolts including the plastic spacers, or the Polystyrene Packaging have not been removed when installing the machine. • The machine is trapped between cabinets and/or walls. • The load is in a slight out of balance condition and machine is spinning, but at a lower speed. • There will always be some motor, pump and drum noise during spin. The machine does not drain or spin (error lights flashing). The wash programme takes too long. The machine vibrates a lot during the spin cycle. The machine is noisy.

13 GB The machine wont spin properly. • Out of Balance detected when attempting to go into a spin cycle - If this happens the machine will continue to try to repeat the distribution of the load required before the machine will go into higher spin speeds - This will increase the programme time accordingly. This is a safety feature to prevent damage. Out of Balance can be caused by washing a single heavy item (eg duvet, quilt, etc). - Try the programme again using a different load. • The dispenser drawer is blocked with detergent and requires cleaning. • The water pressure is too high and requires turning down - turn down the tap on the water supply pipe slightly and try again. • The machine is tilting forwards - It must be level when in its final position. • The fill hose is loose, check both the cabinet and tap ends. • The fill hose is tight but still leaks, if so replace the rubber washers, or the fill hose is missing the rubber washer. • The drain hose is not fixed in properly. • Switch off the machine and unplug it, wait for approximately 1 minute and then switch back on again. If the problem persists contact Technical Assistance Centre. The machine leaks from the dispenser. The machine leaks (other than dispenser). The option lights and the START/ PAUSE indicator light flash while one of the wash cycle progress and DOOR LOCKED lights are lit in a fixed manner. The machine smells. • The machine requires a service wash. Run a 90 degree wash cycle with detergent and no laundry. • The door will not open until the door lock indicator light goes out shortly after the program has finished.

@@@ Door Seal damaged at the bottom. The water level is too low when the machine is washing. @@@ To comply with new energy saving regulations the machine is fitted with an automatic standby system. Press 'ON/OFF' button for 3 seconds to activate the machine, it can then either be switched off or a new programme selected. After completing the programme, or before starting a programme, the machine has turned itself off (no lights). General. • Your washing machine contains sensors that monitor progress during the wash cycle (eg: Water Levels, Temperatures, Out of Balance loads, Wash time/progress). Normally, if your machine successfully completes the cycle, there is unlikely to be anything wrong! Remember, you will be charged for a service call for problems caused by incorrect installation, as listed above. @@@@ The appliance is used only on the electricity or gas supply printed on the rating plate. The appliance has been used for normal domestic purposes only.

The appliance has not been altered, serviced, maintained, dismantled, or otherwise interfered with by any person not authorised by us. Any repair work must be undertaken by us or our appointed agent. Any parts removed during repair work or any appliance that is replaced become our property. The appliance is used in the United Kingdom or Republic of Ireland. GB The guarantee does not cover: - - - Damage resulting from transportation, improper use, neglect or interference or as a result of improper installation. Replacement of any consumable item or accessory. These include but are not limited to: plugs, cables, batteries, light bulbs, fluorescent tubes and starters, covers and filters. Replacement of any removable parts made of glass or plastic. THIS GUARANTEE WILL NOT APPLY IF THE APPLIANCE HAS BEEN USED IN COMMERCIAL OR NON-DOMESTIC PREMISES. 5 Year Parts Guarantee Indesit also offers you a free 5 year parts guarantee.

This additional guarantee is conditional on you registering your appliance with us and the parts being fitted by one of our authorised engineers. There will be a charge for our engineer's time. To activate the extra parts warranty on your appliance, simply call our registration line on 08448 24 24 24 (Republic of Ireland 01 230 0800). Extended Guarantees We offer a selection of repair protection plans that enable you to fully cover yourself against the expense of repair bills for the life of your policy. To find the ideal plan for you please call our advice line on 08448 226 226 (Republic of Ireland 01 230 0233). Free Helpdesk Service We have a dedicated team who can provide free advice and assistance with your appliance if you experience any technical difficulties within the first 90 days of ownership. Simply call our Indesit Service Hotline on 08448 224 224 (Republic of Ireland 0818 313 413) for telephone assistance, or, where necessary, to arrange for an engineer to call. 15 195073988.05 12/2010 - Xerox Fabriano GB After Sales Service No one is better placed to care for your Indesit appliance during the course of its working life than us - the manufacturer. Essential Contact Information Indesit Service We are the largest service team in Europe offering you access to 400 skilled telephone advisors and 1100 fully qualified engineers on call to ensure you receive fast, reliable, local service.

UK: 08448 224 224 Republic of Ireland: 0818 313 413 www.indesitservice.co.uk Please note: Our advisors will require the following information: Model number: Serial number: Parts and Accessories We supply a full range of genuine replacement parts as well as accessory products that protect and hygienically clean your appliance to keep it looking good and functioning efficiently throughout its life. UK: 08448 225 225 Republic of Ireland: 0818 313 413 www.indesitservice.co.uk Appliance Registration We want to give you additional benefits of Indesit ownership. To activate your free 5 year parts guarantee you must register your appliance with us. UK: 08448 24 24 24 Republic of Ireland: 01 230 0800 www.

www.indesitservice.co.uk Indesit Company UK Ltd. Morley Way, Peterborough, PE2 9JB Indesit Company Unit 49 Airways Industrial Estate, Dublin 17 Recycling & Disposal Information As part of Indesit's continued commitment to helping the environment, Indesit reserves the right to use quality, recycled components to keep down customer costs and minimise material wastage. Please dispose of packaging and old appliances carefully. To minimise the risk of injury to children, remove the door, plug and cut the mains cable off flush with the appliance. Dispose of these parts separately to ensure that the appliance can no longer be plugged into a mains socket, and the door cannot be locked shut.



[You're reading an excerpt. Click here to read official INDESIT IWDC6125 user guide](http://yourpdfguides.com/dref/547772)
<http://yourpdfguides.com/dref/547772>