



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for KODAK EASYSHARE CD80. You'll find the answers to all your questions on the KODAK EASYSHARE CD80 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual KODAK EASYSHARE CD80

User guide KODAK EASYSHARE CD80

Operating instructions KODAK EASYSHARE CD80

Instructions for use KODAK EASYSHARE CD80

Instruction manual KODAK EASYSHARE CD80

KODAK EASYSHARE CD80 Digital Camera



Extended user guide

www.kodak.com

For interactive tutorials:

www.kodak.com/go/howto

For help with your camera:

www.kodak.com/go/CD80support



[You're reading an excerpt. Click here to read official KODAK EASYSHARE CD80 user guide](http://yourpdfguides.com/dref/3208388)
<http://yourpdfguides.com/dref/3208388>

Manual abstract:

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

. 2 Setting the language and date/time.....

.....
.....
.....
.....

.....
.....
.....

.... 2 Storing pictures on an SD or SDHC Card

.....
.....
.....
.....

.....
.....
.....

3 2 Taking pictures/videos

.....
.....
.....
.....

.....
.....
.....
.....

.....4 Taking pictures.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 4 Using the optical and digital zoom .

.....
.....
.....

.....
.....
.....
.....

.....
... 5 Using the flash..

.....
.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

.. 6 Using different modes ...

.....
.....
.....
.....

.....
.....
.....
.....

.....
7 Taking a video

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.... 9 Using shortcuts .

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

.. 9 Using the self-timer...

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.. 10 Understanding the picture-taking icons...

.....
.....
.....
.....
.....

..... 11 3 Working with pictures/videos ..

.....
.....
.....
.....
.....
.....
.....

12 Reviewing pictures/videos

.....
.....
.....
.....
.....
.....
.....
.....

..... 12 Deleting pictures/videos

.....
.....
.....
.....
.....
.....
.....

... 13 Viewing pictures/videos in different ways..

.....
.....
.....
.....
.....

..... 14 Selecting multiple pictures/videos

.....
.....
.....
.....
.....
.....
.....

14 Running a slide show

.....
.....
.....
.....
.....
.....
.....
.....
.....

.. 15 Using the menu button in review.....

.....
.....
.....
.....
.....
.....
.....

..... 16 Cropping pictures...

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

..... 17 Using KODAK PERFECT TOUCH Technology.....

.....
.....
.....
.....
.....
.....
.....

.... 17 Rotating pictures.....

.....
.....
.....
.....
.....

.....
.....
.....

... 18 Copying pictures/videos.....

.....
.....
.....
.....
.....
.....
.....
.....

.. 18 Editing videos ...

.....
.....
.....
.....
.....
.....
.....
.....

19 Understanding the review icons....

.....
.....
.....
.....

.. 21 www.kodak.com/go/support iii Table of contents 4 Doing more with your camera

.....
.....
.....
.....

.....22 Using the menu button to change settings.....

.....
.....
.....
.....

. 22 Using the Setup menu

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 26 5 *Transferring, printing, tagging ...*

.....

.....

.....

.....

.....

.....

.....

.....28 *Installing the software...*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 28 *Transferring pictures/videos..*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 29 *Printing pictures....*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 30 *Tagging your pictures....*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....
.....
.....
.....

.....
.....
.....
.....

... 32 6 Troubleshooting

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.....36 7 Getting help

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

...40 Getting help from your camera

.....
.....
.....
.....

.....
.....
.....
.....

. 40 Getting help on the Web

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

... 41 Getting help on the telephone..

.....
.....
.....
.....

.....
.....
.....
.....
.....
.....
..... 42 8 Appendix ...

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

43 Camera specifications

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

. 43 Care and maintenance

.....
.....
.....
.....

.....
.....
.....
.....

. 45 Upgrading your software and firmware....

.....
.....

.....
.....
.....
.....

..... 46 Storage capacities ...

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.... 46 Important safety instructions

.....
.....
.....
.....
.....
.....

46 Battery replacement, battery life

.....
.....
.....
.....
.....
.....

. 47 Limited warranty

.....
.....
.....
.....
.....
.....
.....

48 Regulatory compliance

.....
.....
.....
.....
.....
.....

50 iv www.kodak.com/go/support 1 Setting up your camera **IMPORTANT:** For package contents, see your product package. Attaching the strap Loading the AA batteries For information on replacing the batteries and extending battery life, see page 47. www.kodak.com/go/support 1 Setting up your camera Turning on the camera Press the Power button. Setting the language and date/time Language: to change. OK to accept. Date/Time: At the prompt, press OK. to change current field. for previous/next field. OK to accept. OK (press) NOTE: To change language or date/time in the future, use the Setup menu (see page 26). 2 www.kodak.com/go/support Setting up your camera Storing pictures on an SD or SDHC Card Your camera has internal memory. You can purchase an SD or SDHC Card to conveniently store more pictures/videos. (Maximum supported card size is 32 GB.) CAUTION: A card can only be inserted one way; forcing it may cause damage.

Inserting or removing a card while the camera is on may damage the pictures, the card, or the camera. 1 Turn off the camera. 2 Insert or remove the optional

card. 3 Turn on the camera. optional Purchase accessories www.kodak.com/go/CD80accessories www.kodak.com/go/support 3 2 Taking pictures/videos To get clear, focused pictures: 1 Turn the Mode dial to Auto . Then press the Power button to turn on the camera.

2 Compose the picture. 3 Press the Shutter button halfway to focus and set exposure. When the framing marks turn green, press the Shutter button completely down. (For more about framing marks, page 4.) Taking pictures Framing marks Using the framing marks Framing marks Framing marks indicate the camera focus area.

1 Press the Shutter button halfway. If the camera is not focusing on the desired subject, release the Shutter button and recompose the scene. 2 Press the Shutter button completely down to take the picture. NOTE: Framing marks do not appear in all modes. Multiple framing marks may appear when faces are detected.

When you press the Shutter button halfway down, the framing marks attempt to follow the main subject. 4 www.kodak.com/go/support Taking pictures/videos

Reviewing the picture/video just taken After you take a picture/video, the LCD displays a quickview for approximately 5 seconds. (To exit the quickview sooner, press the Shutter button halfway.) Delete the current picture/video OK Play/pause a video To review pictures/videos anytime, see page 12. Using the optical and digital zoom 1 Use the LCD to frame your subject. 2 To zoom in, press Telephoto (T). To zoom out, press Wide Angle (W). 3 Take the picture or video.

NOTE: For focus distances, see Camera Specifications starting on page 43. Using digital zoom Use digital zoom to get up to 5X magnification beyond optical zoom. Press Telephoto (T) until the slider is at the end of the optical zoom range. Release Telephoto (T), then press it again. NOTE: You may notice decreased image quality when using digital zoom. The slider pauses and turns red when the picture quality reaches the limit for an acceptable 4 x 6-in. (10 x 15 cm) print. www.kodak.com/go/support 5 Taking pictures/videos Using the flash Press the flash button repeatedly to scroll through flash modes.

The current flash mode is shown on the LCD. Flash modes Auto Fill (Flash On) Flash fires When the lighting conditions require it. Every time you take a picture, regardless of the lighting conditions. Use when the subject is in shadow or is "backlit" (when the light is behind the subject). In low light, hold the camera steady or use a tripod.

A preflash fires, shrinking the eye pupil, before the picture is taken. A preflash does not fire; the camera corrects red eye. Red Eye Preflash Your camera can correct red-eye using 2 methods. To choose a Digital red eye setting, see see Correction page 26. Off Never 6 www.kodak.com/go/support

Taking pictures/videos Using different modes Turn the Mode dial to the mode that best suits your subjects and surroundings. Use this mode Auto For General picture taking--it offers excellent image quality and ease of use. The scene is analyzed for other content and for lighting. You can choose the best picture size and aspect ratio for your needs--just press the Menu button and choose Picture Size. 3:2 (the best choice when making 4 x 6 prints) 16:9 (wide screen) 4:3 (the default setting) Close-Up Sport Scene Blur Reduction Video Close range. Use available light instead of flash, if possible. Subjects that are in motion. Point-and-shoot simplicity when taking pictures in practically any situation. (See page 8.)

) Reducing blur caused by camera shake or subject motion. Capturing video with sound. (See page 9.) NOTE: Sound cannot be played on the camera. Sound is heard after the video is transferred to your computer. www.kodak.com/go/support 7 Taking pictures/videos Using Scene (SCN) modes Choose a Scene mode--for great pictures in practically any situation! 1 Turn the Mode dial to SCN. 2 Press to view scene mode descriptions. If the mode description turns off before you finish reading it, press OK.

3 Press OK to choose a Scene mode. SCN mode Portrait Landscape Flower Sunset Backlight For Full-frame portraits of people. Distant scenes. Close-ups of flowers or other small subjects in bright light. Subjects at dusk. Subjects that are in shadow or "backlit" (when light is behind the subject). Subjects illuminated by candle light. Action pictures of children in bright light. Quiet occasions, like a wedding or lecture.



[You're reading an excerpt. Click here to read official KODAK](http://yourpdfguides.com/dref/3208388)

[EASYS SHARE CD80 user guide](http://yourpdfguides.com/dref/3208388)

<http://yourpdfguides.com/dref/3208388>

Flash and sound are disabled.

Place the camera on a steady surface or tripod. Documents. Place the camera on a steady surface or tripod. Bright beach scenes. Bright snow scenes. Fireworks. Place the camera on a steady surface or tripod. Close-ups of yourself. Assures proper focus and minimizes red eye. Candle Light Children Manner/ Museum Text Beach Snow Fireworks SelfPortrait Night Portrait Reduces red eye of people in night scenes or low-light conditions.

Night Landscape Distant scenery at night. Flash does not fire. High ISO People indoors, in low-light scenes. 8 www.kodak.com/go/support Taking pictures/videos Taking a video 1 Turn the Mode dial to Video . 2 Press the Shutter button completely down, then release it. To stop recording, press and release the Shutter button again. To review and work with videos, see page 12. NOTE: Sound cannot be played on the camera.

Sound is heard after the video is transferred to your computer. Using shortcuts Your camera has a clean, uncluttered interface. For quick access to the most popular functions single picture/video, press (T) button. to highlight it. Then press the Telephoto To select multiple pictures/videos, see Selecting multiple pictures/videos, page 14.

Press the Shutter button halfway down to return to Capture mode. Selecting multiple pictures/videos Use the multi-select feature when you have two or more pictures to print, transfer, delete, etc. Multi-select is used most effectively in Multi-Up mode. Viewing as thumbnails (multi-up), page 14. 1 Press the Review button, then to find a picture/video. and Selected pictures 2 Press OK to select pictures/videos.

A check mark appears on the picture. You can now print, transfer, delete, etc. the selected pictures. You can press OK a second time to remove a check mark. 14 www.kodak.com/go/support Working with pictures/videos Running a slide show Use Slide Show to display your pictures/videos on the LCD. 1 Press the Review 2 Press button, then press the Menu button. to highlight Slide Show, then press OK. 3 Press to highlight Begin Show, then press OK.

Each picture/video is displayed once. To interrupt the Slide Show, press OK. IMPORTANT: Your camera offers a built-in Help system. See page 40.

Displaying pictures/videos on a television You can display pictures/videos on a television, computer monitor, or any device equipped with a video input. To connect the camera directly to a television, use an A/V cable (may be sold separately). Purchase accessories www.kodak.com/go/CD80accessories NOTE: Ensure that the Video Out setting (NTSC or PAL) is correct (see page 27). The slide show stops if you connect or disconnect the cable while the slide show is running.

(Image quality on a television screen may not be as good as on a computer monitor or when printed.) www.kodak.com/go/support 15 Working with pictures/videos Using the menu button in review 1 Press the Review 2 Press button, then the Menu button. to highlight a tab: Review to view and share pictures/videos Edit to edit pictures/videos Setup to control how your camera operates to highlight a setting, then press OK.

3 Press 4 Highlight an option, then press OK. IMPORTANT: Your camera offers a built-in Help system. See page 40. 16 www.kodak.com/go/support Working with pictures/videos Cropping pictures You can crop a picture so that only the desired portion of the picture remains. 1 Press the Review picture to crop. Picture button, then to find a Cropped picture 2 Press the Menu button, then to highlight the Edit tab. Highlight Crop, then press OK. to move the crop box. Press OK. 3 Press Telephoto (T) to zoom in, or 4 Follow the screen prompts. The picture is cropped. (The original is saved.) Cropped pictures cannot be cropped again on the camera.

Press the Shutter button halfway down to return to Capture mode. IMPORTANT: Your camera offers a built-in Help system. See page 40. Using KODAK PERFECT TOUCH Technology KODAK PERFECT TOUCH Technology helps ensure better, brighter pictures. 1 Press the Review button, then for previous/next picture. 2 Press the Menu button, then to highlight the Edit tab. Highlight PERFECT TOUCH Tech, then press OK. The enhancement is previewed. Press to view other parts of the picture. 3 Press OK.

Follow the screen prompts to replace the original picture or to save the enhanced picture as a new one. Press the Shutter button halfway down to return to Capture mode. NOTE: You cannot apply PERFECT TOUCH Technology to videos or to pictures to which PERFECT TOUCH Technology is already applied. www.kodak.com.

www.kodak.com/go/support 17 Working with pictures/videos Rotating pictures You can rotate a picture to portrait or landscape orientation. 1 Press the Review 2 Press the Menu 3 Press button, then button. Press to find the previous/next picture. to highlight the Edit tab. to highlight Rotate Picture, then press OK.

4 Press to highlight an option: Rotate Right--rotates the picture 90 degrees clockwise. Rotate Left--rotates the picture 90 degrees counterclockwise. 5 Press OK. Follow the screen prompts to replace the original picture or to save the rotated picture as a new one. Press the Shutter button halfway down to return to Capture mode. IMPORTANT: Your camera offers a built-in Help system. See page 40. Copying pictures/videos You can copy pictures/videos from a card to internal memory or from internal memory to a card. Copy pictures/videos: 1 Press the Review 2 Press the Menu button. button, then to highlight the Edit tab.

3 Press to highlight Copy, then press OK. Highlight a choice, then press OK. NOTE: Pictures/videos are copied, not moved. To remove pictures/videos from the original location after copying, delete them (see page 13). 18 www.kodak.com/go/support Working with pictures/videos Editing videos You can do incredible things with your videos! Making a picture from a video You can choose a single frame from a video, then make a picture suitable for a 4 x 6-inch (10 x 15 cm) print. 1 Press the Review video. Picture button, then to find a Video 2 Press the Menu button, then to highlight the Edit tab. Highlight Make Picture, then press OK.

3 Follow the screen prompts. A picture is created. (The original video is saved.) Press the Shutter button halfway down to return to Capture mode. IMPORTANT: Your camera offers a built-in Help system.

See page 40. Trimming a video You can remove an unwanted start or end from a video, saving only the desired portion. 1 Press the Review video. button, then to find a Video Trimmed video 2 Press the Menu button, then to highlight the Edit tab. Highlight Trim, then press OK.

3 Follow the screen prompts. The video is trimmed. (You can save it as a new video or replace the original.) Press the Shutter button halfway down to return to Capture mode. www.kodak.com/go/support 19 Working with pictures/videos Making a video action print From a video, you can make a 4-, 9-, or 16-up picture, suitable for a 4 x 6-inch (10 x 15 cm) print.



[You're reading an excerpt. Click here to read official KODAK EASYSHARE CD80 user guide](http://yourpdfguides.com/dref/3208388)
<http://yourpdfguides.com/dref/3208388>

1 Press the Review video, 4-, 9-, or 16-up picture button, then to find a Video 2 Press the Menu button, then to highlight the Edit tab. Highlight Action Print, then press OK.

3 Highlight an option, then press OK. Auto: The camera includes the first and last frames, then 2, 7, or 14 equally spaced frames. Manual: Choose the first and last frames; the camera chooses 2, 7, or 14 spaced frames. Full Manual: Choose 4, 9, or 16 frames. A 4-, 9-, or 16-up picture is created. Press the Shutter button halfway down to return to Capture mode. **IMPORTANT:** Your camera offers a built-in Help system. See page 40. 20 www.kodak.com/go/support Working with pictures/videos Understanding the review icons Video duration Print tag/number of print Protected Email tag Picture/Video number Select picture Shortcuts Add text tag View thumbnails Play video Upload tag Favorite tag Text tag name Battery level Date stamp

www.kodak.com/go/support 21 4 Doing more with your camera **IMPORTANT:** Your camera offers a built-in Help system. To get the most from your camera, See page 40. Using the menu button to change settings You can change settings to get the best results from your camera.

NOTE: Some modes offer limited settings. Some settings remain until you change them; others, until you change modes or turn off the camera. 1 Press the Menu 2 Press button, to highlight a tab: Capture/Video for the most common picture/video-taking settings Setup for other camera settings to highlight a setting, then press OK. .

) 3 Press 4 Highlight an option, then press OK. (Some options let you use Using the capture tab Press Menu, , Picture-taking Options , and OK to access **IMPORTANT:** Your camera offers a built-in Help system. settings See page 40. Exposure Compensation 0.0, +/-0.3, +/-0.7, +/-1.0, +/-1.3, +/-1.7, +/-2.

0 Make a picture lighter or darker. (Available in Auto mode.) To use a shortcut, see page 9. Picture Size See Camera specifications, page 43. Choose a picture resolution. 22 www.kodak.com/go/support Doing more with your camera Press Menu, , Picture-taking Options , and OK to access **IMPORTANT:** Your camera offers a built-in Help system. settings See page 40. Focus Mode Auto--for general picture-taking.

Select a large or concentrated Macro--for sharpness and detail in pictures at close range. area of focus. Use available light instead of flash, if possible. The camera automatically sets the focus distance depending on the zoom position. Infinity--for distant subjects; auto-focus framing marks are unavailable. Burst Off Take up to 3 pictures in quick On--press the Shutter button halfway to focus and set succession. exposure. Press the Shutter button completely down and hold it to take pictures. Self-timer 10 seconds--picture is taken after a 10-second delay (so you Take picture(s) after a timed have time to get into the scene). delay.

2 seconds--picture is taken after a 2-second delay (for a steady, shutter release on a tripod). 2 shot--first picture is taken after a 10-second delay. A second picture is taken 8 seconds later. Long Time Exposure None Choose how long the shutter 0.5, 1.0, 2.0, 4.0 seconds stays open. Color Mode High Color Choose color tones. Natural Color Unavailable in Video mode.

Low Color Black & White Sepia **NOTE:** EASYSHARE Software also lets you change a color picture to black-and-white or sepia. www.kodak.com/go/support 23 Doing more with your camera Press Menu, , Picture-taking Options , and OK to access **IMPORTANT:** Your camera offers a built-in Help system. settings See page 40. AF Control (Still) Continuous AF--because the camera is always focusing, Choose an auto-focus setting. there is no need to press the Shutter button halfway down to focus. Single AF--uses TTL-AF (through-the-lens auto focus) when the Shutter button is pressed halfway down. White Balance Auto--automatically corrects white balance. Ideal for general picture taking.

Choose your lighting condition. (Available in Auto Daylight--for pictures in natural lighting. mode.) Tungsten--corrects the orange cast of household light bulbs. Ideal for indoor pictures under tungsten or halogen lighting without flash.

Fluorescent--corrects the green cast of fluorescent lighting. Ideal for indoor pictures under fluorescent lighting without flash. Open Shade--for pictures in shade in natural lighting. Exposure Metering Multi-Pattern--evaluates lighting conditions throughout Evaluate light levels at specific the image to give an optimum picture exposure. Ideal for areas of a scene.

general picture taking. Center-Weight--evaluates the lighting conditions of the subject centered in the lens. Ideal for backlit subjects. Center-Spot--similar to Center-weight, except the metering is concentrated on a smaller area of the subject centered in the LCD. @ Ideal for general picture taking. area of focus. Center-Zone--evaluates the small area centered in the lens. @@@@Sharpness Control picture sharpness. @@settings See page 40. Video Size Choose a video resolution.

@@@@@@@@@@@@@@@@@If not, the camera uses internal memory. @@New Tag--create a tag. Delete Tag--delete a tag. Clear All--selected tags are cancelled. @@@@Image Storage Choose a storage location for pictures/videos. Set Tag Create tag names and assign them to pictures/videos. See page 34. Date Stamp Imprint the date on pictures. @picture is taken. @@See page 40.

All On Shutter Only All Off Set date and time. @@PAL--used in Europe and China. @@@@Language Reset Camera Reset settings to their default.

@@CAUTION: Cancel--exits without making a change. @@@@2 Close all open software applications before starting the installation.

IMPORTANT: If running WINDOWS OS, do not close the WinZip application. If prompted, allow EASYSHARE Software to access the Internet. 3 Follow the on-screen instructions to install the software. **NOTE:** When prompted, register your camera and software. Registering lets you sign up for information that keeps your system up-to-date.

To register later, visit www.kodak.com/go/register. 4 If prompted, restart the computer. For software help, click the Help button in EASYSHARE Software. 28 www.kodak.com/go/support Transferring, printing, tagging Transferring pictures/videos Using the USB cable Connect a KODAK USB Cable, Model U-8. Then turn on the camera. Using other options You can also use a KODAK Card Reader to transfer your pictures/videos.

Purchase accessories Learn more about connecting www.kodak.com/go/CD80accessories www.kodak.com/go/howto www.kodak.com/go/support 29 Transferring, printing, tagging Printing pictures Direct printing with a KODAK All-in-One Printer Your camera is compatible with PICTBRIDGE Technology, so you can print directly to PICTBRIDGE enabled Printers. You need a camera with fully charged batteries, a PICTBRIDGE enabled Printer, and a USB cable. Connecting the camera to a KODAK All-in-One Printer 1 Turn off the camera and printer. 2 Connect the appropriate USB cable from the camera to the printer.

Printing from a KODAK All-in-One Printer 1 Turn on the printer.



[You're reading an excerpt. Click here to read official KODAK](http://yourpdfguides.com/dref/3208388)

[EASYSHARE CD80 user guide](http://yourpdfguides.com/dref/3208388)

<http://yourpdfguides.com/dref/3208388>

Turn on the camera. The PictBridge logo is displayed, followed by the current picture and menu. (If no pictures are found, a message is displayed.) If the menu turns off, press any button to redisplay it.

2 Highlight a printing option, then press OK. Current Picture--Press to choose a picture. Choose the number of copies. Tagged Pictures--If your printer is capable, print pictures that you tagged for printing and choose a print size. Index Print--Print thumbnails of all pictures.

(This option requires one or more sheets of paper.) If the printer is capable, choose a print size. All Pictures--Print all pictures in internal memory or on a card. Choose the number of copies. Image Storage--Access Auto or Internal Memory. NOTE: During direct printing, pictures are not permanently transferred or saved to the printer. To transfer pictures to your computer, see page 29. Purchase accessories www.kodak.com/go/CD80accessories 30 www.kodak.com/go/support

Transferring, printing, tagging Disconnecting the camera from a KODAK All-in-One Printer 1 Turn off the camera and printer. 2 Disconnect the USB cable from the camera and the printer. Using a printer that is not PICTBRIDGE enabled After you transfer pictures from the camera to your computer, you can print them from EASYSHARE Software. For details, see Help in EASYSHARE Software. Ordering prints online KODAK Gallery (www.kodakgallery.com) is one of the many online print services offered in EASYSHARE Software. You can easily: Upload your pictures. Edit, enhance, and add borders to your pictures.

Store pictures, and share them with family and friends. Have prints, photo greeting cards, frames, and albums delivered to your door. Printing from an optional SD or SDHC Card Automatically print tagged pictures when you insert your card into a printer with an SD/SDHC Card slot. See your printer user's guide for details. Make prints at an SD/SDHC Card-capable KODAK Picture Kiosk.

(Contact a location prior to visiting. Visit www.kodak.com/go/picturemaker.) Take the card to your local photo retailer for professional printing.

www.kodak.com/go/support 31 Transferring, printing, tagging Tagging your pictures You can tag your pictures so they are easy to: Print Email Organize with a favorite tag Organize with a tag name that you create Tagging pictures for printing 1 Press the Review 2 Press the Menu 3 Press button. Press button. Press to locate a picture. to highlight Print, then press OK. to select the number of copies. 4 Optional: You can apply a print quantity to other pictures. Press for previous/next. Keep the print quantity as is, or press to change it.

Repeat this step until the desired print quantity is applied to the pictures. 5 Press OK. The Print icon appears in the status area. Press the Shutter button halfway down to return to Capture mode. IMPORTANT: Your camera offers a built-in Help system. See page 40. Printing tagged pictures When you transfer the tagged pictures to your computer, the EASYSHARE Software print screen opens. For details on printing, see Help in EASYSHARE Software. 32 www.kodak.com/go/support

Transferring, printing, tagging Tagging pictures/videos for emailing First, create a new email address: highlight Add Email, press OK, then use the on-camera keyboard. 1 Press the Review 2 Press 3 Press button. Press to locate a picture, then press OK. to highlight Email, then press OK. to locate an email address, then press OK.

4 To tag other pictures/videos with the same address, scroll through them. When the picture you want is displayed, press OK. 5 To send the pictures/videos to more than one address, repeat step 3. To remove a selection, highlight a checked address and press OK. To remove all email selections, highlight Clear All, then press OK.

Press the Shutter button halfway down to return to Capture mode. The Email icon appears in the status area. When you transfer the tagged pictures/videos to your computer, EASYSHARE Software prompts you to send the pictures/videos. For details, see Help in EASYSHARE Software. www.kodak.com/go/support

33 Transferring, printing, tagging Assigning the favorite tag to pictures/videos To make your favorite pictures/videos easier to locate in EASYSHARE Software, you can assign the favorite tag. 1 Press the Review button, then locate a picture/video. 2 Press the Share button. The favorite tag appears with the picture.

When you transfer the tagged pictures/videos to your computer, EASYSHARE Software opens and categorizes your pictures/videos with a 5-star rating tag. (To configure the Share button in different ways, see page 40.) Assigning other tags to pictures/videos First, create a new tag name: highlight New Tag, press OK, then use the on-camera keyboard. 1 Press the Review 2 Press the Menu button, then locate a picture/video. button. 3 Highlight Tag, then press OK. 4 Highlight a tag name, then press OK. 5 To assign the tag to other pictures, press to locate a picture, then press OK. The tag name appears with the picture. A plus (+) means the picture has more than one tag assigned.

To remove a selection, highlight a tag name and press OK. To remove all tag selections, highlight Clear All, then press OK. When you transfer the tagged pictures/videos to your computer, EASYSHARE Software opens and categorizes your pictures/videos with the appropriate tag. IMPORTANT: Your camera offers a built-in Help system. See page 40.

34 www.kodak.com/go/support Transferring, printing, tagging Assigning a tag to pictures/videos you take next Use the Set Tag feature to assign a tag name to the next pictures/videos you take. First, create a new tag name: highlight New Tag, press OK, then use the on-camera keyboard. 1 Press the Menu button. 2 Highlight the Setup tab. 3 Highlight Set Tag, then press OK. 4 Highlight a tag name, then press OK. The selected tag is displayed on the LCD. The tag is applied to new pictures/videos. Press the Shutter button halfway down to return to Capture mode. When you transfer the tagged pictures/videos to your computer, EASYSHARE Software opens and categorizes your pictures/videos with the appropriate tag. IMPORTANT: Your camera offers a built-in Help system. See page 40. www.kodak.com/go/support

35 6 Status Troubleshooting IMPORTANT: Your camera offers a built-in Help system. See page 40. Camera problems Solution Make sure the batteries are charged and installed correctly (see Camera does not turn on Camera does not turn off Camera buttons and controls do not function In Review, a blue or black screen is displayed instead of a picture Pictures remaining number does not decrease after taking a picture Flash does not fire page 1). Turn the camera off, then on again. Transfer all pictures to the computer (see page 29). Take another picture. Continue taking pictures. The camera is operating normally. (The camera estimates the number of pictures remaining after each picture is taken, based on picture size and content.)

) Check the flash setting, and change as needed (see page 6).



[You're reading an excerpt. Click here to read official KODAK EASYSHARE CD80 user guide](http://yourpdfguides.com/dref/3208388)
<http://yourpdfguides.com/dref/3208388>

NOTE: The flash does not fire in all modes. Memory card is almost Transfer the pictures to the computer (see page 29), or entirely full Delete pictures from the card (see page 13) or insert a new card. Battery life is short Make sure the correct battery type is installed (see page 47).

*Wipe the contacts with a clean, dry cloth before inserting a battery in the camera. Insert new or charged batteries (see page 1). 36
www.kodak.com/go/support Troubleshooting Status You cannot take a picture Solution Turn the camera off, then on again.*

Depress the Shutter button all the way (see page 4). Insert new or charged batteries (see page 1). Memory is full. Transfer pictures to the computer (see page 29), delete pictures (see page 13), or insert another card. Memory card not Card may be corrupted. Format the card in the camera (see recognized or camera page 27). freezes with card Use another memory card. Only SD or SDHC Cards are supported. Cannot find the To view pictures on a card or in internal memory, see page 12. desired picture/video Computer/connectivity problems Status Pictures do not transfer to computer Slide Show does not run on an external video device Computer does not communicate with the camera Solution See Help in EASYSHARE Software.

Adjust the camera Video Out setting to NTSC or PAL (see page 27). Make sure the external device settings are correct. (See the device's user's guide). Make sure the batteries are charged and installed correctly (see page 1). Turn on the camera. Make sure the USB cable model U-8 is connected to the camera and the computer (see page 29). Make sure EASYSHARE Software is installed (see page 28). www.kodak.com/go/support 37 Troubleshooting Picture quality problems Status Picture is not clear Solution To automatically set exposure and focus, press the Shutter button halfway.

When the framing marks turn green, press the Shutter button completely down to take the picture. Clean the lens (see page 45). Make sure the camera is not in Macro mode if you are more than 27.6 in. (70 cm) from your subject.

Place the camera on a flat, steady surface or use a tripod (especially in high-zoom settings or in low light). Picture is too dark Reposition the camera for more available light. Use Fill flash (see page 6) or change your position so light is not behind the subject. Move so that the distance between you and the subject is within the effective flash range. (See camera specifications starting on page 43.

) To automatically set exposure and focus, press the Shutter button halfway. When the framing marks turn green, press the Shutter button completely down to take the picture. Picture is too light Reposition the camera to reduce the amount of available light. Turn the flash off (see page 6). Move so that the distance between you and the subject is within the effective flash range. (See camera specifications starting on page 43.) To automatically set exposure and focus, press the Shutter button halfway. When the framing marks turn green, press the Shutter button completely down to take the picture. In Auto mode, adjust the Exposure Compensation (see page 22). 38 www.

kodak.com/go/support Troubleshooting Direct printing (PICTBRIDGE enabled Printer) problems Status Solution Cannot find the Use the Direct printing menu to change the image storage location. desired picture The Direct printing Press any camera button to redisplay the menu. menu interface turns off Cannot print pictures Make sure there is a connection between the camera and the printer (see page 30). Make sure the printer and the camera have power. Camera or printer Follow the prompts to resolve the issue. display an error message www.kodak.com/go/support 39 7 Getting help Getting help from your camera You want the most from your camera. You want to understand: What it can do for you And how to take the best possible pictures and videos Great news! Your camera offers a built-in Help system.

It describes every setting for every menu choice. If you learn nothing else about your camera, learn how to use on-camera Help. Because the more you know your camera, the more confident you become! Turning on camera Help 1 Press the Menu button then highlight a menu choice. 2 Press the Info button. Scroll through a Help topic 40 www.

kodak.com/go/support Getting help Getting help on the Web Camera Email, write, or phone Kodak Get support for your product (FAQs, troubleshooting information, arrange for repairs, etc.) Purchase camera accessories (lenses, cards, etc.) Download the latest camera firmware and software See online demonstrations of your camera Register your camera www.kodak.

com/go/contact www.kodak.com/go/CD80support www.kodak.com/go/CD80accessories www.kodak.com/go/CD80downloads www.kodak.com/go/howto www.kodak.

com/go/register Software www.kodak.com/go/easysharesw (or see Help in EASYSHARE Software) Get help with the WINDOWS Operating System and www.kodak.com/go/pcbasics working with digital pictures Get information on EASYSHARE Software Other Get support for cameras, software, accessories, more www.kodak.com/go/support Get information on KODAK Inkjet Products www.kodak.com/go/inkjet Optimize your printer for truer, more vibrant colors www.kodak.

com/go/onetouch www.kodak.com/go/support 41 Getting help Getting help on the telephone NOTE: If you have questions concerning this product, you may speak with Kodak customer support. Australia Austria Belgium Brazil Canada China Czech Republic Denmark Finland France Germany Greece Hong Kong Hungary India Ireland Italy Japan Korea 1800 267 588 0179 567 357 02 713 14 45 0800 891 42 13 1 800 465 6325 800 820 6027 00 800 56325000 3 848 71 30 0800 1 17056 01 55 1740 77 069 5007 0035 00800 44140775 800 901 514 06 80 456 325 91 80 41374555 (toll free 000800 440 1227) 01 407 3054 02 696 33452 03 5540 9002 080 708 5600 Netherlands New Zealand Norway Philippines Poland Portugal Russia Singapore Slovakia Spain Sweden Switzerland Taiwan Thailand Turkey United Kingdom United States International Toll Line International Toll Fax 020 346 9372 0800 880 120 23 16 21 33 1 800 1 888 9600 00800 4411625 021 415 4125 8 495 929 9166 800 6363 036 00 800 56325000 91 749 76 53 08 587 704 21 044 838 53 51 0800 096 868 001 800 631 0017 00800 448827073 0870 243 0270 1 800 235 6325 +44 131 458 6714 +44 131 458 6962 42 www.kodak.

com/go/support 8 Appendix Camera specifications CCD--1/2.3-type, 10 MP Effective pixels--10.2 MP (3688 x 2770) LCD--5.99 cm (2.4 in.), 115K pixels Image storage--Optional SD/SDHC Card (The SD logo is a trademark of the SD Card Association.) Maximum supported card size: 32 GB Internal storage capacity--16 MB internal memory (11 MB available for image storage. 1 MB equals one million bytes.) Taking lens--3X optical zoom; f/2.9-f/5.5; 35 mm equivalent: 3296 mm Lens protection--Built-in Digital zoom--5X continuous Focus system--TTL-AF (through-the-lens auto focus); Auto: Multi-Zone, Center-Zone.



[You're reading an excerpt. Click here to read official KODAK](http://yourpdfguides.com/dref/3208388)

[EASYSHARE CD80 user guide](http://yourpdfguides.com/dref/3208388)

<http://yourpdfguides.com/dref/3208388>

Working range: 60 cm (23.6 in.)infinity @ wide, normal 60 cm (23.6 in.

infinity @ telephoto, normal 1070 cm (3.927.6 in.) @ wide, Macro mode 3570 cm (13.827.6 in.) @ telephoto, Macro mode 10 m (32.8 ft)infinity @ wide, Landscape mode Auto focus control--Still: Continuous and Single AF (Multi-zone, Center zone) Face detection--Up to 5 faces Shutter speed--0.51/1400 seconds (Long Time Exposure: 0.54 seconds) ISO speed--Auto: 80240 Manual: 80, 100, 200, 400, 800, 1250 www.kodak.com/go/support 43 Appendix Exposure metering--TTL-AE; Multi-Pattern, Center-Weight, Center-Spot Exposure compensation--+/-2.0 EV with 1/3 EV step White Balance--Auto, Daylight, Tungsten, Fluorescent, Open Shade Electronic Flash--Auto flash; Auto, Fill, Red Eye, Off; Guide No.6; working range: @ ISO 240 in Auto mode: 0.63.

2 m (210.5 ft) @ wide; 0.61.8 m (25.9 ft) @ telephoto Burst mode--Maximum 3 pictures @ 1.

7 fps; Auto Exposure, Auto Focus, Auto White Balance executed for first shot only Capture modes--Auto, Close-up, Scene modes, Blur Reduction, Sport, Video Image file format-- Still: EXIF 2.21 (JPEG compression); file organization DCF Video: QUICKTIME (CODEC Motion JPEG); audio: PCM) Picture size--10.1 MP (4:3): 3664 x 2748 pixels 8.9 MP (3:2): 3664 x 2442 pixels 7.6 MP (16:9): 3664 x 2062 pixels 5.0 MP (4:3): 2592 x 1944 pixels 3.1 MP (4:3): 2048 x 1536 pixels 2.2 MP (3:2): 1800 x 1200 pixels 2.1 MP (16:9): 1920 x 1080 pixels 1.2 MP (4:3): 1280 x 960 pixels Color modes--High Color, Natural Color, Low Color, Black & White, Sepia Sharpness modes--Sharp, Normal, Soft Video capture--< 80 minutes maximum in VGA, QVGA VGA (640 x 480 @ 30 fps) QVGA (320 x 240 @ 30 fps) Video blur reduction--Yes 44 www.

kodak.com/go/support Appendix Communication with computer--USB 2.0 full speed (PIMA 15740 protocol); via USB cable model U-8 Video output--NTSC or PAL Microphone--Yes Beeper--Yes PICTBRIDGE Support--Yes Power--KODAK Oxy-Alkaline Digital Camera Batteries AA; KODAK MAX Alkaline Battery AA; KODAK Ni-MH Pre-Charged Rechargeable Digital Camera Batteries AA; KODAK Ni-MH Rechargeable Digital Camera Batteries AA Tripod mount--1/4 inch Size--92.5 x 62 x 24.7 mm (3.6 x 2.4 x 1.0 in.) @ power off Weight--110 g (3.9 oz) without card or batteries Operating temperature--040° C (32104° F) Care and maintenance If you suspect water has gotten inside the camera, remove the batteries and card.

Allow all components to air-dry for at least 24 hours before using the camera. Blow gently on the lens or LCD to remove dust and dirt. Wipe gently with a soft, lint-free cloth or an untreated lens-cleaning tissue. Do not use cleaning solutions unless designed specifically for camera lenses. Do not allow chemicals, such as suntan lotion, to contact painted surfaces.

Service agreements may be available in your country. Contact a dealer of KODAK Products for more information. For digital camera disposal or recycling information, contact your local authorities. In the US, visit the Electronics Industry Alliance at www.eiae.

org or www.kodak.com/go/CD80support. www.kodak.com/go/support 45 Appendix Upgrading your software and firmware Download the latest versions of KODAK EASYSHARE Software and the camera firmware (the software that runs on the camera). Visit www.kodak.com/go/CD80downloads. Storage capacities The LCD displays the approximate number of pictures (or minutes/seconds of video) remaining.

For average SD Card capacities, visit www.kodak.com/go/SDcapacities. Actual storage capacity varies depending on subject composition, card size, and other factors. You may be able to store more or fewer pictures and videos. Favorites take up additional space in internal memory. Important safety instructions CAUTION: Do not disassemble this product; there are no user-serviceable parts inside. Refer servicing to qualified service personnel. KODAK AC Adapters and Battery Chargers are intended for indoor use only. The use of controls, adjustments, or procedures other than those specified herein may result in exposure to shock and/or electrical or mechanical hazards.

If the LCD breaks, do not touch the glass or liquid. Contact Kodak customer support. The use of an accessory that is not recommended by Kodak may cause fire, electric shock, or injury. For approved accessories, go to www.kodak.com/go/accessories.

Use only a USB-certified computer equipped with a current-limiting motherboard. Contact your computer manufacturer if you have questions. If using this product in an airplane, observe all instructions of the airline. When removing the battery, allow it to cool; it may be hot. Follow all warnings and instructions supplied by the battery manufacturer.

Use only batteries approved for this product to avoid risk of explosion. www.kodak.com/go/support 46 Appendix Keep batteries out of the reach of children.

Do not allow batteries to touch metal objects, including coins. Otherwise, a battery may short circuit, discharge energy, become hot, or leak. Do not disassemble, install backward, or expose batteries to liquid, moisture, fire, or extreme temperature. Remove the battery when the product is stored for an extended period of time. In the unlikely event that battery fluid leaks inside the product, contact Kodak customer support. In the unlikely event that battery fluid leaks onto your skin, wash immediately with water and contact your local health provider.

For additional health-related information, contact your local Kodak customer support. Go to www.kodak.com/go/REACH for information about the presence of substances included on the candidate list according to article 59(1) of Regulation (EC) No. 1907/2006 (REACH). Dispose of batteries according to local and national regulations. Go to www.kodak.com/go/kes. Do not charge non-rechargeable batteries.

For more information, go to www.kodak.com/go/batteries. Battery replacement, battery life KODAK Oxy-Alkaline Digital Camera Batteries AA: >200 pictures KODAK MAX Alkaline Battery, AA: >200 pictures KODAK Ni-MH Pre-Charged Rechargeable Digital Camera Batteries AA: >500 pictures per charge KODAK Ni-MH Rechargeable Digital Camera Batteries AA: >500 pictures per charge Battery life per CIPA testing method. (Approx. number of pictures in Auto mode.) Actual life may vary based on usage. www.kodak.com/go/support 47 Appendix Extending battery life Use power-saving features (see Using the Setup menu, page 26).

Dirt on the battery contacts can affect battery life. Wipe the contacts with a clean, dry cloth before loading the batteries in the camera. Battery performance is reduced at temperatures below 41° F (5° C). When using your camera in cold weather, carry spare batteries and keep them warm. Do not discard cold batteries that do not work; when they return to room temperature, they may be usable. Limited warranty Kodak warrants KODAK Consumer Electronic Products and Accessories ("Products"), excluding batteries, to be free from malfunctions and defects in both materials and workmanship for one year from the date of purchase.



[You're reading an excerpt. Click here to read official KODAK EASYSHARE CD80 user guide](http://yourpdfguides.com/dref/3208388)
<http://yourpdfguides.com/dref/3208388>

Retain the original dated sales receipt. Proof of the date of purchase will be required with any request for warranty repair. Limited warranty coverage
Warranty service is only available from within the country where the Products were originally purchased. You may be required to ship Products, at your expense, to the authorized service facility for the country where the Products were purchased.

Kodak will repair or replace Products if they fail to function properly during the warranty period, subject to any conditions and/or limitations stated herein. Warranty service will include all labor as well as any necessary adjustments and/or replacement parts. If Kodak is unable to repair or replace a Product, Kodak will, at its option, refund the purchase price paid for the Product provided the Product has been returned to Kodak along with proof of the purchase price paid. @@@@Limitations This warranty does not cover circumstances beyond Kodak's control. This warranty does not apply when failure is due to shipping damage, accident, alteration, modification, unauthorized service, misuse, abuse, use with incompatible accessories or attachments (such as third party ink or ink tanks), failure to follow Kodak's operation, maintenance or repacking instructions, failure to use items supplied by Kodak (such as adapters and cables), or claims made after the duration of this warranty. Kodak makes no other express or implied warranty for this product, and disclaims the implied warranties of merchantability and fitness for a particular purpose. In the event that the exclusion of any implied warranty is ineffective under the law, the duration of the implied warranty will be one year from the purchase date or such longer period as required by law. The option of repair, replacement, or refund is Kodak's only obligation. Kodak will not be responsible for any special, consequential or incidental damages resulting from the sale, purchase, or use of this product regardless of the cause. Liability for any special, consequential or incidental damages (including but not limited to loss of revenue or profit, downtime costs, loss of the use of the equipment, cost of substitute equipment, facilities or services, or claims of your customers for such damages resulting from the purchase use or failure of the Product), regardless of cause or for breach of any written or implied warranty is expressly disclaimed.

Your rights Some states or jurisdictions do not allow exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. Some states or jurisdictions do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you.

This warranty gives you specific rights, and you may have other rights which vary from state to state or by jurisdiction. www.kodak.com/go/support 49 Appendix Outside the United States and Canada In countries other than the United States and Canada, the terms and conditions of this warranty may be different. Unless a specific Kodak warranty is communicated to the purchaser in writing by a Kodak company, no warranty or liability exists beyond any minimum requirements imposed by law, even though defect, damage, or loss may be by negligence or other act. Regulatory compliance FCC compliance and advisory This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed or used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: 1) reorient or relocate the receiving antenna; 2) increase the separation between the equipment and the receiver; 3) connect the equipment to an outlet on a circuit different from that to which the receiver is connected; 4) consult the dealer or an experienced radio/TV technician for additional suggestions. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation. 50 www.kodak.com/go/support Appendix MPEG-4 Use of this product in any manner that complies with the MPEG-4 visual standard is prohibited, except for use by a consumer engaging in personal and non-commercial activities. China RoHS Russian GOST-R Eastman Kodak Company Rochester, NY 14650 AIO-40 www.kodak.com/go/support 51 Appendix Korean Class B ITE VCCI Class B ITE Waste Electrical and Electronic Equipment labeling In Europe: For human/environmental protection, it is your responsibility to dispose of this equipment at a collection facility established for this purpose (separate from municipal waste).

For more information, contact your retailer, collection facility, or appropriate local authorities; or visit www.kodak.com/go/recycle. Product weight: 110 g (3.9 oz) Australian C-Tick NI37 Canadian DOC statement DOC Class B Compliance--This Class B digital apparatus complies with Canadian ICES-003. Observation des normes-Classe B--Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada. 52 www.kodak.com/go/support Index A A/V out, 15 about this camera, 27 accessories, 29 battery, 48 buying, 41 SD/SDHC Card, 3 AF control (Still), 24 AF zone, 24 auto enhancement, 17 focus control, 24 focus framing marks, 4 power off, 27 auto focus (AF) zone, 24 auto power off, 27 B backlight, 8 battery expected life, 47 loading, 1 types, 47 battery guidelines, 48 beach, 8 button delete, 5 review, ii C cable www.kodak.com/go/support 1 audio/video, 15 USB, 29 camera sounds, 27 Canadian compliance, 52 care & maintenance, 45 care and maintenance, 45 children, 8 clock, setting, 2 color mode, 23 computer connecting camera, 28 transfer to, 28 connector, USB / A/V, 15, 29 copy pictures card to memory, 18 memory to card, 18 to computer via USB cable, 28 cropping pictures, 17 customer support, 42 customize camera, 26 D date setting, 2 date stamp, 26 delete button, ii deleting during quickview, 5 from internal memory, 13 from SD/SDHC Card, 13 protecting pictures, videos, 13 digital zoom, 5 displaying slide show, 15 53 Index disposal, recycling, 45 downloading pictures, 28 E EASYSHARE Software, 28 edit videos, 19 emailing pictures, videos, 33 expected battery life, 47 exposure long time, 23, 26 metering, 24 exposure compensation, 22 exposure metering, 24 external video device viewing pictures, videos, 15 F favorites tagging, 34 FCC compliance, 50 fireworks, 8 firmware, upgrading, 46 flash button, i flash, using, 6 flower, 8 focus framing marks, 4 focus mode, 23 format, 27 framing marks, 4 G guidelines, battery, 48 H help camera help, 40 54 Web links, 40 high ISO, 8 I icons, modes, 7 image storage, 26 installing battery, 1 SD/SDHC Card, 3 software, 28 ISO speed, 25 K Kodak EasyShare software installing, 28 upgrading, 46 Kodak Perfect Touch technology, 17 Kodak Web sites, 40 L language, 27 LCD, ii brightness, 26 reviewing pictures, 12 reviewing videos, 12 LCD brightness, 26 lens cleaning lens, 45 light, self-timer, i loading battery, 1 SD/SDHC Card, 3 software, 28 long time exposure, 23, 26 www.kodak.com/go/support



[You're reading an excerpt. Click here to read official KODAK EASYSHARE CD80 user guide](http://yourpdfguides.com/dref/3208388)
<http://yourpdfguides.com/dref/3208388>

kodak.com/go/support Index M magnify a picture, 12 maintenance, camera, 45 make picture from video, 19 manner/museum, 8 memory inserting card, 3 menu button, ii menu settings, 22 microphone, i mode dial, i modes, 7 backlight, 8 beach, 8 children, 8 fireworks, 8 flower, 8 high ISO, 8 manner/museum, 8 night landscape, 8 night portrait, 8 scene (SCN), 8 self-portrait, 8 snow, 8 text, 8 multiple selections, 14 multi-up, 14 N night landscape, 8 night portrait, 8 O online prints, ordering, 31 www.kodak.com/go/support P Perfect Touch technology, 17 PICTBRIDGE enabled printer, 30 picture size, 22 pictures copying, 18 cropping, 17 emailing tagged, 33 Kodak Perfect Touch, 17 printing, 31 printing tagged, 32 protecting, 13 review icons, 21 reviewing, 12 tagging, 32 taking, modes, 7 transfer via USB cable, 28 pictures/video deleting, 13 playing a video, 12 power camera, 2 pre-tagging, 35 printing from a card, 31 from computer, 31 optimizing printer, 40 order online, 31 PICTBRIDGE, 30 tagged pictures, 31 protecting pictures, videos, 13 Q quickview, using, 5 55 Index R recycling, disposal, 45 regulatory information, 50 repair, 41 reset camera, 27 review button, ii reviewing pictures/video as you take them, 5 deleting, 13 LCD, 12 protecting, 13 slide show, 15 running slide show, 15 S safety, 46 scene modes (SCN), 8 SD/SDHC Card inserting, 3 printing from, 31 select multiple pictures/videos, 14 self-portrait, 8 self-timer, 10 self-timer light, i service and support telephone numbers, 42 set tag, 26 setting AF zone, 24 auto power off, 27 auto-focus, 24 camera sounds, 27 color mode, 23 date and time, 2 56 date stamp, 26 exposure metering, 24 image storage, 26 ISO, 25 language, 27 LCD brightness, 26 long time exposure, 23, 26 picture size, 22 picture-taking mode, 7 self-timer, 10 sharpness, 25 video out, 27 video size, 25 white balance, 24 setting up the camera, 1 setup menu, 26 Share button, 26 share button, ii sharpness, 25 shutter problems, 37 self-timer delay, 10 slide show running, 15 snow, 8 software installing, 28 upgrading, 46 sounds, 27 specifications, camera, 43 strap, 1 strap post, ii support, technical, 42 www. kodak.com/go/support Index T tagging creating tags, 34 favorites, 34 for email, 33 for print, 32 pre-tagging, 35 taking pictures, videos, 4 telephone support, 42 television, slide show, 15 text, 8 time, setting, 2 timer, shutter delay, 10 transfer, via USB cable, 28 trash can, deleting, 5 trimming a video, 19 troubleshooting, 36 turning camera on and off, 2 U undelete, undo, 13 upgrading software, firmware, 46 URLs, Kodak Web sites, 40 USB transferring pictures, 28 V VCCI compliance, 52 video action print, 20 copying, 18 edit, 19 emailing tagged, 33 out, 27 www.kodak.com/go/support playback, 12 protecting, 13 review icons, 21 size, 25 transfer to computer, 28 viewing, 12 video out, 27 video size, 25 viewing by multi-up, 14 picture, after taking, 5, 12 W warranty, 48 white balance, 24 Z zoom digital, 5 zoom button, ii 57 .



[You're reading an excerpt. Click here to read official KODAK EASYSHARE CD80 user guide](http://yourpdfguides.com/dref/3208388)
<http://yourpdfguides.com/dref/3208388>