



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for KODAK EASYSHARE CX7330. You'll find the answers to all your questions on the KODAK EASYSHARE CX7330 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual KODAK EASYSHARE CX7330**  
**User guide KODAK EASYSHARE CX7330**  
**Operating instructions KODAK EASYSHARE CX7330**  
**Instructions for use KODAK EASYSHARE CX7330**  
**Instruction manual KODAK EASYSHARE CX7330**

---

## Kodak EasyShare CX7330 zoom digital camera



### User's guide

[www.kodak.com](http://www.kodak.com)

For interactive tutorials, [www.kodak.com/go/howto](http://www.kodak.com/go/howto)

For help with your camera, [www.kodak.com/go/cx7330support](http://www.kodak.com/go/cx7330support)



[You're reading an excerpt. Click here to read official KODAK EASYSHARE CX7330 user guide](http://yourpdfguides.com/dref/528600)  
<http://yourpdfguides.com/dref/528600>



.....  
.....  
.....  
*8 Taking a picture .....*

.....  
.....  
.....  
.....  
.....  
.....  
.....

*8 Taking a video .....*

.....  
.....  
.....  
.....  
.....  
.....  
.....

*.. 8 Camera modes.....*

.....  
.....  
.....  
.....  
.....  
.....  
.....

*.... 9 Using the camera screen as a viewfinder .....*

.....  
.....  
.....  
.....

*..... 10 Reviewing the picture or video just taken.....*

.....  
.....  
.....

*. 12 Using optical zoom .....*

.....  
.....  
.....  
.....  
.....  
.....

.....  
..... 13 Using digital zoom .

.....  
.....  
.....

.....  
.....  
.....

.....  
... 13 Using the flash..

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

... 14 Putting yourself in the picture.....

.....  
.....

.....  
.....  
.....

. 16 Putting yourself in the video .....

.....  
.....

.....  
.....  
.....

. 16 Taking a burst series of pictures.....

.....  
.....

.....  
.....

..... 17 Changing picture-taking settings ....

.....  
.....  
.....

.....  
.....

.... 18 Customizing your camera .



.....  
.....  
.....

..... 25 Magnifying pictures..

.....  
.....  
.....  
.....

. 25 Protecting pictures and videos from deletion...

.....  
.....

.. 26 Tagging pictures/videos for albums..

.....  
.....  
.....  
.....  
.....

..... 26 Running a slide show ...

.....  
.....  
.....

.. 27 Displaying pictures and videos on a television...

.....  
.....  
.....

. 28 Copying pictures and videos .....

.....  
.....  
.....  
.....

. 29 Viewing picture/video information .....

.....  
.....  
.....

.....  
.....  
.. 29 iv 4 Installing the software ...  
.....  
.....

.....  
.....  
... 30 Minimum system requirements ..  
.....  
.....  
.....  
.....

..... 30 Install the software .  
.....  
.....  
.....  
.....  
.....  
.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.. 31 5 Sharing pictures and videos .....

.....  
.....  
.....  
.....  
.....  
.....  
.....

..... 32 Tagging pictures for printing...  
.....  
.....  
.....  
.....

..... 33 Tagging pictures and videos for emailing ...  
.....  
.....  
.....  
.....

..... 34 Tagging pictures and videos as favorites ..

.....  
.....  
.....

.....  
.....  
.....

35 6 Transferring and printing pictures .....

.....  
.....  
.....  
.....

... 36 Transferring pictures with the USB cable.....

.....  
.....  
.....

.....  
.....

. 36 Printing pictures from your computer ....

.....  
.....  
.....  
.....  
.....

... 37 Ordering prints online .....

.....  
.....  
.....  
.....  
.....  
.....  
.....

.. 37 Printing from an optional SD/MMC card ...

.....  
.....  
.....  
.....

.... 37 Printing without a computer.....

.....  
.....  
.....  
.....

.....  
.....  
.....

.... 37 7 Troubleshooting .....

.....  
.....  
.....  
.....  
.....  
.....

.....  
.....

..... 38 Camera problems.....

.....  
.....  
.....

.....  
.....  
.....

.....  
.....  
.....

. 38 Computer/connectivity problems.....

.....  
.....  
.....

.....  
.....

39 Picture quality problems .....

.....  
.....  
.....  
.....

.....  
.....  
.....

. 40 Camera ready light status.....

.....  
.....  
.....

.....  
.....  
.....

..... 41 8 Getting help .....

.....  
.....  
.....

.....  
.....  
.....

.. 42 Helpful links..

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... 42 Software help....

.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

..... 42 Telephone customer support ..

.....  
.....  
.....  
.....

.....  
.....  
.....

..... 42 9 Appendix ...

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

.... 44 Camera specifications .

.....  
.....  
.....  
.....  
.....

.....  
.....  
.....

..... 44 Tips, safety, maintenance ..

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.. 46 Storage capacities .....



Otherwise, a battery may short circuit, discharge energy, become hot, or leak. For rechargeable battery disposal information, see the Rechargeable Battery Recycling Corporation Web site at [www.rbrcc.com](http://www.rbrcc.com). For more information on batteries, see [www.kodak.com/global/en/service/batteries/batteryUsage.jhtml](http://www.kodak.com/global/en/service/batteries/batteryUsage.jhtml)  
Turning the camera on and off Turn the Mode dial from Off to any other position. The Ready light blinks green while the camera performs a self-check, then stays on when the camera is ready. To turn off the camera, turn the Mode dial to Off.

The camera completes operations that are in process. 4 Getting started Changing the display If you want to Turn the camera screen on or off. Change the camera screen setting so that it is on whenever the camera is on. Then do this Press the OK button. See Liveview, page 20. . Show/Hide the status icons when the Press camera screen is off. Setting the date and time Setting the date & time, first time The Date and Time have been reset message appears the first time you turn on the camera or if the batteries are removed for an extended time. 1 SET DATE & TIME is highlighted. Press the OK button. (Select Cancel to set the date and time at a later time.) 2 Go to step 4 below, Setting the date & time, anytime. Setting the date & time, anytime 1 Turn on the camera. Press the Menu button. 2 Press 3 Press 4 Press setting.  
to highlight Setup Menu to highlight Date & Time , then press the OK button.



[You're reading an excerpt. Click here to read official KODAK EASYSHARE CX7330 user guide](#)  
<http://yourpdfguides.com/dref/528600>

, then press the OK button. to advance to the next to adjust the date and time. Press 5 When finished, press the OK button. 6 Press the Menu button to exit the menu.

*NOTE: Depending on your computer operating system, Kodak EasyShare software may let your computer update the camera clock when you connect the camera. See the EasyShare software Help for details. 5 Getting started Checking camera and pto-focus framing marks, see page 11. OK Framing marks 4 Press the Shutter button halfway and hold to set the exposure and focus. When the framing marks change from blue to red, press the rest of the way down to take the picture. 5 To turn off the camera screen, press the OK button. To make the camera screen turn on whenever the camera is on, see Liveview, page 20. 10 Taking pictures and videos Using the auto-focus framing marks When using the camera screen as a viewfinder, framing marks indicate where the camera is focusing. For the best possible pictures, the camera attempts to focus on foreground subjects, even if the subjects are not centered in the scene. NOTE: This procedure does not apply to videos.*

*1 Press the OK button to turn on the camera screen. 2 Press the Shutter button halfway and hold. When the framing marks turn red, focus is accomplished. While the shutter button is pressed halfway: Center focus Center wide focus Side focus Framing marks Center and side focus Left and right focus 3 Press the Shutter button the rest of the way down to take the picture. 4 If the camera is not focusing on the desired subject (or if the framing marks disappear and the Ready light blinks red), release your finger, recompose the scene, and go to Step 2. NOTE: Framing marks appear only when the camera screen is on. Framing marks do not appear in Landscape mode. 11 Taking pictures and videos Reviewing the picture or video just taken After you take a picture or video, the camera screen displays a Quickview for approximately 5 seconds. While the picture or video is displayed, you can: Delete Review: If you take no action, the picture/video is saved. Play (video): Press the OK button to play the video.*

*(If the camera is connected to a television, press to adjust the volume. See page 28.) Share: Press the Share button to tag a picture/video for email or as a favorite, or to tag a picture for print. (See page 33.) OK Share Delete: Press the Delete button while the picture/video and are displayed. NOTE: Only the final picture of a burst series (see page 17) is displayed during Quickview. If you select Delete, all pictures in the burst series are deleted. To delete selectively, do so in Review (see page 24). 12 Taking pictures and videos Using optical zoom Use optical zoom to get up to 3X closer to your subject.*

*Optical zoom is effective when the lens is no closer than 23. 6 in. (60 cm) to the subject or 5.1 in. (13 cm) in Close-up mode. You can change optical zoom before (but not during) video recording. 1 Use the viewfinder or camera screen to frame your subject. 2 Press Telephoto (T) to zoom in. Press Wide Angle (W) to zoom out. 3 Press the Shutter button halfway and hold to set the exposure and focus, then press the rest of the way down to take the picture. (When taking videos, press and release the Shutter button.*

*) Using digital zoom Use digital zoom in any Still mode to get an additional 3.3X magnification beyond optical zoom. Combined zoom settings are from 3.3X to 10X in 0.3 increments. You must turn on the camera screen to activate digital zoom. 1 If the camera screen is off, press the OK button to turn it on. 2 Press the Telephoto (T) button to the optical zoom limit (3X). Release the button, then press it again. The camera screen displays the zoomed image, the zoom value, and the digital zoom icon.*

*3 Press the Shutter button halfway and hold to set the exposure and focus, then press the rest of the way down to take the picture. NOTE: You cannot use digital zoom for video recording. IMPORTANT: You may notice a decrease in printed image quality when using digital zoom. 13 Taking pictures and videos Using the flash Use the flash when you take pictures at night, indoors, or outdoors in heavy shadows. You can change the flash setting in any Still mode; the default flash setting is restored when you exit the mode or turn off the camera.*

*Flash Range Wide Angle 2-11.8 ft (0.6-3.6 m) Telephoto 2-6.9 ft (0.6-2.1 m) Turning on the flash Press the button to scroll through the flash options. The active flash icon is displayed in the camera screen status area. Flash/status button Flash Mode Auto Off Fill Flash Fires When the lighting conditions require it. Never Every time you take a picture, regardless of the lighting conditions. Use when the subject is in shadow or is "backlit" (when the sun is behind the subject). In low light, hold the camera steady, or use a tripod. Red-eye Once, so the subject's eyes become accustomed to the flash, then fires again when the picture is taken. (If the lighting conditions require flash but do not require Red-eye reduction, the flash may fire only once.) 14 Taking pictures and videos Flash settings in each mode For the best possible pictures, flash settings are preset for each capture mode.*

*Icon Capture mode Default flash setting Auto\* Auto Auto\* Available flash To return to the settings default flash setting: (press the Flash button to change) Auto, Flash Off, Fill Flash, Red-eye Exit the mode or turn off the camera. Auto Sport Night Landscape Off Close-up Video Burst Off Off Off None Flash cannot be turned on. \* When you change to Red-eye in these modes, it remains until you change it. 15 Taking pictures and videos Putting yourself in the picture The Self Timer creates a 10-second delay between the time you press the Shutter button and the time the picture is taken. 1 Place the camera on a flat surface or tripod. 2 In any Still mode, press the Self Timer button. The Self Timer icon appears in the status area. 3 Compose the scene. Then press the Shutter button halfway and hold to set the exposure and focus, then press the rest of the way down. Move so that you are in the scene.*

*The Self Timer light blinks slowly for 8 seconds (then quickly for 2 seconds) before the picture is taken. The Self Timer turns off after you take the picture or if you change modes. To cancel the Self Timer before the picture is taken, press the Self Timer button. (The Self Timer setting remains active.) To turn off the Self Timer, press the Self Timer button twice.*

*Putting yourself in the video 1 Place the camera on a flat surface or tripod. 2 Turn the Mode dial to Video 3 Press , then press the Self Timer button. to choose a video length, then press the OK button. 4 Compose the scene, then press the Shutter button completely down. Move so that you are in the scene.*

*16 Taking pictures and videos Taking a burst series of pictures Burst lets you to take up to 3 pictures in quick succession (approximately 3 frames per second).*



[You're reading an excerpt. Click here to read official KODAK EASYSHARE CX7330 user guide](http://yourpdfguides.com/dref/528600)  
<http://yourpdfguides.com/dref/528600>

Burst is ideal for capturing sporting events or objects in motion. Flash and Self Timer are disabled when you use Burst. Turn on burst Burst Icon Burst button In any Still mode, press the Self Timer/Burst button twice. The Burst icon appears in the status area. NOTE: The setting remains until you change it or turn off the camera. Take the burst pictures 1 Press the Shutter button halfway and hold to set the auto-focus and exposure for all the pictures in the sequence.

2 Press the Shutter button the rest of the way down and hold it to take the pictures. The camera takes up to 3 pictures in quick succession. It stops taking pictures when you release the Shutter button, when 3 pictures are taken, or when there is no more storage space.

Exposure, focus, white balance, and orientation are set for the first picture and applied to all pictures. 17 Taking pictures and videos Changing picture-taking settings You can change settings to get the best results from your camera: 1 Press the Menu button. (Some settings are unavailable in some modes.) 2 Press button. to highlight the setting you wish to change, then press the OK 3 Choose an option, then press the OK button. 4 Press the Menu button to exit. Setting Image Storage Choose a storage location for pictures and videos. This setting remains until you change it. Exposure Compensation (Still mode) Choose how much light enters the camera. This setting remains until you turn the Mode dial or turn off the camera.

Picture Quality Choose a picture resolution. This setting remains until you change it. Icon Options Auto (default)--the camera uses the card if one is in the camera. If not, the camera uses internal memory. Internal Memory--the camera always uses internal memory, even if a card is installed.

If pictures are too light, decrease the value. If pictures are too dark, increase the value. Unavailable in Video mode. Best --3.1 M pixels; for printing up to 11 x 14 in.

(28 x 36 cm). Best (3:2) --2.8 M pixels; ideal for printing 4 x 6 in. (10 x 15 cm) prints on the Kodak EasyShare printer dock and other printing solutions. Also for printing up to 11 x 14 in. (28 x 36 cm). Better --2.1 M pixels; for printing up to 8 x 10 in. (20 x 25 cm). Good --1.

1 M pixels; for emailing, Internet, screen display, or for conserving space. 18 Taking pictures and videos Setting Color Mode Choose color tones. This setting remains until you turn the Mode dial or turn off the camera. Icon Options Color (default)--for color pictures. Black & White--for black-and-white pictures.

Sepia--for pictures with a reddish-brown, antique look. NOTE: EasyShare software also lets you change a color picture to black-and-white or sepia.

Unavailable in Video mode. Set Album Choose Album names. On or Off.

Pre-select album names before you take pictures or videos. Then, all the pictures or videos you take are tagged with those album names. See page 22. Choose a date option, or turn off the feature. @@@@1 In any mode, press the Menu button.

2 Press 3 Press button. @5 Press the Menu button to exit. Setting Return to previous menu. Default Print Quantity Choose the default quantity. Quickview Briefly display a picture after it is taken.

Liveview Change Liveview default to on or off. @@@@None--disables digital zoom. See page 5. @@@PAL--used in Europe and China. Choose a language. Memory Card--deletes everything on the card; formats the card. Cancel (default)--exits without making a change.

@@@@@@@@Repeat to select more than one album name. Selected albums are noted with a check mark. @@To remove all album selections, select Clear All.

5 Highlight Exit, then press the OK button. Your selections are saved. @@@@@@@@@2 Press to scroll backward or forward through pictures and videos. (For fast scrolling, press and hold .) 3 Press the Review button to exit Review. NOTE: Pictures taken at the Best (3:2) quality setting are displayed at a 3:2 aspect ratio with a black bar at the top of the screen. Viewing multiple pictures and videos 1 Press the Review button. 2 Press . NOTE: You can also press the Menu button, highlight , then press the OK button. Thumbnails of pictures and videos are displayed.

To display the previous or next row of thumbnails, press . To scroll through the thumbnails one at a time, press . To display a single view of the selected picture, press the OK button. 23 Reviewing pictures and videos Playing a video 1 Press the Review button. 2 Press to locate a video.

(In Multi-up view, highlight a video, then press the OK button. When a video is highlighted in Multi-up view, the video duration is displayed at the top of the camera screen.) 3 To play or pause a video, press the OK button. (If the camera is connected to a television, press to adjust the volume. See page 28.

) To adjust the volume, press To rewind the video, press . during playback. . To replay the video, press the OK button. To go to the previous or next picture or video, press Deleting pictures and videos 1 Press the Review button. 2 Press to locate a picture or video (or highlight one in multiple view), then press the Delete button. 3 Press to highlight an option, then press the OK button: PICTURE or VIDEO--deletes the displayed picture or video. EXIT--exits the Delete screen. ALL--deletes all pictures and videos from your current storage location. To delete more pictures and videos, go to Step 2.

NOTE: You cannot delete protected pictures and videos this way. Remove protection before deleting (see page 26). 24 Reviewing pictures and videos Changing optional review settings In Review mode, press the Menu button to access optional review settings. Magnify picture (page 25) Play video (page 24)

Share (page 32) Slide Show (page 27) Copy (page 29) Video Date Display (Display Date/Time at the start of video playback.) Multi-up (page 23)

Picture/Video Information (page 29) Setup Menu (page 19) Protect (page 26) Image Storage (page 18) Album (page 26) Magnifying pictures 1 Press the Review button, then locate a picture. 2 To magnify at 2X, press the OK button. To magnify at 4X, press the OK button again. To see different parts of the picture, press . To redisplay the picture at the 1X (original) size, press the OK button again. To exit Magnify, press the Menu button.

To exit Review mode, press the Review button. NOTE: You can also press the Menu button, highlight , then press the OK button. 25 Reviewing pictures and videos Protecting pictures and videos from deletion 1 Press the Review button, then locate the picture or video. 2 Press the Menu button. 3 Press to highlight Protect , then press the OK button.

The picture or video is protected and cannot be deleted. The Protect icon appears with the protected picture or video. 4 To remove protection, press the OK button again. 5 Press the Menu button to exit the menu. CAUTION: Formatting internal memory or an SD/MMC card deletes all (including protected) pictures, videos.

(Formatting internal memory also deletes email addresses and album names. To restore them, see EasyShare software Help.



[You're reading an excerpt. Click here to read official KODAK](#)

[EASYSHARE CX7330 user guide](#)

<http://yourpdfguides.com/dref/528600>

) Tagging pictures/videos for albums Use the Album feature in Review mode to tag the pictures and videos in your camera with album names. First--on your computer Use Kodak EasyShare software (V 3.0 or higher) to create album names on your computer, then copy up to 32 album names to the camera's internal memory. See Kodak EasyShare software Help for details. 26 Reviewing pictures and videos Second--on your camera 1 Press the Review button, then locate the picture or video. 2 Press the Menu button. 3 Press 4 Press to highlight Album , then press the OK button. to highlight an album folder, then press the OK button.

To add other pictures to the same album, press to scroll through the pictures. When the picture you want is displayed, press the OK button. To add the pictures to more than one album, repeat step 4 for each album. The album name appears with the picture. A plus (+) after the album name means the picture was added to more than one album. To remove a selection, highlight an album name and press the OK button. To remove all album selections, select Clear

All. Third--transfer to your computer When you transfer the tagged pictures and videos to your computer, the Kodak EasyShare software opens and categorizes your pictures and videos in the appropriate album folder. See Kodak EasyShare software Help for details. Running a slide show Use the Slide Show to display your pictures and videos on the camera screen.

To run a slide show on a television or on any external device, see page 28. To save battery power, use an optional Kodak 3V AC adapter. (Visit [www.kodak.com/go/cx7330accessories](http://www.kodak.com/go/cx7330accessories).)

) Starting the slide show 1 Press the Review button, then press the Menu button. 2 Press to highlight Slide Show , then press the OK button. 3 Press to highlight Begin Show, then press the OK button. Each picture and video is displayed once, in the order in which you took them. To interrupt the Slide Show, press the OK button.

27 Reviewing pictures and videos Changing the slide show display interval The default interval setting displays each picture for 5 seconds. You can increase the display interval up to 60 seconds. 1 On the Slide Show menu, press OK button. 2 Select a display interval. To scroll through the seconds quickly, press and hold 3 Press the OK button. The interval setting remains until you change it. . to highlight Interval, then press the Running a continuous slide show loop When you turn on Loop, the slide show is continuously repeated. 1 On the Slide Show menu, press button. to highlight Loop, then press the OK 2 Press to highlight On, then press the OK button.

The slide show repeats until you press the OK button or until battery power is exhausted. Displaying pictures and videos on a television You can use an optional audio/video cable to display pictures and videos on a television, computer monitor, or any device equipped with a video input. (Image quality on a television screen may not be as good as on a computer monitor or when printed.) NOTE: Ensure that the Video Out setting (NTSC or PAL) is correct (see page 21). The slide show stops if you connect or disconnect the cable while the slide show is running. 1 Connect the optional audio/video cable from the camera video-out port to the television video-in port (yellow) and audio-in port (white). See your television user's guide for details. 2 Review pictures and videos on the television. 28 Reviewing pictures and videos Copying pictures and videos You can copy pictures and videos from a card to internal memory or from internal memory to a card. Before you copy, make sure that: A card is inserted in the camera.

The camera's picture storage location is set to the location from which you are copying. See Image Storage, page 18. Copy pictures or videos: 1 Press the Review button, then locate the picture or video. 2 Press the Menu button. 3 Press 4 Press to highlight Copy , then press the OK button. to highlight an option: PICTURE or VIDEO--copies the current picture or video. EXIT--returns to the Review menu. ALL--copies all pictures and videos from your selected storage location to the other location. 5 Press the OK button. NOTE: Pictures and videos are copied, not moved. To remove pictures and videos from the original location after they are copied, delete them (see page 24). Tags that you applied for print, email, and favorites are not copied. Protection settings are not copied. To apply protection to a picture or video, see page 26. Viewing picture/video information 1 Press the Review button, then press the Menu button. 2 Press button. to highlight Picture/Video Info , then press the OK . 3 To view information on the next or previous picture or video, press Press the Menu button to exit the menu. 29 4 XP OS Installing the software Macintosh computers iMac; PowerBook G3, G4; or iBook computers Mac OS X version 10.2.

3, 10.3 Safari 1.0 or higher 128 MB RAM 200 MB hard disk space available CD-ROM drive Available USB port Color monitor, 1024 x 768 pixels (thousands or millions of colors recommended) Minimum system requirements Windows OS-based computers Windows 98, 98SE, ME, 2000 SP1, or Power Mac G3, G4, G5, G4 Cube, Internet Explorer 5.01 or higher 233 MHz processor or greater 64 MB RAM (128 MB RAM for Windows XP OS) 200 MB hard disk space available CD-ROM drive Available USB port Color monitor, 800 x 600 pixels (16-bit or 24-bit recommended) NOTE: Mac OS 8.6 and 9.x do not support the Share button functions. Mac OS X version 10.2.x or 10.3 is recommended for full functionality.

To download EasyShare software for Mac OS 8.6 and 9.x, visit [www.kodak.com/go/cx7330downloads](http://www.kodak.com/go/cx7330downloads).

30 Installing the software Install the software CAUTION: Install Kodak EasyShare software before connecting the camera or optional dock to the computer. Failure to do so may cause the software to install incorrectly. 1 Close all software applications that are open on your computer (including anti-virus software). 2 Place the Kodak EasyShare software CD into the CD-ROM drive. 3 Install the software: Windows OS-based computer--if the install window does not appear, choose Run from the Start menu and type d:\setup.exe where d is the drive letter that contains the CD. Mac OS X--double-click the CD icon on the desktop, then click the Install icon. 4 Follow the on-screen instructions to install the software. Windows OS-based computer--select Complete to automatically install the most commonly used applications. Select Custom to choose the applications you wish to install. Mac OS X--follow the on-screen instructions. NOTE: When prompted, take a few minutes to electronically register your camera and software. This lets you receive information regarding software updates and registers some of the products included with the camera. You must be connected to your Internet service provider to register electronically. To register later, see [www.kodak.com/go/register](http://www.kodak.com/go/register).

5 Restart the computer. If you turned off anti-virus software, turn it back on.



[You're reading an excerpt. Click here to read official KODAK EASYSHARE CX7330 user guide](http://yourpdfguides.com/dref/528600)  
<http://yourpdfguides.com/dref/528600>

See the anti-virus software manual for details. For information on the software applications included on the Kodak EasyShare software CD, click the Help button in the Kodak EasyShare software. 31 5 Sharing pictures and videos Press the Share button to "tag" your pictures and videos. When they are transferred to your computer, you can share them by: Pictures Videos Print (page 33) Email (page 34) Favorites (page 35) NOTE: Tags remain until removed. If a tagged picture/video is copied, the tag is not copied. In a burst series, only the last recent picture is tagged during Quickview. When can I tag my pictures and videos? Press the Share button to tag pictures/videos: Any time (The most recent picture/video taken is displayed.) Just after you take a picture/video, during Quickview (see page 12). After pressing the Review button (see page 23). 32 Sharing pictures and videos Tagging pictures for printing 1 Press the Share button. Press 2 Press to highlight Print to locate a picture. , then press the OK button.\* 3 Press to select the number of copies (0-99). Zero removes the tag for that picture. The Print icon appears in the status area. 4 Optional: You can apply a print quantity to other pictures. Press to locate a picture. Keep the print quantity as is, or press to change it. Repeat this step until the desired print quantity is applied to the pictures. 5 Press the OK button. Then press the Share button to exit the menu. \* To tag all pictures in the storage location, highlight Print All, press the OK button, then indicate the number of copies as described above. Print All is not available in Quickview. To remove the print tagging for all pictures in the storage location, highlight Cancel Prints, then press the OK button. Cancel Prints is not available in Quickview. Printing tagged pictures When you transfer the tagged pictures to your computer, the Kodak EasyShare software print screen opens.

See Kodak EasyShare software Help for details. For more information on printing from your computer, printer dock, or card, see page 37. NOTE: For the best 4 x 6 in. (10 x 15 cm) prints, set the camera to the Best (3:2) print quality setting. See page 18. 33 Sharing pictures and videos Tagging pictures and videos for emailing First--on your computer Use Kodak EasyShare software to create an email address book on your computer. Then, copy up to 32 email addresses to the camera's internal memory. See Kodak EasyShare software Help for details. Second--tag pictures/videos on your camera 1 Press the Share button. Press to locate a picture/video.

2 Press to highlight Email , then press the OK button. The Email icon appears in the status area. 3 Press to highlight an email address, then press the OK button. To tag other pictures/videos with the same address, press to scroll through them. When the picture you want is displayed, press OK. To send the pictures/videos to more than one address, repeat step 3 for each address. Selected addresses are checked. 4 To remove a selection, highlight a checked address and press the OK button. To remove all email selections, highlight Clear All. 5 Press to highlight Exit, then press the OK button. The email icon appears in the status area. 6 Press the Share button to exit the menu. Third--transfer and email When you transfer the tagged pictures/videos to your computer, the email screen opens and lets you send them to the addresses you specified. See Kodak EasyShare software Help for details. 34 Sharing pictures and videos Tagging pictures and videos as favorites 1 Press the Share button. Press picture/video. to locate a 2 Press to highlight Favorite , then press the OK button. The Favorite icon appears in the status area. 3 To remove the tag, press the OK button again. 4 Press the Share button to exit the menu.

Using favorites on your computer When you transfer Favorite pictures and videos to your computer, you can use Kodak EasyShare software to retrieve, organize, and label them by subject, date, event, or any category you choose. See Kodak EasyShare software Help for details. 35 6 Transferring and printing pictures CAUTION: Install Kodak EasyShare software before connecting the camera or optional dock to the computer. Failure to do so may cause the software to install incorrectly. Transferring pictures with the USB cable 1 Turn off the camera. 2 Plug the labeled end of the USB cable into the labeled USB port on your computer. See your computer user's guide for details. 3 Plug the other end of the USB cable into the labeled USB port on the camera. 4 Turn on the camera. Kodak EasyShare software opens on your computer.

The software prompts you through the transfer process. NOTE: Visit [www.kodak.com/go/howto](http://www.kodak.com/go/howto) for an online tutorial on connecting. You can also use a Kodak multi-card reader or Kodak SD multimedia card reader-writer to transfer your pictures. Also available for transferring You can also use these Kodak products to transfer your pictures and videos. Kodak EasyShare camera dock, Kodak EasyShare printer dock Kodak multi-card reader, Kodak SD multimedia card reader-writer Purchase these and other accessories at a dealer of Kodak products or [www.kodak.com/go/cx7330accessories](http://www.kodak.com/go/cx7330accessories). 36 Transferring and printing pictures Printing pictures from your computer For details on printing pictures from your computer, click the Help button in the Kodak EasyShare software.

Ordering prints online Kodak EasyShare print service (provided by Ofoto [www.ofoto.com](http://www.ofoto.com)) is one of the many online print services offered in the Kodak EasyShare software. You can easily: Upload your pictures. Edit, enhance, and add borders to your pictures. Store pictures, and share them with family and friends. Order high-quality prints, photo greeting cards, frames, and albums--and have them delivered to your door. Printing from an optional SD/MMC card Automatically print tagged pictures when you insert your card into a printer with an SD/MMC slot. See your printer user's guide for details. Make prints at an SD/MMC-capable Kodak picture maker.

(Contact a location prior to visiting. See [www.kodak.com/go/picturemaker](http://www.kodak.com/go/picturemaker).) Take the card to your local photo retailer for professional printing. Printing without a computer Dock your camera to the Kodak EasyShare printer dock and print directly--with or without a computer. Purchase this and other accessories at a dealer of Kodak products or [www.kodak.com/go/cx7330accessories](http://www.kodak.com/go/cx7330accessories). 37 7 Troubleshooting When you have questions about your camera, start here.

Additional technical information is available in the ReadMe file located on the Kodak EasyShare software CD. For updates to Troubleshooting information, see [www.kodak.com/go/cx7330support](http://www.kodak.com/go/cx7330support). Camera problems If.

.. Try one or more of the following The camera does not Remove, then reinsert the batteries. turn on Insert new or charged batteries. The camera does not Place the camera on a Kodak EasyShare camera or printer dock (sold separately), then try again.



[You're reading an excerpt. Click here to read official KODAK EASYSHARE CX7330 user guide](http://yourpdfguides.com/dref/528600)  
<http://yourpdfguides.com/dref/528600>



7-f/4.6 (35 mm film camera equivalent) Auto focusing, TTL-AF. Working range: 23.6 in. (60 cm) - infinity @ standard 5. 1-27.6 in. (13-70 cm) @ wide/close-up 8.7-27.6 in.

(22-70 cm) @ tele/close-up 1-3.3X with 0.3 step Not supported for movie capture Yes 1.6 in. @ @ @ @ @ (6.

35 mm) 4 in. (103 mm) x 1.5 in. (38 mm) x 2.6 in. @ @ If you suspect water has gotten inside the camera, turn off the camera and remove the batteries and card. Allow all components to air-dry for at least 24 hours before using the camera again. Blow gently on the lens or camera screen to remove dust and dirt. Wipe gently with a soft, lint-free cloth or an untreated lens-cleaning tissue. Do not use cleaning solutions unless designed specifically for camera lenses.

Do not allow chemicals, such as suntan lotion, to contact painted surfaces. Service agreements are available in some countries. Contact a dealer of Kodak products for more information. For rechargeable battery disposal information, visit the Rechargeable Battery Recycling Corporation Web site at [www.rbrc.com](http://www.rbrc.com). For digital camera disposal or recycling information, contact your local authorities. In the US, visit the Electronics Industry Alliance Web site at [www.eiae.org](http://www.eiae.org) or Kodak at [www.kodak.com/go/cx7330support](http://www.kodak.com/go/cx7330support).

46 Appendix Storage capacities File sizes vary. You may be able to store more or fewer pictures and videos. Picture storage capacity Number of pictures Best 16 MB internal memory 16 MB SD/MMC 32 MB SD/MMC 64 MB SD/MMC 128 MB SD/MMC 256 MB SD/MMC 13 16 32 65 131 262 Best (3:2) Better 15 18 36 73 147 294 20 24 48 97 194 388 Good 45 43 87 175 350 700 Video storage capacity Minutes/seconds of video 16 MB internal memory 16 MB SD/MMC 32 MB SD/MMC 64 MB SD/MMC 128 MB SD/MMC 256 MB SD/MMC 53 sec. 1 min. 2 min. 15 sec. 4 min. 30 sec.

9 min. 18 min. Power-saving features If no action for The camera 1 minute 8 minutes 3 hours Screen turns off. Enters auto power off. Turns off. To turn it back on Press the OK button. Press a button or insert/remove card. Turn Mode dial Off, then back on. 47 Appendix Regulatory compliance FCC compliance and advisory Kodak EasyShare CX7330 zoom digital camera This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses, and can radiate radio frequency energy and, if not installed or used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: 1) reorient or relocate the receiving antenna; 2) increase the separation between the equipment and the receiver; 3) connect the equipment to an outlet on a circuit different from that to which the receiver is connected; 4) consult the dealer or an experienced radio/TV technician for additional suggestions. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Where shielded interface cables have been provided with the product or specified additional components or accessories elsewhere defined to be used with the installation of the product, they must be used in order to ensure compliance with FCC regulation. Canadian DOC statement DOC Class B Compliance--This Class B digital apparatus complies with Canadian ICES-003. Observation des normes--Class B--Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada. 48 Appendix Upgrading your software and firmware Download the latest versions of the software included on the Kodak EasyShare software CD and the camera firmware (the software that runs on the camera). See [www.kodak.com/go/cx7330downloads](http://www.kodak.com/go/cx7330downloads).

49 Index Numerics 4-way controller, ii A A/V out, iii, 28 AA battery, inserting, 2 about picture, video, 29 about this camera, 21 AC adapter, 4 accessories, 36 AC adapter, 4 battery, 3 buying, 42 camera dock, 4 printer dock, 4, 37 SD/MMC card, 7 album, 19 albums, tagging pictures for, 22, 26 alkaline batteries, warning, 2 auto, 9 flash, 14 focus framing marks, 11 power-down, 47 B batteries expected life, 3 extending life, 3 inserting, 2 safety and handling, 4 types, 3 battery door location, iii burst, ii, 17 button delete, ii, 12 flash/status, 14 menu, ii OK, 5 on/off, ii reviewing, ii, 23 self timer/burst, 17 share, ii, 32 shutter, i zoom, ii, 13 C cable audio/video, 28 USB, I, 36 camera dock, 4 camera dock connector on camera, iii camera screen reviewing pictures, 23 reviewing videos, 23 using as viewfinder, 10 Canadian compliance, 48 caring for your camera, 46 clock, setting, 5 close-up, 9 color mode, 19 computer connecting camera, 36 transfer to, 36 connector for camera dock, iii contents, camera box, 1 copy pictures card to memory, 29 memory to card, 29 to computer via USB cable, 36 CRV3 battery expected life, 3 inserting, 2 customer support, 42 customizing camera settings, 20 D date & time, 20 date setting, 5 date stamp, 19, 20 DC-in, ii delete button, ii deleting during quickview, 12 50 Index from internal memory, 24 from SD/MMC card, 24 protecting pictures, videos, 26 digital zoom, using, 13 displaying slide show, 27 disposal, recycling, 46 dock camera, 4 printer, 4, 37 downloading pictures, 36 E EasyShare software, 30 emailing pictures, videos, 34 exposure compensation, 18 external video device viewing pictures, videos, 28 F favorites, tagging, 35 FCC compliance, 48 firmware, upgrading, 49 flash settings, 14 unit, i focus framing marks, 11 format, 21 G guidelines, battery, 3 H help camera, 38 software, 42 support, 42 web links, 42 I icons, mode dial, 9 image storage, 18 information about pictures, videos, 29 inserting batteries, 2 SD/MMC card, 7 installing SD/MMC card, 7 software, 31 internal memory storage capacity, 47 K Kodak digital camera batteries, 2 Kodak EasyShare software getting help, 42 installing, 31 upgrading, 49 Kodak web sites, 42 L landscape, 9 language, 21 LCD (liquid crystal display). See camera screen lens, i light ready, ii self timer, 16 sensor, i lights status, ready light, 41 lithium batteries, expected life, 3 liveview, 20 camera screen as viewfinder, 10 M Macintosh installing software on, 31 magnify picture, 25 maintenance, camera, 46 51 Index memory inserting card, 7 storage capacities, 47 menu button, ii menu button, ii microphone, i mode dial, ii, 9 modes auto, 9 close-up, 9 landscape, 9 night, 9 N night, 9 Ni-MH rechargeable battery expected life, 3 O OK button, 5 online prints, ordering, 37 optical zoom, 13 orientation sensor, 19 overview camera, ii camera modes, 9 P package contents, camera, 1 picture quality, 18 pictures checking settings, 6, 7 copying, 29 deleting, 24 emailing tagged, 34 magnifying, 25 printing, 37 printing tagged, 33 protecting, 26 quality problems, 40 reviewing, 23 storage capacity, 47 tagging, 22, 26 taking, modes, 9 transfer via USB cable, 36 power auto off, 47 camera, 4 switch, ii printer dock, 4, 37 printing from a card, 37 optimizing printer, 42 order online, 37 pictures, 37 tagged pictures, 37 without computer, 37 product overview, ii protecting pictures, videos, 26 Q quickview using, 12 R ReadMe file, 38 ready light, ii, 41 recycling, disposal, 46 red-eye, flash, 14 regulatory information, 48 review button, ii, 23 reviewing pictures as you take them, 12 camera screen, 23 deleting, 24 magnifying, 25 protecting, 26 slide show, 27 reviewing videos camera screen, 23 deleting, 24 protecting, 26 slide show, 27 52 Index running slide show, 27 S safety, 46 SD/MMC card inserting, 7 printing from, 37 slot location, iii storage capacities, 47 SD/MMC card, inserting, 7 self timer button, ii light, i with pictures, 16 with videos, 16 sensor, light, i service and support telephone numbers, 42 setting album, 19 color mode, 19 date & time, 20 date and time, 5 date stamp, 19, 20 exposure compensation, 18 flash, 14 image storage, 18 language, 21 liveview, 20 orientation sensor, 19 picture quality, 18 picture taking mode, 9 self timer, 16 video out, 21 setup mode, using, 20 share button, ii, 32 shutoff, auto, 47 shutter self timer delay, 16 shutter, problems, 39 sleep mode, 47 Slide Show problems, 39 slide show continuous loop, 28 running, 27 software getting help, 42 installing, 31 upgrading, 49 specifications camera, 44 storage capacity, 47 support, technical, 42 T tagging favorites, 35 for email, 34 for print, 33 when to tag, 32 tagging pictures for albums, 22, 26 telephone support, 42 telephoto button, ii television, slide show, 28 time, setting, 5 timer, shutter delay, 16 tips battery guidelines, 3 camera maintenance, 46 ReadMe file, 38 safety, 46 transfer, via USB cable, 36 trash can, deleting, 12 troubleshooting camera, 38 computer/connectivity problems, 39 picture quality, 40 turning camera on and off, 4 53 Index U upgrading software, firmware, 49 URLs, Kodak web sites, 42 USB (universal serial bus) connection location, iii transferring pictures, 36 V video out, 21 videos checking settings, 6, 7 copying, 29 deleting, 24 emailing

*tagged, 34 protecting, 26 reviewing, 23 storage capacities, 47 transfer to computer, 36 viewing, 23 viewfinder, i, ii using camera screen, 10 viewing picture after taking, 12, 23 magnified, 25 viewing picture, video information, 29 W wide angle button, ii Windows computers installing software, 31 wrist strap post, i Z zoom button, ii digital, 13 optical, 13 54.*



**[You're reading an excerpt. Click here to read official KODAK EASYSHARE CX7330 user guide](http://yourpdfguides.com/dref/528600)**  
**<http://yourpdfguides.com/dref/528600>**