




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for LG 42LB561V. You'll find the answers to all your questions on the LG 42LB561V in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual LG 42LB561V
User guide LG 42LB561V
Operating instructions LG 42LB561V
Instructions for use LG 42LB561V
Instruction manual LG 42LB561V



[You're reading an excerpt. Click here to read official LG 42LB561V user guide](http://yourpdfguides.com/dref/5575521)
<http://yourpdfguides.com/dref/5575521>

Manual abstract:

Yy If the image quality is poor, install a signal amplifier properly to improve the image quality. Yy If the image quality is poor with an antenna connected, try to realign the antenna in the correct direction. *Not Provided English Connect the TV to a satellite dish to a satellite socket with a satellite RF cable (75 Ω). (Nur 3D-Modelle) AUDIO / VIDEO English Transmits the video and audio signals from an external device to the TV set. @@@@Some separate cable is not provided. @@NOTE yy The external device connection may differ from the model. Yy Connect external devices to the TV regardless of the order of the TV port. Yy If you record a TV programme on a DVD recorder or VCR, make sure to connect the TV signal input cable to the TV through a DVD recorder or VCR. For more information of recording, refer to the manual provided with the connected device. Yy Refer to the external equipment's manual for operating instructions.

Yy If you connect a gaming device to the TV, use the cable supplied with the gaming device. Yy In PC mode, there may be noise associated with the resolution, vertical pattern, contrast or brightness. If noise is present, change the PC output to another resolution, change the refresh rate to another rate or adjust the brightness and contrast on the PICTURE menu until the picture is clear. Yy In PC mode, some resolution settings may not work properly depending on the graphics card. @@For more information about licenses, visit www.

□Dolby™ and the double-D symbol are trademarks of Dolby Laboratories. ENGLISH ENG The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI logo are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries. ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX, LLC, a subsidiary of Rovi Corporation. This is an official DivX Certified® device that has passed rigorous testing to verify that it plays DivX video. visit divx.

Com for more information and software tools to convert your files into DivX videos. ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play purchased DivX Video-on-Demand (VOD) movies. To obtain your registration code, locate the DivX VOD section in your device setup menu. Com for more information on how to complete your registration. "DivX Certified® to play DivX® video up to HD 1080p, including premium content. □ "DivX®, DivX Certified® and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license. □ "Covered by one or more of the following U. s. Patents : 7,295,673; 7,460,668; 7,515,710; 7,519,274" OPEN SOURCE SOFTWARE NOTICE To obtain the source code under GPL, LGPL, MPL and other open source licenses, that is contained in this product, please visit <http://opensource>. In addition to the source code, all referred license terms, warranty disclaimers and copyright notices are available for download.

LG Electronics will also provide open source code to you on CD-ROM for a charge covering the cost of performing such distribution (such as the cost of media, shipping and handling) upon email request to opensource@lge.com. This offer is valid for three (3) years from the date on which you purchased the product. SAFETY INSTRUCTIONS 3 SAFETY INSTRUCTIONS Please read these safety precautions carefully before using the product. ENGLISH ENG WARNING yy Do not place the TV and/or remote control in the following environments: -- location exposed to direct sunlight A -- area with high humidity such as a bathroom An -Near any heat source such as stoves and other devices that produce heat -Near kitchen counters or humidifiers where they can easily be exposed to steam or oil -- area exposed to rain or wind An -Near containers of water such as vases Otherwise, this may result in fire, electric shock, malfunction or product deformation. Yy Do not place the product where it might be exposed to dust. This plug must remain readily attached and operable when TV is in use. Yy Do not touch the power plug with wet hands. Additionally, if the cord pin is wet or covered with dust, dry the power plug completely or wipe dust off. you may be electrocuted due to excess moisture.

Yy Make sure to connect Mains cable to compliant AC mains socket with Grounded earth pin. (Except for devices which are not grounded on earth.) Otherwise possibility you may be electrocuted or injured. Yy Insert power cable plug completely into wall socket otherwise if not secured completely into socket, fire ignition may break out. Yy Ensure the power cord does not come into contact with hot objects such as a heater. this may cause a fire or an electric shock hazard. Yy Do not place a heavy object, or the product itself, on power cables. Otherwise, this may result in fire or electric shock. Yy Bend antenna cable between inside and outside building to prevent rain from flowing in. This may cause water damaged inside the Product and could give an electric shock.

4 SAFETY INSTRUCTIONS yy When mounting TV onto wall make sure to neatly install and isolate cabling from rear of TV as to not create possibility of electric shock /fire hazard. ENGLISH ENG yy Do not plug too many electrical devices into a single multiple electrical outlet. Otherwise, this may result in fire due to over-heating. Yy Do not drop the product or let it fall over when connecting external devices. Otherwise, this may result in injury or damage to the product. Yy Keep the anti-moisture packing material or vinyl packing out of the reach of children. anti-moisture material is harmful if swallowed. If swallowed by mistake, force the patient to vomit and visit the nearest hospital. additionally, vinyl packing can cause suffocation. Keep it out of the reach of children.

Yy Do not let your children climb or cling onto the TV. Otherwise, the TV may fall over, which may cause serious injury. Yy Dispose of used batteries carefully to ensure that a small child does not consume them. Please seek Doctor- Medical Attention immediately if child consumes batteries. Yy Do not insert any metal objects/conductors (like a metal chopstick/cutlery/screwdriver) between power cable plug and input Wall Socket while it is connected to the input terminal on the wall. Additionally, do not touch the power cable right after plugging into the wall input terminal. you may be electrocuted. (Depending on model) yy Do not put or store inflammable substances near the product. There is a danger of combustion/explosion or fire due to careless handling of the inflammable substances. Yy Do not drop metallic objects such as coins, hair pins, chopsticks or wire into the product, or inflammable objects such as paper and matches.

If a foreign object is dropped into the product, unplug the power cord and contact the service centre. Yy Do not spray water on the product or scrub with an inflammable substance (thinner or benzene). fire or electric shock accident can occur. Yy Do not allow any impact, shock or any objects to fall into the unit, and do not drop anything onto the screen.



[You're reading an excerpt. Click here to read official LG 42LB561V user guide](#)

<http://yourpdfguides.com/dref/5575521>

You may be injured or the product can be damaged.

SAFETY INSTRUCTIONS 5 yy Never touch this product or antenna during a thunder or lightning storm. you may be electrocuted. **ENGLISH ENG** yy Never touch the wall outlet when there is leakage of gas, open the windows and ventilate. It may cause a fire or a burn by a spark. yy Do not disassemble, repair or modify the product at your own discretion.

fire or electric shock accident can occur. Contact the service centre for check, calibration or repair. yy If any of the following occur, unplug the product immediately and contact your local service centre. -- product has been impacted by shock The -- product has been damaged The -Foreign objects have entered the product -- product produced smoke or a strange smell The This may result in fire or electric shock. yy Unplug the TV from AC mains wall socket if you do not intend to use the TV for a long period of time. Accumulated dust can cause fire hazard and insulation deterioration can cause electric leakage/shock/fire. yy Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus. yy Do not install this product on a wall if it could be exposed to oil or oil mist. This may damage the product and cause it to fall. **CAUTION** yy Install the product where no radio wave occurs.

yy There should be enough distance between an outside antenna and power lines to keep the former from touching the latter even when the antenna falls. this may cause an electric shock. yy Do not install the product on places such as unstable shelves or inclined surfaces. Also avoid places where there is vibration or where the product cannot be fully supported. Otherwise, the product may fall or flip over, which may cause injury or damage to the product. **6 SAFETY INSTRUCTIONS** yy If you install the TV on a stand, you need to take actions to prevent the product from overturning. Otherwise, the product may fall over, which may cause injury. **ENGLISH ENG** yy If you intend to mount the product to a wall, attach VESA standard mounting interface (optional parts) to the back of the product. When you install the set to use the wall mounting bracket (optional parts), fix it carefully so as not to drop. yy Only use the attachments / accessories specified by the manufacturer.

yy When installing the antenna, consult with a qualified service technician. If not installed by a qualified technician, this may create a fire hazard or an electric shock hazard. yy We recommend that you maintain a distance of at least 2 to 7 times the diagonal screen size when watching TV. If you watch TV for a long period of time, this may cause blurred vision. yy Only use the specified type of battery.

This could cause damage to the remote control. yy Do not mix new batteries with old batteries. This may cause the batteries to overheat and leak. yy Batteries should not be exposed to excessive heat. For example, keep away from direct Sunlight , open fireplace and electric heaters .

yy Do not place non-rechargeable batteries in charging device. yy Make sure there are no objects between the remote control and its sensor. yy Signal from Remote Control can be interrupted due to external/internal lighting eg Sunlight, fluorescent lighting. If this occurs turn off lighting or darken viewing area. yy

When connecting external devices such as video game consoles, make sure the connecting cables are long enough. Otherwise, the product may fall over, which may cause injury or damage the product. yy Do not turn the product On/Off by plugging-in or unplugging the power plug to the wall outlet. (Do not use the power plug for switch.) It may cause mechanical failure or could give an electric shock. **SAFETY INSTRUCTIONS 7** yy Please follow the installation instructions below to prevent the product from overheating.

-- distance between the product and the wall should be more than 10 cm. The -- not install the product in a place with no ventilation (e. -- not install the product on a carpet or cushion. Do -Make sure the air vent is not blocked by a tablecloth or curtain. Otherwise, this may result in fire. yy Take care not to touch the ventilation openings when watching the TV for long periods as the ventilation openings may become hot. This does not affect the operation or performance of thue to tempera-ture and humidity. This noise is common for products where thermal deformation is required. Electrical circuit humming/panel buzzing: A low level noise is generated from a highspeed switching circuit, which supplies a large amount of current to operate a product. it varies depending on the product.

This generated sound does not affect the performance and reliability of the product. **SAFETY INSTRUCTIONS 9** Viewing 3D Imaging (Only 3D models) **WARNING** Viewing Environment yy Viewing Time -When watching 3D contents, take 5 - 15 minute breaks every hour. Viewing 3D contents for a long period of time may cause headache, dizziness, fatigue or eye strain. **ENGLISH ENG** Those that have a photosensitive seizure or chronic illness yy Some users may experience a seizure or other abnormal symptoms when they are exposed to a flashing light or particular pattern from 3D contents. yy Do not watch 3D videos if you feel nausea, are pregnant and/ or have a chronic illness such as epilmodels have a thin film attached on to the screen and this must not be removed.

NOTE yy The items supplied with your product may vary depending on the model. yy Product specifications or contents of this manual may be changed without prior notice due to upgrade of product functions. yy For an optimal connection, HDMI cables and USB devices should have bezels less than 10 mm thick and 18 mm width. Use an extension cable that supports USB 2. 0 if the USB cable or USB memory stick does not fit into your TV's USB port.

B A A B *A < 10 mm = *B < 18 mm = 12 ASSEMBLING AND PREPARING ENGLISH ENG Remote control, batteries (AAA) Owner's manual Power Cord Stand Base (Only LB55**, LB56**-ZE / ZC, LB62**-ZA / ZB) Stand Base (Only LB56**-ZT / ZQ, LB62**-ZE) Stand Screws 4EA, M4 x L14 (Only 42/49LB55**, 39/42/47/50/55/60LB56**, 42/49/55LB62**) Stand Screws 4EA, M4 x L20 (Only 32LB55**, 32LB56**, 32LB62**) Wall Mount Spacers 2EA (Only 42LB55**, 42LB56**, 42LB62**) Cable Managements 2EA Cable holder (Depending on model) Cinema 3D Glasses The number of 3D glasses may differ depending on the model or country. (Only LB62**) **ASSEMBLING AND PREPARING 13** Separate purchase Optional extras can be changed or modified for quality improvement without any notification. Contact your dealer for buying these items. These devices only work with certain models. **LG Audio Device AG-F*** Cinema 3D Glasses AG-F***DP Dual play glasses ENGLISH ENG** Compatibility **LG Audio device AG-F*** Cinema 3D Glasses AG-F***DP Dual play glasses LB56** / LB55** • LB62** • • • •** The model name or design may be changed due to the manufacturer's circumstances or policies.) Speakers Remote control sensor P □ over Indicator yy You can set the power indicator light to on or off by selecting **OPTION** in the main menus.



[You're reading an excerpt. Click here to read official LG 42LB561V user guide](http://yourpdfguides.com/dref/5575521)

<http://yourpdfguides.com/dref/5575521>

NOTE ASSEMBLING AND PREPARING 15 Using the Joystick button ENGLISH ENG You can simply operate the TV functions, pressing or moving the joystick button up, down, left or right. @@@@TV off Settings Close Input List Turns the power off. @@@@Yy Hold the top and bottom of the TV frame firmly. @@@@Yy When transporting a large TV, there should be at least 2 people.

@@@2 Mount the wall brackets with the bolts to the wall. @@@@Make sure to keep the rope horizontal with the flat surface. CAUTION yy Make sure that children do not climb on or hang on the TV. @@ yy Brackets, bolts and ropes are not provided. You can obtain additional accessories from your local dealer. @@@@Otherwise electric shock may occur. Yy If you install the TV on a ceiling or slanted wall, it may fall and result in severe injury. Use an authorized LG wall mount and contact the local dealer or qualified personnel. Yy Do not over tighten the screws as this may cause damage to the TV and void your warranty. Yy Use the screws and wall mounts that meet the VESA standard.

Any damages or injuries by misuse or using an improper accessory are not covered by the warranty. 10 cm 10 cm 10 cm 10 cm Make sure to use screws and wall mount bracket that meet the VESA standard. Standard dimensions for the wall mount kits are described in the following table. NOTE yy Use the screws that are listed on the VESA standard screw specifications. Yy The wall mount kit includes an installation manual and necessary parts. Yy The wall mount bracket is not provided. You can obtain additional accessories from your local dealer. Yy The length of screws may differ depending on the wall mount. Make sure to use the proper length. Yy For more information, refer to the manual supplied with the wall mount.

Separate purchase(Wall Mounting Bracket) Model VESA (A x B) Standard screw 32/39LB56** 42/47/50/55LB56** 32LB55** 42/49LB55** 32LB62** 42/49/55LB62** 200 x 200 M6 400 x 400 M6 4 LSW440B MSW240 Number of screws 4 LSW240B Wall mount bracket MSW240 Model VESA (A x B) Standard screw Wall mount bracket 60LB56** 400 x 400 M6 NOTE yy Only 42LB55**, 42LB56**, 42LB62** Number of screws 4 LSW440B Wall Mount Spacers REMOTE CONTROL 19 REMOTE CONTROL The descriptions in this manual are based on the buttons on the remote control. Please read this manual carefully and use the TV correctly. To replace batteries, open the battery cover, replace batteries (1.5 V AAA) matching the and ends to the label inside the compartment, and close the battery cover. To remove the batteries, perform the installation actions in reverse. ENGLISH ENG CAUTION yy Do not mix old and new batteries, as this may damage the remote control. Make sure to point the remote control toward the remote control sensor on the TV. PAGE Moves to the previous or next screen. teletext buttons (INFO TEXT / T. OPT) These buttons are used for teletext.

Views the information of the current programme and screen. Starts to record and displays record menu. □ (Only Time MachineReady supported model) Control buttons () Controls the MY MEDIA menus, Time MachineReady control or the SIMPLINK compatible devices (USB, SIMPLINK or Time MachineReady). 1 Colour buttons These access special functions in some menus. PAGE Moves to the previous or next screen. teletext buttons (INFO TEXT / T. OPT) These buttons are used for teletext. Views the information of the current programme and screen. Starts to record and displays record menu. □ (Only Time MachineReady supported model) Control buttons () Controls the MY MEDIA menus, Time MachineReady control or the SIMPLINK compatible devices (USB, SIMPLINK or Time MachineReady).

1 Colour buttons These access special functions in some menus. □ (: Red, : Green, : Yellow, : Blue) EXIT AD REC/ 1 SETTINGS 21 SETTINGS Automatically Setting Up Programme SETTINGS SETUP Auto Tuning yy Depending on input signal, available range of picture modes may differ. Expert mode is for picture tuning professionals yy to control and fine-tune using a specific image. For normal images, the effects may not be dramatic. Yy The ISF function is only available on some models.

eNGLISH ENG Automatically tunes the programmes. Yy If Input Source is not connected properly, programme registration may not work. Yy Auto Tuning only finds programmes that are currently broadcasting. Yy If Lock System is turned on, a pop-up window will appear asking for password. To set advanced control SETTINGS PICTURE Picture Mode Advanced Control / Expert Control Calibrates the screen for each picture mode; or adjusts picture settings for a special screen.

First select a Picture Mode of your choice. Yy Dynamic Contrast : Adjusts the contrast to the optimal level according to the brightness of the image. Yy Dynamic Colour : Adjusts colours to make the image appear in more natural colours. @@@@Yy Colour Gamut : Selects the range of colours that can be expressed. @@@@Yy Eco/APS: [Depending on model] The Energy Saver feature changes settings on the TV to reduce power consumption. Yy Cinema/Game: Displays the optimum picture for movie, game. Yy Sports : Optimizes the video image for high and dynamic actions by emphasizing primary colours such as white, grass, or sky blue. Expert 1, 2 : Menu for adjusting picture quality yy that allows experts and amateurs to enjoy the best TV viewing. This is the adjustment menu provided for ISF-certified picture tuning professionals. (ISF logo can only be used on ISF-certified TVs.

) ISFccc: Imaging Science Foundation Certified Calibration Control 22 SETTINGS To set additional picture options ENGLISH ENG SETTINGS PICTURE Picture Option Picture Mode To use Energy Saving feature SETTINGS PICTURE Energy Saving [Depending on model] Adjusts detailed setting for images. Yy Noise Reduction : Eliminates noise in the picture. Yy MPEG Noise Reduction : Eliminates noise generated while creating digital picture signals. Yy Black Level : Adjusts the brightness and contrast of the screen to suit the black level of the input picture by using the blackness (black level) of the screen. Yy Real Cinema : Optimizes the screen for movie viewing. Yy Motion Eye Care/SUPER Energy Saving : [Depending on model] Saves power consumption by adjusting the brightness corresponding to the movement of the image on the screen. @@ reduces power consumption by adjusting screen brightness. Yy Auto : [Depending on model] The TV sensor detects the ambient lighting and automatically adjusts the screen brightness. Yy Screen Off : Screen is turned off and only sound is played. Press any button except Power button on the remote control to turn the screen back on.

To use TV speaker SETTINGS AUDIO Sound Out TV Speaker [Depending on model] Sound is output through the TV speaker. to use TruMotion SETTINGS PICTURE TruMotion [Depending on model] Corrects images to display smoother motion sequences. Yy Smooth : De-judder/De-blur working on higher range in auto mode. Yy Clear : De-judder/De-blur working on middle range in auto mode.



[You're reading an excerpt. Click here to read official LG 42LB561V user guide](http://yourpdfguides.com/dref/5575521)
<http://yourpdfguides.com/dref/5575521>

Auto means Juddering and blurring range that depend on input video status is controlled by TruMotion mode.

To use External Speaker SETTINGS AUDIO Sound Out External Speaker (Optical) [Depending on model] Sound is output through the speaker connected to the optical port. Item Audio Input MPEG Dolby Digital Plus HE-AAC All Digital Audio Output PCM Dolby Digital Dolby Digital PCM Auto PCM SETTINGS 23 To connect and use LG audio device SETTINGS AUDIO Sound Out LG Sound Sync (Optical) [Depending on model] Connect LG audio device with the logo to the optical digital audio output port. LG audio device allows you to enjoy rich powerful sound easily. To use Headphone SETTINGS AUDIO Sound Out Headphone yy If you switch to another input, the SIMPLINK device will stop. Yy If a third-party device with the HDMI-CEC function is also used, the SIMPLINK device may not work normally.

Yy [Depending on model] If you select or play media from a the device with a home theatre function, the HT Speaker(Speaker) is automatically connected. Be sure to connect with an optical cable (sold separately) to use the HT Speaker(Speaker) function. ENGLISH ENG [Depending on model] Sound is output through the headphone connected to the earphone/headphone port. SIMPLINK function description yy Direct Play : Plays the multimedia device on the TV instantly. Yy Select multimedia device : Selects the desired device via the SIMPLINK menu to control it from the TV screen instantly. Yy Disc playback : Manages the multimedia device with the TV remote control. Yy Power off all devices : When you power off the TV, all connected devices are turned off. Yy Sync Power on: When the equipment with SIMPLINK function connected HDMI terminal starts to play, the TV will automatically turn on. Yy Speaker : [Depending on model] Select speaker either on the home theatre unit or the TV. to synchronize audio and video SETTINGS AUDIO AV Sync.

Adjust [Depending on model] Synchronizes video and audio directly when they do not match. yy If you set AV Sync. Adjust to ON, you can adjust the sound output (TV speakers or SPDIF) to the screen image. To use SIMPLINK [Depending on model] SIMPLINK is a feature that enables you to control and manage various multimedia devices conveniently via the SIMPLINK menu. 1 Connect the TV's HDMI IN terminal and the SIMPLINK device's HDMI output terminal using an HDMI cable. Yy [Depending on model] For home theatre units with a SIMPLINK function, connect HDMI terminals as above, and use an optical cable to connect Optical Digital Audio Out from the TV to Optical Digital Audio In of the SIMPLINK device. 4 In SIMPLINK menu window, selects the device you want to control. Yy This function is only compatible with devices with the SIMPLINK logo. Yy To use the SIMPLINK function, you need to use a high-speed HDMI® cable (with CEC (Consumer Electronics Control) feature added). high-speed HDMI® cables have the No.

13 pin connected for information exchange between devices. When France is selected for Country, password is not '0000' but '1234'. When France is selected for Country, password cannot be set to '0000'. To return Factory Reset SETTINGS OPTION Factory Reset All stored information is deleted and TV settings are reset. The TV turns itself off and back on, and all settings are reset.

Yy When Lock System is in place, a pop-up window appears and asks for password yy Do not turn off the power during initialization. When you see a message that the USB device has been removed, separate the device from the TV. Yy Once a USB device has been selected for removal, it can no longer be read. Remove the USB storage device and then re-connect it. Using a USB storage device - warning yy If the USB storage device has a built-in auto recognition program or uses its own driver, it may not work.

Yy Some USB storage devices may not work or may work incorrectly. Yy Use only USB storage devices formatted with the Windows FAT32 or NTFS File System. Yy For external USB HDDs, it is recommended that you use devices with a rated voltage of less than 5 V and a rated current of less than 500 mA. Yy It is recommended that you use USB memory sticks of 32 GB or less and USB HDDs of 1 TB or less. Yy If a USB HDD with power-saving function does not work properly, turn the power off and on. For more information, refer to the user manual of the USB HDD. Yy Data in the USB storage device can be damaged, so be sure to back up important files to other devices. Data maintenance is the user's responsibility and the manufacturer is not responsible for data loss. Psb (PowerDivX) yy Internal supported subtitle formats: XSUB (Supports internal subtitles generated from DivX6) SETTINGS / TO SEE WEB MANUAL / EXTERNAL CONTROL DEVICE SETUP 25 Supported Audio Formats yy File type : mp3 [Bit rate] 32 Kbps - 320 Kbps [Sample freq. ENGLISH ENG EXTERNAL CONTROL DEVICE SETUP To obtain the external control device setup information, please visit www.

Supported Photo Formats yy Category : 2D (jpeg, jpg, jpe) [Available file type] SOF0: Baseline, SOF1: Extend Sequential, SOF2: Progressive [Photo size] Minimum: 64 x 64, Maximum: Normal Type: 15360 (W) x 8640 (H), Progressive Type: 1920 (W) x 1440 (H) yy Category : BMP [Photo size] Minimum : 64 x 64, Maximum : 9600 x 6400 yy Category : PNG [Available file type] Interlace, Non-Interlace [Photo size] Minimum : 64 x 64, Maximum : Interlace : 1200 x 800, Non-Interlace : 9600 x 6400 yy BMP and PNG format files may be slower to display than JPEG. 26 MAINTENANCE MAINTENANCE Cleaning your TV Clean your TV regularly to keep the best performance and to extend the product lifespan. ENGLISH ENG CAUTION yy Make sure to turn the power off and disconnect the power cord and all other cables first. Yy When the TV is left unattended and unused for a long time, disconnect the power cord from the wall outlet to prevent possible damage from lightning or power surges. Screen, frame, cabinet and stand yy To remove dust or light dirt, wipe the surface with a dry, clean, and soft cloth. Yy To remove major dirt, wipe the surface with a soft cloth dampened in clean water or a diluted mild detergent. Then wipe immediately with a dry cloth. CAUTION yy Avoid touching the screen at all times, as this may result in damage to the screen. Yy Do not push, rub, or hit the screen surface with your fingernail or a sharp object, as this may result in scratches and image distortions. Yy Do not use any chemicals as this may damage the product.

Yy Do not spray liquid onto the surface. If water enters the TV, it may result in fire, electric shock, or malfunction. Power cord Remove the accumulated dust or dirt on the power cord regularly. TROUBLESHOOTING 27 TROUBLESHOOTING Problem Cannot control the TV with the remote control. Solution yy Check the remote control sensor on the product and try again.

Yy Check if there is any obstacle between the product and the remote control. Yy Check if the batteries are still working and properly installed (to , to).



[You're reading an excerpt. Click here to read official LG 42LB561V user guide](http://yourpdfguides.com/dref/5575521)

<http://yourpdfguides.com/dref/5575521>

Yy Check if the product is turned on. Yy Check if the power cord is connected to a wall outlet. Yy Check if there is a problem in the wall outlet by connecting other products.

yy Check the power control settings. The power supply may be interrupted. Yy Check if the Automatic Standby (Depending on model) / Sleep Timer / Off Time feature is activated in the TIME settings. Yy If there is no signal while the TV is on, the TV will turn off automatically after 15 minutes of inactivity. eNGLISH ENG No image display and no sound is produced. The TV turns off suddenly. When connecting to the PC yy Turn the TV off/on using the remote control. Yy Restart the PC with the TV on. B A A B *A < 10 mm = *B < 18 mm = 12 ASSEMBLAGE ET PRÉPARATION Télécommande et piles, batteries (AAA) Manuel d'utilisation Cordon d'alimentation FRANÇAIS ENG Base du support (Uniquement LB55**, LB56**-ZE / ZC, LB62**-ZA / ZB) Base du support (Uniquement LB56**-ZT / ZQ, LB62**-ZE) Vis du support 4EA, M4 x L14 (Uniquement 42/49LB55**, 39/42/47/50/55/60LB56**, 42/49/55LB62**) Vis du support 4EA, M4 x L20 (Uniquement 32LB55**, 32LB56**, 32LB62**) Entretoises pour fixation murale 2EA (Uniquement 42LB55**, 42LB56**, 42LB62**) Rangement des câbles 2EA Attache-câble (selon le modèle) Lunettes de cinéma 3D Le nombre de lunettes 3D peut varier suivant le modèle et le pays. 18 ASSEMBLAGE ET PRÉPARATION Fixation du support mural Prenez les précautions nécessaires pour fixer le support mural en option à l'arrière de la TV.

@@@If video is not switched automatically into 3D, manually convert the settings to view 3D images. 97 Component port connecting information Component ports on the TV Y Y Video output ports on DVD player Y Y Y Signal 480i / 576i 480p / 576p 720p / 1080i 1080p PB PB B-Y Cb Pb PR R-Y Cr Pr Component O O O (50 Hz / 60 Hz only) 1920 x 1080 HDMI-PC supported mode (Use HDMI IN 1 for PC mode) Resolution 640 x 350 720 x 400 640 x 480 800 x 600 1024 x 768 1152 x 864 1360 x 768 1280 x 1024 1920 x 1080 Horizontal Frequency (kHz) 31. 00 (Except for 32LB55*B, 32LB55*U, 32LB56*B, 32LB56*U, 32LB62*U) B-6 REGULATORY REGULATORY LG Recycling Policy (Only EU) LG Electronics offers a customized e-waste take-back & recycling service that meets local needs and requirements in the countries where e-waste regulations are in place, and also provides product and packaging take-back & recycling service voluntarily in some countries. LG Electronics evaluates products' recyclability at the design step using LG's recyclability evaluation tool, with the goal of improving recyclability where practicable. @@@@ lg. @@@@ g. When on holiday, yy Putting the television into standby mode, will reduce energy consumption, but will still draw some power, yy Reducing the brightness of the screen will reduce energy use. Disposal of waste batteries (Applicable in the European Union and other European countries with separate collection systems) This symbol on the battery or on the packaging indicates that the battery provided with this product shall not be treated as household waste. By ensuring these batteries are disposed of correctly, you will help prevent potentially negative consequences for the environment and human health which could otherwise be caused by inappropriate waste handling of the battery. The recycling of the materials will help to conserve natural resources.

In case of products that for safety, performance or data integrity reasons require a permanent connection with an incorporated battery, this battery should be replaced by qualified service staff only. To ensure that the battery will be treated properly, hand over the product at end-of-life to the applicable collection point for the recycling of electrical and electronic equipment. For all other batteries, please view the section on how to remove the battery from the product safely. Hand the battery over to the applicable collection point for the recycling of waste batteries. For more detailed information about recycling of this product or battery, please contact your local authority, your household waste disposal service or the shop where you purchased the product.

LGE announced the 'LG Declaration for a Cleaner Environment' in 1994, and this ideal has served as a Guiding managerial principle ever since. The Declaration is a foundation that has allowed us to undertake Environmentally friendly activities in careful consideration of economic, environmental, and social aspects. We promote activities for environmental preservation, and we specifically develop our products to embrace the Concept of environmentfriendly through whole process from getting raw materials, production, transportation, usage and end-of-life. These environmental characteristics are endorsed by the award of the European Commission as approval of the product environmental status for energy saving. Facilities for recycling and a host of other features.

The full list of criteria and more information on the eco label can be found at the web-site address : <http://www.нечних речовин> yy The equipment complies with requirements of the Technical Regulation, in terms of restrictions for the use of certain dangerous substances in electrical and electronic equipment. Isolator (Only Sweden, Norway) yy "Equipment connected to the protective earthing of the building installation through the mains connection or through other equipment with a connection to protective earthing - and to a cable distribution system using coaxial cable, may in some circumstances create a fire hazard. Connection to a cable distribution system has therefore to be provided through a device providing electrical isolation below a certain frequency range (galvanic isolator, see EN 60728-11)" yy "Utrustning som är kopplad till skyddsjord via jordat vägguttag och/eller via annan utrustning och samtidigt är kopplad till kabel-TV nät kan i vissa fall medföra risk för brand. If you have any inquiries or comments, please contact LG customer information centre. Customer Information Centre Country Service Country Service 0 810 144 131 015 200 255 0032 15 200255 07001 54 54 0900 543 5454 800 187 40 801 54 54 54 808 78 54 54 031 228 3542 0850 111 154 902 500 234 54 Record the model number and serial number of the TV. Refer to the label on the back cover and quote this information to your dealer when requiring any service. .



[You're reading an excerpt. Click here to read official LG 42LB561V user guide](http://yourpdfguides.com/dref/5575521)
<http://yourpdfguides.com/dref/5575521>