



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for M-AUDIO BLACK BOX PEDAL BOARD. You'll find the answers to all your questions on the M-AUDIO BLACK BOX PEDAL BOARD in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual M-AUDIO BLACK BOX PEDAL BOARD
User guide M-AUDIO BLACK BOX PEDAL BOARD
Operating instructions M-AUDIO BLACK BOX PEDAL BOARD
Instructions for use M-AUDIO BLACK BOX PEDAL BOARD
Instruction manual M-AUDIO BLACK BOX PEDAL BOARD

Black Box Pedal Board

Foot Controller for Black Box

▶ Quick Start Guide

This guide is intended to help get you started quickly. In order to achieve optimal usage of your new Black Box Pedal Board, we recommend that you carefully study the enclosed product manual, either after completing the process described in this guide or before.

ENGLISH

M-AUDIO



[You're reading an excerpt. Click here to read official M-AUDIO BLACK BOX PEDAL BOARD user guide](http://yourpdfguides.com/dref/3752673)

<http://yourpdfguides.com/dref/3752673>

Manual abstract:

One long cable snake breaks out in to three 1/4" connections. They are labeled Expression, P1 and P2. Plug these connectors in to the 1/4" jacks labeled the same way. An expression pedal has a range of travel from one extreme to another, passing many other values in between, like a wah-wah pedal. In contrast, a momentary pedal is a simple two-position switch. It can be set to either Open or Closed (On or Off) like a distortion pedal. Assignable Expression Pedal Values By pressing the UTILITY key on the Black Box and turning the rotary knob under EXP PEDAL on the LCD, you can assign any of the parameters below to the expression pedal. These values are set "per preset." This means on one preset, the expression pedal may be assigned for Wah, while on another preset the expression pedal might be assigned to Delay Volume. Amp Drive (AmpDrv) The pedal acts as an attenuator right after the drive parameter, varying the signal level from off to the current drive setting.

FX Speed (FXSped) If your current setting is tempo-based, the pedal will range from -2 to +2, limited to the extent of the allowed tempo-based settings. If the current setting is number-based, the pedal ranges from halfway between 0 and the current setting to halfway between the current setting and 99. FX Frequency (FXFreq) The pedal range is -30 to +30 of current panel setting. 3 English FX Depth (FXDpth) The pedal range is from 0 to the current setting (positive or negative). FX Key (FXKey) The range is from the current setting to +7.

FX Wet/Dry (FX WetDry) The pedal movement replaces the panel parameter and has a range of 0-99. Delay Volume (DlyVol) The pedal range is from 0 to the current setting. Delay Repeats (DlyRpt) The pedal movement replaces the panel parameter and has a range of 0-99. Drums to Delay (Dm2Dly) The pedal movement replaces the panel parameter and has range of D0-D99, the first half of the parameter's range. Drums to Filter (Dm2Flt) The pedal movement replaces the panel parameter and has a range of F0-F99, the second half of the parameter's range.

What Does the Knob Do? This is known as a "minimum/maximum" knob. Rolling the knob all the way forward sets it to maximum, while turning it all the way back sets it to minimum. Normally you'll want this knob set to the maximum setting. To explain how to use this knob creatively, let's use the FX Wet/Dry setting as an example. First, select factory preset 80 TAKBX1. Turn the knob to the maximum position. Press the UTILITY key and use the 3rd rotary knob to assign WETDRY for the expression pedal. With the pedal at the toe position, the sound is 100% wet with the TalkBox effect. @@Now roll the knob back just a bit. @@@@Set your Tempo to 120BPM.

This allows you to start and stop the drum machine with P1. Start playing with the FX Off. @@This will bring in a big Random Flanger sound. Start with the expression pedal all the way to the heel position. Throw in some solo lines here and there while pushing the pedal towards the toe position. This will add some beat-synced delay to your signal. Bring the pedal back to the heel position to start playing your rhythm parts again. When you start playing rhythm, your last solo licks will repeat over your rhythm part and then fade out. < P1=Delay On/Off < P2=FX On/Off < Expression=FX DEPTH 5 English Try these settings with the BRTHVY amp, FX WAHPDL and Delay time 4N, Delay Repeats 30 and delay volume 40. Set your Tempo to 120BPM.

This allows you to turn the Delay on and off with P1, which can really add to a solo. P2 will turn the Wah effect on and off. The expression pedal will act as your wah pedal. This works well with clean or heavy amp tones. Contact Us For additional help, technical support is available on our website at www.m-audio.com, where you can fill out our technical support form. Alternatively, you can email us at support@m-audio.com, or contact us by phone at: (626) 633-9055. Technical support is available by telephone from 7am - 7pm PST.

Warranty Terms and Registration Warranty Terms M-Audio warrants products to be free from defects in materials and workmanship, under normal use and provided that the product is owned by the original, registered user. @@@@.



[You're reading an excerpt. Click here to read official M-AUDIO BLACK BOX PEDAL BOARD user guide](http://yourpdfguides.com/dref/3752673)
<http://yourpdfguides.com/dref/3752673>