



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MOTOROLA FIRE XT316. You'll find the answers to all your questions on the MOTOROLA FIRE XT316 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual MOTOROLA FIRE XT316**  
**User guide MOTOROLA FIRE XT316**  
**Operating instructions MOTOROLA FIRE XT316**  
**Instructions for use MOTOROLA FIRE XT316**  
**Instruction manual MOTOROLA FIRE XT316**

MOTOROLA FIRE™

LIFE.  POWERED.



[You're reading an excerpt. Click here to read official MOTOROLA FIRE XT316 user guide](http://yourpdfguides.com/dref/4209498)  
<http://yourpdfguides.com/dref/4209498>

**Manual abstract:**

*Note: Certain apps and features may not be available for all countries/carriers. Caution: Before assembling, charging or using your phone for the first time, please read the important legal and safety information at the back of this guide. Want more? · Support: Online help and more at [www.motorola.com/support](http://www.motorola.com/support). Accessories: Find accessories for your phone at [www.motorola.com/products](http://www.motorola.com/products). Congratulations ! Your phone the important keys & connectors Power/ Lock key Press = sleep. Hold = turn off.*

*Volume keys Touchscreen Home key Back key 3.5mm headset jack Contents Let's go. . . .*

.....  
.....  
.....  
.....  
.....

*3 Touchscreen & keys . . . . .*

.....  
.....  
.....

*. . . . . 4 Home screen & apps . . . .*

.....  
.....  
.....

*. . . . . 7 Personalise . . . . .*

.....  
.....  
.....

*. . . . . 9 Calls . . . . .*

.....  
.....  
.....  
.....

*. . . . . 11 Contacts . . . . .*

.....  
.....  
.....  
.....

*. . . . . 13 Messaging . . . . .*

.....  
.....  
.....

*. . . . . 15 Text entry . . . . .*

.....  
.....  
.....  
.....

*. . . . . 17 Schedule . . . . .*

.....

.....  
.....

.....

.....

... *18 Web* ...

.....

.....

.....

.....

..... *19 Location* .....

.....

.....

.....

.....

.....

.....

..... *20 Photos & videos* .....

.....

.....

.....

.....

..... *21 Music* .....

.....

.....

.....

.....

.....

.....

..... *23 Connections* .....

.....

.....

.....

.....

..... *24 Security* .....

.....

.....

.....

.....

.....

.....

... *27 Tips & tricks* .....

.....

.....

.....

.....

..... *28 Troubleshooting* .....

.....

.....

.....

..... *30 Safety, regulatory & legal* .....

.....

.....

.....

.. @@@@Note: This phone supports data-intensive apps and services. @@@@Touch Menu > Settings > Wireless & networks > Wi-Fi settings. Touch . Wi-Fi to turn it on and search for nearby wireless networks. Touch a network to connect. There's more in "Wi-Fi networks" on page 25 Touchscreen & keys Touchscreen on/off a few essentials Your touchscreen is on when you need it and off when you don't. · To make your touchscreen sleep or wake up, just press the Power/Lock key . · When you hold the phone to your ear during calls, your touchscreen sleeps to prevent accidental touches. · To let the touchscreen adjust brightness automatically, touch Menu > Settings > Display > Brightness and select Automatic brightness. Touch tips Here are some tips on how to navigate around your phone. Touch To choose an icon or option, touch it. 4 Touchscreen & keys Touch & hold To open special options, touch and hold an icon or other item. Try it: On the home screen, touch > Contacts, then touch and hold a contact to open options. Phone Call log Contact Favourites Flick To scroll through a list or move quickly, flick across the touchscreen (drag quickly and release). Tip: When you flick a long list, touch the screen to stop it from scrolling. Barry Smyth Barry Smyth View contact Cheyenne Medina Christine Fanning Pinch-to-zoom Get a closer look at maps, webpages or photos. To zoom in, touch the screen with two fingers and then slide them apart. To zoom out, drag your fingers together.

Favourites Add to favourites Drag To scroll through a list or move slowly, drag across the touchscreen. Try it: On the home screen, touch > Contacts, then drag your Contacts list up or down. Tip: When you drag or flick a list, a scroll bar appears on the right. Drag the scroll bar to move the list to a letter A Z. Phone Call log Call log A arborn St Arthur Baudo Pinch to zoom in. M N Michigan Ave Barry Smyth Ontario St Grand Red E Ontario St N Wabash Ave E Ohio St N Rush St acker Dr N New St N Park St E Wacker Pl State/lake ES W Lake N Michigan Ave E Grand Ave N Co l u m b u s Dr N Dearborn St Cheyenne Medina M W Lake St M E Wacker Pl State/lake N Clark St Wacker Dr M W Lake St M E S WaterSt W Lake St N Michigan Ave Christine Fanning E Randolph St Messaging Lake Randolph/ Wabash M M do ph o ph Randolph etra ta St Metra Washington-Blue Randolph St Messaging E R a n d o l p h S t Randolph Market p h St Markeolp Lake Randolph/ Wabash M M Christopher Somers Washington-Blue Touchscreen & keys 5 Key tips Menu, home, back & search Menu key Touch to open menu options. Search key Touch for text search. Power key menu Press and hold the Power/Lock key to open the power key menu, where you can turn off the phone (Power off) or turn Silent mode or Flight mode on or off. Adjust volume Press the volume keys to change the ringer volume (on the home screen), or the earpiece volume (during a call). Home key Back key Touch Home to close any menu or app and return to the home screen.

On the home screen, touch and hold Home to show the last few apps you used, then touch an app to open it. Touch Search for text search. Touch Menu to open menu options, or touch Back to go back. Volume keys Rotate the screen The touchscreen can spin to stay the right way up when you rotate your phone: Find it: Menu screen > Settings > Display > Auto-rotate Sleep & wake up To save your battery, prevent accidental touches, or when you want to wipe smudges off your touchscreen, put the touchscreen to sleep by pressing the Power/Lock key . To wake up the touchscreen, just press the Power/Lock key again.

To change how long your phone waits before the screen goes to sleep automatically, touch Menu > Settings > Display > Screen timeout. 6 Touchscreen & keys Home screen & apps a few essentials Use & change your home screen On your home screen, shortcuts are icons that open your favourite apps, web bookmarks, contacts, mail labels or music playlists. Widgets show you news, weather, messages and other updates. Flick the home screen left or right to open other panels of shortcuts and widgets. · To open something, touch it.

Touch Home return to the home screen. Tip: When you open a widget, touch Menu show any options or settings. to to Quick start: Home screen The home screen gives you all your latest information in one place. It's what you see when you turn on the phone or touch Home from a menu. It's basically like this: Status indicators Widgets Touch to open. Touch & hold to move or delete. · To add something or change your wallpaper, touch and hold an empty spot until you see the Add to Home screen menu. You can add a folder to organise your shortcuts. · To move or delete something, touch and hold it until you feel a vibration, then drag it to another spot, another panel or the bin at the bottom of the screen. Notifications Flick down to see details.

Browser Contacts Calculator Settings Touch to see all your apps. Use the widgets, shortcuts and panels to show what's important to you--whether it's home, work or play.



[You're reading an excerpt. Click here to read official MOTOROLA FIRE XT316 user guide](http://yourpdfguides.com/dref/4209498)  
<http://yourpdfguides.com/dref/4209498>

Home screen & apps 7 Phone status & notifications At the top of the screen, icons on the left notify you about new messages or events (notifications). Icons on the right tell you about phone status. Flick the bar down to show notification details. 11 June 2011 Apps The app menu shows you all of your applications. To open it from the home screen, touch . Flick up and down to see all of your apps. Any new apps that you download are added to the app menu. To close the app menu, touch Home 10:32 12:09 11 June 2011 12:09 Clear Notifications New voicemail Dial (your voicemail number) 10:32 Notifications New voicemail Dial (your voicemail number) or Back .

Running multiple apps No need to close an app before opening another one. Your phone runs multiple apps, all at the same time. voicemail message Bluetooth™ active Wi-Fi™ active vibrate mode mute call firewall active battery (fully charged) USB connection Bluetooth connected flight mode silent mode speakerphone active alarm set battery (charging) You can open a new app while running another. Touch Home to return to the home screen, touch to open the main menu, then touch the app you want. To switch from one running app to another, touch and hold Home to see what apps are already open, then touch the one you want.

8 Home screen & apps download apps To download new apps from Android Market™, touch > Market. Touch Search to find an app, or touch My apps to show or reinstall the apps you downloaded. To download apps from websites, you need to change your security settings: Touch Menu > Settings > Applications > Unknown sources. Personalise add your personal touch Customise your phone's sounds and appearance to make it unique to you! Quick start: personalise From the home screen, touch Menu Sound or Display. Sound settings General > Settings > Warning: Apps downloaded from the web can be from unknown sources.

To protect your phone and personal data, only download apps from sources you trust. To move or uninstall your apps, touch Menu > Settings > Applications > Manage applications. Touch an app in the list to show details and options. On your computer, you can browse and manage apps for all your devices powered by Android™ at market.android.com. Silent mode Silence all sounds except media & alarms Vibrate Only in Silent mode Choose separate volume settings for incoming calls, media, alarms and notifications. Call & message notifications Display settings Volume Incoming calls Phone ringtone Notifications Brightness Auto-rotate screen Animation Notification ringtone Turn on or off menu animations. All window animations are shown Screen timeout Adjust the delay before the screen automatically turns off Personalise 9 · To choose a ringtone or vibration for calls and messages, touch Menu > Settings > Sound, then choose Phone ringtone, Notification ringtone or Vibrate. · To change the volume, touch Menu > Sound > Volume.

> Settings · To calibrate the sensors used by some games or navigation apps, touch Menu > Settings > Display > G-Sensor calibration (movement) or E-Compass calibration (direction). Language & region > To set your menu language and region, touch Menu > Settings > Language & keyboard > Select language · To turn dial pad sounds on or off, touch Menu Settings > Sound > Audible touch tones. · To turn menu selection sounds on or off, touch Menu > Sele you call, touch Menu > Settings > Call settings > Additional settings > Caller ID. Call forwarding & waiting To forward calls, touch Menu > Settings > Call settings > Call forwarding. You can forward 12 Calls Emergency calls Note: Your service provider programs one or more emergency phone numbers that you can call under any circumstances, even when your phone is locked. Emergency numbers vary by. For details, contact the account provider. To set up a standard email account, touch > Email and follow the wizard. To add more standard accounts, open Email and touch Menu > Accounts > Menu > Add account. For details, contact the account provider.

· To open email, touch > Touch a message to open it. Tip: Touch Menu Search. Email or Gmail. If you need to change your voicemail number, on the home screen touch Menu > Settings > Call settings > Voicemail settings. for options like Refresh or > Email or > Compose.

· To create an email, touch Gmail, then touch Menu Tip: Touch Menu Cc/Bcc. for options like Attach or Add Voicemail When you have a new voicemail, shows in the status bar at the top of your screen. To hear voicemails, touch > then touch and hold 1. 16 Messaging Text entry keys when you need them To change your text entry settings and see the dictionary of terms you've used, from the home screen, touch Menu > Settings > Language & keyboard. Typing tips To.

.. Enter alternative characters From the number keyboard, touch Alt . Touch again to return to symbols/numbers. Touch Shift . Text input settings Find it: Menu > Settings > Language & keyboard · To edit your dictionary, touch User dictionary. · To change the language and the style for your touchscreen keyboard, touch Select language. · To change the device keypad settings, touch Built-in keyboard. Enter one capital letter Enter only capital letters, until you touch Shift again Cut or copy selected text Touch Shift twice. Touch again to revert to lowercase.

Touch and hold text to select, then touch and hold to Cut or Copy. Paste cut or copied text Touch and hold location to paste then touch Paste. Touch Delete .

Delete a character (hold to delete more) Text entry 17 Schedule helping you stay in control Your Calendar events can synchronise with your Google™ account and the Clock can wake you up! · To create an event, touch > Calendar > Menu > More > New event, then enter details (to close the display keyboard, touch Back ). · To edit or delete an event, touch > Calendar, touch the event to open it, then touch Menu > Edit event or Delete event. Quick start: Schedule From the home screen, touch June 2012 Mon Tue Wed Thu Fri Sat Sun > Calendar. Alarm clock To set an alarm (like to wake up), touch then touch the alarm. > next to it. Clock, 28 29 30 31 1 2 3 Colour indicates events. · To turn an alarm on or off, touch 4 5 6 7 8 9 10 · To add an alarm, touch Add alarm, then enter alarm details.

Drag or flick to scroll. · To change an alarm, touch the time. · To set a snooze period, in the Alarm clock list touch Menu > Settings > Snooze duration. When an alarm sounds, touch Dismiss to turn it off or Snooze to delay it.



[You're reading an excerpt. Click here to read official MOTOROLA FIRE XT316 user guide](http://yourpdfguides.com/dref/4209498)

<http://yourpdfguides.com/dref/4209498>

To cancel a snoozed alarm, drag down the status bar and touch the alarm name.

11 12 13 14 15 16 17 Touch to open. Touch & hold to open options. 18 19 20 21 22 23 24 25 26 Day 27 28 Week 29 30 31 Month 1 2 Diary 3 4 Today 5 6 More 7 Touch to choose the calendar view. Choose More to create an event or change settings. Date & time To set the date, time, time zone and formats, touch Menu > Settings > Date & time.

18 Schedule Web surf the web with your phone Open the Browser or just touch Search to find a page, then bookmark it, send it or just explore. · To zoom in or out, pinch two fingers together or apart. · To send the website address in a message, touch Menu > More > Share page. www.google.com: Google www.google.com: Google News results for android Verizon Droid Success Limited by Android Market 7 hours ago The iDon't ad campaign pits the Android-based Droid head-to-head against the formidable iPhone. Based on preliminary predictions..

PC World - 1778 related articles » Quick start: Browser From the home screen, touch 12:09 AM > Browser http://www.google.com... Connection Mobile network: Wi-Fi: Enter a webpage URL. Touch to open. Touch & hold to open options. Note: Your phone automatically uses your mobile phone network to connect to the web. Your service provider may charge to surf the web or download data.

If you can't connect, contact your service provider. Tip: You can connect to the web with "Wi-Fi networks" on page 25. Desconhec. Drag or flick to scroll.

Downloads To download files in your browser, touch a file link or touch and hold a picture to choose Save image.

To show the files you downloaded, touch > Browser > > More > Downloads. Touch and hold an item to open it, see details or remove it from the list. New window Bookmarks Windows Touch to open bookmarks, windows and more. Refresh Forward More · To enter a web address in the browser or your home screen, just touch Search . Web 19 Location where you are, where you're going · To find an address, touch Menu > Search and then enter it in the search bar at the top.

The map moves to show the address. Tip: You can touch and hold a spot on the map to show the nearest address. Quick start: Location From the home screen, touch 12:09 AM Ontario St Grand Red > Maps · To find stores, restaurants and other places near you, touch Menu > My Location to see details. · To get directions, find an address on the map, touch it, then touch Menu > Directions. E Ontario St E Ohio St N Michigan Ave N Rush St E Grand Ave N New St N Park St Dr N Wabash Ave M N Co l u m b u s · For help, touch Menu Drag or flick to scroll. > More > Help. N Dearborn St E Wacker Pl State/lake Lake Randolph/ Wabash M Google Maps™ offers powerful, user-friendly mapping technology and local business information--including business locations, contact information and driving directions. 20 Location N Clark St Google Maps Navigation™ Google Maps Navigation is an Internet-connected GPS navigation system with voice guidance. To open navigation, touch > Navigation. Follow the prompts to speak or type your destination.

For more, go to [www.google.com/mobile/navigation](http://www.google.com/mobile/navigation). Wacker Dr M W Lake St M E S WaterSt W Lake St N Michigan Ave M Randolph St Metra E Randolph St Touch to open, then touch to add to Starred Places. Touch to open a menu where you can get directions, open your Starred Places, windows and more.

Washington-Blue Search Directions Layers My Location Join Latitude More Latitude Latitude lets you see where your friends and family are on Google Maps™. Plan to meet up, check that they got home safely or just stay in touch. Don't worry, your location is not shared unless you agree to it. After you join Latitude, you can invite your friends to view your location, or accept their invitations. Touch > Maps and then: Photos & videos see it, capture it, share it! > Latitude > · To join Latitude, touch Menu > Join Latitude.

Read the privacy policy and, if you agree with it, choose to continue. · To add friends touch Menu Menu > Add friends. Quick start: Photos & videos Press the Camera key on the right side of the phone to open the camera. Open your last photo or video. Touch Select from Contacts or Add via email address, then touch a contact and Add friends.

Your friend will receive an email notice. · To remove friends touch Menu > Latitude to show your friends list. Touch a name, then touch Remove this friend. Photo or video quality. Store your location in photos.

Set white balance for your lighting. Zoom. · To share your location when you receive a request, you can choose Accept and share back (show your location and see theirs), Accept, but hide my location (hide your location, but see theirs) or Don't accept (hide both locations). · To hide your location touch Menu > Latitude to show your friends list. Touch your contact name, then touch Menu > Settings > Hide your location. · To sign out of Latitude, touch Menu to show your friends list. Touch Menu Settings > Sign out of Latitude. > Latitude > Choose camera or camcorder. Capture. Tip: For the clearest photos and videos, clean the lens with a soft, dry cloth.

· To take a photo, open the camera, then press the Camera key. · To record a video, open the camera, then touch the camcorder icon to switch to the camcorder. Press the Camera key to start and stop recording. Photos & videos 21 View & share photos & videos From the home screen, touch > My gallery.

YouTube™ The YouTube user-generated content website lets you share videos with YouTube users everywhere. You don't need a YouTube account to browse and view videos. From the home screen, touch > YouTube. Flick left and right to show folders. Touch a folder to show its photos or videos, then touch a thumbnail image to open, share or delete it. Tip: From the viewfinder, you can touch the thumbnail in the top right to open your last photo or video.

· To zoom in, touch the screen with two fingers and then drag them apart. To zoom out, drag your fingers together. · To send or post the photo or video, touch Menu > Share. · To delete the photo or video, touch Menu > Delete. · To set a photo as your wallpaper or a contact photo, touch More > Set as.

· To crop or rotate a photo, touch More. · To play a video, touch . Tip: Turn the phone sideways for a widescreen view. · To watch videos, touch a video clip or touch Search to find a video. Touch a video to watch it.

For more video categories, touch Menu Browser.



[You're reading an excerpt. Click here to read official MOTOROLA FIRE XT316 user guide](http://yourpdfguides.com/dref/4209498)

<http://yourpdfguides.com/dref/4209498>

> > To watch a video in high quality, touch Menu Settings > High quality video on mobile. · To share a video, touch it to open it, touch More at the top, choose Share, then choose how you want to share it. · To upload a video from your phone to your YouTube account, touch > YouTube > Menu > Upload. Touch the video, then touch Upload. To sign into your YouTube account, touch YouTube > Menu > My account. > Note: If you don't have an account, touch the link to create one. For more, visit [www.youtube.com](http://www.youtube.com).

22 Photos & videos Music when music is what you need... Keep your music with you! Put music on your phone so you can listen and create playlists anytime.

To adjust volume, use the phone's volume keys. · When a song is playing, touch Menu a playlist or Use it as a ringtone. to add it to > To edit, delete, or rename playlists, touch the playlist name. Music touch the Playlists tab, then touch and hold Quick start: Music From the home screen, touch choose a song to play it. 11:04 > Music, then · To hide the player and use other apps, touch Home . Your music keeps playing.

To return to the player, flick down the status bar and touch . Tip: For quick music player controls, touch and hold an empty spot on your home screen, then choose Widget > Music. · To stop the player, touch . · Before a flight, turn off network and wireless connections so that you can keep listening to music: press and hold Power/Lock key > Flight mode. Note: When you select flight mode, all wireless services are disabled.

You can then turn Wi-Fi and/or Bluetooth back on, if permitted by your airline. Other wireless voice and data services (such as calls and text messages) remain off in flight mode. Emergency calls to your region's emergency number can still be made. Open playlist Shuffle on/off Repeat off/all/current Music artist Album title Song title 0:26 3:27 Music controls Total song time Progress bar Music 23 You can use your phone's 3.5 mm OMTP headset jack to connect wired headphones, or go wireless with "Bluetooth™ Devices" on page 25.

To listen to FM radio stations, plug in a 3.5mm OMTP headset and touch > FM Radio. Your phone uses the headset wire as the radio aerial. 98 1 101 106 Connections home, office or hotspot Quick start: Connections From the home screen, touch Menu > Settings > Wireless & networks, then Bluetooth settings or Wi-Fi settings. Bluetooth settings Music files Note: Copyright--do you have the right? Always follow the rules. See "Content copyright" in your legal and safety information. To get songs for your music player, you can download them from online services or copy them from your computer. Your music player can play these file formats: MP3, M4A, AAC, ACC+, MIDI, WAV or OGG Vorbis. Note: Your phone does not support any DRM-protected files. To copy files from your computer to your phone, you can use "Cable connections" on page 26 or "Bluetooth™ Devices" on page 25.

To save a CD as files on your computer ("rip" the CD), you can use a program like Microsoft™ Windows™ Media Player. First, make sure you change the format to MP3 (under Rip > Format in Windows Media Player). 24 Connections Bluetooth Device name (Your phone) Turn Bluetooth power on & scan, or turn off. Change your phone's Bluetooth device name. Re-scan. Connect a device found by the scan. Wi-Fi settings Discoverable Make device discoverable Scan for devices Bluetooth devices (Nearby Bluetooth device) Pair with this device Wireless Network notification Turn Wi-Fi power on & scan, or turn off. Connect a device found by the scan. Notify me when an open network is available Wi-Fi networks (Your network) Add Wi-Fi network · To connect Bluetooth devices, touch Menu > Settings > Wireless & networks > Bluetooth settings > Scan for devices (or Bluetooth, if it is off). Touch a device that your phone found, to connect it.

· To connect Wi-Fi networks, touch Menu > Settings > Wireless & networks > Wi-Fi settings (then touch Wi-Fi, if it is off). Touch a network that your phone found, to connect it. · To use a cable connection, connect your phone's micro USB port to a standard USB port on your computer, then use a computer program to transfer files to and from your phone's memory card. Your phone supports microSD cards up to 32 GB. On your phone, flick down the status bar and touch to enable your phone's memory card (optional accessory).

You can download your phone's driver files from [www.motorola.com/support](http://www.motorola.com/support). 2 Touch Menu > Settings > Wireless & networks > Bluetooth settings. 3 Touch Scan for devices (Bluetooth if it is turned off).

Your phone scans, and lists nearby devices. 4 Touch a device to connect. 5 If necessary, touch Pair or enter the device passkey (like 0000) to connect to the device. When the device is connected, the Bluetooth connected indicator appears in the status bar. To reconnect a device you've connected before, just turn it on. To disconnect a device, just turn it off. Note: Using a mobile device or accessory while driving may cause distraction and may be illegal. Always obey the laws and drive safely. Tip: Touch and hold an empty spot on your home screen, then choose Widgets > Power control for a widget that lets you turn on or off Wi-Fi, Bluetooth, Use GPS satellites and more. Bluetooth™ Devices Note: This feature requires an optional accessory.

You can connect your phone to other Bluetooth devices for hands-free calls, file transfers and more: 1 Make sure the device you are pairing with is in discoverable mode. Wi-Fi networks You can connect to Wi-Fi networks for even faster Internet access and to download data: 1 Touch Menu > Settings > Wireless & networks > Wi-Fi settings. Connections 25 2 Touch Menu > Scan (or touch Wi-Fi, if it is off). Your phone scans for nearby networks. To see your phone's MAC address or other Wi-Fi details, touch Menu > Advanced. 3 Touch a network to connect. 4 If necessary, enter details from the network administrator. When your phone is connected, the Wi-Fi indicator appears in the status bar. When power is on and your phone finds a network you've used, it automatically reconnects and shows in the status bar. Tip: To see the available memory on your memory card, from the home screen touch Menu > Settings > Storage.

To connect your phone and computer with a cable: 1 Insert a memory card in your phone, then connect your phone's micro USB port to a USB port on your computer. Note: If your computer asks for your phone's driver files, you can download them from [www.motorola.com/support](http://www.motorola.com/support). 2 Your phone should show in the status bar.

Flick down the status bar, touch the to enable your phone's memory card.



[You're reading an excerpt. Click here to read official MOTOROLA](#)

[FIRE XT316 user guide](#)

<http://yourpdfguides.com/dref/4209498>





If you continue to have discomfort during or after such use, stop use and see a doctor. Children Keep your mobile device and its accessories away from small children. These products are not toys and may be hazardous to small children. For example: · A choking hazard may exist for small, detachable parts. · Improper use could result in loud sounds, possibly causing hearing injury. · Improperly handled batteries could overheat and cause a burn. Similar to a computer, if a child does use your mobile device, you may want to monitor their access to help prevent exposure to inappropriate apps or content.

Seizures/blackouts Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing videos or games. These may occur even if a person has never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing videos or games or enabling a flashing-lights feature (if available) on your mobile device.

Discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements or disorientation. It is always a good idea to hold the screen away from your eyes, leave the lights on in the room, take a 15-minute break every hour and stop use if you are tired. Glass parts Some parts of your mobile device may be made of glass. This glass could break if the product receives a substantial impact. If glass breaks, do not touch or attempt to remove.

Stop using your mobile device until the glass is replaced by a qualified service centre. 32 Operational warnings Obey all posted signs when using mobile devices in public areas. Symbol Definition Do not use tools. Potentially explosive areas Potentially explosive areas are often, but not always, posted and can include blasting areas, fuelling stations, fuelling areas (such as below decks on boats), fuel or chemical transfer or storage facilities or areas where the air contains chemicals or particles, such as grain dust or metal powders. When you are in such an area, turn off your mobile device, and do not remove, install or charge batteries unless it is a radio product type especially qualified for use in such areas as "Intrinsically Safe" (for example, Factory Mutual, CSA or UL approved).

In such areas, sparks can occur and cause an explosion or fire. For indoor use only. Listening at full volume to music or voice through a headset may damage your hearing. Symbol key Your battery, charger or mobile device may contain symbols, defined as follows: Symbol 032374o Radio frequency (RF) energy Exposure to RF energy Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate using your mobile device, the system handling your call controls the power level at which your mobile device transmits. Your mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy. Definition Important safety information follows. Do not dispose of your battery or mobile device in a fire. 032376o RF energy operational precautions 032375o Your battery or mobile device may require recycling in accordance with local laws.

@@@The SAR limit for mobile devices is 2 W/kg. @@The highest SAR values under the ICNIRP guidelines for your device model are listed below: Head SAR Body-worn SAR UMTS 900/2100 + Wi-Fi + Bluetooth GSM 850/900/1800/1900 + Wi-Fi + Bluetooth 0,819 W/kg 0,669 W/kg Follow instructions to avoid interference problems Turn off your mobile device in any location where posted notices instruct you to do so, such as hospitals or healthcare facilities. In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers flight mode or similar feature, consult airline staff about using it in-flight. Medical devices If you have a medical device, including an implantable medical device such as a pacemaker or defibrillator, consult your healthcare provider and the device manufacturer's directions before using this mobile device. Persons with implantable medical devices should observe the following precautions: · ALWAYS keep the mobile device more than 20 centimetres (8 inches) from the implantable medical device when the mobile device is turned ON. · DO NOT carry the mobile device in the breast pocket. · Use the ear opposite the implantable medical device to minimise the potential for interference. · Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place. Read and follow the directions from the manufacturer of your implantable medical device.

If you have any questions about using your mobile device with your implantable medical device, consult your health care provider. During use, the actual SAR values for your device are usually well below the values stated. This is because, for purposes of system efficiency and to minimise interference on the network, the operating power of your mobile device is automatically decreased when full power is not needed for the call. The lower the power output of the device, the lower its SAR value. Body-worn SAR testing has been carried out using an approved accessory or at a separation distance of 2.5 cm (1 inch). To meet RF exposure guidelines during body-worn operation, the device should be in an approved accessory or positioned at least 2.5 cm (1 inch) away from the body. If you are not using an approved accessory, ensure that whatever product is used is free of any metal and that it positions the phone at least 2.5 cm (1 inch) away from the body.

Additional information can be found at [www.who.int/emf](http://www.who.int/emf) (World Health Organisation) or [www.motorola.com/rfhealth](http://www.motorola.com/rfhealth) (Motorola Mobility, Inc.). \* 34 The tests are carried out in accordance with [CENELEC EN50360] [IEC standard PT62209-1]. European Union directives conformance statement The following CE compliance information is applicable to Motorola mobile devices that carry one of the following CE marks: EU conformance FCC notice to users The following statement applies to all products that bear the FCC logo on the product label. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. See 47 CFR Sec.

15.105(b). These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: · Reorient or relocate the receiving antenna.



[You're reading an excerpt. Click here to read official MOTOROLA FIRE XT316 user guide](http://yourpdfguides.com/dref/4209498)  
<http://yourpdfguides.com/dref/4209498>

· Increase the separation between the equipment and the receiver. · Connect the equipment to an outlet on a circuit different from that to which the receiver is connected. · Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(a)(3). Motorola has not approved any changes or modifications to this device by the user.

Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21. For products that support Wi-Fi 802.11a (as defined in the product specifications available at [www.motorola.com](http://www.motorola.com)), the following information applies. This equipment has the capability to operate Wi-Fi in the 5 GHz Unlicensed National Information Infrastructure (U-NII) band. Because this band is shared with MSS (Mobile Satellite Service), the FCC has restricted such devices to indoor use only (see 47 CFR 15.407(e)). Since wireless hot spots operating in this band have the same restriction, outdoor services are not offered. Nevertheless, please do not operate this device in Wi-Fi mode when outdoors. FCC notice 0168 0168 [Only indoor use allowed in France for Bluetooth and/or Wi-Fi] Hereby, Motorola declares that this product is in compliance with: · The essential requirements and other relevant provisions of directive 1999/5/EC · All other relevant EU directives 0168 Product approval number The above gives an example of a typical product approval number. You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at [www.motorola.com/rtte](http://www.motorola.com/rtte). To find your DoC, enter the Product approval number from your product's label in the "Search" bar on the website.

35 Location services (GPS & AGPS) The following information is applicable to Motorola mobile devices that provide location based (GPS and/or AGPS) functionality. Your mobile device can use Global Positioning System (GPS) signals for location-based applications. GPS uses satellites controlled by the U.S. government that are subject to changes implemented in accordance with the Department of Defense policy and the Federal Radionavigation Plan. These changes may affect the performance of location technology on your mobile device. Your mobile device can also use Assisted Global Positioning System (AGPS), which obtains information from the mobile network to improve GPS performance.

AGPS uses your wireless service provider's network and therefore airtime, data charges and/or additional charges may apply in accordance with your service plan. Contact your wireless service provider for details. GPS & AGPS Navigation The following information is applicable to Motorola mobile devices that provide navigation features. When using navigation features, note that mapping information, directions and other navigational data may contain inaccurate or incomplete data. In some countries, complete information may not be available.

Therefore, you should visually confirm that the navigational instructions are consistent with what you see. All drivers should pay attention to road conditions, closures, traffic and all other factors that may impact driving. Always obey posted road signs. Navigation Smart practices while driving Check the laws and regulations on the use of mobile devices and their accessories in the areas where you drive. Always obey them.

The use of these devices may be prohibited or restricted in certain areas--for example, hands-free use only may be required. Go to [www.motorola.com/callsmart](http://www.motorola.com/callsmart) (in English only) for more information. Your mobile device lets you communicate by voice and data, almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your mobile device while driving, remember the following tips: · Get to know your Motorola mobile device and its features such as speed dial, redial and voice dial. If available, these features help you to place your call without taking your attention off the road. · When available, use a hands-free device. If possible, add an additional layer of convenience to your mobile device with one of the many Motorola original hands-free accessories available today.

· Position your mobile device within easy reach. Be able to access your mobile device without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voicemail answer it for you. · Let the person you are speaking to know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions. Rain, sleet, snow, ice and even heavy traffic can be hazardous. · Do not take notes or look up phone numbers while driving. Jotting down a "to do" list or going through your address book takes attention away from your primary responsibility--driving safely.

Driving safety Your location Location-based information includes information that can be used to determine the approximate location of a mobile device. Mobile devices that are connected to a wireless network transmit location-based information. Devices enabled with GPS or AGPS technology also transmit location-based information.

Additionally, if you use applications that require location-based information (e.g. driving directions), such applications transmit location-based information. This location-based information may be shared with third parties, including your wireless service provider, applications providers, Motorola and other third parties providing services. Emergency calls When you make an emergency call, the mobile network may activate the AGPS technology in your mobile device to tell the emergency responders your approximate location.

AGPS has limitations and might not work in your area. Therefore: · Always tell the emergency responder your location to the best of your ability; and · Remain on the phone for as long as the emergency responder instructs you. 36 · Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic. If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue. · Do not engage in stressful or emotional conversations that may be distracting.

Make people you are talking to aware you are driving and suspend conversations that can divert your attention away from the road. · Use your mobile device to call for help. Dial 999 or another local emergency number in the case of fire, traffic accident or medical emergencies (wherever wireless phone service is available). · Use your mobile device to help others in emergencies.



[You're reading an excerpt. Click here to read official MOTOROLA FIRE XT316 user guide](http://yourpdfguides.com/dref/4209498)  
<http://yourpdfguides.com/dref/4209498>

If you see an accident, crime in progress, or other serious emergency where lives are in danger, call 999 or other local emergency number (wherever wireless phone service is available), as you would want others to do for you. · Call roadside assistance or a special non-emergency wireless assistance number when necessary. If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured or a vehicle you know to be stolen, call roadside assistance or another special non-emergency wireless number (wherever wireless phone service is available). Privacy & data security Motorola understands that privacy and data security are important to everyone. Given that some features of your mobile device may affect your privacy or data security, please follow these recommendations to enhance protection of your information: · Monitor access--Keep your mobile device with you and do not leave it where others may have unmonitored access. Use your device's security and lock features, where available.

· Keep software up to date--If Motorola or a software/application vendor releases a patch or software fix for your mobile device that updates the device's security, install it as soon as possible. · Secure personal information--Your mobile device can store personal information in various locations including your SIM card, memory card and phone memory. Make sure you remove or clear all personal information before you recycle, return or give away your device. You can also back up your personal data to transfer to a new device. Note: For information on how to back up or wipe data from your mobile device, go to [www.motorola.com/support](http://www.motorola.com/support) Privacy & data security · Online accounts--Some mobile devices provide a Motorola online account (such as MOTOBLUR). Go to your account for information on how to manage the account and how to use security features such as remote wipe and device location (where available). · Applications and updates--Choose your apps and updates carefully and install from trusted sources only. Some apps can impact your phone's performance and/or have access to private information including account details, call data, location details and network resources.

· Wireless--For mobile devices with Wi-Fi features, only connect to trusted Wi-Fi networks. Also, when using your device as a hotspot (where available) use network security. These precautions will help prevent unauthorised access to your device. · Location-based information--Location-based information includes information that can be used to determine the approximate location of a mobile device. Mobile phones that are connected to a wireless network transmit location-based information.

Devices enabled with GPS or AGPS technology also transmit location-based information. Additionally, if you use applications that require location-based information (e.g. driving directions), such applications transmit location-based information. This location-based information may be shared with third parties, including your wireless service provider, applications providers, Motorola and other third parties providing services.

· Other information your device may transmit--Your device may also transmit testing and other diagnostic (including location-based) information, and other non-personal information to Motorola or other third-party servers. This information is used to help improve products and services offered by Motorola. If you have further questions regarding how the use of your mobile device may impact your privacy or data security, please contact Motorola at [privacy@motorola.com](mailto:privacy@motorola.com), or contact your service provider. 37 Use & care To care for your Motorola phone, please observe the following: Use & care Recycling Recycling Mobile devices & accessories Please do not dispose of mobile devices or electrical accessories (such as chargers, headsets or batteries) with your household waste or in a fire. These items should be disposed of in accordance with the national collection and recycling schemes operated by your local or regional authority. Alternatively, you may return unwanted mobile devices and electrical accessories to any Motorola approved service centre in your region. Details of Motorola-approved national recycling schemes and further information on Motorola recycling activities can be found at: [www.motorola.com/recycling](http://www.motorola.com/recycling) liquids Don't expose your mobile device to water, rain, extreme humidity, sweat or other liquids.

If it does get wet, don't try to accelerate drying with the use of an oven or dryer, as this may damage the phone. extreme heat or cold Don't store or use your mobile device in temperatures below -10°C (14°F) or above 60°C (140°F). Don't recharge your mobile device in temperatures below 0°C (32°F) or above 45°C (113°F). microwaves Don't try to dry your phone in a microwave oven. dust and dirt Don't expose your phone to dust, dirt, sand, food or other inappropriate materials. cleaning solutions To clean your phone, use only a dry soft cloth. Do not use alcohol or other cleaning solutions. shock and vibration Don't drop your phone. protection To help protect your mobile device, always make sure that the battery compartment and any connector covers are closed and secure. Packaging & product guides Product packaging and product guides should only be disposed of in accordance with national collection and recycling requirements.

Please contact your regional authorities for more details. Software copyright notice Motorola products may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in Motorola products may not be modified, reverse-engineered, distributed or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of Motorola products shall not be deemed to grant, either directly or by implication or estoppel or otherwise, any licence under the copyrights, patents or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free licence to use that arises by operation of law in the sale of a product.

Software copyright notice Content copyright The unauthorised copying of copyrighted materials is contrary to the provisions of the copyright laws of the United States and other countries. This device is intended solely for copying non-copyrighted materials, materials in which you own the copyright or materials which you are authorised or legally permitted to copy. If you are uncertain about your right to copy any material, please contact your legal advisor.



[You're reading an excerpt. Click here to read official MOTOROLA FIRE XT316 user guide](http://yourpdfguides.com/dref/4209498)  
<http://yourpdfguides.com/dref/4209498>

Content copyright 38 Open source software information For instructions on how to obtain a copy of any source code being made publicly available by Motorola related to software used in this Motorola mobile device, you may send your request in writing to the address below. Please make sure that the request includes the model number and the software version number.

MOTOROLA MOBILITY, INC. OSS Management 600 North US Hwy 45 Libertyville, IL 60048 USA The Motorola website [opensource.motorola.com](http://opensource.motorola.com) also contains information regarding Motorola's use of open source. Motorola has created the [opensource.motorola.com](http://opensource.motorola.com) website to serve as a portal for interaction with the software community-at-large. To view additional information regarding licences, acknowledgments and required copyright notices for open source packages used in this Motorola mobile device, please press Menu Key > Settings > About phone > Legal information > Open source licences. In addition, this Motorola device may include self-contained applications that present supplemental notices for open source packages used in those applications. OSS information 39 WARRANTY INFORMATION Motorola guarantees to you, the original purchaser, the Personal Communicator and accessories which you have purchased from an authorised Motorola dealer (the "Products"), to be in conformance with the applicable Motorola specifications current at the time of manufacture for a different period of time from date of purchase of the Product(s) (warranty term).

The warranty period starts at the time of the Product(s) original purchase by the first end-user. The Product may consist of several different parts and different parts may be covered by a different warranty period (hereinafter "Warranty Period"). The different Warranty Periods are: a) Twelve (12) months for the Personal Communicator and for accessories (whether included in the Product sales package or sold separately) other than the consumable parts and accessories listed in (b) and (c) below; b) Six (6) months for the following consumable parts and accessories: batteries, and c) Ninety (90) days for the media on which any software is provided e.g. CD-ROM, memory card. You must inform Motorola of the lack of conformity to the applicable specifications of any of the Products within a period of two (2) months from the date on which you detect a defect in material, workmanship or lack of conformity and in any event within a term not to exceed the Warranty Term, and must immediately submit the Product for service to Motorola's Authorised Repair or Service Centre. Motorola shall not be bound by Product related statements not directly made by Motorola nor any warranty obligations applicable to the seller. During the Warranty term, Motorola will, at its discretion and without extra charge, as your exclusive remedy, repair or replace your Product which does not comply with this warranty; or failing this, to reimburse the price of the Product but reduced to take into account the use you have had of the Product since it was delivered. This warranty will expire at the end of the Warranty Term. This is the complete and exclusive warranty for a Motorola Personal Communicator and accessories and in lieu of all other warranties, terms and conditions, whether express or implied.

Where you purchase the product other than as a consumer, Motorola disclaims all other warranties, terms and conditions express or implied, such as fitness for purpose and satisfactory quality. 40 In no event shall Motorola be liable for damages nor loss of data in excess of the purchase price nor for any incidental special or consequential damages\* arising out of the use or inability to use the Product, to the full extent such may be disclaimed by law. This Warranty does not affect any statutory rights that you may have if you are a consumer, such as a warranty of satisfactory quality and fit for the purpose for which products of the same type are normally used under normal use and service, nor any rights against the seller of the Products arising from your purchase and sales contract. HOW TO GET WARRANTY SERVICE? In most cases the authorised Motorola dealer which sold and/or installed your Motorola Personal Communicator and original accessories will honour a warranty claim and/or provide warranty service. Alternatively, for further information on how to get warranty service, please contact either the customer service department of your service provider or go to <http://www.motorola.com/support/warrantyselector>.

Where, in the Country of purchase, there is a statutory requirement to provide extended repair service to consumers beyond the first year of purchase (South Africa and Portugal), this warranty will be provided by Motorola Authorised Service Centres or Motorola directly appointed dealers in the country of purchase according to the terms of this warranty information document. However, please note that you will be referred back to the place of purchase, if the Motorola Dealer has purchased the product directly from Motorola, in the country of purchase or in a country where Motorola is not required to support supplementary repair service during the second year of purchase because of the statutory obligations that may apply to the seller or importer of the product, but not to the manufacturer, to provide an extended warranty to consumers beyond the first year. CLAIMING In order to claim the warranty service, you must return the Personal Communicator and/or accessories in question to Motorola's Authorised Repair or Service Centre in the original configuration and packaging as supplied by Motorola.

Please avoid leaving any \* including without limitation loss of use, loss of time, loss of data, inconvenience, commercial loss, lost profits or savings. supplementary items like SIM cards. The Product should also be accompanied by a label with your name, address, and telephone number; name of operator and a description of the problem. In the case of vehicular installation, the vehicle in which the Personal Communicator is installed should be driven to the Authorised Repair or Service Centre, as analysis of any problem may require inspection of the entire vehicular installation. In order to be eligible to receive warranty service, you must present your receipt of purchase or a comparable substitute proof of purchase bearing the date of purchase. The phone should also clearly display the original compatible electronic serial number (IMEI) and mechanic serial number [MSN]. Such information is contained with the Product. You must ensure that any and all repairs or servicing is handled at all times by a Motorola Authorised Service Centre in accordance with the Motorola Service requirements. In some cases, you may be requested to provide additional information concerning the maintenance of the Products by Motorola Authorised Service Centres only, therefore it is important to keep a record of any previous repairs, and make them available if questions arise concerning maintenance.



[You're reading an excerpt. Click here to read official MOTOROLA FIRE XT316 user guide](http://yourpdfguides.com/dref/4209498)  
<http://yourpdfguides.com/dref/4209498>