




# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for NEFF W5320X0GB. You'll find the answers to all your questions on the NEFF W5320X0GB in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual NEFF W5320X0GB**  
**User guide NEFF W5320X0GB**  
**Operating instructions NEFF W5320X0GB**  
**Instructions for use NEFF W5320X0GB**  
**Instruction manual NEFF W5320X0GB**

Instruction Manual  
and Installation Instructions  
Washing machine



W 5320 X0 GB



[You're reading an excerpt. Click here to read official NEFF W5320X0GB user guide](http://yourpdfguides.com/dref/3567034)  
<http://yourpdfguides.com/dref/3567034>

**Manual abstract:**

.....  
.....  
.....  
.... Control panel .....

.....  
.....  
.....  
... Before using your washing machine for the first time .....

.....  
.....  
.....  
. Preparing, sorting and loading the washing .... Preparing the washing .....

.....  
.... Sorting the washing .  
.....  
.....

..... Degrees of dirt .....

.....  
.....  
.....

. Loading the washing .....

.....  
.....  
.....  
. Detergents and cleaning products .....

... Dosing detergent .....

.....  
.....  
..... Adding detergent/cleaning product ....

.... Programmes and functions .....

.....  
.....  
.. Programme selector .....

.....  
... Spin speed selector ..  
.....  
.....

.... Additional option - buttons .....

.....  
.... Wash .  
.....  
.....

.....  
.....  
.....  
..... Changing the programme .....

.....  
.. Cancelling the programme ....  
.....  
..... After washing ....

.....  
.....  
.....  
..... Remove the washing .....

.....  
.....  
*Signal*.....  
.....

.....  
.....  
*... Special applications ...*  
.....

.....  
*.. Soaking ..*  
.....  
.....

.....  
*... Starching ..*  
.....  
.....

.....  
*... Cleaning and Care ..*  
.....  
.....

..... *Clean housing, fascia and supply lines ..*  
..... *Cleaning the drum .*  
.....  
.....

..... *Descaling the washing machine .....*  
.....  
*.. Cleaning the detergent dispenser ...*  
..... *Cleaning the drain pump ...*

.....  
*.... Cleaning water inlet strainers .*  
.....  
*..... Help with minor problems ..*

.....  
.....  
*.. Fault displays ...*  
.....

.....  
*... @@...*  
.....  
.....

..... *Customer service .....*  
.....  
.....  
.....

*@ @ .....*  
.....  
.....  
*..... Safety instructions ..*

.....  
.....  
.....  
*Removing the transportation protection devices .....*

.....  
.....

.....  
.. Installation surface .....

.....  
.... Connecting the water .

.....  
.... Aligning the washing machine .....

.....  
.. Connecting the power ...

.....  
..... Transport, e.g. when moving ..

.....  
.. Aqua Stop warranty .....

.....  
. Index .....

.....  
.. Programme overview .....

.....  
Quick reference instructions .....

. @@@@- For washing machine washable fabrics in washing lye. - For operation using cold tap water and conventional laundry detergents and additives that are suitable for use in washing machines. Safety Instructions Never leave children unattended in the proximity of the washing machine. Keep domestic pets away from the washing machine. Do not insert / remove the mains plug with wet or damp hands. Handle the plug body only when removing the plug from the socket. Take care when draining hot washing lye. Do not touch the loading door when washing at high temperatures. Do not climb onto the washing machine.

Do not lean on the open washing machine door. d Danger of suffocation! Keep children away from shipping carton and packaging components. Danger of suffocation from folding cartons and plastic film. d Danger of fatal injury! On out of service appliances, unplug mains plug. Cut off power cord and discard with mains plug.

To prevent playing children from becoming trapped and endangered, ensure that the door locking mechanism is disabled. 4 Control panel Start button For starting the wash cycle (programme must have been selected). Programme selector For switching the machine on and off and for selecting the programme.

Can be rotated in either direction. The programme selector does not rotate while the programme is running the programme sequence is electronically controlled.

Buttons for additional options (in addition to the programme if required) Prewash: actuate Prewash Less Ironing: Gentle spin Extra Rinse: Additional rinsing cycle Intensive: Intensive wash Additional options can be combined. The indicator lights of the buttons come on, if the additional options are active. Switching off the additional option: Press the button again. Indicator light goes out. Indicator lights for the programme status Ready illuminate, if the programme is selected. Washing, Rinsing, Spin illuminate when the Start button is pressed and the particular programme section is running. End is lit when the programme has ended. Indicator lights flash: Operation error. Spin speed selector (if required) For stepless setting of the spin speed; must click in place at Rinse Hold.

See chapter Signal, page 18, for switching off acoustic signal or changing the volume.

5 Before using your washing machine for the first time Attention The washing machine must have been installed and connected properly refer to Page 30. i The washing machine was tested before leaving the factory. To remove any water left over from te sting procedures, the first washing cycle should be carried out without laundry in the machine. q Turn the tap on. q Pull out the detergent drawer all the way. q Pour approx. 1 litre / 1 ¾ pt of water into chamber II of the detergent dispenser. q ½ Half fill the measuring beaker with detergent and pour into chamber II. i Do not use any special detergents for delicates or woollens (excessive foam). q Close the detergent drawer.

q Close the washing machine door. q Set the programme selector to Cottons 90 °C. q Press the Start button. The programme starts. The programme has ended when the End indicator light is lit: q Turn the programme selector to Off.

6 Preparing, sorting and loading the washing Preparing the washing Attention Loose debris (e.g. coins, paper clips, needles, nails) can damage items of clothing as well as parts of the washing machine (e.g. drum).

q Empty all pockets on items of clothing. q Brush sand out of pockets and cuffs/turn ups. q Close zips, fasten pillow cases/cushion covers. q Remove curtain runners or tie up in a net/bag. q Wash in a net/cushion cover: - delicates, e.g. tights, curtains, - small laundry items, e.g. socks or handkerchiefs, - underwired bras (underwire may become detached during washing and cause damage). q Trousers, knitwear and knitted textiles, e.

g.jersey garments, T shirts or sweatshirts should be turned inside out. Sorting the washing Attention Washing may become discoloured. Do not wash new coloured washing with other washing. White items may become grey. Wash white and coloured items separately. i Observe the treatment symbols on the

textile labels (see also programme overview). 7 Degrees of dirt lightly soiled No visible soiling or stains. Washing has probably absorbed body odour.  
normally soiled Visible soiling and/or a few light stains.

very soiled Visible soiling and/or stains, e.g work clothes, e.g. mechanic's overalls, baker's and butcher's clothing. Typical stains - Skin grease, cooking oil/fat, sauces, mineral oil, wax (containing fat/oil).

- Tea, coffee, red wine, fruit, vegetables (which can be bleached). - Blood, egg, milk, starch (containing protein, carbohydrate). - Soot, earth, sand (pigments), tennis clothing soiled with red clay. Removing stains Remove/pretreat stains as soon as possible after they have occurred. First dab with a soapy solution. Do not rub. Then select the appropriate programme and wash the item. Stubborn/dried in stains can sometimes only be removed by washing several times.



[You're reading an excerpt. Click here to read official NEFF](#)

[W5320X0GB user guide](#)

<http://yourpdfguides.com/dref/3567034>

8 Loading the washing d Risk of explosion! Items of clothing that have been pretreated with solvent based cleaning agents, e.g. stain remover and dry cleaning spirit, represent an explosion hazard once loaded into the washing machine. Before loading the laundry, rinse thoroughly by hand. Attention Foreign objects in the drum may damage the laundry. Before loading the laundry, check that there is no debris in the drum. q Open the washing machine door.

q Unfold the sorted items of clothing and place them loosely into the drum. Mix large and small items. Laundry items which vary in size are more evenly distributed during the spin cycle. i Do not exceed recommended loads (see programme overview). Overloading will cause poor wash results and encourage creasing. q Close the washing machine door. Take care not to trap any items of clothing between the loading door and rubber seal. 9 Detergents and cleaning products Dosing detergent d Risk of poisoning! Keep detergents and additives out of the reach of children. Dose detergent according to - the water hardness.

You can find out the water hardness from your water utility company.

- the amount of laundry. - the degree of soiling. - the specifications of the detergent manufacturer. Pour liquid detergent into the corresponding dispenser.

Too little detergent: The laundry is not washed clean and eventually becomes grey and hard.

Greyish brown dots (grease spots) may stain the laundry. The heating elements are calcifying. Too much detergent: Environmentally incompatible, excessive foam reduces wash agitation causing poor washing and rinsing results. Adding detergent/ cleaning product Dispenser I Detergent for prewash or starch.

Dispenser II Detergent for main wash, water softener, pre soaking agent, bleach and stain removal product.

Dispenser 2 Cleaning product, e.g. fabric softener or fabric conditioner (fill up to the max mark on insert 1). i Concentrated or viscous fabric softener or fabric conditioner must be diluted with a little water before it is poured into the dispenser (prevents the overflow from becoming blocked). 10 Programmes and functions Programme selector Select the desired programme see also programme overview. i Programmes wash lightly soiled textiles in the shortest possible time. For heavily soiled textiles reduce the load or press the Intensive button! Basic programmes Cottons/Coloureds 30, 40, 60 °C For hard wearing textiles, e.g. made of cotton or linen. Cottons/Coloureds 60 °C Stains For stained, heavily soiled textiles, e.

g. cotton or linen. Energy and water saving programme. The longer washing time in this 60 °C programme means that the cleaning effects are comparable with those of a 90 °C programme, although the power and water consumption is considerably lower. Cottons 90 °C Energy intensive programme for heat resistant textiles, e.g. made of cotton or linen. To protect the waste water pipes, the hot water is mixed with approx. 7 litres of cold water and cooled before being drained. Easy Care 30, 40, 60 °C For easy care textiles, e.

g. made of cotton, linen, synthetic or blended fabrics. i Also suitable as short programme. Mix 30 °C Time optimised programme for lightly soiled cotton textiles and easy care textiles. Different types of washing can be washed together.

Even suitable for washing new textiles before they are worn for the first time. i Wash white and coloured items separately. Do not wash new coloured washing with other washing. 11 Short washing time. Delicates 30 °C For delicate, washable textiles, e.

g. silk, satin, synthetic materials or blended fabrics (e.g. curtains). Delicates cycle at 30 °C for hand and machine washable silk. i We do not recommend washing these textiles with other rougher textiles. Wool cold, 30 °C For hand and machine washable wool or wool rich textiles, e.g. cashmere, mohair or angora. Also suited for hand washable silk.

Programme options Rinse Rinse cycle with subsequent spin cycle for rinsing hand washed items or for starching. Press the Extra Rinse button for an additional rinse cycle. Spin Spin cycle after a programme with setting Rinse Hold or for spinning hand-washed washing with selection of the required speed machine door may remain locked until the appliance has cooled down. Cancelling the programme 16 After washing The End indicator light comes on. q Turn the programme selector to Off. or Setting selected Rinse Hold (without final spin) i The programme has ended and the Spin indicator light is lit. q Select an additional programme (Drain or Spin). q Press the Start button. q At the end of the programme option, turn the programme selector to Off. q Open the washing machine door.

If the loading door cannot be opened: Wait 2 minutes (safety function is active) or there is still water in the washing machine if the Rinse Hold option was selected. Select the Drain or Spin programme and press the Start button. q Unload the laundry. Attention Remove any foreign objects (e.g. coins, paper clips) from the drum and rubber seal - Risk of corrosion and damage to the drum and rubber seal! q Leave the washing machine door and detergent drawer open to allow the interior of the washing machine to dry. Remove the washing 17 Signal The acoustic signal indicates: - that the additional functions (buttons) have been switched on or off, - individual programme statuses (e.g. start of programme, end of programme), operating errors and faults. q Press the Start button and set the programme selector to Cottons/Coloureds 30 °C.

Hold down the Start button until the signal is emitted. The selected setting is saved. i When the additional functions are switched on, a long signal is emitted; when the additional function is switched off, the signal is short. The volume of the signal cannot be changed. Signal for switching buttons on and off Signal for programme status The signal can be switched on and off and the volume set before the start or after the end of the programme. q Press the Intensive button and hold down until the signal is emitted and the volume of the signal changes. q Release the button when the required volume is reached. The selected setting is stored. 18 Special applications Attention Do not bleach/dye washing in the washing machine. q Load laundry of the same colour.

q Pour soaking agent into dispenser II according to the manufacturer's instructions. q Set the programme selector to Cottons/Coloureds 30 °C. q Press the Start button. The programme starts. q After approx. 10 minutes, turn the programme selector to Off. The laundry is left to lie in the water. q Select a programme according to the required soaking time, the detergent solution is pumped out. i Only little detergent to be dispensed for the main wash. The laundry must not be treated with fabric softener.

q Insert the washing. q Dose a quantity of starch for approx. 15 litres of water. Dissolve starch according to the manufacturer's instructions. q Turn the programme selector to Rinse.



[You're reading an excerpt. Click here to read official NEFF](http://yourpdfguides.com/dref/3567034)

[W5320X0GB user guide](http://yourpdfguides.com/dref/3567034)

<http://yourpdfguides.com/dref/3567034>

q Set the spin speed; Rinse Hold is possible. q Press the Start button. As soon as the water runs in: q Pull out the detergent drawer a little and q Pour starch solution into dispenser I. q Close the detergent drawer. If the Rinse Hold option has been selected, select the Drain programme.

Soaking Starching 19 Cleaning and Care d Risk of electric shock! First, always disconnect the appliance from the power supply. Never clean the washing machine with a water jet. d Risk of explosion! Never clean the appliance with solvents. Clean housing, fascia and supply lines As required: q Use hot soapy water or a mild, non abrasive cleaning agent. q Wipe dry with a soft cloth. Cleaning the drum If metal items (e.g. coins, paper clips, needles, nails) left in the drum have caused rust spots: q Use chlorine free cleaning agents; comply with the manufacturer's instructions. Never use steel wool. Descaling the washing machine Attention Descaling agents contain acids which may corrode the components of the washing machine and discolour the washing.

Provided that you use the correct amount of detergent, it is not necessary to descale the washing machine. If descaling is nevertheless required, please follow the instructions supplied by the manufacturer of the descaling agent. 20 Cleaning the detergent dispenser In the event that residual detergents or additives have accumulated: q Pull out the detergent drawer all the way, q Press down the insert and q remove the detergent drawer. q Lift out the insert. q Clean the detergent drawer and insert under running water and dry. q Attach the insert and lock into position. q Slide in the detergent drawer. 21 Cleaning the drain pump Drain the water This is necessary if the washing solution has not been completely drained. The pump is blocked by either loose debris or fluff which accumulates if fluff giving fabrics are washed. (Up to 20 litres.

Have a suitable container ready.) d Risk of scalding! Allow the hot water to cool down beforehand. Keep children and pets away from the washing machine. q Turn the programme selector to Off. q Remove the drain hose from its holder and pull the hose out of the housing.

q Pull down the closing cap carefully and allow the washing lye to flow into a suitable container. q Push up the closing cap and place the drain hose back in its holder. q Carefully remove the pump cap. A little more residual water will flow out. q Remove foreign objects/fluff from inside and clean the interior. The pump impeller wheel must be able to rotate. Clean any residual lye or fluff from the thread of the pump cap and pump housing. q Insert the pump cover and screw tight. @@@@q Press the Start button, and allow the programme to run for approx. 40 seconds. q Turn the programme selector to Off. q Disconnect the hose from the water tap. q Clean the filter with a small brush or paint brush. q Connect the hose. q Turn the tap on.

@@@q Disconnect the washing machine from the mains. q Turn off the tap. q Call customer service, see Page 29. d Risk of electric shock! @@@@Turn the tap on. Eliminate cause. Clean filter, see Page 23. Eliminate cause. Clean the pump, see Page 22. @@Inlet hose kinked or pinched. Filter blocked in water inlet hose.

Water pressure too low. Spin Loose debris is blocking the pump. @@Safety function is active. Remedial action Select Drain or Spin. Wait for 2 minutes. Clean and dry the detergent dispenser; see Page 21. @@Odour in the appliance. Washing mainly at low temperatures and/or with liquid detergents. @@Start Cottons 90 °C programme without washing. Use a standard detergent.

Switch on/replace the fuse. @@@@Programme does not start. Loading door not closed properly. Check whether laundry is trapped in door. Close the loading door (a click should be heard). Programme does not start. Water does enter the machine or detergent is not washed away. Start button not pressed. Tap not turned on. Inlet hose kinked or pinched.

Filter blocked in water inlet hose. Detergent in chamber I is not washed away. A programme without Prewash was selected. Clean the strainer; see from Page 23. Select programme with Prewash. Press the Start button. Turn the tap on. 25 Problems Water not visible in the drum. @@The water lies below the visible part of the drum. Pumped blocked by foreign objects.

Fluff producing laundry was washed. The water drainage pipe or drain hose is blocked. Water in the base pan; Appliance leaking. Screw fitting of the inlet hose is leaking. Drainage hose is leaking.

Clean the pump refer to page 22. Clean drainage pipe and/or drainage hose. @@@@Replace the drain hose. @@@@Appliance feet not secured. @@For safety reasons, the high speed final spin cycle was automatically cancelled.

Remove the transit bolts. Secure the appliance feet. Do not put only large items in the drum. Spin result unsatisfactory. Less Ironing button pressed for reduced spin speed see page 13. The Rinse or Spin programme selected maximum spin speed: see Page 13. Spin cycle actuated several times. Not a fault. Unbalanced load detection system is attempting to compensate the imbalance by spinning the washing several times. 26 Problems The programme takes longer than usual.

Cause Not a fault. Imbalance compensation system attempts to balance the laundry by repeated distribution. The foam detection feature has activated an additional rinsing cycle to reduce the amount of foam. Remedial action Wash large and small items together in order to reduce the imbalance. Adjust the detergent dosage for the next wash cycle. Select suitable programme and press the Intensive button or reduce load. Dose detergent according to the manufacturer's instructions. Select Rinse immediately or brush out the washing after drying. Select maximum detergent dosage and maximum permitted temperature for the next wash cycle. Washing result not satisfactory.

Soiling is greater than expected or recommended load has been exceeded. Detergent was underdosed. Detergent residue on the washing. Some phosphate free detergents contain water insoluble residue which may appear as light stains on the washing. Soiling caused by ointment, grease or oil.

Grey residue on the washing. If the fault recurs, call Customer Service, see Page 29. 27 Consumption values Normal programme Additional option Load Consumption values \*\* Power 6 kg 5 kg 6 kg 6 kg 0.65 kWh 0.95 kWh 1.

02 kWh 2.1 kWh Water 60 l 60 l 49 l 67 l Programme duration 2:10 h 1:17 h 2:15 h 2:10 h Cottons/Coloureds 40 °C Cottons/Coloureds 60 °C Cottons/Coloureds 60 °C Stains Cottons 90 °C (the hot washing solution is mixed with approx. 7 litres of cold water before being drained) Easy Care 40 °C Easy Care 40 °C (Also suitable as short programme) Delicates 30 °C Wool 30 °C \* Intensive \* Intensive \* Intensive Intensive \* - 3 kg 3 kg 0.5 kWh 0.5 kWh 50 l 38 l 1:18 h 0:47 h Intensive \* 2 kg 2 kg 0.3 kWh 0.2 kWh 42 l 35 l 0:35 h 0:50 h Programme setting with Intensive option for test in accordance or in conformity with EN 60 456 and IEC 60 456.



[You're reading an excerpt. Click here to read official NEFF](http://yourpdfguides.com/dref/3567034)

[W5320X0GB user guide](http://yourpdfguides.com/dref/3567034)

<http://yourpdfguides.com/dref/3567034>

*\*\* Consumption values will differ from the indicated values depending on the water pressure, water hardness, water inlet temperature, ambient temperature, type and quantity of washing and degree of soiling, utilised detergent, fluctuations in the mains voltage and selected additional options. 28 Customer service Each washing machine which leaves our factory is checked carefully to ensure that it functions properly and is in perfect condition. If you have any questions especially with respect to installing and connecting your washing machine - please do not hesitate to contact our customer service department.*

*Before you call customer service, please check whether you can eliminate the fault yourself (see from Page 24). A technician who is called out to give advice will charge you, even if the appliance is still under guarantee. You can find your nearest customer service in the enclosed address list. Please provide customer service with the product number (E Nr.) and the production number (FD) of the appliance. Rating plate These numbers are shown on the rating plate which can be found on the frame of the open door and also on the identification plate, enclosed by a thick line, on the front of the machine behind the nameplate. E Nr. FD Product number Production number Please note the two numbers in the space provided above. In specifying the product number and production number of your appliance, you help us in our attempt to prevent unnecessary travelling and the associated extra costs. Further information and a selection of our products can be found on our Internet page: <http://www.neff.de>*

*29 Installing, connecting and transporting the appliance Please install and connect the washing machine in accordance with the enclosed installation and assembly instructions. Be sure to read the information contained in this chapter! Safety instructions d Risk of injury! The washing machine is very heavy. Take care when lifting it. Attention Frozen hoses may tear/burst.*

*Do not install the washing machine in an area where there is a risk of frost or outdoors. The worktop must not have any cut outs in the area of the washing machine. In addition to the safety information listed here, the local water and electricity supplier may have special requirements. If in doubt, have the appliance connected by a specialist. Unpack the appliance and dispose of the packaging in an environmentally responsible manner.*

*This appliance is labelled in accordance with European Directive 2002/96/EC concerning used electrical and electronic appliances (waste electrical and electronic equipment WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU. Packaging and old appliances ó 30 Removing the transportation protection devices Removing the transportation protection devices d Caution The transport bolts must always be removed before using the appliance for the first time. q Release screws 1, 2 and 3 using the A/F 13 wrench until they can be moved freely. q Completely remove all transportation protection devices (A and B screw together with washer and bushing; C screw together with spring, washer and bushing). q Insert the covers. Storing the transportation protection devices Always keep the transport bolts for subsequent transportation of the appliance (e.g. when moving house). q Store transport bolts 1 and 2 (screw washer and bushing onto bolt).*

*31 Installation surface Appliance stability is important so that the washing machine does not wander" during the spin cycles. The installation surface must be solid and level. Soft floor coverings, e.g. carpets or floor coverings with a foam backing are not suitable. Always place the washing machine on the supplied slide plates. If the washing machine is to be aligned with the height adjustment kit WZ 20270 / Z 7040X0 / WMZ 2270: q Moisten the slide plates with a mixture of water and washing up liquid before pushing in the washing machine. Do not use grease and/or oil! If the washing machine is to be installed on a base: q Do not use slide plates. q Secure the front feet of the washing machine with holding brackets\*. If the washing machine is to be installed on a wooden floor: q If possible, install the washing machine in a corner.*

*q Screw a water resistant wooden board (at least 30 mm thick) to the floor. Take into account the height of the worktop in your kitchen! q Do not use slide plates. q Secure the front feet of the washing machine with holding brackets\*. \* Holding brackets (set) can be obtained from a specialist store or the Customer Service order no. CZ 110600.*

*32 Connecting the water d Risk of electric shock! @@To prevent leaks or water damage, it is essential to follow the instructions in this chapter! Water inlet hose Attention Operate the washing machine with cold drinking water only. Do not connect to the mixer tap of an unpressurised hot water apparatus. If in doubt, have the appliance connected by a specialist. The water inlet hose must not be - kinked or crushed, - modified or severed (strength is no longer guaranteed). Check the mains water pressure: - The water pressure should be between 1 and 10 bars (when the tap is turned on, at least 8 litres of water is discharged per minute).*

*- If the water pressure is higher, install a pressure reducing valve. Water drainage hose Attention Do not bend or pull the water drainage hose. Level the washing machine with the assistance of the four adjustable feet and a spirit level: All four feet must be firmly on the floor. The washing machine must not wobble. The locknuts on the front feet of the appliance must be screwed against the housing! Attention Loud noise generation, vibrations and "wandering" may be due to incorrect alignment! Aligning the washing machine 33 Connecting the power Attention Connect the washing machine only to an alternating current via a correctly installed earthed socket. The mains voltage must correspond to the voltage specification on the washing machine (nameplate).*

*Connection specifications as well as the required fuses are stipulated on the appliance nameplate. Ensure that: - The mains plug and socket are compatible. - The cable cross section is adequate. - The earthing system has been installed correctly.*

*The mains cable may be changed (if required) by an electrician only. Replacement mains cable available from customer service. Do not use multiple plugs/sockets or extension cables. @@@@Do not insert/pull out the mains plug with wet hands. @@@@- Disconnect the washing machine from the power supply, - remove the hoses, - install the lower 2 transport bolts. Having transported the appliance and ensured proper installation and connection, allow the Drain programme to run through before starting the first wash programme. Preparing and inserting the transport bolts q Remove the 2 lower covers. q Prepare the transport bolts: Loosen the screw in the sleeve until the end of the screw is level with the end of the sleeve.*



[You're reading an excerpt. Click here to read official NEFF](http://yourpdfguides.com/dref/3567034)

[W5320X0GB user guide](http://yourpdfguides.com/dref/3567034)

<http://yourpdfguides.com/dref/3567034>



q Through the open washing machine door have a second person pull the top of the drum forwards. Now insert transportation protection devices 1 and 2 and tighten the screws.

The washer lugs must be located in the groove in the rear panel of the housing. 35 Aqua Stop warranty In addition to warranty claims against the seller based on the sales contract and in addition to our appliance warranty we shall be liable for payment of damages under the following conditions: 1. If damage is caused by water due to a fault of our Aqua Stop system, we shall compensate the private user for the damage. 2. This liability guarantee is valid for the service life of the appliance.

3. A claim under the warranty can only be considered provided Aqua Stop has been properly installed and connected to the appliance according to our instructions, including a properly installed Aqua Stop extension (original accessory). Our warranty does not apply to defective supply lines or fittings up to the Aqua Stop connection on the tap. 4. If your washing machine features Aqua Stop, you do not need to keep your eye on the washing machine during operation or turn the tap off afterwards.

You should only turn the tap off if you intend being away from home for a prolonged period, e.g. on holiday. 36 Index A Adding detergent, 10 Additional options, 5, 13 Extra Rinse, 5, 14 Intensive, 5, 14 Less Ironing, 5, 13 Prewash, 5, 13 Aligning the washing machine, 33 Aqua Stop, 36 C Cancelling the programme, 16 Changing the programme, 16 Cleaning and care, 20 Control panel, 20 Detergent drawer, 21 Drain pump, 22 Drum, 20 Housing, 20 Strainer, 23 Supply lines, 20 Closing cap, 22 Connecting the power, 34 Connecting the water, 33 Consumption values, 28 Control panel, 5 Cottons/Coloureds, 11 13 Stains, 11 Customer service, 29 F Fault display, 24 Functions, 11 I Indicator lights, 5 End of programme, 5 Ready, 5 Rinsing, 5 Spin, 5 Washing, 5 Insert transportation protection devices, 35 Installation surface, 32 Internet, 29 B Basic programmes, 11 L Loading the washing, 7, 9 M Mix, 11 P Preparing the washing, 7 Problems, 24 Product number, 29 Production number, 29 Programme duration., 28 Programme options, 12 Programme selector, 5, 11 Programmes, 11 Pump cap, 22 D Degrees of dirt, 8 Delicates, 12 Descaling, 20 Dosing detergent, 10 Drain, 12 E Easy-Care, 11 End of the programme, 5, 17 37 R Rating plate, 29 Remove the washing, 17 Removing stains, 8 Removing the transportation protection devices, 31 Rinse, 12 Rinse Hold, 13 S Safety instructions, 30 Signal, 18 Soaking, 19 Sorting the washing, 7 Spin, 12 Spin speed selector, 5, 12 Starching, 19 Start button, 5 Start programme, 15 Storing the transportation protection devices, 31 T Take out the drain hose., 22 Transporting the washing machine, 35 W Wash, 15 Wool, 12 1105 / 9000 039 542 38 Programmes 1) 2) Type of laundry Amount of Degree of soiling laundry Required button, additional function Cottons/Coloureds ab Hard wearing textiles, heat resistant textiles e.g. cotton or linen 30, 40 3), 60 °C 60 °C Stains 3) 90 °C 30, 40, 60 °C 30, 40, 60 °C 60 °C Stains up to 5 kg 6 kg light to normal normally with stains normal light normal to heavy normally to heavily with stains cde Intensive Intensive Intensive Intensive Intensive Easy Care fg Easy Care textiles e.g. cotton, linen, synthetic materials or blended fabrics (also suitable as a short programme) 30, 40, 60 °C 30, 40 3), h light up to 3 kg normal to heavy Intensive 60 °C Mix k For cotton washing and easy care textiles - different types of washing can be washed together 30 °C 30 °C up to 3 kg light normal to heavy Intensive f Delicates kfl Delicate, washable textiles, e.

g. silk, satin, synthetic or blended fabrics without wool component (e.g. curtains) 30 °C 30 °C up to 2 kg light normal to heavy Intensive g Wool 6kflg light 3) hand and machine washable wool or woolrich textiles, e.g. cashmere, mohair or angora. Also suited for hand washable silk. cold, 30 °C cold, 30 °C up to 2 kg Intensive normal to heavy Programme options Rinse, Spin, Drain 1) The following additional options can be selected in addition to the programmes: Spin speed selector: Spin speeds or Rinse Hold, Buttons: Prewash, Less Ironing, Extra Rinse, Intensive. 2) Pour detergent into dispenser II (on left) for programme without prewash; distribute detergent between dispensers I and II for programmes with prewash. 3) Programme setting for test in accordance or in conformity with EN 60456 and IEC 60456.

Quick reference instructions 1 2 3 4 5 If required: 6 If required: 7 8 9 10 At the end of the programme: 1 2 1105 / 9000 039 542 \$.



[You're reading an excerpt. Click here to read official NEFF](#)

[W5320X0GB user guide](#)

<http://yourpdfguides.com/dref/3567034>