



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for PHILIPS HD3011/08. You'll find the answers to all your questions on the PHILIPS HD3011/08 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual PHILIPS HD3011/08 User guide PHILIPS HD3011/08 Operating instructions PHILIPS HD3011/08 Instructions for use PHILIPS HD3011/08 Instruction manual PHILIPS HD3011/08

This image displays a collage of various pages from the Philips HD3011/08 user manual. The pages are arranged in a grid-like fashion, showing different sections of the document. Key elements visible include:

- Product images:** A small image of the rice cooker at the top left.
- Diagrams:** Exploded view diagrams of the rice cooker's components, such as the inner pot, lid, and steaming rack.
- Text blocks:** Sections of text in multiple languages, including English, Spanish, and Chinese, providing instructions and information.
- Tables:** Specification tables, including one for 'Cooking rice' and another for 'Specifications'.
- Icons:** Safety and warning icons, such as a flame and a warning symbol.
- Section Headers:** Various sub-sections like 'Cooking rice', 'Cleaning and Maintenance', 'Troubleshooting', and 'Specifications'.



You're reading an excerpt. [Click here to read official PHILIPS HD3011/08 user guide](http://yourpdfguides.com/dref/5321108)
<http://yourpdfguides.com/dref/5321108>

Manual abstract:

philips. Com/welcome HD3011 HD3012 HD3015 HD3016 HD3017 HD3018 What's in the box Contenido de la caja Apa dalam kotak ini ภายในกล่องเครื่องใช้ไฟฟ้า Trong hộp có gì 1 Using the rice cooker Uso de la arrocera Menggunakan pemasak nasi การใช้หม้อหุงข้าว SỬ DỤNG nồi cơm điện Cooking rice Cocción del arroz Memasak nasi Cách nấu cơm Accesorios Cuchara para arroz, recipiente externo, cestilla de vapor, tapa de ventilación de vapor: • Remójelos en agua caliente y límpielos con una esponja. All registered and unregistered trademarks are property of their respective owners. English 1 Your rice cooker Congratulations on your purchase, and welcome to Philips! @@ When the cooking is finished, the cooking (COOK) indicator will be off. The rice cooker switches to keep warm mode automatically, and the keep warm (WARM) indicator lights up. Exterior Surface of the outer lid and outside of the main body: • Wipe with a cloth dampened with soap water. □ ONLY use soft and dry cloth to wipe the control panel. □ Make sure to remove all the food residues around the control buttons. 2 What's in the box Rice cooker main unit Rice scoop User manual Warranty card Steam basket Measuring cup Safety leaflet Power cord Accessories Rice scoop, inner pot, steam basket, steam vent cap: • Soak in hot water and clean with sponge. 6 Note • Do not exceed the volume indicated nor exceed the maximum water level indicated in the inner pot, as this may cause the rice cooker to overflow. 5 Environment Do not throw away the appliance with normal household waste at the end of its life, but hand it in at an official collection point for recycling. By doing this, you can help to preserve the environment. Overview a b c d e f g Steaming h i j k l m Descripción general a b c d e f g Inner pot Water level indications Scoop holder Heating element Control Key Steam water storage Outer lid Lid release button Detachable steam vent cap Main body Power socket Keep warm indicator Cooking indicator 1 2 3 4 5 6 7 8 3 Using the rice cooker Before first use 1 2 Take out all the accessories from the inner pot. Remove the packaging material of the inner pot. Clean the parts of the rice cooker thoroughly before using the rice cooker for the first time (see chapter 'Cleaning'). Measure a few cups of water with the measuring cup. Pour the water into the inner pot. Put the steam basket into the inner pot. Put the food into the steam basket. Close the lid of the rice cooker, and put the plug in the power socket. @@ When the steaming is finished, pull up the control key. @@ philips. Com or contact the Philips Customer Care Center in your country. You can find its phone number in the worldwide guarantee leaflet. @@ 7 Troubleshooting Problem The lights on the buttons does not go on. solution There is a connection problem. @@ the light is defective. @@ The rice is not cooked. There is not enough water. Add water according to the scale on the inside of the inner pot. You did not press down the control key. @@ The heating element is damaged, or the inner pot is deformed. @@ The rice is not well Add more water. cooked. The cooker does not The temperature control is defective. @@ You have not rinsed the rice properly. Rinse the rice until water runs clear. @@ That corresponds to the number of cups of rice used. @@ • You can cook rice while steaming food. @@ • You can adjust the water level as needed. @@ Preparations before use Before using the rice cooker, you need to follow the preparation: 1 Measure the rice using the measuring cup provided. 2 Wash the rice thoroughly. 3 Put the pre-washed rice in the inner pot. 4 Add water to the level indicated on the scale inside the inner pot that corresponds to the number of cups of rice used. Then smooth the rice surface. 5 Press the release lever to open the lid. 6 Put the inner pot in the rice cooker. Check if the inner pot is in proper contact with the heating element. 7 Close the lid of the rice cooker, put the plug in the power socket. 4 Cleaning and Maintenance Note • Unplug the rice cooker before starting to clean it. □ • Wait until the rice cooker has cooled down sufficiently before cleaning it. Note • Each cup of uncooked rice normally gives 2 bowls of cooked rice. Do not exceed the quantities indicated on the inside of the inner pot. □ • The level marked inside the inner pot is just an indication. You can always adjust the water level for different types of rice and your own preference. If the voltage is unstable at the area you live, it is possible that the rice cooker overflows. @@ 2 ratio for rice cooking. @@ Interior Inside of the outer lid and the main body: • Wipe with wrung out and damp cloth. □ Make sure to remove all the food residues stuck to the rice cooker. Heating element: • Wipe with wrung out and damp cloth.

□ Remove food residues with wrung out and damp cloth or toothpicks. .



[You're reading an excerpt. Click here to read official PHILIPS](http://yourpdfguides.com/dref/5321108)

[HD3011/08 user guide](http://yourpdfguides.com/dref/5321108)

<http://yourpdfguides.com/dref/5321108>