



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for POLAROID IS529. You'll find the answers to all your questions on the POLAROID IS529 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual POLAROID IS529
User guide POLAROID IS529
Operating instructions POLAROID IS529
Instructions for use POLAROID IS529
Instruction manual POLAROID IS529

 **Polaroid**

IS529
USER MANUAL



© 2012 All Rights Reserved.

Windows and the Windows logo are registered trademarks of Microsoft Corporation.
All other trademarks are the property of their respective companies.

 **Questions? Need some help?**
This manual will help you enjoy your new product.

 **If you still have questions, call our help line:**
877-408-0033

 **or visit us at:**
www.polaroid.com

Let's Get Started →



[You're reading an excerpt. Click here to read official POLAROID IS529 user guide](http://yourpdfguides.com/dref/5417332)
<http://yourpdfguides.com/dref/5417332>

Manual abstract:

@@@Digital Camera 2. Lithium Battery 3. USB Cable 4. Polaroid Instant Memories Software Installation CD 5. Wrist Strap 6. AC Charger

Note: SD Memory Card not included. 2 1. Power Button 2. Shutter Button 3. LCD Screen 4.

LED (Charge/Flash Indicator) 5. Zoom Out Button 6. Zoom In Button 7. Up/Flash/Slide Show Button 8. Right / Delete Button 9.

Down / Insta-Share Button 10. SET (Menu/OK) Button 11. Left / Scene Button 12. MODE Button 13. Microphone 14.

Flash 15. USB Slot 16. Tripod Mount 17. Optical Lens 18. Battery / SD Memory Card Slot 19. Wrist Strap Connector 20. Speaker 21. Self-Timer LED Indicator 3 □ 1. 2. 3.

To Charge the Battery: Insert the battery (as shown above). Power off the camera. Connect one end to the supplied USB cable to the camera and the other end to the computer's USB port or to the AC Charger (which is then connected to a standard wall socket). 4. Allow the battery to charge for at least 3 hours before using the first time. 5. The charge light will turn off when the battery is fully charged. □ SD Memory card (up to 32GB) needed for normal use. 4 When powering the camera ON for the first time the camera will take you through the initial camera setup. 1) Installing and Charging the Battery First make sure that the battery is correctly inserted.

The lithium battery should be inserted all the way into the battery compartment. @@@@- Connect one end of the USB cable into the USB port on your camera. @@The battery is fully charged when the LED light turns off. Battery Power: □ □ Some features, will not work if the battery power level is low.

When the battery power is low the battery icon turns red and the camera will automatically turn off a few seconds later.

□ The energy status of the power is displayed on LCD as shown below: Full battery power Medium battery power Low battery power 2) SD Card Make sure an SD card has been properly inserted into your camera. (SD card not included.) To properly insert the SD Card: □ Push the SD card into the slot in the direction shown on the camera (see SD icon by the SD card slot). □ Push the SD card until you hear a slight clicking sound. This indicates the SD card has been inserted correctly.

6 NOTE: □ After the camera is powered on, an SD icon will appear on the LCD display. If you do not see the SD icon on the display, please check if the card was inserted properly. □ Make sure the SD card is not locked (check the lock switch on the side of the SD card). If the SD card is locked this will prevent the camera from saving captured photos to the SD card. 3) Power On Press the POWER button to turn on the camera. After powering on your camera for the first time, you will be prompted to select a language for the camera. The Language selection menu appears. Select the language of your choice by pressing the UP and DOWN direction control buttons. Then press the SET button to confirm the selection. Once a language has been selected, you will be asked if you would like to continue with the initial camera setup.

A message will appear: "Continue with Camera Setup?" Select "Yes" to continue or "No" to exit the setup. Note: If you select "No" and decide to leave the camera setup, the camera will be set to its default settings. These settings can be adjusted at any time manually through the menus in the camera. 7 The next step in the initial camera setup is to set the date and time on the camera. Set the Date and Time as desired by pressing the RIGHT and LEFT direction control buttons to choose the specific setting and the UP and DOWN buttons to change each setting. Once you have completed setting the time and date, press the SET button to confirm the selection and finish the camera setup. Next you will be asked to set the default Insta-Share destination for photos and videos taken with your camera. The Insta-Share technology allows you to quickly and easily upload your camera's photos and videos to social networks with the accompanying software application. 1) First you will be asked to choose the default Insta-Share social network for Photos. Highlight the desired default social network and press the SET button to confirm the selection.

2) Next you will be asked to choose the default Insta-Share social network for Videos. Highlight the desired default social network and press the SET button to confirm the selection. Congratulations! Your camera is now ready to use. 8 Your camera has different modes for the various camera functions. You can switch modes by pressing the MODE button on your camera after the camera has been powered ON.

Use this mode to capture pictures with your camera. This is the default mode when the camera is powered ON. To take a picture, aim your camera as desired and press the Shutter button. The picture will be automatically saved to your camera's memory card. To access the various menus for the Photo Capture mode, press the SET button while in the Photo Capture mode.

Use this mode to capture videos with your digital camera. After turning on your camera, press the MODE button once to open the Video Capture mode. To take a video, aim your camera as desired and press the Shutter button to start the record. A red record indicator will appear on the LCD screen while record is in progress. To stop the record, press the Shutter button again. The video will be automatically saved to your camera's memory card. To access the various menus for the Video Capture mode, press the SET button while in the Video Capture mode. Use this mode to view and manage the photos and videos on your camera. After turning on your camera, press the MODE button twice to open the Playback mode for photos and videos. You can scroll through the photos and videos that you've previously taken to view, edit or delete them as desired.

To access the various menus for the Playback mode for photos and videos, press the SET button while in the Playback mode. 9 Image Sensor CMOS Sensor 4608x3456 (16M), 4416x3312 (14M), 4000x3000 (12M), 3648x2736 (10M), 3456x2592 (9M), 3264x2448 (8M), 3648x2048 (7M-HD), 2592x1944 (5M), 2048x1536 (3M), 1920x1080 (2M-HD), 640x480 (VGA) 1280x720 (720P), 640x480 (VGA), 320x240 (QVGA) JPEG (Photo) /AVI (Video) SD MMC SDHC (up to 32G)- SD Card not included 2.7 Inch TFT LCD Screen f=6.0-18mm , F3.0-5.5 5X Optical Zoom ; 4X Digital Zoom -3.0EV ~ +3.0EV Auto, Daylight, Cloudy, Fluorescent, Incandescent Auto, 100, 200, 400 Auto, Scenery, Portrait, Night Scenery, Night Portrait, High Sensitivity, Beach No Flash, Forced On, Auto, Red Eye Reduction 2 seconds, 5 seconds, 10 seconds, Off Yes Yes Yes Yes 1, 3 or 5 minutes; Disable English, French, Spanish, Portuguese, German, Italian, Russian Polish, Greek Yes Yes USB 2.0 (HS) Windows XP (SP 3), Vista (SP1) and 7 ; Mac OSX v10.5.

x and above Lithium Battery (Nokia BL-5B) 0~40°C Image Resolution Video Resolution File Format External Memory LCD Display Lens Zoom Exposure White Balance ISO Scene Flash Self-Timer Anti-Shake Face Detect Print Photos Macro Auto Power Off Language Microphone Speaker Interface System Requirements Battery Working Temperature 10 To be able to download photos and videos to your PC using the Polaroid Instant Memories Software, you will need the following minimum configuration: □ □ □ □ □ □ □ □ □ □ Microsoft® Windows XP with Service Pack 3, Windows Vista with Service Pack 1 or Windows 7 Pentium® 4 processor (or above) 1 GB of RAM, with 250 MB of free hard disk space 16-bit Color monitor, 1024 X 768 recommended screen resolution CD-ROM Drive QuickTime® 6 or higher Microsoft® Internet Explorer 7 or higher Windows Media Player 10 or higher DirectX 9 or higher Internet connection required to access social networks and software features To be able to download photos and videos to your Macintosh using the Polaroid Instant Memories Software, you will need the following minimum configuration: □ □ □ □ □ □ Intel processor running Mac OS X v10.

[You're reading an excerpt. Click here to read official POLAROID IS529 user guide](#)



<http://yourpdfguides.com/dref/5417332>

5.x or later 1 GB RAM, 250 MB free hard disk space Display: 1024 x 768 or higher-resolution monitor QuickTime® 6 or higher CD-ROM Drive Internet connection required to access social networks and software features 11 □ □ Make sure the built-in lithium battery has been fully charged before the first use. Make sure an SD card has been inserted into your camera. (SD card up to 32GB - SD Card not included) Please see Initial Camera Setup for more information.

Press the □ □ Power button to turn your camera ON. After powering on, the camera emits a sound and the LED light turns on briefly. The LCD screen turns on with your camera in Photo Capture mode to start. While the camera is on, you can press the camera OFF. Power button again at any point to turn your Note: Your digital camera also has an Auto Power Off feature that automatically turns off your camera after a specific period of time that your camera is left idle.

The Auto Power Off settings can be set from the Auto Power Off settings menu (in either Photo Capture Mode or Video Capture Mode). 12 Your camera has three main modes: 1) 2) 3) Photo Capture Mode - Use this mode to capture photos with your camera. Video Capture Mode - Use this mode to capture videos with your camera. Playback Mode (for photos and videos) - Use this mode to view the photos and videos you have already taken with your camera. □ □ When the camera is first powered ON, the Photo Capture Mode will be active. The icons that appear on the LCD screen are the best default settings so that you can begin to capture and enjoy clear quality photos and videos. To change the active camera mode, make sure the camera is powered ON and press the MODE button. When in Photo Capture Mode, this icon will display on the top-left corner of the LCD display When in Video Capture Mode, this icon will display on the top-left corner of the LCD display 13 Each camera mode has a set of menus specific to that mode. 1) 2) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll between the various menus for the current mode.

3) 4) 5) Press the UP or DOWN direction control button to highlight the desired menu selection. Press the SET button to confirm and save the highlighted menu option. If the selection can be remembered by the camera, a selection icon will appear to the right of the selected menu option. Changes made to these options will remain as is until you decide to change them again at a later time. 6) Some menu options are single-use functions that are not remembered by the camera and do not display this icon when selected. 7) At any time you can press the MODE button to exit the menus and return to the previous screen. 14 The Photo Capture mode allows you to capture pictures with your digital camera. When the camera is first powered ON, the camera will be in Photo Capture Mode by default. 1) While in Photo Capture mode, use the LCD display on the back of the camera to direct the camera at the scene you would like to capture.

2) Press the T/Zoom In and W/Zoom Out buttons to zoom in/out if desired.

Note: The actual shape of these buttons may vary per camera model. Optical and Digital Zoom: Digital Zoom □ As you press the Zoom buttons, a bar indicator moves up and down the rectangular box on the right side of the LCD screen according to the zoom used. The bottom section of the box shows the Optical Zoom and the top section displays the menu for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Scene menu. @@ Press the SET button to select the desired option.

@@@ An icon reflecting your selection will display on the LCD screen. Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. The Image Resolution meff' option in the Macro menu. The mountain □ icon will appear on the LCD. Anti-Shake On - Ensure that the Anti-Shake option is set to 'On'.

The Anti-Shake option is 'On' by default when you start using your camera and assists you in properly focusing the image. □ Distance from the camera - The subject's face must be no further than 8 to 9 feet (3.5 meters) from the camera and the face must cover at least 20% (1 / 5th) of the picture as viewed on the LCD screen. □ Facing the camera - The face of the subject(s) you are photographing must be facing the camera and must hold the pose for at least 4 to 5 seconds until the green square(s) appears around the subject's face. Face Detect will not work with a side shot of the subject's head. 1) 2) 3) 4) 5) 6) 7) 8) 9) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Face Detect menu. @@ Press the SET button to select the desired option. @@@ An icon reflecting your selection will display on the LCD screen. Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings.

22 Your camera contains a Macro Menu that allows you to enable or disable the Macro mode on your camera. @@@@ The mountain icon appears on the LCD display. When Macro mode is off, images can be captured from 1.5m - ∞ (infinity). Note: The Macro mode must be turned OFF when you want to use the following features of your camera: Flash and Face Detect. 1) 2) 3) 4) 5) 6) 7) 8) 9) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Macro menu. @@ Press the SET button to select the desired option. @@@ An icon reflecting your selection will display on the LCD screen. Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings.

The White Balance feature allows your camera to adjust the coloring of the captured images depending on the type of light source in the current environment. Properly adjusting the White Balance setting to match your current environment will allow the 23 camera to properly balance the colors in the images that are taken with your camera. 1) 2) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the White Balance menu. 3) 4) 5) 6) 7) 8) 9) Press the UP or DOWN direction control buttons to scroll through the menu options.

Press the SET button to select the desired option. @@@ An icon reflecting your selection will display on the LCD screen. Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. You can choose to add a color effect to the images taken with your camera. 1) 2) 3) 4) 5) 6) 7) 8) Press the SET button to open the menus for the current mode.



[You're reading an excerpt. Click here to read official POLAROID IS529 user guide](http://yourpdfguides.com/dref/5417332)

<http://yourpdfguides.com/dref/5417332>

Press the LEFT or RIGHT direction control button to scroll and select the Color Effect menu. @@Press the SET button to select the desired option. @@@Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. 24 When enabled, the Multi SnapShots feature allows you to take six rapid snapshots in a row with a single click of the Shutter button. This feature can be effective when trying to capture a particular moment in a sporting event or other scenes with quick movements. 1) 2) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Multi SnapShots menu. 3) 4) 5) 6) 7) 8) 9) Press the UP or DOWN direction control buttons to scroll through the menu options. Press the SET button to select the desired option. @@@@An icon reflecting your selection will display on the LCD screen.

Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. You can set the level of sharpness in the images taken with your camera. The sharpness level dictates if the edges of objects in the image are more or less distinct. 1) 2) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Image Sharpness menu. 3) 4) 5) 6) 7) @@Press the SET button to select the desired option. @@ 25 8) 9) An icon reflecting your selection will display on the LCD screen. Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. The Light Exposure setting helps you control the amount of light that enters your camera's lens. This setting should be adjusted when the environment is lighter or darker than normal.

When the environment has more light than is needed, reduce the exposure setting (by using the negative - count) to reduce the amount of light allowed into the lens by your camera. If the environment has less light (darker) than is needed, increase the exposure setting (by using the positive + count) to increase the amount of light allowed into the lens by your camera. 1) 2) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Light Exposure menu. 3) 4) 5) 6) 7) 8) 9) Press the UP or DOWN direction control buttons to scroll through the menu options.

Press the SET button to select the desired option. @@@@An icon reflecting your selection will display on the LCD screen. Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. The ISO menu allows you to set the level of sensitivity that your camera has to light in the surrounding environment. When the ISO level is increased, the image sensor in your camera will be more sensitive to light and allow you to capture images in lower-light situations.

The higher sensitivity to light however, may reduce the quality of the images that are taken. 26 When the ISO is reduced, the image sensor in your camera will be less sensitive to light and will optimize the image quality in environments with bright lighting. 1) 2) 3) 4) 5) 6) 7) 8) 9) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the ISO menu. @@Press the SET button to select the desired option. @@@@An icon reflecting your selection will display on the LCD screen. Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. The Metering setting will affect how your camera focuses when capturing an image. Depending on your selection, the camera will be more sensitive to focusing on particular areas in the display and adjust the image color and lighting accordingly. Center – Averages the light metered from the entire frame, but giving greater weight to the subject in the center Multi – Used in standard conditions the camera divides and adjusts the settings of the image into several zones for light metering such as complex light conditions, position of subject, brightness, background, direct light and scenes Spot – Meters the area within the spot point frame at the center of the LCD to set the exposure on the subject in the center of the monitor.

1) 2) 3) 4) 5) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Metering menu. @@Press the SET button to select the desired option. A selected option icon will appear on the selected item. 27 6) 7) 8) 9) Press the LEFT or RIGHT button to select the next menu item. @@An icon reflecting your selection will display on the LCD screen. Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. You can select your camera's language setting by selecting the desired language from the Language menu. 1) 2) 3) 4) 5) 6) 7) 8) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Language menu.

@@Press the SET button to select the desired option. @@@@Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. When you capture an image with your camera, the image will include a time stamp with the date and time that the image was taken. The Date/Time menu allows you to set your camera's date and time as desired. You can also disable the timestamp for future images that will be taken with your camera.

On – The timestamp will appear on photos taken Off – The date stamp will not appear on photos taken 28 1) 2) 3) 4) 5) 6) 7) 8) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Date/Time menu. @@Press the SET button to select the desired option. A selected option icon now appears to the right of the option name. Press the LEFT or RIGHT button to select the next menu item. @@Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. 1) 2) 3) 4) 5) 6) 7) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control buttons to scroll and select the Date/Time menu. Press the UP or DOWN direction control buttons to scroll through the menu options. Highlight the "Date Setup" menu option. Press the SET button to select the desired option. The "Date Setup" submenu will open. Scroll through the window with the RIGHT and LEFT navigation buttons. For each field in the menu, use the UP and DOWN navigation buttons to set the time and date.



[You're reading an excerpt. Click here to read official POLAROID IS529 user guide](http://yourpdfguides.com/dref/5417332)

<http://yourpdfguides.com/dref/5417332>

8) Press the **MODE** button to exit the menu and return to your previous screen.

You have the option of activating the camera's Silent mode to disable all of the sound effects (except for beeps heard during the Self-Timer countdown) that the camera emits when performing camera functions. Note: The camera features that emit sounds include - Power On, Power Off, Shutter 'Click' and Self-Timer. 29 The Silent Mode Options include: Silent Mode Off (default): All camera features will emit sound when activated. Silent Mode On: All camera features will not emit sound EXCEPT for the Self-Timer and associated Shutter 'Click' at the end of the Self-Timer countdown. 1) 2) 3) 4) 5) 6) 7) 8) Press the **SET** button to open the menus for the current mode. Press the **LEFT** or **RIGHT** direction control button to scroll and select the Silent menu. @@ Press the **SET** button to select the desired option. @@@@ Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. You can use the Auto Power Off feature in order to conserve your camera's battery life. The designated time represents when your camera will automatically power off.

When the camera sits idle for the designated period of time, the camera will shut off completely and will need to be powered on again with the power button before the next use. 1) 2) Press the **SET** button to open the menus for the current mode. Press the **LEFT** or **RIGHT** direction control button to scroll and select the Auto Power Off menu. 3) 4) 5) 6) 7) 8) @@ Press the **SET** button to select the desired option. @@@@ Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings.

30 The options in the Frequency menu represent the frequency of the electrical current in fluorescent lighting sources in your locale. If your camera is set to a frequency that does not match your country's electric current, you may see waves on the images taken by your camera. 50Hz – UK, Europe and Australia 60Hz – US, Canada and South America 1) 2) 3) 4) 5) 6) 7) 8) Press the **SET** button to open the menus for the current mode. Press the **LEFT** or **RIGHT** direction control button to scroll and select the Frequency menu. @@ Press the **SET** button to select the desired option.

@@@@ Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. You can use the Format Memory Card menu to delete all of the content that is currently on your camera's memory card. Keep in mind that formatting the memory card will permanently delete all of the content on your camera's memory card. This option will delete all of the content at one time. If you would like to delete individual images, use the delete menu in the camera's Playback mode. Note: Restoring factory defaults or formatting the camera may result in the loss of data. Please ensure you have backed up your images before you attempt this. defaults or formatting the player may result in the loss of data. Please ensure you have backed up all important files before you attempt this 1) 2) Press the **SET** button to open the menus for the current mode. Press the **LEFT** or **RIGHT** direction control button to scroll and select the Format Memory N 31 Card menu.

3) 4) 5) Press the **UP** or **DOWN** direction control button to highlight the menu options. To exit without formatting the card, select 'Cancel' and press the **SET** button. To proceed with the format, select "Yes" and press the **SET** button. You will be asked to confirm the formatting of the memory card. Select "No" to exit without formatting. Select "Yes" and press the **SET** button to begin the format. The memory card will be completely formatted. Use this menu to view the Firmware version on your camera or to reset your camera settings to the Factory Default Settings. 1) 2) 3) 4) 5) Press the **SET** button to open the menus for the current mode. Press the **LEFT** or **RIGHT** direction control button to scroll and select the Firmware menu.

The "Default Setting" is selected. Press the **SET** button to reset the camera to the factory default settings. You will be asked to confirm the resetting to the factory default settings. Select "No" to exit the menu and return to the previous mode without resetting to the default settings. Select "Yes" and press the **SET** button to proceed with the reset.

You will then automatically exit the menu and return to the previous mode with the digital camera settings set to the Factory Default Settings. Note: After RESETTING to the default settings, it is recommended to select your system Language, Date/Time and Insta-Share for Photos and Videos. If you do not, the next time your camera is powered on, you will be prompted to define those settings. 32 The Playback Mode allows you to review and edit photos and videos that you've already taken with your camera. When you first turn on the camera, the camera will be in Photo Capture mode by default.

Press the **MODE** button twice to open the Playback Mode. The latest captured image appears on the LCD screen. If there are no images stored, a message (No File) appears. 1) Select your Photo: Once in Playback Mode, press the **LEFT** or **RIGHT** direction button to scroll through the images on your camera's memory card until you find the image you would like to view. Each captured image (video and photo) is displayed on the LCD screen. Photos appear with a 'JPG' icon on the top left of the LCD screen. 2) Zooming In/Out of your selected Photo: Press the **UP** / Zoom In button to Zoom In and magnify the selected photo. Use the **UP** / **DOWN** / **LEFT** / **RIGHT** direction buttons to navigate around the photo. Press the **DOWN** / Zoom Out button to Zoom Out of the selected photo. Use the **UP** / **DOWN** / **LEFT** / **RIGHT** direction buttons to navigate around the photo.

Easily navigate and select the image you wish to view by using the Thumbnail View. The images on your camera will be displayed in a 3 X 3 matrix where you can use the direction buttons to scroll and select images from the thumbnails. 1) Press the **W** / Zoom Out button. All the images on your camera will appear in the Thumbnail View. 2) Use the **UP** / **DOWN** / **LEFT** / **RIGHT** direction buttons to scroll and select the image you wish to view. 3) 4) Press the **SET** button to enlarge the selected image full size. Once the selected photo is full size you can zoom in/out and edit the photo. 33 Ph Your digital camera has a four-directional pad that functions as Quick Function buttons. Quick Function Button Left Function Displays the PREVIOUS image Views all the Photos as a Slide Show with 3, 5 or 10 second Up Right Down intervals. To exit the Slide Show, press any button.

Displays the NEXT image Insta-Share – Opens the Insta-Share for Photos menu Other **SET** Opens the menu options for Photo Playback Mode Saves your selected menu option Note: To navigate through the Menus, use the **UP**/**DOWN**/**LEFT**/**RIGHT** direction control buttons.



[You're reading an excerpt. Click here to read official POLAROID](http://yourpdfguides.com/dref/5417332)

[IS529 user guide](http://yourpdfguides.com/dref/5417332)

<http://yourpdfguides.com/dref/5417332>

□ MODE □ Toggles between the Photo Capture Mode, Video Capture Mode and Playback Mode Exits the menu screen Opens Thumbnail View □ W/Zoom Out □ T/Zoom In To Navigate in the Thumbnail View: press the UP / DOWN / LEFT / RIGHT direction buttons To select a JPG in the Thumbnail View: press the SET button Zooms Out of selected photo Zooms In to selected photo 34 The following are the menus that appear in your camera's Photo Playback Mode: While in the Playback Mode, you can delete captured photos and videos from your camera through the Delete menu. 1) 2) 3) 4) 5) Select the photo you would like to delete. Press the SET button to open the menus for the Photo Playback mode. Press the LEFT or RIGHT direction control button to scroll and select the Delete menu.

Press the UP or DOWN direction control buttons to scroll through the menu options. To delete the selected photo: Select "Delete This Photo?" and press SET button. You will be asked to confirm the deletion of the photo. □ If you would like to proceed with deleting the current image: select 'Yes' and press the SET button to confirm. The photo will be deleted and you will exit the menu and return to the Playback mode.

□ If you do not want to delete the current image: select 'No' and press the SET button. The photo will not be deleted and you will exit the menu and return to the Playback mode. 35 6) To delete all the images (videos and photos) you have saved on your SD Memory card: Select 'Delete All Images?' and press the SET button. @@All of your images will be permanently deleted. A blank 'No Files Exist' screen will appear. @@@@Note: The INSTA Share feature is deactivated by default. @@@@Press the SET button to open the menus for the current mode. @@3) 4) 5) 6) @@Press the SET button to select and save the desired option. @@@@1) 2) 3) 4) 5) 6) Select the photo you would like to rotate. Press the SET button to open the menus for the current mode.

@@@@Press the SET button to select and save the desired option. @@1) 2) 3) 4) 5) 6) 7) 8) 9) View the photo you would like to crop. Press the SET button to open the menus for the current mode. @@Press the UP or DOWN to highlight the Crop option. Press the SET button to open the Crop option. The Crop window will open on the selected picture. @@@@1) 2) 3) View the image you would like to protect/lock. Press the SET button to open the menus for the current mode. @@4) 5) 6) 7) @@Press the SET button to select the desired option. Press the LEFT or RIGHT button to select the next menu item.

@@Photos that are not locked will not display the lock symbol. @@@@Press the SET button to open the menus for the current mode. @@4) 5) @@@@1) 2) 3) Press the SET button to open the menus for the current mode. @@Setting up the Interval: @@@@4) Beginning the Slide Show: Press the UP button. Press any button to exit the Slide Show.

5) Press the LEFT or RIGHT button to select the next menu item, if you wish to view other menus without viewing the Slide Show. 6) 39 The Video Capture Mode allows you to capture videos with your digital camera. When the camera is first powered ON, the camera will be in Photo Capture Mode. Press the MODE button once to access the Video Capture Mode. 1) While in Video Capture Mode use the LCD display to direct the camera at the scene you would like to capture.

2) Press the T/Zoom In and W/Zoom Out buttons to zoom in/out if desired. Note: The actual shape of these buttons may vary per camera model. Optical and Digital Zoom: Digital Zoom □ As you press the Zoom buttons, a bar indicator moves up and down the rectangular box on the right side of the LCD screen according to the zoom used. The bottom section of the box shows the Optical Zoom and the top section displays the Digital Zoom. Bar indicating the zoom. Optical Zoom □ To use the Optical Zoom: Press the T/Zoom In and W/Zoom Out buttons. The Optical Zoom stops when the bar reaches the top of the Optical Zoom section of the box. □ To use the Digital Zoom: Press the T/Zoom In button. Once you reach the maximum of the Optical Zoom, re-press the T/Zoom In button to continue zooming using the Digital Zoom. 3) Press the Shutter button to START the video capture.

A blinking red icon and the elapsed time appear at the top of the LCD indicating that the record is in progress. 4) 5) To STOP the video record, press the Shutter button again. The video is automatically saved to the camera's SD memory card. 40 Your digital camera has a four-directional pad that functions as Quick Function buttons. Quick Function Button Left Function Scene Selection - Opens the Scene menu Light Exposure - Opens the Light Exposure menu Up Right Delete - Opens the 'Delete This Video' option and allows you to view and delete the last video taken as well as previously captured videos Down INSTA Share - Opens the INSTA Share for Videos menu Other Shutter STARTS/STOPS the video capture □ SET □ Opens the menu options for Video Capture Mode Saves your selected menu option Note: To navigate through the Menus, use the UP/DOWN/LEFT/RIGHT direction control buttons. □ MODE □ T W Toggles between the Video Capture Mode, Photo Capture Mode, and Playback Mode Exits the menu screen Zooms In Zooms Out The display of the icons on the LCD screen can be hidden or visible as desired. 1) 2) Hold the MODE button for 2 seconds to hide the display of the icons on the screen. Press the MODE button again to redisplay the icons on the screen. 41 The following are the menus that appear in your camera's Video Capture Mode: 42 The Scene Menu allows you to choose scene settings that let your camera to adapt properly to your current environment. 1) 2) 3) 4) 5) 6) 7) 8) 9) Press the SET button to open the menus for the current mode.

Press the LEFT or RIGHT direction control button to scroll and select the Scene menu. @@Press the SET button to select and save the desired option. @@@@An icon reflecting your selection will display on the LCD screen. Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. The Image Size menu allows you to choose the desired size of the images taken by your camera. Keep in mind that images with a larger size will also take up more of your camera's memory. 1) 2) 3) 4) 5) 6) 7) 8) 9) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Image Size menu. @@Press the SET button to select and save the desired option. @@@@An icon reflecting your selection will display on the LCD screen.

@@@@1) 2) Press the SET button to open the menus for the current mode. @@3) 4) 5) 6) 7) 8) 9) @@Press the SET button to select and save the desired option. @@@@An icon reflecting your selection will display on the LCD screen. @@@@The mountain icon appears on the LCD display. When Macro mode is off, images can be captured from 1.



[You're reading an excerpt. Click here to read official POLAROID IS529 user guide](http://yourpdfguides.com/dref/5417332)

<http://yourpdfguides.com/dref/5417332>

5m - ∞ (infinity). Note: The Macro mode must be turned OFF when you want to use the following features of your 44 camera: Flash and Face Detect. 1) 2) 3) 4) 5) 6) 7) 8) 9) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Macro menu. @@Press the SET button to select the desired option.

@@@An icon reflecting your selection will display on the LCD screen. Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. The White Balance feature allows your camera to adjust the coloring of the captured images depending on the type of light source in the current environment. Properly adjusting the White Balance setting to match your current environment will allow the camera to properly balance the colors in the images that are taken with your camera. 1) 2) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the White Balance menu. 3) 4) 5) 6) 7) 8) 9) @@Press the SET button to select and save the desired option. @@@An icon reflecting your selection will display on the LCD screen. Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. 45 You can choose to add a color effect to the images taken with your camera.

1) 2) 3) 4) 5) 6) 7) 8) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Color Effect menu. @@Press the SET button to select and save the desired option. @@@Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. You can set the level of sharpness in the images taken with your camera. The sharpness level dictates if the edges of objects in the image are more or less distinct. 1) 2) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Image Sharpness menu. 3) 4) 5) 6) 7) 8) 9) @@Press the SET button to select and save the desired option. @@@An icon reflecting your selection will display on the LCD screen Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings.

46 The Light Exposure setting helps you control the amount of light that enters your camera's lens. This setting should be adjusted when the environment is lighter or darker than normal. When the environment has more light than is needed, reduce the exposure setting (by using the negative - count) to reduce the amount of light allowed into the lens by your camera. If the environment has less light (darker) than is needed, increase the exposure setting (by using the positive + count) to increase the amount of light allowed into the lens by your camera. 1) 2) 3) 4) 5) 6) 7) 8) 9) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Light Exposure menu. @@Press the SET button to select and save the desired option. @@@An icon reflecting your selection will display on the LCD screen. Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. The ISO menu allows you to set the level of sensitivity that your camera has to light in the surrounding environment.

When the ISO level is increased, the image sensor in your camera will be more sensitive to light and allow you to capture images in lower-light situations. The higher sensitivity to light however, may reduce the quality of the images that are taken. When the ISO is reduced, the image sensor in your camera will be less sensitive to light and will optimize the image quality in environments with bright lighting. 1) 2) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the ISO menu. 47 3) 4) 5) 6) 7) 8) 9) @@Press the SET button to select and save the desired option. @@@An icon reflecting your selection will display on the LCD screen. Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. The Metering setting will affect how your camera focuses when capturing an image. Depending on your selection, the camera will be more sensitive to focusing on particular areas in the display and adjust the image color and lighting accordingly.

Center – Averages the light metered from the entire frame, but giving greater weight to the subject in the center Multi – Used in standard conditions the camera divides and adjusts the settings of the image into several zones for light metering such as complex light conditions, position of subject, brightness, background, direct light and scenes Spot – Meters the area within the spot point frame at the center of the LCD to set the exposure on the subject in the center of the monitor. 1) 2) 3) 4) 5) 6) 7) 8) 9) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Metering menu. @@Press the SET button to select and save the desired option. @@@An icon reflecting your selection will display on the LCD screen.

Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. 48 You can select your camera's language setting by selecting the desired language from the Language menu. 1) 2) 3) 4) 5) 6) 7) 8) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Language menu. @@Press the SET button to select and save the desired option.

@@@Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. When you capture an image with your camera, the image will include a time stamp with the date and time that the image was taken. The Date/Time menu allows you to set your camera's date and time as desired. You can also disable the timestamp for future images that will be taken with your camera. On – The timestamp will appear on photos taken Off – The date stamp will not appear on photos taken 1) 2) 3) 4) 5) 6) 7) 8) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Date/Time menu. @@Press the SET button to select and save the desired option. @@@Remember that this setting will be saved by your camera until you manually change the 49 setting or restore the camera's default factory settings. 1) 2) 3) Press the SET button to open the menus for the current mode.



[You're reading an excerpt. Click here to read official POLAROID](http://yourpdfguides.com/dref/5417332)

[IS529 user guide](http://yourpdfguides.com/dref/5417332)

<http://yourpdfguides.com/dref/5417332>

Press the LEFT or RIGHT direction control button to scroll and select the Date/Time menu.

Press the UP or DOWN direction control button to highlight the "Date Setup" menu option then press the SET button to select the option. 4) 5) 6) 7) The "Date Setup" submenu will open. Scroll through the window with the RIGHT and LEFT navigation buttons. For each field in the menu use the UP and DOWN navigation buttons to set the date and time. When you have finished setting the date and time, press the SET button to save your settings and return to the previous mode. 8) Press the MODE button to exit the menu without saving your settings and return to your previous screen. You can use the Auto Power Off feature in order to conserve your camera's battery life. The designated time represents when your camera will automatically power off. When the camera sits idle for the designated period of time, the camera will shut off completely and will need to be turned on again with the power button before the next use. 1) 2) 3) 4) 5) 6) 7) 8) Press the SET button to open the menus for the current mode.

Press the LEFT or RIGHT direction control button to scroll and select the Auto Power Off menu. @@ Press the SET button to select and save the desired option. @@@ Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. 50 The options in the Frequency menu represent the frequency of the electrical current in fluorescent lighting sources in your locale. If your camera is set to a frequency that does not match your country's electric current, you may see flickering or waves on the images taken by your camera. 50Hz – UK, Europe and Australia 60Hz – US, Canada and South America 1) 2) 3) 4) 5) 6) 7) 8) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Frequency menu. @@ Press the SET button to select and save the desired option. @@@ Remember that this setting will be saved by your camera until you manually change the setting or restore the camera's default factory settings. You can use the Format Memory Card menu to delete all of the content that is currently on your camera's memory card.

Keep in mind that formatting the memory card will permanently delete all of the content on your camera's memory card. This option will delete all of the content at one time. If you would like to delete individual images, use the delete menu in the camera's Playback mode. Note: Restoring factory defaults or formatting the camera may result in the loss of data. Please ensure you have backed up your images before you attempt this. defaults or formatting the player may result in the loss of data. Please ensure you have backed up all important files before you attempt this 1) Press the SET button to open the menus for the current mode. N 51 2) Press the LEFT or RIGHT direction control button to scroll and select the Format Memory Card menu. 3) 4) 5) Press the UP or DOWN direction control button to highlight the menu options. To exit without formatting the card, select 'Cancel' and press the SET button.

To proceed with the format, select "Yes" and press the SET button. You will be asked to confirm the formatting of the memory card. Select "No" to exit without formatting. Select "Yes" and press the SET button to begin the format. The memory card will be completely formatted. Use this menu to view the Firmware version on your camera or to reset your camera settings to the Factory Default Settings. 1) 2) 3) 4) 5) Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the Firmware menu. The "Default Setting" is selected. Press the SET button to reset the camera to the factory default settings.

You will be asked to confirm the resetting to the factory default settings. Select "No" to exit the menu and return to the previous mode without resetting to the default settings. Select "Yes" and press the SET button to proceed with the reset. You will then automatically exit the menu and return to the previous mode with the digital camera settings set to the Factory Default Settings. Note: After RESETTING to the default settings, it is recommended to select your system Language, Date/Time and Insta-Share for Photos and Videos.

If you do not, the next time your camera is powered on, you will be prompted to define those settings. 52 The Playback Mode allows you to review and edit photos and videos that you've already taken with your camera. When you first turn on the camera, the camera will be in Photo Capture mode by default. Press the MODE button twice to open the Playback Mode. The latest captured image appears on the LCD screen.

If there are no images stored, a message (No File) appears. 1) Select your Video: Once in Playback mode, press the LEFT or RIGHT direction button to scroll through the images on your camera's memory card until you find the video you would like to view. Each captured image (video and photo) is displayed on the LCD screen. Videos appear with an 'AVI' icon on the top left of the LCD screen. 2) Play your selected video: Press the Shutter button to START playing the video. Press the Shutter button again to PAUSE the video and to continue playing and pausing as needed. To fully STOP the video and restore the icons to the LCD, press the UP button. While the Video is playing all the icons on the top section of the LCD disappear. Easily navigate and select the image you wish to view by using the Thumbnail View. The images on your camera will be displayed in a 3 X 3 matrix where you can use the direction buttons to scroll and select images from the thumbnails.

1) Press the W/Zoom Out button All the images on your camera will appear in the Thumbnail View. 2) Use the UP / DOWN / LEFT / RIGHT direction buttons to scroll and select the image you wish to view. 53 3) 4) Press the SET button to enlarge the image full size. Once the selected video is full size you can play and view the video. Your digital camera has a four-directional pad that functions as Quick Function buttons. Quick Function Button Left Function Displays the PREVIOUS image STOPS a playing video Displays the NEXT image INSTA Share – Opens the INSTA Share for Videos menu Up Right Down Other Shutter PLAYS and PAUSES a playing video SET Opens the menu options for Photo Playback Mode Saves your selected menu option Note: To navigate through the Menus, use the UP/DOWN/LEFT/RIGHT direction control buttons. MODE Toggles between the Photo Capture Mode, Video Capture Mode and Playback Mode Exits the menu screen Opens Thumbnail View W/Zoom out To Navigate in the Thumbnail View: press the UP / DOWN / LEFT / RIGHT direction buttons To select a JPG in the Thumbnail View: press the SET button 54 The following are the menus that appear in your camera's Video Playback Mode: While in the Playback Mode, you can delete captured photos and videos from your camera through the Delete menu.



[You're reading an excerpt. Click here to read official POLAROID](http://yourpdfguides.com/dref/5417332)

[IS529 user guide](http://yourpdfguides.com/dref/5417332)

<http://yourpdfguides.com/dref/5417332>

1) 2) 3) 4) 5) Select the video you would like to delete. Press the SET button to open the menus for the Video Playback mode. Press the LEFT or RIGHT direction control button to scroll and select the Delete menu.

Press the UP or DOWN direction control buttons to scroll through the menu options. To delete the selected video: Select "Delete This Video?" and press SET button. You will be asked to confirm the deletion of the video. If you would like to proceed with deleting the current image: select 'Yes' and press the SET button to confirm. The video will be deleted and you will exit the menu and return to the Playback mode.

If you do not want to delete the current image: select 'No' and press the SET button. The video will not be deleted and you will exit the menu and return to the Playback mode. 6) To delete all the images (videos and photos) you have saved on your SD Memory card: Select 'Delete All Images?' and press the SET button. @@All of your images will be permanently deleted. A blank 'No Files Exist' screen will appear.

Press the MODE button to exit the 'No Files Exist' screen and return to Photo Capture 55 mode. @@@@Note: The INSTA Share feature is deactivated by default. @@1) 2) 3) View the image to which you would like to add an INSTA Share. Press the SET button to open the menus for the current mode. Press the LEFT or RIGHT direction control button to scroll and select the INSTA Share for Videos menu. 4) 5) 6) 7) 8) 9) @@Press the SET button to select and save the desired option. A selected option icon will appear on the selected item @@An icon will appear on the image with the selected INSTA Share destination site. @@A new default can be selected at any time through this menu. Remember: You can also easily access the INSTA Share menu by pressing the INSTA Share (Down) button. 56 Pictures and Videos taken with your camera can be protected or "locked" to prevent any deletion or alteration being made to the files.

1) 2) 3) View the image you would like to protect/lock. Press the SET button to open the menus for the current mode. @@4) 5) 6) 7) @@Press the SET button to select the desired option. Press the LEFT or RIGHT button to select the next menu item. @@Photos that are not locked will not display the lock symbol. Remember that you cannot delete or edit photos while they are locked. 57 1) Insert the installation CD into your CD-ROM drive. On PC: The Polaroid Instant Memories Installer window appears. If the window does not appear, open the application's CD/DVD drive and click on "Setup.exe" to launch the installer. On Macintosh: Click the icon that appears on the desktop to install the Polaroid Instant Memories the click "Continue". 2) Please review the license terms. PC: Click the "I accept the terms of the License Agreement" and then click "Next" to continue. MAC: Click "Continue" to accept the license agreement. 3) On PC: Let the "Polaroid Instant Memories" installer create the folder to where the program will be installed, and then click "Install".

On Mac: Click "Install". 4) Please wait while the application continues the installation process on your computer. Follow all instructions. 5) On PC: Click the "Close" button when the installation is complete. The application automatically opens.

On MAC: After the installation is complete, the application automatically opens. 6) If you closed the application, click on Polaroid Instant Memories desktop icon or open and run the application from the Programs menu on your computer. 58 1) 2) 3) Use the USB cable that came with your camera to connect your camera to your computer. Power the camera ON. The first time you connect the device to the computer you will have to wait a few seconds until the computer recognizes the device. An SD card needs to be inserted. Do not disconnect the cable during transfer. Doing so will cancel the transfer of any files on their way to your computer. 1) Select the "Get Images" button from the Main menu. 2) 3) 4) 5) The "Get Images from device" window opens.

You can select to download photos, videos or both. Select your camera (removable disk) from the device window. If your camera is the only USB device connected then it will be selected automatically. Select a location on the computer where to place the new photo and video files. 59 6) 7) 8) 9) Add the new photo and video files to albums if desired. Select to remove the media files from the selected device (removable disk) after the import. Click the "Get Images" button to transfer the photos and videos from your camera to your computer. A media download progress bar appears on the bottom left showing the number of media files downloading to your computer. A message appears when the download is complete. 10) The photo and video files that you selected are now downloaded to your computer to the selected folder and albums ready for your use.

Using the Polaroid Instant Memories, you can: Upload and manage photos and videos to and from the most popular photo sharing and social networking sites - Facebook, Flickr, Picasa, MySpace, Photobucket, Twitpic, Twitgoo and YouTube Seamlessly transfer photos and videos from one social network to another Organize your images by creating offline and online albums Edit images using automatic and manual tools For more details on how to use the Polaroid Instant Memories open the "Help" from the menu option. 60 1) 2) 3) 4) 5) Use the USB cable that came with your camera to connect your camera to your computer. MSDC appears on the LCD. A window appears with a list of options, select "Open folder to view files" and click OK. Open the DCIM folder and the folder inside to view the media files.

Select the media and copy the files from this folder into your computer. Optionally, select the files and choose Copy from the Edit menu. Then select a folder and choose Paste from the Edit menu. 6) We recommend that you copy the images into the Pictures/My Pictures folder and the videos into the Videos/My Videos folder. 7) Do not disconnect the cable during transfer.

Doing so will cancel the transfer of any files on their way to your computer. 1) 2) 3) 4) Use the USB cable that came with your camera to connect your camera to your computer. MSDC appears on the LCD. The camera's device icon appears on the desktop. Click on the device icon and open the DCIM folder and the folder inside to view the media files. 5) Select the files and drag them into your computer. Optionally, select the files and choose Copy from the Finder's Edit menu. Then select a folder and choose Paste from the Edit menu. 6) We recommend that you copy the images into the Pictures folder and the videos into the Movies folder. 7) Do not disconnect the cable during transfer.

Doing so will cancel the transfer of any files on their way to your computer.



[You're reading an excerpt. Click here to read official POLAROID](http://yourpdfguides.com/dref/5417332)

[IS529 user guide](http://yourpdfguides.com/dref/5417332)

<http://yourpdfguides.com/dref/5417332>

61 NOTE: Please check your device packaging for compatibility with the iPad. For models that are compatible with the iPad, photos and videos can be imported from your digital camera to your iPad by following either one of the options below: 1) Connecting your digital camera to your iPad using an iPad Camera Connector: Plug the Camera Connector into the dock connector port on your iPad, and then attach your digital camera using a USB cable (included) to the Camera Connector. NOTE: The iPad Camera Connector is not included. This item may be purchased separately. 2) Using an iPad SD Card Reader: Connect the SD Card Reader to your iPad, and then insert your digital camera's SD Memory card into the slot to import photos and videos directly from your camera's SD card. NOTE: The iPad SD Card Reader is not included. This item may be purchased separately. After you make the connection, your iPad automatically opens the 'Photos' application. This allows you to choose which photos and videos to import and to organize them into albums. The digital camera is a delicate device. Please handle your camera with care to avoid damaging it. Do not expose your camera to heat sources. Do not use you camera in wet or moist conditions. 62 This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workmanship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year. Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties. Call 877-408-0033 or Visit our website at www.polaroid.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the Product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepared. 63 NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED

TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER.

@@EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. @@@@Contact your authorized retailer to determine if another warranty applies. This product is manufactured, distributed and sold by SAKAR International, Inc. Polaroid, Polaroid & Pixel, Made in Polaroid and Polaroid Classic Border Logo are trademarks of PLR IP Holdings, LLC, used under license. All other trademarks are the property of the respective owner, who has not sponsored, endorsed or approved this product. PLR IP Holdings, LLC does not manufacture this product or provide any Manufacturer's Warranty or support. 64 For technical support issues please visit our website at www.polaroid.com. @@@@What do I do? First ensure that you have in fact taken photos.

@@@@These photos should be uploaded quickly before the camera's power is off. card, then all the photos should appear. If the photos are saved to the SD memory Q: How do I make sure I don't lose important pictures? This camera requires an SD card for normal use. If the camera's power is off, nothing will happen to the images stored on the SD memory card. We recommend always downloading your photos to your computer as soon as possible to prevent unintentional data loss.

Q: I deleted images using the Polaroid Instant Memories. The images were also deleted from my computer. How do I recover images that I accidentally deleted? All images deleted using the Polaroid Instant Memories are sent to your computer's Recycle or Trash Bin and can be retrieved from there. 65 Disposal of Waste Electrical and Electronic Equipment and/or Battery by users in private households in the European Union. This symbol on the product or on the packaging indicates that this can not be disposed of as household waste.

You must dispose of your waste equipment and/or battery by handling it over to the applicable take-back scheme for the recycling of electrical and electronic equipment and/or battery. For more information about recycling of this equipment and/or battery, please contact your city office, the shop where you purchased the equipment or your household waste disposal service. The recycling of materials will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and environment. Battery 66 E-Waste - PLR IP Holdings, LLC, its licensees, affiliates, and Sakar International, Inc. fully supports all electronic waste initiatives. As responsible stewards of the environment, and to avoid violating established laws, you should properly dispose of this product in compliance with all applicable regulations, directives or other governances in the area where you reside. Please check with local authorities or the retailer where you purchased this product to determine a location where you can appropriately dispose of the product. You may also go to www.polaroid.com and reference Social Responsibility to learn more about the specific laws in your area and to locate a collection facility near your home.

If your electronic device has internal memory on which personal or other confidential data may be stored, you may want to perform a data sanitization process before you dispose of your device to assure another party cannot access your personal data. Data sanitization varies by the type of product and its software, and you may want to research the best sanitization process for your device before disposal. You may also check with your local recycling facility to determine their data sanitization procedures during the recycling process. This device complies with the part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



[You're reading an excerpt. Click here to read official POLAROID IS529 user guide](http://yourpdfguides.com/dref/5417332)
<http://yourpdfguides.com/dref/5417332>