




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for RANE ECM 64E. You'll find the answers to all your questions on the RANE ECM 64E in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual RANE ECM 64E
User guide RANE ECM 64E
Operating instructions RANE ECM 64E
Instructions for use RANE ECM 64E
Instruction manual RANE ECM 64E



Quick Start

The ECM 64e is a very versatile product with many applications. This section will help you with basic setup, then use the Contents below to find the detail you need for your specific application.

Although the ECM 64e or ECM 64eAD are configured to operate 'out of the box', to get the best performance please review this manual for proper configuration and alignment (see page Manual-12). The ECM 64eAD includes both the DH-1c Digital Hybrid and the ECA-2 Echo Canceller. If you are using the ECM 64e without these options, hardware and software references to them in this manual will not apply.

The ECM 64e is configured using RaneWare® software. To become familiar with the ECM 64e signal routing, you can load and run RaneWare on a PC before connecting the ECM 64e. In RaneWare, click on the **Device** button and select **Offline ECM 64e**. This creates a virtual product which is fully operational, even saving and recalling system files as if it were a real unit. Press F1 at any time to get help, then get information about any feature by clicking on it. Here at Rane, we spend a lot of time putting together very informative help files, so please use them — you'll help us feel appreciated!

Before connecting any cables to the ECM 64e, unplug the RS-3 power supply and turn the amplifier(s) down or off until all connections are complete. Connect balanced audio **INPUTS** and **OUTPUTS** to the handy Euroblock connectors.

Connect the **RW 232 INPUT** jack to a serial (COM) port on a PC-compatible computer using a standard 9-pin RS-232 cable (a short one is supplied with the unit, intended to connect between multiple RW 232 units in a rack). *The cable or adaptor must not be a null-modem type.* If this unit is to be used by jack/E, set the **RW 232 DEVICE ADDRESS** switch to '1' by setting all switches **off** (down), except switch one (labeled '1' on the chassis, the right-most switch). If there is more than one unit, refer to "Setting the Device Address" on page Manual-7 to set a unique number.

After all connections are made, connect the RS-3 remote power supply and line cord. **CAUTION: don't connect anything but an approved Rane power supply.** If the RS-3 and the ECM 64e are getting power, the yellow **POWER** indicator lights.

Start your computer running Windows®, and launch RaneWare. Select **System Setup** from the **System** menu. Be sure to select the **COM** port which is physically connected to the ECM 64e and RS-232 under **Connection**, and click **OK**. Now, choose **Select** from the **Device** menu. Click on **Poll**, and **Devices Found** displays the number of units. Click the **Stop** button. Select the unit listed in the **Device Selection** window and click **OK**. If no unit was found, refer to the "Troubleshooting" section on page Manual-13.

Several clues indicate communication between the computer and the ECM 64e. The yellow **COM** (communications) indicator should flash periodically. The **Memory** numbers (1-16) near the top of the RaneWare screen should be **black** rather than gray.

Most echo problems are caused by improper microphone placement and gain. To achieve good acoustic echo canceller performance, setup is critical. Follow the "Alignment Procedure" on page Manual-12.

Table of Contents

Hardware	
ECM 64e - Front Panel Description	2
ECM 64e - Rear Panel Description	3
Typical ECM 64eAD Installation	4
Site Survey	6
ECM Connection	6
Memory Recall Port	7
Software Operation	
Overview	8
System Requirements	8
Software Installation	8
Device Selection	9
Memory & Security	9
Saving & Printing	9
Inputs	10
Outputs	10
Acoustic Echo Canceller	10
Digital Hybrid	11
Alignment Procedure	12
Troubleshooting	12
ECM 64e Options	13
Advanced Application	14
Device Control Language	16
RW 232 Communications Interface	24
Example Packet Expansion Code	25
Compliance Notices	26

WEAR PARTS: This product contains no wear parts.

Manual-1



[You're reading an excerpt. Click here to read official RANE ECM 64E user guide](http://yourpdfguides.com/dref/3395249)
<http://yourpdfguides.com/dref/3395249>

Manual abstract:

The ECM 64e is configured using RaneWare® software. To become familiar with the ECM 64e signal routing, you can load and run RaneWare on a PC before connecting the ECM 64e. In RaneWare, click on the Device button and select Offline ECM 64e. This creates a virtual product which is fully operational, even saving and recalling system files as if it were a real unit. Press F1 at any time to get help, then get information about any feature by clicking on it. Here at Rane, we spend a lot of time putting together very informative help files, so please use them -- you'll help us feel appreciated! Before connecting any cables to the ECM 64e, unplug the RS 3 power supply and turn the amplifier(s) down or off until all connections are complete. Connect balanced audio INPUTS and OUTPUTS to the handy Euroblock connectors. Connect the RW 232 INPUT jack to a serial (COM) port on a PC-compatible computer using a standard 9-pin RS-232 cable (a short one is supplied with the unit, intended to connect between multiple RW 232 units in a rack). The cable or adaptor must not be a null-modem type. If this unit is to be used by itself, set the RW 232 DEVICE ADDRESS switch to ' 1 ' by setting all switches off (down), except switch one (labeled ' 1 ' on the chassis, the right-most switch).

If there is more than one unit, refer to "Setting the Device Address" on page Manual-7 to set a unique number. After all connections are made, connect the RS 3 remote power supply and line cord. CAUTION: don't connect anything but an approved Rane power supply. If the RS 3 and the ECM 64e are getting power, the yellow POWER indicator lights. Start your computer running Windows®, and launch RaneWare.

Select System Setup from the System menu. Be sure to select the COM port which is physically connected to the ECM 64e and RS-232 under Connection, and click OK. Now, choose Select from the Device menu. Click on Poll, and Devices Found displays the number of units. Click the Stop button.

Select the unit listed in the Device Selection window and click OK. If no unit was found, refer to the "Troubleshooting" section on page Manual-13. Several clues indicate communication between the computer and the ECM 64e. The yellow COM (communications) indicator should flash periodically. The Memory numbers (1-16) near the top of the RaneWare screen should be black rather than gray. Most echo problems are caused by improper microphone placement and gain. To achieve good acoustic echo canceller performance, setup is critical. Follow the "Alignment Procedure" on page Manual-12. Table of Contents
Hardware ECM 64e Front Panel Description ..

.....
 . 2 ECM 64e Rear Panel Description

..... 3 Typical ECM 64eAD Installation

 4 Site Survey

 6 ECM Connection .

.. 6 Memory Recall Port

 7 Software Operation .

 8 Overview

.....
.....
.....
.....

... 8 System Requirements

.....
.....
.....

. 8 Software Installation

.....
.....

.....
.....
.....

. 8 Device Selection

.....
.....
.....
.....

..... 9 Memory & Security .

.....
.....
.....

.....
.....
.....

... 9 WEAR PARTS: This product contains no wear parts. Saving & Printing

.....
.....
.....
.....

. 9 Inputs

.....
.....

.....
.....
.....
.....

.....
.....

... 10 Outputs ..

.....

.....
.....
.....
.....

.....
.....
.....

. 10 Acoustic Echo Cancellor

.....
.....

.....
... 10 Digital Hybrid

.....
.....
.....

.....
.....
.....
11 Alignment Procedure

.....
.....
.....
.....
..... 12 Troubleshooting

.....
.....
.....
.....

.....
.....
.....
.....
..... 12 ECM 64e Options

.....
.....
.....
.....
.....

..... 13 Advanced Application

.....
.....
.....

.....
..... 14 Device Control Language

.....
.....
.....
.....

.. 16 RW 232 Communications Interface

.....

.. 24 Example Packet Expansion Code

.....
.....

25 Compliance Notices

.....
.....
.....
.....

... 26 Manual-1 Front Panel Description INPUT SIG and OL level indicators: SIG lights when the Input signal (before trim) is above 25 dBu for Mics and 19 dBu for Line inputs. OL lights when the Input signal (before trim) is within 2 dB of clipping. OUTPUT SIG and OL level indicators: SIG lights when the Output signal is above -19 dBu. OL lights when the Output signal is within 2 dB of clipping. Use the INPUT and OUTPUT level indicators to check correct signal flow. GAIN Switches: Selects Input Gain between 0 dB (line level), 34 dB (most mics), or 46 dB. OFF HOOK button: Toggles between Off Hook (conference mode) and On Hook.

The front panel OH indicator lights when the ECM 64e is in conference mode and the telephone line has been siezed. This button can be disabled using the FP Lock in RaneWare. VOLUME UP & DOWN buttons: When UP is pressed Out 1's level is increased. When DOWN is pressed, Out 1's level is decreased. These buttons can be disabled using the FP Lock in RaneWare.

OH Indicator Off Hook: When lit, the ECM 64e is in conference mode. The DH 1e must be installed to light this indicator. RNG Indicator - Ring: When lit,

there is an incoming call. PRV Indicator - Privacy: When lit, the ECM 64e is in privacy mode and all Mic Inputs are muted. MUT Indicator - MUTE: When lit, all ECM 64e Outputs are muted.

AA Indicator Auto Answer: When lit, the ECM 64e has been placed in Auto Answer and will accept an incoming call when the number of rings matches the set ring count. LEVEL meter: Selectively displays any one of the inputs or outputs by using RaneWare or the PORT STEP button (see). This display is also used for status display, PORT STEP meter selection and errors. During download programming, the -6 LED flashes by itself indicating program data is transferring. During RW 232 operation, if the -3 LED flashes by itself, an RW 232 receive parity error occurred. During download programming, if the 0 LED lights by itself, the download program checksum does not match. The ECM 64e will not accept the program. If the +6 LED lights by itself either the system not ready, an RW 232 overflow has occurred or a flash memory error has occurred. To remedy, cycle the power off, then back on. PORT STEP button: Pressing this for 1 second causes the LEVEL meter to flash its currently monitored Input or Output.

If this button is pressed and held for 3 seconds, the monitored port can be changed by pressing the button in 1 second steps. The LEVEL Meter LEDs will step Mic Mix (-18), Line In (-15), Aux In (-12), Hybrid In (-9), Out 1 (-6), Out 2 (-3), Out 3 (-0) and Hybrid Out (6), then back to Mic Mix (-18). COM indicator: flashes randomly when receiving valid data from the control system or PC. If the DEVICE ADDRESS is set to 0, this indicator flashes steadily at ½ second intervals. POWER indicator: Lights when the ECM 64e operating system is running. Security cover: Installs over the GAIN switches once they are set. . . . Manual-2 Rear Panel Description Chassis ground point: A #6-32 screw is supplied for chassis grounding purposes. Although the RS 3 supplies a third wire ground, some installations may require that all audio equipment be tied together using a grounding bus. POWER input jack: This 5-pin DIN connects to the included RS 3 power supply. Warning! Connect the power supply DIN connector to the ECM 64e BEFORE connecting to AC power, otherwise damage may occur.

RW 232 CONTROL - OUTPUT: This DB-9 male connects to downstream RW 232 units. RW 232 CONTROL - INPUT: This DB-9 female connects to the RS-232 output of the controller (or PC), or the OUTPUT of another RW 232 unit connected to the controller. Rane uses a standard RS-232 interface using Rane's RW 232 protocol operating at 19.



[You're reading an excerpt. Click here to read official RANE ECM 64E user guide](http://yourpdfguides.com/dref/3395249)
<http://yourpdfguides.com/dref/3395249>

2 kb. Units connect by daisy-chaining the products on a serial bus, OUTPUT to INPUT.

RW 232 CONTROL - DEVICE ADDRESS: Sets the RW 232 address for the ECM 64e. Each RW 232 unit connected together requires a different address. If the RW 232 Control Device Address is set to an invalid address, the COM indicator continually flashes. The Device Address can be changed without power cycling the unit. See page #.

MRP/EXT. CTRL: is a DB-15 female connector used for remote functions. See Memory Recall Port / External Control on page Manual-7. DH 1e cover plate: is supplied with ECM 64e units that do not include the DH 1e Digital Hybrid. The ECM 64eAD includes the DH 1e, therefore the plate is not supplied.

PHONE and LINE: These 4-pin RJ-11 jacks magically appear when the DH 1e is installed, included with the ECM 64eAD. The PHONE jack connects to a standard two-wire POTS telephone. This connection is disconnected when the ECM 64e is Off Hook. The LINE jack connects to a standard two-wire POTS line. **AEC OUT:** is an unbalanced line-level Output.

This delivers direct access to the ECA 2 Acoustic Echo Canceller's Output, when installed. The ECA 2 is included in the ECM 64eAD. This may be useful in larger system configurations. **OUT 3:** is a balanced line-level Output for general purpose, typically connected to a VCR's input. **OUT 2:** is a balanced line-level Output for general purpose, typically connected to a Video Codec's input. **PROGRAM (OUT 1):** is a balanced line-level Output, typically connected to the room's program loudspeaker amplifier. This Output can also be assigned to the ECA 2 Acoustic Echo Canceller Reference in RaneWare. **AEC REF OUT:** is an unbalanced line-level Output. This connects to what is being sent to the ECA 2 Acoustic Echo Canceller's Input, when installed. The ECA 2 is included in the ECM 64eAD.

This may be useful in larger systems. **AUX IN:** is a balanced line-level Input, typically connected to a VCR's output. **AEC REF IN:** is an unbalanced line-level Input. Use this when the Reference for the ECA 2 Acoustic Echo Canceller needs to come from an external source. In RaneWare select EXT.

IN as the AEC REF. LINE IN: is a balanced line-level Input, typically connected to the video codec's output. **MIC INPUTS:** Four Mic or Line balanced Inputs via a 12-pin Euroblock. These Inputs route to the matrix mixers and the ECA 2 Acoustic Echo Canceller Input. **PHANTOM POWER switches:** select Phantom Power to each individual MIC Input.

Manual-3 Typical ECM 64eAD Installation The ECM 64eAD is preprogrammed to operate out of the box using the following system configuration. Run RaneWare, choose Device > Restore Memories from File, and load the ECM 64e file API.C64. In this example we will not use custom names, just the defaults to keep things clearer. In this configuration: · Mic Mix is routed to the AEC IN · Out 1 is used for the AEC REF · Line, AUX and HYBRID are routed to Out 1 (to the loudspeaker amplifier) · AEC OUT, AUX and HYBRID are routed to Out 2 (to the video codec) · Mic Mix, Line, AUX and HYBRID are routed to Out 3 (to the record VCR) · AEC OUT, Line and AUX are routed to HYBRID. The API.C64 file uses two Memories: · Memory 1 is set for the above application ·

Memory 2 allows local speech reinforcement. In Memory 1, since Out 1 is used for the AEC Reference, Mics cannot be sent to Out 1 for local speech reinforcement. If Mics are sent to both the AEC Input and the AEC Reference, the AEC will not perform properly. The Memory 2 application solves this problem by changing the AEC Reference from Out 1 to the mix of Line In and Aux In.

Since Out 1's Limiter is no longer part of the AEC Reference, Memory 2 disables Out 1's Limiter. See Memory & Security on page Manual-9 for more information. Refer to the Appendix for an example of a larger system combining the ECM 64e with ECS. ECM 64eAD MIC 1 MIC 2 MIC 3 MIC 4 VIDEO CODEC IN 1 2 MIX IN PROGRAM PROGRAM SPEAKER PROGRAM AMP IN OUT OUT 1 3 4 DH 1 Installed ECA 1 Installed AUDIO OUT LINE IN OUT 2 RECORD VCR IN AUX IN OUT 3 Act this RW 232 INPUT to the RS-232 connector on a PC-compatible or control system. If a Rane RW 232 device is already connected to the PC or control system, use the supplied short DB-9 connector to link the RW 232 OUTPUT of the upstream device to the ECM 64e RW 232 INPUT. Check that the RW 232 devices are set to different addresses (see RW 232 Communications Interface on page Manual-24). Note: do not use a null-modem cable for RS-232 control. Memory Recall Port (MRP) / External Control External contact closure control is provided through the DB-15 female MRP/EXT. CTRL connector providing: · Recall of internal Memories · Level control for OUT 1 using external up / down buttons · Control and status signals for Off Hook, Privacy and Mute. Complete programmability of the MRP is possible using RaneWare by selecting Device > Edit MRP Configuration.

Manual-6 Rane does not supply an external control device to operate the ECM 64e. Custom wiring recommendations: · Use momentary or toggle-type switches to ground (pin 15) to operate the MRP Data pins. · Use momentary switches to ground (pin 15) to operate the control pins. · Status pins use open-collector type drivers that can sink 100 ma to ground. · +5 Volts (pin 14) can be used as the power source for lamps, relays or LEDs connected to the status pins.

Connector type DB-15 female Pin Description 1 MRP Data 1 2 MRP Data 2 3 MRP Data 3 4 MRP Data 4 5 Off Hook control 6 Out 1 Volume Up control 7 Ring status 8 Out 1 Volume Down control 9 Privacy control 10 Mute control 11 Off Hook status 12 Privacy status 13 Mute status 14 +5 Volts (1 amp maximum) 15 Gnd Setting The Device Address The Device Address is set using a binary code which may be determined using the following table, our Windows Address Calculator program, or by adding the place values (115) silk-screened on the chassis. Ignore all numbers printed directly on the switch. For example, turning ON the switches labeled '1' and '2' yields address '3'. In the following table, 0 means switch down (OFF) and 1 means switch up (ON).

Rane also provides a special calculator to assist in setting the dip switches.

After installing the software, in the RaneWare program group, launch the RaneWare 232 Address Calculator. This binary calculator converts decimal numbers into corresponding dip switch settings. Since the ECM 64e only has a four position dip switch instead of an eight position, ignore the four left most digits. Address 1 2 3 4 5 6 7 8 Dip Switch 0001 0010 0011 0100 0101 0110 0111 1000 Address 9 10 11 12 13 14 15 Dip Switch 1001 1010 1011 1100 1101 1110 1111 Device Address Calculator Manual-7 Software Operation Overview RaneWare controls and commands will be in Sans-serif type like this and match the defaults shown in RaneWare. Be aware that Inputs and Outputs may be given custom names in RaneWare and may not match the text in this manual after they are changed.



[You're reading an excerpt. Click here to read official RANE ECM 64E user guide](http://yourpdfguides.com/dref/3395249)

<http://yourpdfguides.com/dref/3395249>

The ECM 64e hardware is controlled by software using an addressable RS-232 protocol called RW 232TM. RaneWare® is the software, and the family of products that the software controls. RW 232 describes the protocol and the DB-9 hardware used to communicate between units. This interface operates with any RS-232 serial port, allowing control system communication with up to 16 RW 232 products at a time, each with a unique address. Rane's RW 232 products can be controlled from remote locations with the optional RPD 1 Programming & Diagnostics Unit (see the RPD 1 data sheet) or over a network with the Via 10 Ethernet Bridge (see the Via 10 data sheet).

For those that want to write their own software to control the ECM 64e see the following: · Device Control Language page Manual-16 · RW 232 Communications Interface page Manual-24 · Example Packet Expansion code for RW 232 Messages page Manual-25 Panja/AMX demo software is downloadable from Rane's web site at <http://www.rane.com>, on the Conferencing page. Also see RaneNote 139, "Using SR 1L's with Other Rane Products." System Requirements · RaneWare works under Microsoft Windows®, on a PC or laptop with an unused serial port. · The following is recommended as a minimum system: 80386SX with a 80387 coprocessor, 33 MHz Unused serial port 4M RAM Color monitor · RW 232 needs a DB-9 cable less than 50' long, connecting from the serial port of a computer to the RW 232 CONTROL INPUT port. This cable is wired straight through, not null modem. No interface boxes are required; just a cable and the computer. See the ECS Hardware Manual. · RaneWare can be fully demonstrated and operated without any unit attached (called 'offline').

· A RaneWare CD-ROM comes with each unit. RaneWare is a single program with different windows capable of controlling not only the ECS units, but also the RPE 228d equalizer, the RPM 26v multifunction processor, the Via 10 Ethernet Bridge, and the RPD 1 Programming and Diagnostics Unit. New products and revisions may be added in the future. Software updates can be obtained at Rane's web site, www.rane.com.

Software Installation The CD should auto-start when inserted unless that feature is disabled on your computer. If it doesn't, you may install by navigating to the installer file. Go to the Start menu, Select Run..

.. Select Browse.... Navigate to the CD-ROM drive or Navigate to the file you downloaded from www.rane.com Select the RW***.EXE file.

Click OK. Installation begins. Starting RaneWare Once RaneWare is installed, a RaneWare program group is created. When the software is first installed, Rane's Software License Agreement is displayed. Read it and close it. Then, the Help screen appears. Here, any questions may be answered. Subsequent activations do not bring up the License Agreement or the Help screen unless they are asked for. Close the Help file, and welcome to RaneWare! If any question arises about a particular control on any software screen, position the pointer over the control and press F1 on your keyboard for Help. The System Setup screen asks to which Com port RW 232 is attached.

If you don't have a unit connected, you can still use RaneWare Offline. Click OK, then Polling begins the first time the program is run. This process checks for units connected to the serial port. Polling may also be invoked by selecting Device > Select > Poll. If a Device is found, you are in control! (If a device is hooked up and it is not found, read the Troubleshooting section of the Help file.

) RaneWare polls addresses 1 thru 250. If the connected products are found, you may click the stop button at any time to end polling. System Setup Dialog Manual-8 Device Selection After Polling, the Device Selection window displays any connected RW 232 units, as well as Offline versions of all Rane RW 232 products. The quickest way to get to the RW 232 Device Edit screen, if not already displayed, is to click the Device button on the far right side of the toolbar.

When pressed, a list of the first fifteen connected devices appears.

Click one of the devices-- either an offline device or an actual device--and the selected device's edit screen appears. The selected device name is displayed at the top within the title bar. Alternatively, after Polling, the same device list appears in the Device Selection window. Select the connected or offline device from the list and click OK. The connected unit's Device Address is displayed within brackets [] to the left of the device name. Double-clicking on the device name is equivalent to selecting the device and clicking OK. If the installation changes by adding more RW 232 units, choose Device > Select, and the Poll button to make the computer recognize currently connected units. ECM 64e Devices can also be given custom names, tailored to your installation. Simply choose Device > Name Device, and the following screen appears. Memory names are stored in the computer, not in the ECM 64e, along with other installation-specific information.

Select System > Save Job File to support multiple installations. Returning to Device Edit from the Site Control panel requires a password. Right-click on the title bar to Select Device Edit (password required), or Exit the program. If more than 16 Memories are needed, they can be saved to disk and recalled later. Memory Selection Toolbar All of Rane's RW 232 products have 16 programmable Memories with one working Memory called Memory 0. Recalling a Memory replaces the working Memory with the selected Memory. The selected Memory is then displayed next to the Store button. All control changes are made to working Memory, not to the selected Memory. The selected Memory flashes whenever working Memory does not match it. To save these settings in one of the 16 Memories, simply click Store, and the Memory number key.

After Storing, clicking any Memory number instantly recalls it. The 16 Memories are stored within the units non-volatile Memory, and recalled by: Selecting a Memory using RaneWare, or from a control system by a. Sending a Program channel from memory command, or b. @@@@Recall all c. Recall Input settings only c.

@@@@@Retrieval of Memories and Names are performed separately. @@@@@@@@@@The default password is "please". @@@@The Site Control Panel is all an operator needs to recall Memories. @@@@The Input Trim operates from 15 to +16 dB in 1 dB steps. @@@@For a 10 dBu input, set the Input Trim to +10 dB.

@@@@@@@@@@@@@The Limiter attack rate is 10 millisecond using 1 dB steps. @@@@@@The ECA 2 is included in the ECM 64eAD, along with the DH 1e. The AEC performs full-duplex audio teleconferencing by subtracting the room loudspeaker audio from audio received by the room microphones. This is accomplished by routing the room loudspeaker audio to the AEC Reference (REF.) and room microphones to the AEC IN. The ECM 64e allows selection of different audio inputs and reference audio feeds to create a flexible system design.



[You're reading an excerpt. Click here to read official RANE ECM 64E user guide](http://yourpdfguides.com/dref/3395249)

<http://yourpdfguides.com/dref/3395249>

The AEC Input selects Mic Mix, Line In and Aux In, in any combination. Most applications will require Mic Mix at a minimum. The AEC Reference selects between Internal Mix (consisting of Line In, Aux In and Hybrid In), Out 1 and EXT. IN.

Note: do not use Out 1 for AEC Reference if Near-End Mics are routed to Out 1 for speech reinforcement. Since the ECA 2 automatically adapts to the room, training is not required. The status of the ECA 2 can be checked in Device > Peripheral Status. If operating properly, the Acoustic Echo Canceller's Rev Level is displayed. Otherwise, Peripheral Status displays Not Installed. The ECM 64e provides a Noise Gate. When enabled, the Noise Gate attenuates the AEC output by the Gate Depth selected if no near end audio is detected. This feature is useful in noisy room situations. The ECM 64e also provides control over the AEC suppression. An Echo Canceller can only reduce the echo down around the background noise of the near end room.

Suppression is used to further reduce the echo. The three Suppression choices give the installer some flexibility in matching the ECM 64e to the room's requirements. Moderate will be appropriate for most rooms. Soft offers less Suppression and Strong offers more. Since Suppression affects the subjective quality of a room, experimentation is the best method to determine which setting is best for a given room.

Manual-10 Peripheral Status and Dial Dialogs Digital Hybrid Controls Digital Hybrid The DH 1e Digital Hybrid is an optional module, included in the ECM 64eAD. This internal module allows audio conferencing over a standard POTS 2-wire phone line. A 32 millisecond Line Echo Canceller is utilized to remove line echo caused by the four-wire to two-wire conversion. In a standard telephone the echo caused by this conversion is actually beneficial to the user as side-tone. With a conference system line echo can cause all types of problems including feedback and echo canceller problems.

When the Digital Hybrid is in an Off Hook state, the ECM 64e is in a conference call using the telephone line. During Off Hook, the RJ 11 connector labeled PHONE is disconnected from the telephone line that is connected to the LINE connector. The term 'Off Hook' represents the handset being removed from the hook switch. For best performance, always connect the RJ 11 connector labeled LINE directly to a POTS-type line by itself. Do not connect other equipment such as phones and modems in parallel or in front of the ECM 64e. Only connect other equipment to the RJ 11 connector labeled PHONE. Features include: Auto-Answer and Ring Detect · Auto Disconnect · Off Hook status · DTMF Dialing with six programmable speed numbers · DTMF Decoding (See Opstat page Manual-19) You can check the status of the digital hybrid in Device > Peripheral Status. If operating properly the Digital Hybrid's Rev level is displayed. Otherwise, Peripheral Status displays Not Installed. When the DH 1e is installed, the Limiter is always enabled.

no matter how the Limiter's checkbox is set. The DH 1e always limits the phone line to 10 dBm. Setting the Hybrid's Output Trim above 10 dB causes any audio levels above 10 dBm to become compressed. Note that setting the Output Trim to 4 dB (adding 6 dB of compression) increases the level of softer talkers. The Auto Disconnect checkbox tells the ECM 64e to monitor the phone line for loss of DC voltage and the lack of received audio within three minutes. If any of these two actions occur, the ECM 64e instructs the Digital Hybrid to go On Hook. Always use Auto Disconnect when setting the Digital Hybrid in Auto Answer. You may want to disable Auto Disconnect once you have placed a call. There is always the possibility that the ECM 64e may disconnect the call when you are not expecting it. For Rev 1.

2 or greater there are added special function DTMF dialing operators: Operator !1 Performs a 100 ms Flash Hook !2 Performs a 500 ms Flash Hook !3 Places the caller on Hold !4 Removes the caller from Hold Manual-11 Alignment Procedure Quick Overview a. Setup Mic gains b. Setup Line In and Aux In Input levels c. Select matrix routing and if necessary the matrix level d. Adjust the output levels e.

Select the input mix for the acoustic echo canceller. f. Select the reference for the acoustic echo canceller. Mic Setup The ECM 64e is shipped with its Mic gains set for 34 dB and Mic trims set to +6 dB. If using boundary-type mics, this setting may be good enough.

To improve on this setting it is best to use a sound level meter like the Radio Shack 33-2050. 1. Remove the front security cover. 2. On the rear select the correct function for phantom power. Shipped with phantom power on. 3. Select the front panel gain setting. Typically 34 dB. Shipped in the 34 dB position.

4. Start with Mic 1 and mute all other mics. 5. Set Meter to Mic Mix. 6. Make certain that this is the correct mic by tappin on it. The Meter should go about full scale. If not, recheck mic wiring. 7. Place the sound level meter next to the mic and point both towards the loudspeaker. 8. Route the Pink Noise to Out 1 and adjust the amplifier level for 80 dBA, using the slow response on the sound level meter. 9. Adjust the Mic Trim so that the 0 dB LED on the ECM 64e meter just comes on. 10.

Turn off the pink noise source. Go to step 4 and replace Mic 1 with next mic. Troubleshooting POWER LED is Off: Check POWER connection on rear panel, and that the remote supply is connected to a live AC source. No communication between the unit and computer: Set the DEVICE ADDRESS to a unique small number, and try polling for units in RaneWare (under Device > Poll). The unit should be found quickly.

Check that the COM port selected in RaneWare (under Setup > System Setup) is the one on your computer that is connected to the unit. Also check that the cable is a standard RS-232 cable (not a null modem type). If an adapter is used, it must not be null modem. The cable must be connected to the RW 232 INPUT jack on the rear of the unit. Audio hum or noise: Try Muting the unit. If this helps significantly, the problem may be with the Input connection, or the equipment driving the Input. If Muting has little effect, the problem is likely either the Output connection, or equipment driven by the Output. The ECM 64e is intended to connect to equipment with balanced audio I/O and chassis-grounded shield/common. This kind of audio interconnection should maximize audio quality. Connecting equipment with signal grounded shields or unbalanced connections may result in hum or noise due to induced currents in the signal path.

It may be possible to reduce or eliminate these problems, although some experimentation may be required: Try disconnecting the audio cable shields at one end, particularly between chassis grounded and signal grounded equipment. Try combinations of lifting grounds on units supplied with ground lift switches (or links). Verify that all chassis are tied to a good earth ground.



[You're reading an excerpt. Click here to read official RANE ECM 64E user guide](http://yourpdfguides.com/dref/3395249)

<http://yourpdfguides.com/dref/3395249>

Some units with outboard power supplies do not ground the chassis through the line cord. Make sure these units are grounded by tying the Chassis Ground Point to a known earth ground. A star washer guarantees proper contact. For more information on balanced interconnection and grounding, please refer to RaneNote 110, "Sound System Interconnection" or Journal of the AES Vol. 43 No. 6 (June 1995). Manual-12 ECM 64e Options Two internal cards are available for the ECM 64e.

The ECM 64eAD already includes both options. ECA 2 Acoustic Echo Canceller The ECA 2 is a continually adaptive Acoustic Echo Canceller (AEC) module, required when the ECM 64e is used for audio teleconferencing. The ECA 2 installs by temporarily removing the top cover of the ECM 64e and seating the module onto factory installed standoffs on the motherboard. The connectors on the ECA 2 and the motherboard are keyed, so there is only one direction that the ECA 2 can be installed (see below). Warning: To protect against damage from electrostatic discharge (ESD) proper control measures must be followed.

See page Manual-10 for Acoustic Echo Canceller operation. DH 1e Digital Hybrid The DH 1e Digital Hybrid allows audio conferencing over a standard POTS 2-wire phone line. A 32 millisecond Line Echo Canceller is utilized to remove line echo caused by the four-wire to two-wire conversion. In a standard telephone the echo caused by this conversion is actually beneficial to the user as side-tone. With a conference system line echo can cause all types of problems including feedback and echo canceller problems.

The DH 1e installs by first temporarily removing the top cover of the ECM 64e and the rear phone jack cover on the back of the ECM 64e. See the diagram on page Manual-6. Seat the DH 1e module from its bottom side onto the ECM 64e J10 header. Make certain that the header pins are properly aligned with the DH 1e before applying force to seat the card. Warning: To protect against damage from electrostatic discharge (ESD) proper ESD control measures must be followed when installing the DH 1e. ECA 2 DH 1e DH 1e and ECA 2 Installation Manual-13 Advanced Application Connecting the ECM 64e to a larger ECS

In this application the system required: · Full duplex audio for a Video Codec and a telephone connection · Automatic mic mixing with acoustic echo cancelling of 15 table top, 2 podium and 2 wireless microphones · Speech reinforcement of 2 podium and 2 wireless mics · Playback of stereo audio sources from an audio router, a VCR and a DVD player · Recording of the audio sources · Assisted listening of the audio sources Rane Equipment: 1 - ECM 64e Conference System with 1 - DH 1e Digital Hybrid (included in ECM 64eAD) 1 - ECB 62 Base Unit with 1 - ECS 62 Stereo Expansion card 2 - ECM 82A Automatic Mic Mixer with 2 - ECA 1 Acoustic Echo Cancellers (included) 2 RPD 228d Programmable Equalizers Refer to the diagram on the following page. While designing a large audio system for a client that requires 19 mic inputs, the client informs you he only has enough audio budget for 2 ECM 82As. Before telling your client there is no way, here is a solution. Since the ECM 64e has 4 Mic Inputs, use these for the speech reinforcement mics. In RaneWare, route the Mic Mix to Out 1, and connect OUT 1 to Input 8 of an ECM 82A.

Set the ECM 64e's Output Trim of Out 1 to 10 dB in RaneWare. Turn the ECM 82A Input 8's Phantom Power off and set the Input Gain to +6 dB. For speech reinforcement of the podium and wireless mics, route the Mic Mix to Out 3 of the ECM 64e in RaneWare. To perform a telephone conference: · Route the HYBRID audio to Out 2 of the ECM 64e · Connect OUT 2 to PORT 6 IN on the ECB 62 · Route PORT 6 IN to PORT 1 OUT (Program) and PORT 2 OUT (Codec) · Route PORT 1 and PORT 2 IN to PORT 6 OUT · Connect ECB 62's PORT 6 OUT to the ECM 64e's LINE IN · Route LINE IN to the HYBRID For this application load AP2.C64 using Device > Restore Memories From File and Device > Restore Names From File. Memory 1 Only sends the ECM 64e's four mics to the ceiling speakers. See Memory & Security on page Manual-9 for more information. Manual-14 ECM 64e and Larger ECS Installation Manual-15 Device Control Language Data Structures Abbreviations used: Definition: \$: signifies hexadecimal number ADDR: Device Address CHNUM: Channel Number code COMSTAT: Communications Status code DCL: Device Control Language DT: Device-Type code (predefined) ID: Manufacturer's ID code (predefined) MEMNUM: Memory Number code OPSTAT: Operational Status code SPL: Stored Parameter List (product dependent) ECM 64e Stored Parameter List (SPL): System Parameters: Index Hex Name / System Parameters 0 \$00 Meter Display 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17-20 Encoding Method 0-7 (byte) 0 = Mic Mix 1 = Line In 2 = Aux In 3 = Hybrid Rx 4 = Out 1 5 = Out 2 6 = Out 3 7 = Hybrid Tx \$01 Auto Answer Ring Count 0-9 (byte) 0 = Auto Answer Off; 1 = Answer after 1st ring \$02 Auto Disconnect 1/0 (byte) 1 = On, 0 = Off \$03 Privacy 1/0 (byte) 1 = On, 0 = Off \$04 Mute 1/0 (byte) 1 = On, 0 = Off \$05 (Reserved) 1/0 (byte) 1 = On, 0 = Off \$06 (Reserved) 0 (byte) \$07 AEC Mute 1/0 (byte) 1 = On, 0 = Off \$08 AEC In Mic Mix 1/0 (byte) 1 = On, 0 = Off \$09 AEC In Line 1/0 (byte) 1 = On, 0 = Off \$0A AEC In Aux 1/0 (byte) 1 = On, 0 = Off \$0B AEC Ref. (Mix In/Out1/Ext) 0/1/2 (byte) 0 = Mix In, 1 = Out 1, 2 = Ext. \$0C AEC Ref.

Line In 1/0 (byte) 1 = On, 0 = Off \$0D AEC Ref. Aux In 1/0 (byte) 1 = On, 0 = Off \$0E AEC Noise Gate 1/0 (byte) 1 = On, 0 = Off \$0F Noise Gate Depth 0 to 90 (byte) 0 = 0 dB to 90 = -90 dB \$10 Suppression 1/2/3 (byte) 1 = Soft, 2 = Moderate, 3 = Strong \$11-\$14 Reserved (Fill with 0s) 0 (byte) 0 Inputs Parameters: Index Hex Name / System Parameters Encoding Method 21 \$15 Mic 1 (Mute)* 1/0 (byte) 1 = Mute 22 \$16 Mic 2 (Mute)* 1/0 (byte) 1 = Mute 23 \$17 Mic 3 (Mute)* 1/0 (byte) 1 = Mute 24 \$18 Mic 4 (Mute)* 1/0 (byte) 1 = Mute 25 \$19 Line In (Mute)* 1/0 (byte) 1 = Mute 26 \$1A Aux In (Mute)* 1/0 (byte) 1 = Mute 27 \$1B Mic 1 Level 0 to 31 (byte) -15 to +16 28 \$1C Mic 2 Level 0 to 31 (byte) -15 to +16 29 \$1D Mic 3 Level 0 to 31 (byte) -15 to +16 30 \$1E Mic 4 Level 0 to 31 (byte) -15 to +16 31 \$1F Line In Level 0 to 31 (byte) -15 to +16 32 \$20 Aux In Level 0 to 31 (byte) -15 to +16 * Only these function are recalled when setting CHNUM to 1 or 2. dB dB dB dB dB dB Manual-16 Output Index 33 34 35 36 1 Parameters: Hex Name / System Parameters \$21 Output (Mute)* \$22 Output Level \$23 Output Limiter (On/Off)* \$24 Input Select* 37 38 39 40 41 42 Output Index 43 44 45 46 \$25 \$26 \$27 \$28 \$29 \$2A Mic Level AEC Level Line-level Aux Level Phone Level Noise Level Encoding Method 1/0 (byte) 1 = Mute 0 to 118 (byte) -114 to +4 dBu 1/0 (byte) 1 = On, 0 = Off 0 - 63 (byte) Bitwise where Bit 0 = Mics, Bit 1 = AEC, Bit 2 = Line In, Bit 3 = Aux In, Bit 4 = Phone, Bit 5 = Noise 0 to 31 (byte) -15 to +16 dB 0 to 31 (byte) -15 to +16 dB 0 to 31 (byte) -15 to +16 dB 0 to 31 (byte) -15 to +16 dB 0 to 31 (byte) -15 to +16 dB 2 Parameters: Hex Name / System Parameters \$2B Output (Mute)* \$2C Output Level (dB) \$2D Output Limiter (On/Off)* \$2E Input Select* 47 48 49 50 51 52 Output Index 53 54 55 56 \$2F \$30 \$31 \$32 \$33 \$34 Mic Level AEC Level Line-level Aux Level Phone Level Noise Level Encoding Method 1/0 (byte) 1 = Mute 0 to 118 (byte) -114 to +4 dBu 1/0 (byte) 1 = On, 0 = Off 0 - 63 (byte) Bitwise where Bit 0 = Mics, Bit 1 = AEC, Bit 2 = Line In, Bit 3 = Aux In, Bit 4 = Phone, Bit 5 = Noise 0 to 31 (byte) -15 to +16 dB 0 to 31 (byte) -15 to +16 dB 0 to 31 (byte) -15 to +16 dB 0 to 31 (byte) -15 to +16 dB 0 to 31 (byte) -15 to +16 dB 3 Parameters: Hex Name / System Parameters \$35 Output (Mute)* \$36 Output Level (dB) \$37 Output Limiter (On/Off)* \$38 Input Select* 57 58 59 60 61 62 Hybrid Index 63 64 65 66 \$39 \$3A \$3B \$3C \$3D \$3E Mic Level AEC Level Line-level Aux Level Phone Level Noise Level Encoding Method 1/0 (byte) 1 = Mute 0 to 118 (byte) -114 to +4 dBu 1/0 (byte) 1 = On, 0 = Off 0 - 63 (byte) Bitwise where Bit 0 = Mics, Bit 1 = AEC, Bit 2 = Line In, Bit 3 = Aux In, Bit 4 = Phone, Bit 5 = Noise 0 to 31 (byte) -15 to +16 dB 0 to 31 (byte) -15 to +16 dB 0 to 31 (byte) -15 to +16 dB 0 to 31 (byte) -15 to +16 dB 67 68 69 70 71 72 Encoding Method 1/0 (byte) 1 = Mute 0 to 118 (byte) -114 to +4 dBu 1/0 (byte) 1 = On, 0 = Off 0 - 63 (byte) Bitwise where Bit 0 = Mics, Bit 1 = AEC, Bit 2 = Line In, Bit 3 = Aux In, Bit 4 = Phone, Bit 5 = Noise \$42 Mic Level 0 to 31 (byte) -15 to +16 dB \$44 AEC Level 0 to 31 (byte) -15 to +16 dB \$45 Line-level 0 to 31 (byte) -15 to +16 dB \$46 Aux Level 0 to 31 (byte) -15 to +16 dB \$47 Reserved (Set to 0) 0 (byte) \$48 Noise Level 0 to 31 (byte) -15 to +16 dB * Only these function are recalled when setting CHNUM to 1 or 2.



[You're reading an excerpt. Click here to read official RANE ECM 64E user guide](#)

Parameters: Hex Name / System Parameters \$3F Output (Mute)* \$40 Output Level (dB) \$41 Output Limiter (On/Off)* \$42 Input Select* Manual-17 Device Type (DT): \$32 = ECM 64e Manufacturer's Identification code (ID): \$08 = Rane Corporation Channel Number codes (CHNUM): Typically set to 0, unless otherwise stated. Memory Number codes (MEMNUM): \$00 = live or working memory, \$01 = preset memory #1, \$02 = preset memory #2, . . . , \$10 = preset memory #16 (ECM 64e has 16 preset memories) Communications status codes (COMSTAT): \$00 = no error \$01 = invalid data \$02 = invalid command code \$03 = device locked \$04 = device not locked \$05 = channel(s) muted \$06 = channel(s) not muted \$07 = checksum error \$08 = not connected Operational Status codes (OPSTAT): \$00 = Opstat Ok \$07 = RW232 RX Overflow \$09 = RW232 Parity Error \$0A = Not Ready \$0B = Flash Error Send data to channel (81 hex): Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$XX (where \$XX = number of data bytes to follow including checksum) Transmit \$81 (command code) Transmit \$00 (CHNUM) Transmit MEMNUM Transmit 2 bytes; the starting SPL param byte index (See Note 5) Transmit SPL Transmit Checksum Get COMSTAT Program channel from memory (82 hex): Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$04 (where \$04 = number of data bytes to follow including checksum) Transmit \$82 (command code) Transmit \$00 (CHNUM) (\$00 = program device, \$01 = program inputs settings only, \$02 = program outputs settings only) (See Note 4) Transmit MEMNUM Transmit Checksum Get COMSTAT Manual-18 Program all channels from memory on all devices (82 hex): Transmit \$FB 00 \$FB 00 Transmit \$00 \$03 (where \$03 = number of data bytes to follow including checksum) Transmit \$82 (command code) Transmit MEMNUM Transmit Checksum Lock device (85 hex): Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$02 (where \$02 = number of data bytes to follow including checksum) Transmit \$85 (command code) Transmit \$79 (checksum) Get COMSTAT Unlock device (86 hex): Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$02 (where \$02 = number of data bytes to follow including checksum) Transmit \$86 (command code) Transmit \$78 (checksum) Get COMSTAT Mute Output (87 hex): Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$03 (where \$03 = number of data bytes to follow including checksum) Transmit \$87 (command code) Transmit Output # Transmit Checksum Get COMSTAT Mute all Outputs of all devices (87 hex): Transmit \$FB 00 \$FB 00 Transmit \$00 \$02 (where \$02 = number of data bytes to follow including checksum) Transmit \$87 (command code) Transmit Checksum UnMute Output (88 hex): Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$03 (where \$03 = number of data bytes to follow including checksum) Transmit \$88 (command code) Transmit Output # Transmit Checksum Get COMSTAT UnMute all Outputs of all devices (88 hex): Transmit \$FB 00 \$FB 00 Transmit \$00 \$02 (where \$02 = number of data bytes to follow including checksum) Transmit \$88 (command code) Transmit Checksum Manual-19 Send Globals (8C hex): Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$72 (where \$72 = number of data bytes to follow including checksum) Transmit \$8C (command code) Transmit Global Parameters Transmit Checksum Get COMSTAT Global Parameters (114 bytes): Type Bytes Description Unit Name 16 ASCII string Input Names 56 ASCII string (Mics 1-4, Line, Aux, Hybrid) Output Names 32 ASCII string (Out 1-3, Hybrid) Font Panel 1 1 if front panel switches are disabled Locked 1 1 if unit is locked (read-only) Elapsed Time 4 Time of use in seconds (read-only) Reserved 4 Stored Number Parameter List SNPL (120 bytes): Encoding Method: Null terminated ASCII string, or 20 characters max. Index Hex Parameters 00-19 \$00-\$13 DTMF Number 1 20-39 \$14-\$27 DTMF Number 2 40-59 \$28-\$3B DTMF Number 3 60-79 \$3C-\$4F DTMF Number 4 80-99 \$50-\$63 DTMF Number 5 100-119 \$64-\$77 DTMF Number 6 A ' ' within the DTMF number inserts a 500 millisecond delay. A non-digit within the DTMF number is allowed for separation (425.355.6000). Send Stored DTMF Numbers (\$8D) Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$X2 (where \$X2 = number of data bytes to follow including checksum) Transmit \$8D (command code) Transmit the starting SNPL index (0 = Beginning of the first SNPL) Transmit SNPL Transmit Checksum Get COMSTAT Reset Unit (91 hex): Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$03 (where \$03 = number of data bytes to follow including checksum) Transmit \$91 (command code) Transmit RESET (\$00 = Reset unit, \$01 = Reset unit and set all data to default. Warning: If Firmware has been downloaded, program returns to original version.) Transmit Checksum Get COMSTAT Manual-20 Hybrid Parameter List (HPL) Hybrid Command Data Description 0 Dial DTMF Number (char) string Null terminated ASCII string, 20 (char) max 1 Dial Stored Number 1-6 Dial stored number (1 6) 2 Off Hook 1/0 1= Off Hook / 0 = On Hook A ' ' within the DTMF number inserts a 1 second delay. A non-digit within the DTMF number is allowed for separation (425.355.6000). For Rev 1.2 or greater there are added special function DTMF dialing operators: Operator !1 Performs a 100 ms Flash Hook !2 Performs a 500 ms Flash Hook !3 Places the caller on Hold !4 Removes the caller from Hold Send Hybrid Command (92 hex) Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$XX (where \$XX = number of data bytes to follow including checksum) Transmit \$92 (command code) Transmit Hybrid command Transmit Data Transmit the checksum Get COMSTAT Send MRP Table (93 hex) Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$12 (where \$12 = number of data bytes to follow including checksum) Transmit \$93 (command code) Transmit 16 byte table Transmit the checksum Get COMSTAT Get OPSTAT (00 hex): Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$02 (where \$02 = number of data bytes to follow including checksum) Transmit \$00 (command code) Transmit \$FE (checksum) Get STATUS Get Checksum Get COMSTAT Manual-21 STATUS consist of 20 bytes returned in this order: Byte Parameter Value 1 OPSTAT See OPSTAT 2 Preset Memory 1 - 16 3 Working/Stored Flag 1/0 (See Note 6) 4 Working/Dirty Flag 1/0 (See Note 7) 5 Meter Display 0 - 7, 0 = Mic Mix, 1 = Line In, 2 = Aux in, 3 = Hybrid Rx, 4 = Out 1, 5 = Out 2, 6 = Out 3, 7 = Hybrid Tx. 6 Meter Level -45 to +9 dB 7 Off Hook Flag 1/0, 1 = Off Hook 8 New Ring Flag 1/0, 1 = Ring detected - Cleared when read 9 Privacy Flag 1/0, 1 = Privacy On 10 Mute Flag 1/0, 1 = Mute On 11 Suppression Flag 1/0, 1 = Suppression active 12 AEC Installed Firmware Rev or 0 if not installed 13 Hybrid Installed Firmware Rev or 0 if not installed 14 DTMF Number (Char) Set to 0 after read.



[You're reading an excerpt. Click here to read official RANE ECM 64E](http://yourpdfguides.com/dref/3395249)

[user guide](http://yourpdfguides.com/dref/3395249)

<http://yourpdfguides.com/dref/3395249>

15 Prog. Out Level 0 - 118 Value for SPL 34 16 - 20 Reserved 0, Not used Flash COM LEDs on all units (00 hex): Transmit \$FB 00 \$FB 00 Transmit \$00 \$02 (where \$02 = number of data bytes to follow including checksum) Transmit \$00 (command code) Transmit \$FE (checksum) Get Data From Channel (01 hex): Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$08 (where \$08 = number of data bytes to follow including checksum) Transmit \$01 (command code) Transmit \$00 (CHNUM) Transmit MEMNUM Transmit 2 bytes; the starting SPL param byte index (See Note 5) Transmit 2 bytes; the number of SPL param bytes (See Note 5) Transmit Checksum Get COMSTAT Get Device Type and Manufacture's Identification Codes (02 hex): Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$02 (where \$02 = number of data bytes to follow including checksum) Transmit \$02 (command code) Transmit \$FC (checksum) Get COMSTAT Get Globals (03 hex): Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$02 (where \$02 = number of data bytes to follow including checksum) Transmit \$03 (command code) Transmit \$FB \$FB (checksum, See Note 1) Get Global Parameters Get Checksum Get COMSTAT Manual-22 Get Device Serial/Identification Number (04 hex): Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$02 (where \$02 = number of data bytes to follow including checksum) Transmit \$04 (command code) Transmit \$FA (checksum) Get 3 byte number (MSB first) Get Checksum (for serial ID) Get COMSTAT Get Software Revision (05 hex): Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$02 (where \$02 = number of data bytes to follow including checksum) Transmit \$05 (command code) Transmit \$F9 (checksum) Get Hardware Revision Get Software Revision (x10) Get Checksum (for both revisions) Get COMSTAT Get MRP Table (0B hex) Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$02 (where \$02 = number of data bytes to follow, including checksum) Transmit \$0B (command code) Transmit \$F3 (checksum) Get 16 entries Get Checksum (for entries) Get COMSTAT Get Stored DTMF Numbers (0C hex) Transmit ADDR header (\$FB XX \$FB XX, where XX = ADDR) (See Note 9) Get DT Get ID Transmit \$00 \$04 (where \$04 = number of data bytes to follow through the start parameter) Transmit \$0C (command code) Transmit the SNPL Index (0 = Beginning of the first SNPL) Transmit the number of SNPL Indexes Transmit the checksum Get SNPL Get Checksum (for SNPL) Get COMSTAT Manual-23 Notes 1. When the value \$FB occurs anywhere except in an ADDR header, it is repeated. 2. The data size is the number of bytes, prior to the \$FB repetition, between the command code and the checksum inclusively. 3. The checksum applies to the "data size" bytes through the byte immediately before the checksum, inclusive. Repeated \$FB's are counted only once. The sum is the two's complement negative of the LS Byte of the arithmetic sum.

For example, if the sum is \$1234, the checksum is \$CC. 4. The parameter bytes are indexed using a 2-byte number (MSB first) starting with 0. The number of parameter bytes also uses a 2-byte number with the same format. When sending parameters, the number sent is determined by the data size.

5. The working/stored flag is set if the working memory doesn't match the stored memory from which it originated. 6. The working/dirty flag is set when the unit is powered up, or when a memory is recalled. It is cleared when the working parameters are sent or received.

RW 232 Communications Interface RW 232 is loosely based on PA-422. One key hardware difference is that RW 232 does not utilize hardware handshaking via DTR/DSR. The beginning of a message always takes the form: \$FB xx FB xx (where xx = ADDR) Note: When \$FB appears in the body of the message, it is always repeated. Input port: 9-pin female input port (DB-9F) on device Output port: 9-pin male output port (DB-9M) on device (for serial linking to the input port on the next device. Upto 16 devices can be linked in this manner.) Device address means: 4-position DIP switch on device (valid device addresses are 1 through 15) Baud Rate: 19.2 kilobaud Character frame bits: 1 start bit, 8 data bits, 1 parity bit (even), and 1 stop bit Cabling: Use standard RS-232 serial printer or modem cables. Warning: NULL modem cables will not work! Host or computer interface: Standard PC serial COM port (DB-9M, or DB-25M with adapter) Note: Only three lines, Tx, Rx, and Ground, are used. References Rodgers, Robert L., "PA-422 Communications Interface and Device Control Language", Journal of the Audio Engineering Society, Vol.

38, Number 9, 1990 September, pp. 619-639. Audio Engineering Society, Inc., "AES Recommended practice for sound-reinforcement systems- Communications interface (PA-422)", Journal of the Audio Engineering Society, Vol. 39, Number 9, 1991 September, pp. 664-679. Standards documents: AES15-1991 (Audio Engineering Society) ANSI S4.49-1991 (American National Standards Institute) Manual-24 Example Packet Expansion Code for RW 232 Messages // 09-10-96 - Devin Cook (Derived from RW232.CPP code) // This code only deals with the Body of an RW 232 message (Command/Data) // The steps needed to fully communicate with an RW 232 device are as follows: // 1. Send the Address: [FB xx FB xx] // 2.

Get the returned Device Type and Device ID flags // 3. Send the FB expanded Body // 4. Get and check the returned ComStat byte // Take a simple command and expand it into a full packet. // Input: // Buff - BYTE array with the unexpanded message and lots of extra room // MsgLen - Unexpanded message length // Steps required are: // 1. Add Packet size.

This is simply the Command length + 1 for the checksum // 2. Duplicate 0xFBs // 3. Calculate Checksum // 4. Add Checksum to packet (Check for a 0xFB Checksum!) // 5. Copy Packet back to the buffer // 6.

Return the new Packet Size // Note: The buffer must be large enough to accept the expanded data. No checking is done to verify it is, so be careful! // A packet into this routine consists of the one byte Command and any Data int CmdToPacket(BYTE Buff[], int MsgLen) { BYTE L_MSB = ((MsgLen+1) >> 8) & 0xFF; // Grab MSB of Size BYTE L_LSB = (MsgLen+1) & 0xFF; // Grab LSB of Size // FBs is the number of 0xFB bytes in the messages int FBs = 0; // Don't forget to check message length for FBs if (L_MSB == 0xFB) FBs ++; if (L_LSB == 0xFB) FBs ++; // Calculate Checksum of Message Length bytes along with bytes in the packet int CheckSum = L_MSB + L_LSB; for (int x=0;x<L;x++) { CheckSum += Buff[x]; if (Buff[x] == 0xFB) FBs ++; } CheckSum = (256-CheckSum) & 0xFF; // Don't forget to up the FB count for a FB checksum! if (CheckSum == 0xFB) FBs ++; // New Length is: 2 (For 2 length bytes) + L (Old message Length) + Repeated FBs count + 1 (For CheckSum) int NewLen = 2 + MsgLen + FBs + 1; // Create a temporary holding tank for Packet Expansion BYTE Packet[MAX_CMD_BUF]; BYTE *Ptr = Packet; // Stick message length in the packet (Watching for FBs of course) *(Ptr++) = L_MSB; if (L_MSB == 0xFB) *(Ptr++) = 0xFB; *(Ptr++) = L_LSB; if (L_LSB == 0xFB) *(Ptr++) = 0xFB; // Expand the original packet into the new buffer for (x=0;x<L;x++) { *(Ptr++) = Buff[x]; if (Buff[x] == 0xFB) *(Ptr++) = 0xFB; } // Add the Checksum byte (or Bytes if Checksum == FB) *(Ptr++) = CheckSum; if (CheckSum == 0xFB) *(Ptr++) = 0xFB; // Copy the expanded packet back into the original buffer memcpy(Buff,Packet,NewLen); return NewLen; } Manual-25 Compliance Notices FCC Notice This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.



[You're reading an excerpt. Click here to read official RANE ECM 64E user guide](http://yourpdfguides.com/dref/3395249)
<http://yourpdfguides.com/dref/3395249>

These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of the equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense. Changes or modifications not expressly approved by Rane Corporation could void the user's authority to operate the equipment. Canadian EMC Notice This Class B digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations. Cet Appariel numerique de la classe B respecte toutes les exigences du Reglement sur le material broilleur du Canada. FCC Part 68 - Compliance FCC Part 68 Registration Number: 6PV USA-35030-BR-T Ringer Equivalence Number (REN): 0.1B This equipment complies with Part 68 of the FCC rules.

The FCC Part 68 registration number and Ringer Equivalence Number (REN) is posted on the rear of the equipment. This information must be provided to your telephone company, if requested. USOC Jacks: This product uses RJ11C type terminal jacks. The quantity of devices which may be connected to a telephone line and still operate properly is determined by REN. @@Typically, the number of RENs should not exceed five. @@@@In addition, you will be advised of your right to file a complaint with the FCC. It is possible that the Telephone Company may make changes to their equipment, operations, facilities and/or procedures that could affect the operation of this equipment. Should this happen, the telephone company will provide advance notice of such changes for you to make the necessary modifications in your equipment. If this equipment is causing problems, contact Rane Corporation, 10802 47th Avenue West, Mukilteo, WA 98275, (425) 3556000 for repair and warranty information. The Telephone Company may instruct you to remove the equipment from the network until the problem is resolved.

No user serviceable parts are contained within this product. If problems occur, contact Rane Corporation for service. Use of this equipment is prohibited on Telephone Company provided coin service. Connecting to Party Line service is subject to State tariffs. IC Compliance IC Certification Number: 3614 10632 A Ringer Equivalence Number (REN): 0.

1B; Standard Connecting Arrangement RJ11C Notice: The Industry of Canada label identifies certified equipment that meets certain telecommunications network standards, including protective operation and safety requirements, as prescribed in the appropriate Terminal Equipment Technical Requirements documents(s). By this label, The Industry of Canada does not guarantee the equipment will operate to the user's satisfaction. Before connecting this equipment to the telephone network, the user should ensure that the equipment is acceptable to the local Telephone Company. An acceptable method of connecting to the telephone network must be followed. All electrical ground connections of the power utilities, metal water pipes, and telephone lines must be connected together.

Proper grounding precaution may be particularly important in rural areas. Extending the telephone service of a single line may be accomplished by means of a certified telephone extension cord. In addition, extension of telephone service must not degrade the telephone service. Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate. Repairs of Industry of Canada certified equipment must be performed by an authorized Canadian service facility specified by Rane Corporation. Unauthorized user modifications or repairs to this equipment may result in the Telephone Company requesting that the user disconnect the equipment from the telephone service. NOTICE: The Ringer Equivalence Number (REN) assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed five. ©Rane Corporation 10802 47th Ave. W.

, Mukilteo WA 98275-5098 TEL (425)355-6000 FAX (425)347-7757 WEB <http://www.rane.com> Manual-26 All features & specifications subject to change without notice. 104477 .



[You're reading an excerpt. Click here to read official RANE ECM 64E user guide](#)

<http://yourpdfguides.com/dref/3395249>