



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for SANYO HEC-DR8700. You'll find the answers to all your questions on the SANYO HEC-DR8700 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SANYO HEC-DR8700
User guide SANYO HEC-DR8700
Operating instructions SANYO HEC-DR8700
Instructions for use SANYO HEC-DR8700
Instruction manual SANYO HEC-DR8700



INSTRUCTION MANUAL

HEC-DR8700

Massage Lounger



CONTENTS	PAGE
IMPORTANT SAFETY INSTRUCTIONS	1~4
NAME/FUNCTION OF EACH PART	5~8
HOW TO PLACE THE MASSAGER	9
HOW TO INSTALL THE STAND	10
PRIOR TO USE	11
ADJUSTMENT OF CHAIR	12~15
FEATURES OF COURSES	16
MASSAGING	17~27
WHOLE BODY SENSOR AUTOMATIC COURSES	17~20
AUTOMATIC COURSES	21~22
MANUAL (ROLLER) COURSES	23~26
MANUAL (AIR) COURSES	27
ADJUSTING MASSAGE INTENSITY	28
AFTER USE	29
MAINTENANCE PROCEDURES	30
CONTENTS OF MASSAGING	31~32
TROUBLE-SHOOTING	33
SPECIFICATIONS	34
WARRANTY	35

Thank you for purchasing this massage lounger.
Be sure to read this manual thoroughly in order to ensure proper use. In particular, make certain to read the section "IMPORTANT SAFETY INSTRUCTIONS."
Keep this manual in a safe place so that it can be found easily.



[You're reading an excerpt. Click here to read official SANYO HEC-DR8700 user guide](http://yourpdfguides.com/dref/3810397)

<http://yourpdfguides.com/dref/3810397>

Manual abstract:

..... 58 HOW TO PLACE THE MASSAGER ..

.....

.....

... 9 HOW TO INSTALL THE STAND

.....

.... 10 PRIOR TO USE .

.....

.....

.....

.....

.....

..... 11 ADJUSTMENT OF CHAIR

.....

.....

.. 1215 FEATURES OF COURSES ...

.....

.....

.... 16 MASSAGING .

.....

.....

.....

.....

.....

1727 WHOLE BODY SENSOR AUTOMATIC COURSES 1720 AUTOMATIC COURSES

.....

.....

.. 2122 MANUAL (ROLLER) COURSES ...

..... 2326 MANUAL (AIR) COURSES .

.....

.....

.....

... 27 ADJUSTING MESSAGE INTENSITY

..... 28 AFTER USE

.....

.....

.....

.....

.....

.....

... 29 MAINTENANCE PROCEDURES

.....

.... 30 CONTENTS OF MASSAGING .

.....

..... 3132 TROUBLE-SHOOTING .

.....

.....

.....

.....

.. 33 SPECIFICATIONS

.....

.....

.....

.....
. 34 WARRANTY

.....
.....

.....
.....
.....

..... @@@@Do not modify the plug provided with the product if it will not fit outlet, have a proper outlet installed by a qualified electrician. **WARNING**
To reduce the risk of burns, fire, electric shock, or injury to persons: This product contains a chemical known to the State of California to cause cancer, birth defects or other reproductive harm. An appliance should never be left unattended when plugged in. Unplug from outlet when not in use, and before putting on or taking off parts.

Do not operate under blanket or pillow. Excessive heating can occur and cause fire, electric shock, or injury to persons. Close supervision is necessary when this appliance is used by, on, or near children, invalids, or disabled persons. Use this appliance only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer. Never operate this appliance if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the appliance to a service center for examination and repair. Do not carry this appliance by supply cord or use cord as a handle. Keep the cord away from heated surfaces. Never operate the appliance with the air openings blocked.

Keep the air openings free of lint, hair, and the like. Never drop or insert any object into any opening. Do not use outdoors. Do not operate where aerosol (spray) products are being used or where oxygen is being administered. To disconnect, turn all controls to the off position, then remove the plug from the outlet.

This product is for Household Use Only. Polarization Instructions To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet.

Do not change the plug in any way. If you are currently receiving medical treatment of any type or if any of the following apply to you, be sure to consult a doctor prior to using this appliance. If you are using an internal electronic medical device such as a pacemaker which may be affected by electromagnetic interference If you have any malignant tumors If you suffer from heart trouble If you have lost temperature sensitivity. If you are having your menstrual period, or if you are pregnant or have just given birth If you have any sensory problems due to severe peripheral circulation problems caused by illnesses such as diabetes If you have any injuries to your skin If you require complete rest If your body temperature is 38°C (100 or higher (if you are feverish)

Example If you have symptoms of acute inflammation [such as fatigue, chills or fluctuating blood pressure] or if you are suffering from general debility If you suffer from osteoporosis, or if you suffer from acute pain from causes such as spinal injuries, sprains or torn muscles If your spine is abnormal or bent If you are planning to use the massager on a part of the body which is currently receiving medical treatment or which is diseased If you use the massager while any of the above apply to you, accidents or feeling of sickness may occur. 1 All of the following information is important. Be sure to follow the instructions carefully. If you feel no effect after using the product for a while, consult your doctor or health care professional. Be sure to check that there is no person (children in particular), or any pets under the foot rest and that there are no other obstructions in the way before reclining the back rest or lowering the foot rest or when using the stretch. In addition, do not leave the foot rest in the raised position when not in use. If this is not observed, accidents or injury may occur.

Do not use the massager if you have been forbidden to use it by a doctor. Example: If you are suffering from blood clots (embolisms), severe aneurysms, acute varicose veins, skin inflammation or skin infections (including epidermal infections) Do not allow persons in the following categories to use massager. If this is not done, they may be burned. Those who have a diminished sense of temperature or pain Those who cannot move their legs by themselves Do not allow people to use the massager if they are unable to clearly indicate their intentions or if they do not know how to operate the massager. Do not let children use the massager. Do not let them play on or around the massager or allow them to come near the massager while it is being used. Do not allow any children to use the massager, play on or around it. Also, while in use, keep children away from the massager. Lock the plug with the paddle lock provided when not in use and store key out of reach of children. Otherwise, an injury may occur.

PLUG KEY PLUG COVER PADDLE LOCK Be careful not to put your hand or foot into the spaces between any moving parts, including into the space between the back rest and arm rest or into the space at the underside of the back rest or between the foot rest and the seat or into the space under the foot rest. Furthermore, do not place your hands, feet or head inside the upholstery of the massager. If this is not observed, accidents or injury may occur. Be sure to check that the upholstery is not torn before using the massager. If a tear is found, stop using the massager immediately, disconnect the power plug from the wall outlet and consult the place of purchase.

Do not use the massager if the upholstery is torn, otherwise injury or electric shock may occur. Do not use the massager on the head, the chest, the abdomen, the joint (knee and elbow, etc.) and parts f painful. In addition, do not place your hands, feet or arms between the massaging rollers. felt If this is not observed, there is the danger that you may start to feet sick or an injury may occur.

(When massaging the nape of the neck, place a soft towel on the neck in order to avoid strong stimulation.) Do not stand or sit on the arm rests, foot rest or back rest. If this is not observed, you may fall down and accidents or injury may occur. Do not suddenly release your hand while raising the foot rest manually. To ensure safety, release your hand gently from the foot rest. Do not raise or lower the foot rest while your feet are receiving an air massage. If this is not observed, injury may occur. Wipe off any dust that has collected on the prongs or the base of the power plug. If this is not done, fire may occur. Do not use the massager at any current other than the designated voltage.



[You're reading an excerpt. Click here to read official SANYO HEC-DR8700 user guide](http://yourpdfguides.com/dref/3810397)
<http://yourpdfguides.com/dref/3810397>

If this is not done, fire or electric shock may occur. Do not wind the power cord, remote control cord or sensor controller cord around the main unit, remote control, sensor controller, or remote control stand. Moreover, be careful not to operate the back rest with the cord hooked on an obstruction. If this is not done, unreasonable force may be applied to the cord, possibly resulting in fire or electric shock. **2 IMPORTANT SAFETY INSTRUCTIONS (continued)**
WARNING To reduce the risk of burns, fire, electric shock, or injury to persons: Do not scratch, damage, process, excessively bend, pull, twist or bundle the power cord or place heavy objects on it or clamp it. If this is not observed, the power cord may become damaged and fire or electric shock may result. Do not use the product if the power cord or power plug is damaged or if it does not fit securely into the wall outlet. If this is not observed, electric shock, short-circuits or fire may result. Be sure to disconnect the power plug from the wall outlet before cleaning. Do not pull out the power plug with wet hands.

If this is not observed, electric shock, accidents or injury may result. Be careful not to spill water over the remote control, sensor controller, seat, or foot rest. If this is not observed, electric shock, short circuit or fire may occur. Never attempt to dismantle the massager. Do not allow any person other than a qualified repair technician to dismantle or repair the massager.

If this is not observed, fire, electric shocks, accidents or injury may occur. Ask the place of purchase of your nearest Customer Service Center (separate sheet) if repairs are required. Before using the massager, check all switches and other parts while referring to this instruction manual to make sure they all operate correctly. For safety, check that the massaging rollers are located at their origin (about shoulder height) and then sit on the chair slowly. Be sure to keep your body straight without twisting and center between the left and right rollers.

If it is not observed, an accident or injury may occur. Do not use the massager for more than 20 minutes at a time. In addition, limit the use of the massager on one point to 5 minutes or less. Using the massager continuously for long periods of time will apply more stimulation than is necessary and may result in adverse effects or injury. Be careful not to fall asleep during massaging. If this is not observed, accidents or injury may occur. Place the massager main unit on a level floor surface. If it is placed on an unstable surface, it may fall over and injury may occur. If discomfort or pain is felt during use, stop using the massager and consult a doctor immediately. In addition, if the massage force feels too strong, stop using the massager earlier than planned.

Otherwise, if you continue using the massager under such conditions, an unexpected accident may occur. If the massager has not been used for a long time, check that it operates correctly and safely before using it. In addition, check that there are no problems with the cords and other parts. If this is not done, accidents or injury may occur. After use, be sure to set the POWER switch to the "OFF" position, and disconnect the power plug from the wall outlet. If this is not done, accidents or injury due to a child's mischief may occur. At first, do not attempt to recline the seat deeply or lean on the back rest forcibly (until you have become accustomed to massaging). If the massaging force is too strong at first, it may result in adverse effects or injury. Do not wear accessories (such as a necklace or earrings) while massaging. If this is not done, accidents or injury may occur.

Do not hang anything from the back pad or head rest, or pull the back pad or head rest forcibly. If this is not observed, the head rest may come off and injury may occur. Do not place anything other than the remote control and the sensor controller respectively on the remote control stand. If this is not done, the stand may break, resulting in injury. Do not use the massager on bare skin.

If this is not observed, injury may occur. Do not move the massager while a person is sitting in it. If this is not observed, the massager may fall over and injury may occur. Do not swing the head rest because it contains a weight. If it is not done, injury may occur.

3 Do not attempt to adjust the foot rest slide while reclining. If this is not done, accidents or injury may occur. Do not attempt to stand on the foot rest when the foot rest slide position and angle are not completely returned to the home positions. If this is not done, the user may fall over, resulting in an accident or an injury, and can be turned off. **INSTANT STOP button** Used if you have felt abnormal physical sensation or want to stop the massager immediately.

RECLINING buttons Adjusts the angles between the back rest, seat and the foot rest. The back rest, seat and foot rest move in conjunction with each other. **OPERATION ON/OFF button** Used for switching the operation ON/OFF. **FOOT REST buttons** Adjusts the angle of the foot rest. **ROLLER POSITION buttons** **HOME POSITION button** Used to return the back rest, foot rest and seat to their home positions.

Used to position the massaging rollers at your shoulders or move them up and down. **WHOLE BODY SENSOR AUTOMATIC COURSE buttons** Used to select the desired type of Whole Body Sensor Automatic Course. **BEST POSITION button** Used to adjust the back rest, foot rest and seat to the three preset best positions. **FULL AUTO button** Used to measure the degree of stress and stiffness using the sensors and massage your body automatically based on the measurement results. **AGE buttons** Used to measure the degree of stress and stiffness. **AUTOMATIC COURSE buttons** Used to select the desired type of Automatic Course. **MANUAL (AIR) MASSAGE buttons** Used to select the desired type of lower body air massaging. **SHIATSU ON/OFF buttons** **MANUAL (ROLLER) MASSAGE buttons** Used to select the desired type of upper body massage. Used to turn ON/OFF shiatsu massage for your calves and soles (the corresponding lamp lights up when the shiatsu massage is ON). **SENSOR ADJUST button** Used if the sensors do not detect stress and stiffness correctly due to your skin condition such as dry skin (the red lamp lights up when the sensor adjustment is ON).

ROLLER ADJUST buttons Adjusts the width and speed of the massaging rollers in five stages. **SOLE WARMER ADJUST button** **7** Used to turn ON (HIGH/LOW) or OFF the sole warmer (the HIGH lamp lights up when the sole warmer is ON in HIGH mode; the LOW lamp lights up when the sole warmer is ON in LOW mode). Repeat display Flickers if you press the Repeat button on the sensor controller to repeat the current massage in a Whole Body Sensor Automatic Course or Automatic Course. Illuminates if the fingers (hand) are not placed on the sensor during a measurement of stress and stiffness in the Whole Body Sensor Automatic Courses.



[You're reading an excerpt. Click here to read official SANYO HEC-DR8700 user guide](http://yourpdfguides.com/dref/3810397)

<http://yourpdfguides.com/dref/3810397>

Body areas that can be massaged.

Areas where a high degree of stiffness has been detected. Areas where a low degree of stiffness has been detected. STIFFNESS display The upper part of the lamp indicates the degree of stiffness, and the lower side of the lamp indicates the degree of relaxation. The more the upper part of the lamp is illuminated, the higher the degree of detected stiffness. STRESS display Shows the degree of stress after stress measurement.

Shoulder position measurement / Original position display The "SHOULDER" icon flickers when the user (the shoulder position) is being measured, and "ADJUST" lights up when the measurement is over. WHOLE BODY SENSOR AUTOMATIC COURSE display Turns on during a Whole Body Sensor Automatic Course. (flickers) does not light up if the fingers (hand) are not placed on the sensor correctly. SOLE WARMER display Turns on when the sole heater is on. STRESS/STIFFNESS sensor mode display The following icon appears sensor modes. Stress measurement mode Stiffness measurement mode Body pressure display Shows the degree of pressure between your body and the massaging rollers. STRENGTH adjustment display Shows the degree of massage strength. You can adjust the massage strength while this indicator is lit, by using the STRENGTH UPPER BODY and LOWER BODY buttons. Sensor controller Front Rear Sensors The degree of perspiration is measured if the fingers are placed on the sensors during a Whole Body Sensor Automatic Course. Grip the sensor controller with both fingers (hands) so that the four sensors at the upper and lower portions are touched.

(Stress will be measured based on heart rate variability .) Grip the sensor controller with one fingers (hand) so that the lower three sensors are touched. (Stiffness will be measured based on the amount of perspiration from your hand.) RECLINING buttons Adjusts the angle between the back rest and foot rest.

The back rest and foot rest are moved in conjunction with each other. To measure stress Repeat button If this button is pressed during Whole Body Sensor Automatic Courses or Automatic Courses, the current massage pattern will be repeated once. To measure stiffness Sensors react to the surrounding situation. 8 HOW TO PLACE THE MASSAGER How to move the massager When carried by two people. When moving using the casters. Hold by the back rest and foot rest when moving.

Back rest Foot rest Lift up the front and move using the casters. Press the BEST POSITION button to fold down the back rest. Casters NOTE Before moving the massager, be sure to remove the power plug from the outlet. Be careful not to step on the power cord, remote control or sensor during movement. Be sure to move the massager with the assistance of another person on an easily damaged floor surface or concrete surface.

WARNING Do not suddenly release your hand while raising the foot rest manually. To ensure safety, release your hand gently from Slowly the foot rest.

Decide where to place it 1 Lay a carpet, etc. on the set-up area. 2 Ensure there is sufficient space to allow the massager to recline.

To prevent damaging the floor and muffle the noise while massaging. In order not to touch the wall or other things when reclined, allow a clearance of 60 cm (23 5/8") or more to the front and 60 cm (23 5/8") or more to the back. 60 cm (23 5/8") or more Foot rest 60 cm (23 5/8") or more Carpet Back rest NOTE Place the massager on a level floor surface. Keep the massager at least 1 m (39 3/8") away from AV products like a TV or radio. Otherwise, the program may be disturbed by noise. Do not keep the massager in a place with high humidity like a bathroom. Do not keep the massager in a place where it will be exposed to direct sunshine for an extended period, yor in a place near a heater where the temperature may reach high levels. 9 HOW TO INSTALL THE STAND Tools needed: Phillips (crosshead) screwdriver Screwdriver is not included. Installation screws are included in the accessory box. (See page 6) 1 Remove the cover attached to the right face of the right arm rest.

Cover 4 Put the remote control on the remote control stand (upper part). Put the sensor controller on the sensor controller stand (lower part). Place the remote control in the remote control stand as indicated by arrows and then push it in the direction of arrow . Remote control stand Remote control If the remote control stand moves too loosely, tighten the hand screw. Sensor controller stand Gently pull the lower portion of the cover toward you. Sensor controller 2 Secure the stand on the right-hand side of the arm rest, using the installation screws (3 screws). 5 Place the sensor cable into the hook on the left side of the sensor stand. Stopper Attach so that the stopper is set into the top of the hook. Hand screw Hook Installation screws Sensor controller cord 3 Reattach the cover to the right side of the arm rest. 6 Place the remote control cable into the hook on the right side of the sensor stand.

Remote control cord Hook Press the lower portion of the cover until you hear a click. 10 PRIOR TO USE 1 Check the upholstery of the chair. WARNING Be sure to check that the upholstery is not torn before using the massager. If a tear is found, stop using the massager immediately, disconnect the power plug from the wall outlet and consult the place of purchase. Do not use the massager if the upholstery is torn, otherwise injury or electric shock may occur.

2 Check the power cord, remote control cord and sensor controller cord. Check that there is neither breakage nor damage to the cords. Check that the cords are not caught between the back rest and the arm rest, and that they are not placed beneath the massager. 3 Insert the power plug into an outlet. Set the POWER switch to the "ON" position.

Connect the power source. Power switch Press WARNING At first, do not attempt to select a strong method of massaging (until you are accustomed to massaging). Do not recline the back rest deeply. Do not lean on the back rest forcibly. Do not massage with the back pad flipped to the rear of the back rest. Do not attempt to continuously use the massager on one place for an extended period. Do not attempt to speed up the movement of the massaging rollers or increase the strength of massage. Otherwise, strong massaging at first may result in injury. Particularly, aged persons and those who have weak bones need to use the massager with great care. 11 ADJUSTMENT OF CHAIR Before sitting on the massage chair Bring all parts of the massage chair to their home position by pressing the HOME POSITION button.

Sitting on the massage chair while the foot rest is being raised is dangerous. Be sure to lower the foot rest completely before sitting on the massage chair.



[You're reading an excerpt. Click here to read official SANYO HEC-DR8700 user guide](http://yourpdfguides.com/dref/3810397)
<http://yourpdfguides.com/dref/3810397>

The chair will be automatically brought to its home position by pressing the HOME POSITION button. Foot rest Back rest 1 Install the head rest. Hook-and-loop fasteners Remove the Hook-and-loop fasteners and pass the cord through. Cord Align the Hook-and-loop fasteners. 2 Sit on the center of massage chair. Sit deeply in the massage chair so that the waist touches the back rest. Center of the chair WARNING Do not attempt to stand on the foot rest when the foot rest slide position and angle are not completely returned to the home positions. If this is not done, the user may fall over, resulting in an accident or an injury, and the floor may be damaged.

For safety, check that the massaging rollers are located at their origin about shoulder height and then sit on the chair slowly. Be sure to keep your body straight without twisting and center between the left and right rollers. If it is not observed, an accident or injury may occur. Foot rest 3 Adjust the position of the head rest. During the massage, adjust the head rest so that it does not touch the shoulders.

Head rest WARNING Do not swing the head rest because it contains a weight. If it is not observed, injury may occur. Do not wear accessories (such as a necklace or earrings) while massaging. If it is not observed, an accident or injury may occur. 12 ADJUSTMENT OF CHAIR (continued) 4 Press the OPERATION ON/OFF button.

When the button is pressed, the lamps of the sole warmer and remote control will illuminate, and the sole warmer will turn on. @@@@[at the origin] During the movement, the icon of "ORIGIN" on the remote control flickers. 5 Adjust the angle of back rest, foot rest, and the seat. Pre-set Angles Press the BEST POSITION button. Reclining positions change automatically at each press of the button. (Button illuminates while reclining and flickers when in position) BEST POSITION 1 BEST POSITION 2 Button Illuminates Illuminates Illuminates BEST POSITION 3 Lamp Illuminates Flashes Flashes At BEST POSITION

During the reclining motion When you stop reclining BEST POSITION 1 Posture suited for whole body massaging BEST POSITION 2 Posture suited for lower body and air massaging Automatically starts massaging BEST POSITION 3 Posture suited for stretching STRETCH course massage will in Air Course. be selected automatically. (massage courses other than COMFORT AIR COURSE and STRETCH cannot be selected). Reclining (massage courses other than COMFORT AIR COURSE and STRETCH cannot be selected). can be stopped during the reclining motion by pressing either the BEST POSITION button, HOME POSITION button, RECLINING button, FOOT REST button, OPERATION ON/OFF button, or STOP button.

Stretch course The back rest and foot rest angles are adjusted automatically. WARNING Be sure to check that there is no person (children in particular), or any pets under the foot rest and that there are no other obstructions in the way before reclining the back rest or lowering the foot rest or when using the stretch function. In addition, do not leave the foot rest in the raised position when not in use. If this is not observed, accidents or injury may occur. 13 5

Custom Angles Keep pressing the RECLINING button until the desired angle is achieved. RECLINING Raise the back rest, and lower the foot rest by continuously pressing the () button. 120° Foot rest Adjustment range Approx. 50° Recline the back rest, and raise the foot rest by continuously pressing (Remote control) (Sensor controller) the () button. When OR adjusted at BEST POSITION, the seat is lowered together with the above mentioned movement. (It is not possible to adjust only the seat.

) Back rest Adjustment range Approx. 90° For the sake of safety, if the () button is pressed with the seat raised, the foot rest may be raised briefly before going down. WARNING Be sure to check that there is no person (children in particular), or any pets under the foot rest and that there are no other obstructions in the way before reclining the back rest or lowering the foot rest or when using the stretch function. In addition, do not leave the foot rest in the raised position when not in use. If this is not observed, accidents or injury may occur.

If you are using air bags in a calf & foot air massage, do not attempt to recline, or use force to pull out your legs. If this is not observed, injury may occur. At first, do not attempt to recline the seat deeply or lean on the back rest forcibly (until you have become accustomed to massaging). If the massaging force is too strong at first, it may result in adverse effects or injury. 6 Adjust the angle of the foot rest.

The angle of the foot rest can be adjusted independently. Keep the FOOT REST button pressed until the desired angle is achieved. When massaging the soles or calves, adjust the angle so that the massaging part of the foot rest touches the soles or calves. Raise the foot rest by continuously pressing the button.

Lower the foot rest by continuously pressing the button. Foot rest (Remote control) Adjustment range Approx. 90° WARNING Do not suddenly release your hand while raising the foot rest manually. To ensure safety, release your hand gently from the foot rest. Slowly 14 ADJUSTMENT OF CHAIR (continued) 7 Adjust the position (sliding length) of the foot rest. Adjust the position (sliding length) of the foot rest to fit the length of your legs.

While Pull the lever toward you. Release when desired position is achieved. Slide lever for foot rest pulling the slide lever for the foot rest, set the foot rest in the desired position. Release the slide lever to lock the foot rest in position. (Foot rest sliding length : Maximum approx. 21 cm (8 1/4")) WARNING Be Push the foot rest with your soles to extend. sure to check that there is no person (children in particular), or any pets under the foot rest and that there are no other obstructions in the way before reclining the back rest or lowering the foot rest or when using the stretch. In addition, do not Raise your feet slightly leave the foot rest in the raised position when not Foot rest to retract. in use. If this is not observed, accidents or injury may occur.

Be careful not to put your hand or foot into the spaces between any moving parts, including into the space between the back rest and arm rest or into the space at the underside of the back rest or between the foot rest and the seat or into the space under the foot rest. Furthermore, do not place your hands, feet or head inside the upholstery of the massager. If this is not observed, accidents or injury may occur. Do not attempt to adjust the foot rest slide while reclining. If this is not done, accidents or injury may occur.

Do not attempt to stand on the foot rest when the foot rest slide position and angle are not completely returned to the home positions.



[You're reading an excerpt. Click here to read official SANYO HEC-DR8700 user guide](http://yourpdfguides.com/dref/3810397)

<http://yourpdfguides.com/dref/3810397>

If this is not done, the user may fall over, resulting in an accident or an injury, and the floor may be damaged. To return the massager to the home position, press the HOME POSITION button. The HOME POSITION button lights up and the chair automatically returns to its home position. The foot rest is raised first, and then lowers completely.

Foot rest Back rest 15 FEATURES OF COURSES WHOLE BODY SENSOR AUTOMATIC COURSES Features of courses Automatic massages based on the degrees of stress and stiffness measured by sensors prior to massaging. Massages using a whole body Sensor automatic course program based on the degree of stiffness detected by sensors. (See page 17-20) Massaging on the degree of stress and stiffness detected by sensors Sub-courses Features of program Fully automatic massage based on the degrees of stress and stiffness In stress measurement mode, only air massage of your legs is performed. FULL AUTO STIFFNESS RECOVERY RELAX QUICK Shiatsu massage to counteract stiffness Tapping massage to ease muscle fatigue Kneading massage to relax the whole body Short massage to promote blood circulation (Reduced time course) The degree of stress and stiffness are measured by placing your fingers (hand) on the sensors. Massaging of each course is possible without placing fingers (hand) on the sensor. In this case the degree of stress and stiffness is not detected. AUTOMATIC COURSES Easy 1 or 2-button operation Massages automatically by effective combination of gripping, kneading up, kneading down, tapping, combo (tapping and kneading), shiatsu, full stretching, partial stretching, focus stretching, and lower body (air) massage. (See page 21-22) Features of program Massages mainly the neck and shoulders Massages mainly the waist and lower back Air massage of the whole body Stretch to relax the whole body Sub-courses NECK & SHOULDER LOWER BACK COMFORT AIR COURSE STRETCH MANUAL COURSES Full programable upper and lower body massage Massages with your own adjustment of massage types such as gripping, kneading up, kneading down, tapping, combo (tapping and kneading), shiatsu, full stretching, partial stretching, focus stretching, and lower body (air) massage. (See page 23-27) Features of program Multiple roller massages (for upper body) and air massages (for lower body) are available. When the massaging rollers detach from the body during the Whole Body Sensor Automatic Course or the Automatic Course, the body pressure sensor will work to stop the operation by pulling back the massaging rollers for safety.

@@@ Press the button to select the desired course. @@@@ When stress measurement is completed... @@ Air massage of your legs starts. @@ Your heart rate is extremely high, after exercise for example. Electrocardiographic monitoring with both hands is not possible. In some cases it may take maximum 2 minutes 30 seconds for the sensor to activate. and icons flash (a beep sounds) in turn. And stiffness measurement will start.

NOTE If your skin is dry, the degree of stress/stiffness may not be measured correctly. In such a case, press the SENSOR ADJUST button (the SENSOR ADJUST lamp is lit when the sensor adjustment mode is ON). Wash your hands clean for the correct degree of stress. (Sebum or dirt interrupt the stress measurement.) 18 MASSAGING (WHOLE BODY SENSOR AUTOMATIC COURSES) (continued) 7 Stiffness is measured.

Grip the sensor controller with your fingers (with one hand) so that three sensors are touched. Be sure to place your fingers (hand) on the sensor. The degree of stiffness cannot be measured if your fingers (hand) are not placed on the sensor. @@ (The icon lights up when the user is being measured.) If your fingers (hand) are not touching the sensor points, massages will be carried out according to the standard operation of the selected course.

Before gripping the sensor After gripping the sensor How to grip the sensor controller when the icon is shown on the remote control display Rear of sensor controller Sensors Measure the position of shoulder. Check if the position of shoulder is correct. If not, adjust the position using the ROLLER POSITION buttons. (The ROLLER POSITION buttons can also be used while massaging is in progress.) Measurement of shoulder position Massaging rollers move up and down to measure the position of shoulder. (Sit deeply on the massage chair and raise your head slightly. The matching of the position of shoulders may not be possible if the head is leaning on the back rest.) Massaging operation at recognized position of shoulder. Check that massaging rollers match the position of your shoulder. If not, when the lamp of is flickering (a beep sounds), adjust the position by pressing the ROLLER POSITION buttons.

The massaging rollers are moved up or down by approx. 1 cm (3/8") each time the ROLLER POSITION button is pressed. When it is difficult to adjust with ROLLER POSITION button, move your body for adjustment. The height that can be adjusted is between approx. 150 (59 1/4") to 180 cm (71"). (Remote control display) Position too high Appropriate position Position too low Decides the position of shoulder. Massaging rollers Sensor massaging will start. Measures the degree of stiffness in each part of body with the sensor and informs of the degree of stiffness. Displays the aim of massaging positions, the stiffness, body pressure and the remaining massaging time on the remote control. The explanation uses stiffness as an example.

SENSOR MESSAGE Measurement of the degree of stiffness. Displays the position where the The sensor will display the positions of stiffness stiffness has been detected. (those where stiffness has been detected) by measuring the amount of perspiration from your hand in reaction to sensor massage. Body areas that can be massaged. Areas where a high degree of stiffness has been detected.

Areas where a low degree of stiffness has been detected. 19 7 Massages according to detected stiffness. FULL AUTO : Massages according to detected stress and stiffness. Adjusts the operation and strength of standard massaging according to the measured degree of stiffness. The STRESS indicator disappears.

8 Adjust the strength of massage. UPPER BODY Each time the UPPER button is pressed, the strength of upper body massaging can be adjusted in five stages. (The strength is displayed by the lamp on the remote control.) LOWER BODY Each time the LOWER BODY STRENGTH ADJUST button is pressed, the strength of lower body massaging (air) can be adjusted in three stages. (The strength is displayed by the lamp on the remote control.) If you continue to press the " " button until the illumination of the lower body strength scale turns off, you can turn off the massaging of the lower body. If you press the " " button, the massaging will resume. SHIATSU(CALF/SOLE) The ON/OFF state of sole/calf shiatsu massage toggles each time the button is pressed.



[You're reading an excerpt. Click here to read official SANYO HEC-DR8700 user guide](http://yourpdfguides.com/dref/3810397)

<http://yourpdfguides.com/dref/3810397>

(when calf/sole shiatsu massage is on, the corresponding lamp is lit.) When it is felt that the massaging on the soles or calves is too strong even when reducing the strength of lower body (air) massaging, use the SHIATSU ON/OFF button or put a towel etc.

on those massaged parts. Finishes massaging automatically by timer operation. Massaging rollers are moved to the upper position, and stop massaging automatically. The beep sounds and the lamp on the remote control will turn off. The massaging time differs according to the detected stiffness, but the maximum is approx. 20 minutes. The massaging rollers are moved to the upper position and are stopped. [at the origin] NOTE Try to be relaxed while you are massaging. Immediately after taking a bath or when watching TV, you may not be able to measure the degrees of stress and stiffness correctly. Measured based on heart rate variability .

Stress Stiffness Measured based on the amount of perspiration on your hand. The measurement results show the biological response of your body and may not match your feelings of stress and stiffness. Heart rate variability depends on age that is classified into three generations. 20 MASSAGING (AUTOMATIC COURSES) 1 4 5 3 2 4 1 Press the OPERATION ON/OFF button. When the button is pressed, the lamps of the sole warmer and remote control will illuminate, and the sole warmer will turn on.

@@@@[at the origin] (During the movement, the icon of "ORIGIN" on the remote control flickers.) (See page 23) 2 Open the cover of the remote control. 3 Turn the sole warmer ON/OFF. 4 Adjust the positions of the back rest and the foot rest. 5 Press the desired Automatic Course button.

LOWER BACK COMFORT AIR COURSE STRETCH NECK & SHOULDER (See page 17) (See page 12-15) Massages mainly the neck and shoulders Massages mainly the waist and lower back Air massage of the whole body Stretch to relax the whole body COMFORT STRETCH AIR COURSE can be operated simultaneously with NECK & SHOULDER or LOWER BACK. COURSE cannot be operated simultaneously with any other courses. Refer to the page 32 regarding the massaging contents of Automatic Courses. Change of course while massaging, or change to the Whole Body Sensor Automatic Courses or the Manual Courses, is possible. Stretch course The back rest and foot rest angles are adjusted automatically. Be WARNING sure to check that there is no person (children in particular), or any pets under the foot rest and that there are no other obstructions in the way before reclining the back rest or lowering the foot rest or when using the stretch function. In addition, do not leave the foot rest in the raised position when not in use. If this is not observed, accidents or injury may occur. 21 starts 6 The massager position massaging automatically. Measure the of shoulder.

Check if the position of shoulder is correct. If not, adjust the position using the ROLLER POSITION buttons. (The ROLLER POSITION buttons can also be used while massaging is in progress.) Measurement of shoulder position (Sit deeply on the massage chair and raise your head slightly. The matching of the position of shoulders may not be possible if the head is leaning on the back rest.) Massaging rollers move up and down to measure the position of shoulder.

Massaging operation at recognized position of shoulder. Check that massaging rollers match the position of your shoulder. If not, when the lamp of is flickering (a beep sounds), adjust the position by pressing the ROLLER POSITION buttons. (Remote control display) 3/8") The massaging rollers are moved up or down by approx.

1 cm (Position too high each time the ROLLER POSITION button is pressed. When it is difficult to adjust with ROLLER POSITION button, move Appropriate position your body for adjustment. The height that can be adjusted is Position too low between approx. 150 (59 1/4") to 180 cm (71") . Massaging rollers Decides the position of shoulder.

Starts the massaging of selected course. Displays the aim of massaging positions, the stiffness, body pressure and the remaining massaging time on the remote control. The following explanation assumes that you are performing a NECK & SHOULDER course. The position of current massage flickers. Massaging concentrated on the neck and shoulders will be carried out.

The timer will operate and then stop. After the rollers have retracted, the display will turn off. 7 Adjust the strength of massage. UPPER BODY LOWER BODY Each time the UPPER button is pressed, the strength of upper body massaging can be adjusted in five stages. (The strength is displayed by the lamp on the remote control.) Each time the LOWER BODY STRENGTH ADJUST button is pressed, the strength of lower body massaging (air) can be adjusted in three stages. (The strength is displayed by the lamp on the remote control.) When it is felt that the massaging on the soles or calves is too strong even when reducing the strength of lower body (air) massaging, use the SHIATSU ON/OFF button or put a towel etc. on those massaged parts. (See page 20) Finishes massaging automatically by timer operation.

The massaging rollers are moved to the upper position and are stopped automatically approx. 15 minutes after starting the operation. The beep sounds and the lamp on the remote control will turn off. 22 MASSAGING (MANUAL[ROLLER] COURSES) Massaging of upper body 1 4 6 5 2 4 6 3 1 Press the OPERATION ON/OFF button. When the button is pressed, the lamps of the sole warmer and remote control will illuminate, and the sole warmer will turn on.

@@@@[at the origin] (During the movement, the icon of "ORIGIN" on the remote control flickers.) Cover 2 Open the cover of the remote control. If an excessive force is applied to the cover, it may be detached. In such a case, re-attach the cover according to the following procedure. How to attach the cover Align the left hook on the back of the cover with the left post on the remote control.

Hook Align the right hook on the back of the cover with the right post on the remote control and push the cover onto the remote Hook control. Post Post 3 Turn the sole warmer ON/OFF. 4 Adjust the positions of the back rest and the foot rest. (See page 17) (See page 12-15) 23 5 Press the desired ROLLER MASSAGING button. to pages 25-26 for details of the contents of massage.

For spine stretching (full), the shoulder position is first measured. When the position of shoulder is not correct, adjust the position of massaging rollers. (See page 19) During massaging operation, the operation can be changed to other manual massage, Whole Body Sensor Automatic Course or Automatic Courses. It is possible to operate the upper body massage and lower body massage simultaneously. Refer ROLLER MASSAGE buttons (for upper body) 6 Adjust the height, width, speed, and strength of the massaging rollers.



[You're reading an excerpt. Click here to read official SANYO HEC-DR8700 user guide](http://yourpdfguides.com/dref/3810397)
<http://yourpdfguides.com/dref/3810397>

There are some adjustments which are not possible, depending on the type of massage chosen. (See page 25-26) Adjusting the height of massaging rollers. Adjusting the strength of roller massaging. Press the button. The massaging rollers will move up if the UP () button is pressed continuously and move down if the DOWN () button is pressed continuously. The approximate position of the massaging rollers is indicated by the lamp on the remote control. Press the button. The strength of the massage will change each time the button is pressed, and is indicated by the lamp on the remote control. (in five stages) Adjusting the width of the massaging rollers. Adjusting the movement speed of massaging rollers.

Press the button. The width of the massaging rollers will change each time the button is pressed and is indicated by the lamp on the remote control. (in five stages) Press the button. The speed of the massaging rollers will change each time the button is pressed, and is indicated by the lamp on the remote control. (in five stages) Finishes massaging automatically by timer operation. The massaging rollers are moved to the upper position and are stopped automatically approx. 15 minutes after starting the operation. The beep sounds and the lamp on the remote control will turn off. If a different course button (manual) is pressed during the course of operation, the massage will be completed by operation of the timer approx. 30 minutes after starting the massage selected first.

The massaging rollers are moved to the upper position and are stopped. [at the origin] 24 MASSAGING (MANUAL [ROLLER] COURSES) (continued) Types of massage and adjustments of massaging rollers 24 types of desired massage can be selected. It is possible to adjust the movement speed, height position and width of massaging rollers and the strength of massage. (There are some adjustments that are not possible, depending on the type of massaging. Refer to the tables below.

) Adaptation No adaptation Individual massages Adjustment of massaging rollers Type of massage Height Strength Speed Width Operation Kneading while gripping shoulders Kneading upward Kneading downward Tapping Combined tapping and kneading actions Shiatsu massage Spinal stretch along the entire length of back Spinal stretch along a 210 mm (8 1/4") region of back Spinal stretch along a 110 mm (4 3/8") region of back felt To stop the massage during operation. @@@@ (The massaging rollers move to the upper position and remain in that position.) After the movement, repeat the operation to begin a massage. 25 Combined massages Adjustment of massaging rollers Type of massage Height Strength Speed Width Operation Massaging by spine stretching (full) with kneading upward operation Massaging by spine stretching (partial) with kneading upward operation Massaging by spine stretching (focus) with kneading upward operation Massaging by spine stretching (full) with kneading downward operation Massaging by spine stretching (partial) with kneading downward operation Massaging by spine stretching (focus) with kneading downward operation Massaging by spine stretching (full) with tapping operation Massaging by spine stretching (partial) with tapping operation Massaging by spine stretching (focus) with tapping operation Massaging by spine stretching (full) with tapping and kneading operations Massaging by spine stretching (partial) with tapping and kneading operations Massaging by spine stretching (focus) with tapping and kneading operations Massaging by spine stretching (full) with shiatsu operation Massaging by spine stretching (partial) with shiatsu operation Massaging by spine stretching (focus) with shiatsu operation 26 MASSAGING (MANUAL[AIR] COURSES) Massaging of lower body Simultaneous massaging of any part of "upper body (roller)" and "lower body (air)" is possible. Independent massaging of "upper body (roller)" and "lower body (air)" is possible.

1 to 4 are the same operation for massaging the upper body. When massaging the upper body, continue to operation 5. 1 4 5 6 3 2 4 1 Press the OPERATION ON/OFF button. 2 Open the cover of the remote control. 3 Turn the sole warmer ON/OFF. 4 Adjust the positions of the back rest and the foot rest. 5 Press the desired AIR LOWER BODY CALF & FOOT THIGH & BACK TWIST MASSAGING button. (See page 23) (See page 17) (See page 12-15) During massaging operation, you can change to a different manual massage, Whole Body Sensor Automatic Courses, or Automatic Courses. TWIST cannot be used together with other massaging. LOWER BODY Air massage mainly on the lower body CALF & FOOT Air massage of the legs and soles of the feet THIGH & BACK Air massage of thighs and lower back TWIST To carry out air massaging of the hips at left and right alternately.

LOWER 6 By pressing the massage.BODY strength adjustment button, adjust the strength of The strength of massage will change each time the button is pressed, and is indicated by the lamp on the remote control. (in three stages) Finishes massaging automatically by timer operation. It will stop automatically approx. 15 minutes after starting the operation. The beep sounds, and the display part of the remote control turns off. 27 ADJUSTING MESSAGE INTENSITY

When the massage is too strong Use the massager after placing a towel, etc., on the back pad. WARNING Towel At first, do not attempt to recline the seat deeply or lean on the back rest forcibly (until you have become accustomed to massaging). If the massaging force is too strong at first, it may result in adverse effects or injury.

When the massage is too weak Flip the back pad to the rear. Remove the head rest from the back pad. Head rest Back pad Flip the back pad to the rear. Back pad Attach the head rest to the back rest. Head rest WARNING Do not swing the head rest because it contains a weight.

If it is not observed, injury may occur. Back pad 28 AFTER USE WARNING After use, be sure to set the POWER switch to the [OFF] position, and be sure to disconnect the power plug from the outlet. 1 Bring the back rest and foot rest to their home position. If the foot rest is extended, pull the slide lever and return the foot rest to the original position. Press the HOME POSITION button to bring the seat, back rest, and foot rest to their home position.

Pull the lever toward you. Release when desired position is achieved. Slide lever for foot rest WARNING Be sure to check that there is no person (children in particular), or any pets under the foot rest and that there are no other obstructions in the way before reclining the back rest or lowering the foot rest or when using the stretch. In addition, do not leave the foot rest in the raised position when not Raise your feet slightly Foot rest in use.



[You're reading an excerpt. Click here to read official SANYO HEC-DR8700 user guide](http://yourpdfguides.com/dref/3810397)

<http://yourpdfguides.com/dref/3810397>

to retract. If this is not observed, accidents or injury may occur. Be careful not to put your hand or foot into the spaces between any moving parts, including into the space between the back rest and arm rest or into the space at the underside of the back rest or between the foot rest and the seat or into the space under the foot rest. Furthermore, do not place your hands, feet or head inside the upholstery of the massager. If this is not observed, accidents or injury may occur. Do not attempt to adjust the foot rest slide while reclining.

If this is not done, accidents or injury may occur. Do not attempt to stand on the foot rest when the foot rest slide position and angle are not completely returned to the home positions. If this is not done, the user may fall over, resulting in an accident or an injury, and the floor may be damaged. Push the foot rest with your soles to extend. 2 When the display part of the remote control does not turn off, press the OPERATION ON/OFF button. Turn off the POWER. Close the cover of remote control. Put the remote control and the sensor controller back on the stand. Set the POWER switch to the [OFF] position. POWER switch 3 29 Unplug the power cord from the outlet.

MAINTENANCE PROCEDURES WARNING Be sure to disconnect the power plug from the outlet prior to maintenance. **NOTE** Do not attempt to use benzene, thinner, alcohol, alkaline detergent or bleaching agent for cleaning, as this may result in deformation, discoloration or cracking. Do not wash the head rest or the back pad. This may cause discoloration or deformation. **HEAD REST, BACK PAD, SEAT COVER, ARM REST (SYNTHETIC LEATHER PARTS)** Perform daily maintenance by wiping with a soft dry cloth.

When they are badly soiled, adopt the following maintenance procedure: Soak a soft cloth in diluted neutral kitchen detergent and squeeze it well. Wipe the main unit with the damp cloth in a tapping motion. Soak a cloth in clean water, and squeeze it well. Wipe off the remaining detergent with the damp cloth. Wipe it with a dry cloth afterwards.

Do not force-dry with a drier. Do not make contact with synthetic leather products for an extended period. It may cause discoloration. **MAIN UNIT (Cloth, plastic parts and frame), REMOTE CONTROL, SENSOR CONTROLLER** Soak a soft cloth in diluted neutral kitchen detergent, and squeeze it well. Wipe the main unit with the damp cloth, and wipe it with a dry cloth afterwards. 30 **TROUBLE-SHOOTING WARNING** If the trouble still persists even after the following proper countermeasures have been taken, stop using the massager to avoid possible accidents. Disconnect the power plug from the outlet and consult an authorized service center. Do not attempt to repair the equipment at home by yourself, as it is very dangerous. Sounds and sensations during operation Sounds and sensations such as the following may occur while the massager is operating, but these occur as part of the normal mechanism of the massager and are not the signs of a malfunction. (They have no effect on normal functioning.

) Rattling sound during tapping The sound of massaging rollers moving up and down and the sound of kneading operation (Knocking, clinking, rubbing or whistling sounds) Creaking sound caused by massaging rollers and cloth during massaging operation. Gear meshing sound Wobbling of the foot rest Creaking or sliding sounds when reclining Sound of air massaging Whooshing sound (switching valve sound) Hissing or blowing sound (air exhaust sound) Sounds from the pump operating Sound of the air bag filling up Small sounds and shocks coming from the massaging rollers when massaging near the waist Bouncing movement of the massaging rollers when they move from the back to the shoulder Type of Trouble Operation failure Check points Countermeasure Push the power plug into the outlet securely. (See page 11) Press the POWER switch to the [ON] position. (See page 11) Please press each button separately.

After adjusting the angle of back rest, select the massaging button. (See page 13) be selected. Movement of massaging rollers in upward direction, causing operation to stop. The operation stops in the middle of massaging in the Whole Body Sensor Automatic Course or Automatic Course Reclining is not possible. The foot rest cannot be raised or lowered. The foot rest cannot be extended.

Check that the power plug is securely plugged into the outlet. Check that the POWER switch is set to the ON position. Make sure that no more than one button is being pressed at any one time. Courses other than Air Course cannot Check if the chair is set to the BEST POSITION 2 or 3. This phenomenon is caused by the operation of the timer, but is not a problem.

When the massaging rollers detach from the Begin the operation again from the start. body, the body pressure sensor will work to stop the operation automatically. Is it being obstructed by something? Remove the obstruction. reclining. (Move toward the opposite direction temporarily, or do not move smoothly.

) The position of massaging rollers differ between right and left. The "Grip the Sensor" indicator remains on the remote control display, preventing stress/stiffness measurement. The display of stress and stiffness differs from the degree of stress and stiffness actually felt. Check if you attempt to adjust the foot rest with Adjust the foot rest with the foot rest slide lever the foot rest slide lever pulled. pulled. (See page 15) Check that the foot rest is not extended.

Return the foot rest by pulling the foot rest slide The foot rest cannot be stored. lever. (See page 15) You feel discomfort during the operation of This operation is conducted for safety, but is not a problem. This phenomenon is caused by the adoption of the function of alternative tapping on the right and left sides, but is not a problem.

Check your skin for dryness. Press the SENSOR ADJUST button. (See page 18) Slightly moisten your hand using hand cream and place the fingers (hand) on the sensor again. Check if your fingers (hand) are placed on the sensor. Place your fingers (hand) on the sensor. (See page 18) The measurement result indicates the stress and stiffness according to the body's biological reaction to the sensor massage, so it may differ from the stress and stiffness the user actually feels. Massage in relaxed condition as much as possible. The degree of stiffness may not be measured correctly when the user massages immediately after taking a bath or is given stimulation other than sensor massage, like watching TV. **NOTE** If people who are heavier than the maximum weight (120 kg (265 lbs) or more) use the massager, it may stop operating suddenly. 33 **SPECIFICATIONS** Power consumption Power dissipation of electric heating equipment Rated time 200 W 33 W 30 min.

WHOLE BODY SENSOR AUTOMATIC COURSES FULL AUTO Approx. 17 minutes **STIFFNESS, RECOVERY, RELAX** Approx. 15 minutes **QUICK Course** Approx. 8 minutes (Maximum of approx. 20 minutes due to stiffness detection) **AUTOMATIC COURSES** Approx.



[You're reading an excerpt. Click here to read official SANYO HEC-DR8700 user guide](http://yourpdfguides.com/dref/3810397)

<http://yourpdfguides.com/dref/3810397>

15 minutes MANUAL COURSESAprox. 15 minutes 730 mm(28 3/4") [width]×1,370 mm (53 7/8") [depth]×1,220 mm (48") [height] When upright (with foot rest retracted) 730 mm (28 3/4") [width]×1,940 mm (76 3/8") [depth]×760 mm (29 7/8") [height] When reclined (with foot rest set horizontally) Aprox. 90 kg (198 lbs) Aprox. @ @9 24 times/min. (5 stages) Aprox. @ @110 mm (4 3/8") Vertical stroke length approx. @ @ @ @1 cm (3/8") /one press of button Aprox. 120170° Back rest: Motor-driven type (Linked with foot rest) Foot rest: Motor-driven type (Foot rest only) Seat surface: Motor-driven type (Linked with back rest and foot rest) (3 stages) Aprox. 1127 kPa There is a slight difference according to the part. Do not use the massager on other than the designated voltage. 34 SANYO MASSAGE LOUNGER LIMITED WARRANTY OBLIGATIONS (USA ONLY) HEC-DR8700 In order to obtain warranty service, the product must be delivered to and picked up from an Authorized Sanyo Factory Service Center at the user's expense, unless specifically stated otherwise in this warranty. If you need assistance with product operation, authorized service center referral, service assistance, problem resolution, or parts and accessories availability; you may contact us by: A. Visiting www.sanyoservice.com on a 24 hr/7 days a week basis or B. calling the customer support center at 1-800-421-5013 Weekdays 7:30 AM - 5:00 PM Pacific Time THIS WARRANTY IS VALID ONLY ON SANYO PRODUCTS PURCHASED AND USED IN THE UNITED STATES OF AMERICA. THIS WARRANTY APPLIES ONLY TO THE ORIGINAL RETAIL USER AND DOES NOT APPLY TO PRODUCTS USED FOR ANY INDUSTRIAL, PROFESSIONAL OR COMMERCIAL PURPOSE. THE ORIGINAL DATED BILL OF SALE OR SALES SLIP MUST BE SUBMITTED TO THE AUTHORIZED SANYO SERVICE CENTER AT THE TIME WARRANTY SERVICE IS REQUESTED. Subject to the OBLIGATIONS above and EXCLUSIONS below, SANYO FISHER COMPANY (SFC) warrants this SANYO products against defects in materials and workmanship for the periods of LABOR and PARTS specified below. SFC will repair or replace (at its option) the product and any of its parts which fail to conform to this warranty.

The warranty period commences on the date the product was first purchased at retail CONDITION (sold to consumers in factory-sealed cartons) LABOR 1 YEAR 60 DAYS PARTS 1 YEAR 60 DAYS ROLLER MECHANISM 3 YEARS 60 DAYS IN - HOME ** 1 YEAR 60 DAYS NEW PRODUCTS DEMONSTRATION *** FLOOR SAMPLES Note: Roller Mechanism consists of the mechanical parts directly behind the back rest of the massage chair, excluding belts. In-home service is defined as product service in the consumer home or offsite if further repairs are required. Products which have been utilized for demonstration or as floor samples. This warranty does not cover (A) the adjustment of customer-operated controls as explained in the appropriate model's instruction manual, or (B) the repair of any product whose serial number has been altered, defaced or removed. This warranty shall not apply to the following items: non-electrical / mechanical attachments; accessories; damage to head cover, back pad, arm covers, seat cover, foot rest cover when not caused by defects in workmanship.

This warranty shall not apply to setup, installation, removal of the product for repair or reinstallation of the product after repair. This warranty does not apply to repairs or replacements necessitated by any cause beyond the control of SFC including, but not limited to, any malfunction, defect or failure caused by or resulting from unauthorized service or parts, improper maintenance, operation contrary to furnished instructions, shipping or transit accidents, modification or repair by the user, abuse, misuse, neglect, accident, incorrect power line voltage, fire, flood or other Acts of God, or normal wear and tear. The foregoing is in lieu of all other expressed warranties and SFC does not assume or authorize any party to assume for it any other obligation or liability. THE DURATION OF ANY WARRANTIES WHICH MAY BE IMPLIED BY LAW (INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS) IS LIMITED TO THE TERM OF THIS WARRANTY. IN NO EVENT SHALL SFC BE LIABLE FOR SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING FROM OWNERSHIP OR USE OF THIS PRODUCT, OR FOR ANY DELAY IN THE PERFORMANCE OF ITS OBLIGATIONS UNDER THIS WARRANTY DUE TO CAUSES BEYOND ITS CONTROL. SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS AND/OR DO NOT ALLOW THE EXCLUSION OR LIMITATION OF CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE. For your protection in the event of theft or loss of this product, please fill in the information below for your own personal records. EXCLUSIONS Model No.

Date of Purchase Where Purchased Serial No. (Located on back or bottom side of unit) Purchase Price Please register your massage chair at www.sanyomassagechairs.com SANYO NORTH AMERICA CORPORATION 21605 Plummer Street Chatsworth, CA 91311 us.sanyo.com 9BF -6 -P111-336CJ-0 1009 35 .

 [You're reading an excerpt. Click here to read official SANYO HEC-DR8700 user guide](http://yourpdfguides.com/dref/3810397)

<http://yourpdfguides.com/dref/3810397>