



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for SONY HANDYCAM HDR-CX290/B. You'll find the answers to all your questions on the SONY HANDYCAM HDR-CX290/B in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual SONY HANDYCAM HDR-CX290/B**  
**User guide SONY HANDYCAM HDR-CX290/B**  
**Operating instructions SONY HANDYCAM HDR-CX290/B**  
**Instructions for use SONY HANDYCAM HDR-CX290/B**  
**Instruction manual SONY HANDYCAM HDR-CX290/B**

**SONY**

4-447-514-12(1)

Digital HD Video  
Camera Recorder

**Operating Guide**



Please also refer to:  
<http://www.sony.net/SonyInfo/Support/>

|   |  |
|---|--|
| Table of contents                         |  |
| Getting started                           |  |
| Recording/Playback                        |  |
| Saving movies and photos with a computer  |  |
| Saving images on an external media device |  |
| Customizing your camcorder                |  |
| Others/Index                              |  |

HANDYCAM.

AVCHD Progressive HDMI



HDR-CX220/CX220E/CX230/CX230E/CX280/CX280E/CX290/CX290E/  
PJ220/PJ220E/PJ230/PJ230E



[You're reading an excerpt. Click here to read official SONY HANDYCAM HDR-CX290/B user guide](http://yourpdfguides.com/dref/5026449)  
<http://yourpdfguides.com/dref/5026449>



Declaration of Conformity Trade Name: SONY Model No.

: HDR-CX230 Responsible Party: Sony Electronics Inc. Address: 16530 Via Esprillo, San Diego, CA 92127 U.S.A. Telephone No.

: 858-942-2230 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Declaration of Conformity Trade Name: SONY Model No.: HDR-PJ230 Responsible Party: Sony Electronics Inc. Address: 16530 Via Esprillo, San Diego, CA 92127 U.S.A. Telephone No.: 858-942-2230 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Regulatory Information Declaration of Conformity Trade Name: SONY Model No.: HDR-CX220 Responsible Party: Sony Electronics Inc. Address: 16530

Via Esprillo, San Diego, CA 92127 U.S.A.

Telephone No.: 858-942-2230 This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.  GB Declaration of Conformity Trade Name: SONY Model No.: HDR-CX290 Responsible Party: Sony Electronics Inc. Address: 16530 Via Esprillo, San Diego, CA 92127 U.S.A. Telephone No.: 858-942-2230 This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver.  Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  Consult the dealer or an experienced radio/ TV technician for help.

The supplied interface cable must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules. FOR CUSTOMERS IN EUROPE Notice for the customers in the countries applying EU Directives This product has been manufactured by or on behalf of Sony Corporation, 1-7-1 Konan Minato-ku Tokyo, 108-0075 Japan. Inquiries related to product compliance based on European Union legislation shall be addressed to the authorized representative, Sony Deutschland GmbH, Hedelfinger Strasse 61, 70327 Stuttgart, Germany. For any service or guarantee matters, please refer to the addresses provided in the separate service or guarantee documents. This product has been tested and found compliant with the limits set out in the EMC regulation for using connection cables shorter than 3 meters (9.

8 feet). CAUTION You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment. Note This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: GB Attention The electromagnetic fields at the specific frequencies may influence the picture and sound of this unit. Notice If static electricity or electromagnetism causes data transfer to discontinue midway (fail), restart the application or disconnect and connects.  removing LCD Panel

On recording     Before starting to record, test the recording function to make sure the image and sound are recorded without any problems.

Compensation for the contents of recordings cannot be provided, even if recording or playback is not possible due to a malfunction of the camcorder, recording media, etc.

TV color systems differ depending on the country/region. To view your recordings on a TV, you need a TV that supports the signal format for your camcorder. For details on the signal format, refer to "How to use this manual" (p. 12). Television programs, films, video tapes, and other materials may be copyrighted. Unauthorized recording of such materials may be contrary to the copyright laws. The LCD screen is manufactured using extremely high-precision technology, so over 99.99% of the pixels are operational for effective use. However, there may be some tiny black points and/or bright points (white, red, blue, or green in color) that appear constantly on the LCD screen. These pointsems, the descriptions are explained with the model name.

Safety Regulation (p. 2)  Parts and controls (p. 16)  Menu lists (p. 37)  Specifications (p. 46) 13 GB Table of contents Read this first.

.....  
.....

.....  
.....  
.....

.....  
.....  
.....

.. 2 IMPORTANT SAFETY INSTRUCTIONS..

.....  
.....  
.....  
.....

... 3 Learning more about the camcorder ("Handycam" User Guide).. . . . .

.....

... 11 Selecting items on the LCD screen..

.....  
.....  
.....  
.....

..... 11 Supplied Items.

.....  
.....  
.....  
.....

..... 11 How to use this manual.....

.....  
.....  
.....  
.....  
.....  
.....

..... 12 Differences in functions..

.....  
.....  
.....  
.....  
.....

.. 12 Differences in equipment..

.....  
.....  
.....  
.....

..... 13 Differences in supplied items.

.....  
.....  
.....  
.....

. 13 Parts and controls...

.....  
.....

.....  
.....  
.....  
.....  
.....  
.....  
.....

*.. 16 Getting started Charging the battery pack.....*

.....  
.....  
.....  
.....  
.....  
.....

*.. Attaching/Removing the battery pack..*

.....  
.....  
.....  
.....

*..... Charging the battery using the AC Adaptor (Models with an AC Adaptor)..*

.....  
.....  
.....  
.....  
.....  
.....

*. Charging the battery using your computer.....*

.....  
.....  
.....  
.....

*. Setting.....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

*..... Preparing your camcorder.....*

.....  
.....  
.....  
.....  
.....  
.....  
.....

..... *Changing the recording media (Models with internal memory).*



[You're reading an excerpt. Click here to read official SONY  
HANDYCAM HDR-CX290/B user guide  
http://yourpdfguides.com/dref/5026449](http://yourpdfguides.com/dref/5026449)

...  
.....  
.....  
.....  
*. Inserting a memory card .....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
*... 18 18 19 19 21 21 21 22 Recording/Playback Recording.....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
*.... Zooming.....*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
*.. Playback..*

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
*.... Playing images on a TV.*

.....  
.....  
.....  
.....  
.....  
.....

.....  
.....

... Using the built-in projector (Models with a projector).....

.....  
.....  
.....

..... 24 25 26 28 29 Saving movies and photos with a computer Playing images on a computer.

.....  
.....  
.....

.....  
.....  
.....  
.....

..... What you can do with "PlayMemories Home" software (Windows).

.....  
..... Software for Mac.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

..... Preparing a computer (Windows)..

.....  
.....  
.....

.....  
.....  
.....  
.....

..... Checking the computer system.

.....  
.....  
.....

.....  
.....  
.....  
.....

... Installing the "PlayMemories Home" software in your computer.....

.. Starting the "PlayMemories Home" software..

.....  
.....

.....  
.....  
.....

..... 31 31 31 32 32 32 33 14 GB Saving images on an external media device Creating a standard definition image quality (STD) disc with a recorder.....

..... 34 Saving images on an external media device with high definition (HD) image quality (Models with an AC Adaptor).

.....

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....  
..... 35 Customizing your camcorder Using menus... .

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

... 36 Menu lists... ..

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....  
.....

.... 37 Table of contents Others/Index Troubleshooting... ..

.....  
.....  
.....  
.....

.....  
.....  
.....  
.....

.....  
.....

. Self-diagnosis display/Warning indicators... .

.....

.....  
.....  
.....  
.....

..... About handling of your camcorder.. .

.....  
.....  
.....

.....

.....  
.....  
.....

..... Specifications.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.. Screen indicators.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

.... Index.....

.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....  
.....

. 40 41 42 46 49 51 15 GB Parts and controls Figures in ( ) are reference pages. □ LCD screen (21) If you rotate the LCD panel 180 degrees, you can close the LCD panel with the LCD screen facing out. This is convenient during playback operations. □ Multi selector (11) □ (View Images) button □ PROJECTOR FOCUS lever (29) □ Projector lens (29) HDR-CX220/CX220E/CX230/CX230E/ CX280/CX280E/CX290/CX290E □ Lens (Carl Zeiss lens) □ LENS COVER switch □ Built-in microphones HDR-PJ220/PJ220E/PJ230/PJ230E HDR-PJ220/PJ220E/PJ230/PJ230E □ Speaker □ PROJECTOR button (29) □ HDMI OUT jack (28) 16 GB To fasten the grip belt □ Power zoom lever (25) □ PHOTO button (24) □ POWER/CHG (charge) lamp (19) □ Battery pack (18) □ START/STOP button (24) □ DC IN jack (19) □ Multi/Micro USB Terminal Supports Micro USB compatible devices. □ Grip belt □ Built-in USB Cable (19) □ Memory card access lamp (22) While the lamp is lit or flashing, the camcorder is reading or writing data. □ Tripod receptacle Attach a tripod (sold separately: the length of the screw must be less than 5.5 mm (7/32 in.)). Depending on the specifications of the tripod, your camcorder may not attach in the proper direction.

□ Memory card slot (22) □ BATT (battery) release lever (18) 17 GB Getting started Charging the battery pack For information on your camcorder model, see the following page: Functions and equipment □ p.12 Supplied items □ p.13 Attaching/Removing the battery pack Close the LCD screen and attach the battery pack. □ □ Align the indentation on the camcorder and projection on the battery pack, then slide the battery pack upwards. To remove the battery pack, close the LCD screen, then slide the BATT (battery) release lever and remove the battery pack.

Battery pack 18 GB Charging the battery using the AC Adaptor (Models with an AC Adaptor) Connect the AC Adaptor (□) and the power cord (mains lead) (□) to your camcorder and the wall outlet (wall socket). □ □ □ □ To the wall outlet (wall socket) The POWER/CHG (charge) lamp turns orange. The POWER/CHG (charge) lamp turns off when the battery pack is fully charged. DC plug Getting started Align the □ mark on the DC plug with that on the DC IN jack POWER/CHG (charge) lamp DC IN jack Charging the battery using your computer Connect the camcorder to a running computer using the Built-in USB Cable. □ □ □ The POWER/CHG (charge) lamp turns orange.

The POWER/CHG (charge) lamp turns off when the battery is fully charged. Use the USB connection support cable when the Built-in USB Cable is too short for connection. Built-in USB Cable To the wall outlet (wall socket) 19 GB To charge the battery using an AC-UD10 USB charger/AC Adaptor (sold separately) You can charge the battery by connecting the Built-in USB Cable to a wall outlet (wall socket) using an AC-UD10 USB charger/AC Adaptor (sold separately). You cannot use a Sony CPAH2R, CP-AL, or AC-UP100 portable power supply device (sold separately) to charge the camcorder. □ Notes In the default setting, the power turns off automatically if you leave your camcorder without any operation for about 2 minutes, to save battery power ([Power Save], p. 39). Charging time Approximate time (min.) required when you fully charge a fully discharged NP-FV30 battery pack (supplied). When using the AC Adaptor (models with an AC Adaptor): 115 min. When using your computer connected with the Built-in USB Cable\*: 150 min.

The charging times shown above are measured when charging the camcorder at a room temperature of 25 °C (77 °F). It is recommended that you charge the battery in a temperature range of 10 °C to 30 °C (50 °F to 86 °F). \* The charging times are measured without using the USB connection support cable. 20 GB Setting For information on your camcorder model, see the following page: Functions and equipment □ p.12 Supplied items □ p.13 Preparing your camcorder

1 Open the LCD screen of your camcorder and turn the power on. □ Getting started To turn off the power, close the LCD screen. 2 Select the desired language, the geographical area, and the time using the multi-selector. To turn off the beep sound Select □ [Setup] □ [ General Settings] □ [Beep] □ [Off]. □

Notes The recording date and time are recorded automatically on the recording media.

They are not displayed during recording. However, you can check them as [Data Code] during playback. To display them, select □ [Setup] □ [ Playback Settings] □ [Data Code] □ [Date/Time].



[You're reading an excerpt. Click here to read official SONY](#)

[HANDYCAM HDR-CX290/B user guide](#)

<http://yourpdfguides.com/dref/5026449>

Changing the recording media (Models with internal memory) In the default setting, movies and photos are recorded on the internal memory. You can change the recording media to a memory card.

[Setup] [Media Settings] [Media Select] [the desired medium]. Select 21 GB Inserting a memory card Open the cover, and insert the memory card until it clicks. [Access lamp] To eject the memory card, lightly push the memory card in once. Insert the card with the notched corner in the direction as illustrated. Notes To ensure stable operation of the memory card, it is recommended to format the memory card with your camcorder before the first use (p. 38). Formatting the memory card will erase all the data stored on it and the data will be irrecoverable. Save your important data on your PC, etc. Confirm the direction of the memory card. If you forcibly insert the memory card in the wrong direction, the memory card, memory card slot, or image data may be damaged. When inserting or ejecting the memory card, be careful so that the memory card does not pop out and drop. [Types of memory card you can use with your camcorder] SD Speed Class "Memory Stick PRO Duo" media (Mark2) "Memory Stick PRO-HG Duo" media "Memory Stick XC-HG Duo" media SD memory card SDHC memory card SDXC memory card [Capacity (operation verified)] Up to 32 GB Up to 64 GB Described in this manual "Memory Stick PRO Duo" media — Class 4 or faster Up to 64 GB SD card Operation with all memory cards is not assured. Notes A MultiMediaCard cannot be used with this camcorder. Movies recorded on "Memory Stick XC-HG Duo" media and SDXC memory cards cannot be imported to or played back on computers or AV devices not supporting the exFAT\* file system by connecting the camcorder to these devices with the USB cable. Confirm in advance that the connecting equipment is supporting the exFAT system.

If you connect an equipment not supporting the exFAT system and the [22 GB format screen] appears, do not perform the format. All the data recorded will be lost. \*The exFAT is a file system that is used for the "Memory Stick XC-HG Duo" media and SDXC memory cards. Getting started 23 GB Recording For information on your camcorder model, see the following page: Functions and equipment [p.12] Supplied items [p.13] Recording/Playback 1 Open the lens cover. 2 Open the LCD screen and select [MODE] [the desired shooting mode]. Movie: Photo: 3 Movie: Press START/STOP. [You can record photos during movie recording by pressing PHOTO (Dual Capture). Photo: Press PHOTO.

To display items on the LCD screen Items on the LCD screen disappear if you do not operate the camcorder for a few seconds after you turn the camcorder on or switch between the movie recording and photo shooting modes. You can display the icons and indicators by pressing the multi-selector if they are not shown. STBY STBY 2 h 25 m 00:00:00 14 h 48 m 60i >9999 16:9 L 8.9M MODE 24 GB AUTO [Notes] The following states will be indicated if data is still being written onto the recording media after recording has finished. During this time, do not apply shock or vibration to the camcorder, or remove the battery or AC Adaptor.

[Access lamp (p. 22) is lit or flashing] [The media icon in the upper right of the LCD screen is flashing] Zooming Move the power zoom lever to magnify or reduce the size of the image. W (Wide angle): Wider range of view T (Telephoto): Close view In the default setting, you can magnify images up to the following: [27 times optical zoom (models with electronic SteadyShot)] [50 times extended zoom (models with optical SteadyShot)] [Move the power zoom lever slightly for a slower zoom. Move it further for a faster zoom. Recording/Playback To magnify images further (Extended Zoom) (Models with electronic SteadyShot) Set [SteadyShot] to [Standard] or [Off] (p.

37). You can magnify images up to 32 times the original size by extending the wide angle. To select the suitable setting automatically for the recording situation (Intelligent Auto) Select [On] [at the subject and record it. on the recording screen of movies or photos, then point your camcorder 25 GB Playback For information on your camcorder model, see the following page: Functions and equipment [p.12] Supplied items [p.13] You can search for recorded images by date and time of recording (Event View). 1 Open the LCD screen and press the button on the camcorder to enter the playback mode. [You can enter the playback mode by on the LCD screen. selecting 2 Select / to move the desired event to the center ([ ]) and then select it ([ ]). [MENU] The camcorder displays recorded images as an event automatically, based on the date and time.

1 1 2013 2013 1-2 Highlight 3 Select the image. [1 1 2013 12 00:00:00] The camcorder plays from the selected image to the last image in the event. 1 18 2013 1 19 4 Select the appropriate buttons on the LCD screen for various playback operations. Volume Delete Context Stop [GB] [Previous/Next] Fast-reverse/fast-forward Play/Pause Start/stop slide show Some buttons described above may not appear, depending on the image being played back. 26 [As you repeat selecting / during playback, movies are played as fast as about 5 times [about 10 times [about 30 times [about 60 times. / during pause to play movies slowly. Select [Slideshow Set] when is selected with the Switch Image Type To repeat Slideshow, select button. Notes To prevent your image data from being lost, save all your recorded images on external media periodically. (p. 35) In the default setting, a protected demonstration movie is pre-recorded (HDR-PJ230/PJ230E).

[To play back images with other devices] [Recording/Playback] You may not be able to play back with other devices images that were recorded on your camcorder normally. Also, you may not be able to play back images recorded on other devices with your camcorder. Standard definition image quality (STD) movies recorded on SD memory cards cannot be played on AV equipment of other manufacturers. To delete images Select on the playback screen of movies or photos. 27 GB Playing images on a TV For information on your camcorder model, see the following page: Functions and equipment [p.

12] Supplied items [p.13] Connection methods and the image quality viewed on the TV screen differ depending on what type of TV is connected, and the connectors used. 3 [Play a movie or a photo on the camcorder (p. 26). [High definition Standard definition Yellow White [Red] HDMI Cable (supplied) AV Cable (sold separately) [Notes] Refer to the instruction manuals of the TV as well.

You should use the AC Adaptor as the power source (models with an AC Adaptor) (p. 19). If the TV does not have the HDMI input jack, use an AV Cable (sold separately) for connection.



[You're reading an excerpt. Click here to read official SONY](#)

[HANDYCAM HDR-CX290/B user guide](#)

<http://yourpdfguides.com/dref/5026449>



..... Focuses on the subject with its background blurred. SteadyShot...

.....

.. Sets the SteadyShot function when recording movies. SteadyShot\*1..

.....

.... Sets the SteadyShot function when shooting photos. Digital Zoom....

.....

.....

Sets the maximum zoom level of the digital zoom. Auto Back Light...

.....

Adjusts the exposure for backlit subjects automatically. . Face Face Detection.....

.....

... Automatically detects faces. Smile Shutter.

.....

..... Automatically takes a shot whenever a smile is detected. Smile Sensitivity.

.....

.....

.. Sets the smile detection sensitivity for the Smile Shutter function. Microphone Bt-in Zoom Mic.....

..... Records movies with vivid sound appropriate to the zoom position. Wind Noise Reduct..

.....

. Reduces the wind noise recorded from the built-in microphone. Micref Level...

.....

..... Sets the microphone level for recording.  
Shooting Assist My Button.....

.....

.....

.... Assigns functions to My Buttons. Grid Line....

.....

.....

.....

... Displays grid lines as a guide to make sure the subject is horizontal or vertical. Display Setting.....

.....

.....

. Sets the duration that icons or indicators are displayed on the LCD screen. Customizing your camcorder Image Quality/Size REC Mode.....

.....

.....

.... Sets the mode to record movies.  
Frame Rate.....

.....

.....

Sets the frame rate to record movies. // Setting...

. Sets the image quality for recording movies. Wide Mode.....

.....

.....

.. Sets the horizontal to vertical ratio when recording movies with standard definition image quality (STD). 37 GB x.v.  
Color.....

.....

.....

.....

. Records a wider range of colors. Set this item when you watch images with a TV which is compliant with x.v.Color. Image Size.....

.....

.....

.....

. Sets the photo size. Playback Function Event View.....

.....  
.....  
.....  
..... Starts playing images from the Event View display. Highlight Movie...

.....  
.....  
.....  
Starts playing Highlight Playback scenes or Highlight Scenarios saved with standard definition image quality (STD). Scenario.....

.....  
.....  
.....  
... Starts playing the scenarios that were saved by Highlight Playback. Edit/Copy Delete.....

.....  
.....  
.....  
.....

..... Deletes movies or photos. Protect...  
.....  
.....  
.....

.....  
.....  
.....  
... Protects movies or photos to avoid deleting. Copy\*2.  
.....

.....  
.....  
.....  
.....

Copies images. Direct Copy.....  
.....  
.....  
.....

... Copies images stored in the camcorder to some type of external media device. Setup Media Settings Media Select\*2. ....  
.....  
.....

Selects the type of recording media (p. 21). Media Info.....  
.....  
.....

.. Displays information on the recording media. Format..  
.....  
.....

Deletes and formats all data on the recording media. Repair Img. DB F.....

..... Repairs the image database file on the recording media (p. 42). File Number..  
.....  
.....

..... Sets how to assign the file number to photos.

. Playback Settings Data Code.....

..... Displays information that was recorded automatically at the time of recording. Volume...  
.....  
.....

.....  
..... Adjusts the volume of playback sound. Download Music\*3.

..... Downloads your favorite music files from the computer to your camcorder (while the camcorder is connected to the computer) that can be played with the Highlight Playback scenes.



[You're reading an excerpt. Click here to read official SONY  
HANDYCAM HDR-CX290/B user guide  
http://yourpdfguides.com/dref/5026449](http://yourpdfguides.com/dref/5026449)

Empty Music\*3.

.....

.....

..... Deletes all music files. Connection TV Type....

.....

.....

.....

..... Converts the signal depending on the TV connected (p. 28). HDMI Resolution..

.....

Selects the output image resolution when connecting your camcorder to a TV with the HDMI cable. CTRL FOR HDMI....

.....

..... Sets whether or not the TV's Remote Commander is to be used when the camcorder is connected to a "BRAVIA" Sync compatible TV with the HDMI cable. USB Connect....

.....

.....

. Select this item when no instructions appear on the LCD screen when you connect your camcorder to an external device via USB. USB Connect Setting...

. Sets the connection mode when the camcorder is connected to a computer or a USB device. USB LUN Setting.....

..... @@Sets whether the camcorder sounds operation beeps or not. LCD Brightness . ...

.....

.....

Adjusts the brightness of the LCD screen. Language Setting.....

. Sets the display language (p. 10). Battery Info.....

.....

.....

..... Displays the approximate remaining battery time. Power Save...

.....

.....

.....

@@Initialize.....

.....

.....

.... Initializes all the settings to the default settings.

Demo Mode.....

.....

. @@Clock Settings Date & Time Setting....

.. Sets the date and time. Area Setting..

.....

..... @@@@ Select [Setup] [General Settings] [Initialize].

@@@@@This is not a malfunction. @@This is not a malfunction. The power abruptly turns off. [ ] [ ] [ ] You may need to initialize or change the current internal memory (models with internal memory) of your camcorder depending on the problem. If you do so, the data stored on the internal memory will be deleted.

Be sure to save the data on the internal memory on other media (backup) before sending your camcorder for repair. We will not compensate you for any loss of internal memory data. During repair, we may check a minimum amount of data stored on the internal memory in order to investigate the problem.

However, your Sony dealer will neither copy nor retain your data. See the "Handycam" User Guide (p.

11) for details on the symptoms of your camcorder, and "PlayMemories Home Help Guide" (p. 33) on connecting your camcorder to a computer. [ ] Use the AC Adaptor (models with an AC Adaptor) (p. 19). In the default setting, the camcorder turns itself off when no operations are performed for about 2 minutes ([Power Save]) (p. 39), or turn on the power again. Charge the battery pack (p. 18). Pressing START/STOP or PHOTO does not record images. [ ] [ ] The playback screen is displayed.

Stop the playback, and select [Shooting Mode] [Movie] or [Photo]. Your camcorder is recording the image you have just shot on the recording media. You cannot make new recording during this period. The recording media is full. Delete unnecessary images (p. 27). 40 GB [ ] Total number of movie scenes or photos exceeds the recordable capacity of your camcorder. Delete unnecessary images (p. 27). Self-diagnosis display/Warning indicators For information on your camcorder model, see the following page: Functions and equipment [ ] p.

12 Supplied items [ ] p.13 If indicators appear on the LCD screen, check the following. If the problem persists even after you have tried to fix a couple of times, contact your Sony dealer or local authorized Sony service facility. In this case, when you contact them, give them all the numbers of the error code beginning with C or E. You may hear a melody when some warning indicators appear on the screen.

C:04:[ ] [ ] "PlayMemories Home" cannot be installed. [ ] [ ] An Internet connection is required to install "PlayMemories Home." Check the computer environment or installation procedure required to install "PlayMemories Home." "PlayMemories Home" does not work correctly. [ ] Quit "PlayMemories

Home” and restart your computer.

The camcorder is not recognized by the computer. □ □ □ Disconnect all USB devices from the USB jack of your computer except the keyboard, mouse, and your camcorder. Disconnect the Built-in USB Cable from the computer, and restart the computer, then connect the computer and your camcorder again in the correct order. When both the Built-in USB Cable and the USB jack of the camcorder are connected to the external devices at the same time, disconnect the one that is not connected to a computer. □ The battery pack is not an “InfoLITHIUM” battery pack (V series). Use an “InfoLITHIUM” battery pack (V series) (p. 18). Connect the DC plug of the AC Adaptor (models with an AC Adaptor) to the DC IN jack of your camcorder securely (p. 19). Others/Index C:06: □ □ □ The battery pack temperature is high.

Change the battery pack or place it in a cool place. C:13: □ □ / C:32: □ □ □ Remove the power source. Reconnect it and operate your camcorder again. E: □ □: □ □ □ Follow the steps from □ on page 40. □ □ The battery pack is nearly used up. 41 GB About handling of your camcorder □ The battery pack temperature is high. Change the battery pack or place it in a cool place. For information on your camcorder model, see the following page: Functions and equipment □ p.12 Supplied items □ p.13 □ □ □ No memory card is inserted (p.

22). When the indicator flashes, there are not enough free spaces for recording images. Delete unnecessary images (p. 27), or format the memory card after storing the images on other media (p. 38).

The image data base file may be damaged. Check the data base file by selecting □ [Setup] □ [ Media Settings] □ [Repair Img. DB F.] □ the recording medium (models with internal memory). On use and care □ □ The camcorder is not dustproofed, dripproofed or waterproofed.

Do not hold the camcorder by the following parts, and also do not hold the camcorder by the jack covers. LCD screen Battery pack □ □ The memory card is damaged. Format the memory card with your camcorder (p. 38). Built-in USB Cable □ Incompatible memory card is inserted (p. 22). □ □ □ The memory card is write-protected. Access to the memory card was restricted on another device. □ □ The camcorder is unsteady, so camera-shake easily occurs. Hold the camcorder steady with both hands and record the image.

However, note that the camera-shake warning indicator does not disappear. □ □ □ The recording medium is full. Photos cannot be recorded during processing. Wait for a while, then record. Do not aim the camcorder at the sun. Doing so might cause your camcorder to malfunction. Take images of the sun only in low light conditions, such as at dusk. Do not use or store the camcorder and accessories in the following locations: □ Anywhere extremely hot, cold or humid. Never leave them exposed to temperatures above 60 °C (140 °F), such as under direct sunlight, near heaters or in a car parked in the sun. They may malfunction or become deformed.

□ Near strong magnetic fields or mechanical vibration. The camcorder may malfunction. □ Near strong radio waves or radiation. The camcorder may not be able to record properly. 42 GB □ □ □ □ □ □ □ □ □ tuner devices such as TVs or radio.



[You're reading an excerpt. Click here to read official SONY HANDYCAM HDR-CX290/B user guide](http://yourpdfguides.com/dref/5026449)  
<http://yourpdfguides.com/dref/5026449>

Noise may occur. □ On a sandy beach or anywhere dusty. If sand or dust gets in your camcorder, it may malfunction. Sometimes this malfunction cannot be repaired. □ Near windows or outdoors, where the LCD screen, or the lens may be exposed to direct sunlight.

This damages the LCD screen. For DC or AC operation, use the accessories recommended in these operating instructions. Do not let your camcorder get wet, for example, from rain or sea water. If your camcorder gets wet, it may malfunction. Sometimes this malfunction cannot be repaired. If any solid object or liquid gets inside the casing, unplug your camcorder and have it checked by a Sony dealer before operating it any further. Avoid rough handling, disassembling, modifying, physical shock, or impact such as hammering, dropping or stepping on the product. Be particularly careful with the lens. Keep the LCD screen closed when you are not using your camcorder. Do not operate your camcorder with it wrapped in an object such as a towel.

When disconnecting the power cord (mains lead), pull it by the plug and not the cord (models with an AC Adaptor). Do not damage the power cord (mains lead) such as by placing anything heavy on it (models with an AC Adaptor). Do not use a deformed or damaged battery pack. Keep metal contacts clean. If the battery electrolytic liquid has leaked: □ Consult your local authorized Sony service facility. □ Wash off any liquid that may have contacted your skin. □ If any liquid gets in your eyes, wash with plenty of water and consult a doctor. □ Near When not using your camcorder for a long time □ □ To keep your camcorder in optimum state for a long time, turn it on and let it run by recording and playing back images about once a month. Use up the battery pack completely before storing it. Note on the camcorder/battery pack temperature □ When the temperature of the camcorder or battery pack becomes extremely high or extremely low, you may not be able to record or play back on the camcorder, due to the protection features of the camcorder being activated in such situations.

In this case, an indicator appears on the LCD screen. Others/Index Notes on charging through the USB cable □ □ □ Charging may not be possible with all computers. If you connect the camcorder to a laptop computer that is not connected to a power source, the battery of the laptop computer will continue to use up its charge. Do not leave the camcorder connected to a computer in this manner. Charging with a personally assembled computer, with a converted computer, or through a USB hub are not guaranteed.

The camcorder may not function correctly depending on the USB device which is used with the computer. 43 GB When the camcorder is connected to a computer or accessories □ LCD screen □ □ □ Do not try to format the recording media of the camcorder with a computer. If you do so, your camcorder may not operate correctly. When connecting the camcorder to another device with communication cables, be sure to insert the connector plug in the correct way.

Pushing the plug forcibly into the terminal will damage the terminal and may result in a malfunction of the camcorder.

When the camcorder is connected to other devices through a USB connection and the power of the camcorder is turned on, do not close the LCD panel. The image data that has been recorded may be lost. □ □ Do not apply excessive pressure on the LCD screen, as it may cause uneven color and other damage. If your camcorder is used in a cold place, a residual image may appear on the LCD screen. This is not a malfunction. While using your camcorder, the back of the LCD screen may heat up. This is not a malfunction. To clean the casing and the projector lens (Models with a projector) □ Notes on optional accessories □ □ □ We recommend using genuine Sony accessories. Genuine Sony accessories may not be available in some countries/regions. □ On handling the LCD screen □ □ □ If you leave fingerprints, hand cream, etc.

on the LCD screen, the coating of the LCD screen will come off easily. Wipe those off as soon as possible. If you wipe the LCD screen strongly with a tissue, etc., the coating of the LCD screen may be scratched. If the LCD screen becomes dirty with fingerprints or dust, it is recommended that you gently remove those from the screen then clean it with a soft cloth, etc. Wipe the casing and the lens gently with a soft cloth such as a cleaning cloth or eyeglass cleaning cloth. If the casing and the projector lens is very dirty, clean the camcorder casing and the lens with a soft cloth lightly moistened with water, and then wipe the casing and the projector lens with a dry soft cloth. Avoid the following so as not to deform the casing, damage the finish or scratch the lens: □ Using chemicals such as thinner, benzine, alcohol, chemical cloths, insect repellent, insecticide and sunscreen □ Handling the camcorder with the above substances on your hands □ Leaving the camcorder in contact with rubber or vinyl objects for a long period of time About care and storage of the lens □ □ □ 44 GB Wipe the surface of the lens clean with a soft cloth in the following instances: □ When there are fingerprints on the lens surface □ In hot or humid locations □ When the lens is exposed to salty air such as at the seaside Store in a well-ventilated location subject to little dirt or dust. To prevent mold, periodically clean and store the lens as described above. On charging the pre-installed rechargeable battery Your camcorder has a pre-installed rechargeable battery to retain the date, time, and other settings even when the LCD screen is closed.

The pre-installed rechargeable battery is always charged while your camcorder is connected to the wall outlet (wall socket) via the AC Adaptor (models with an AC Adaptor) or while the battery pack is attached. The rechargeable battery will be fully discharged in about 3 months if you do not use your camcorder at all. Charge the pre-installed rechargeable battery before you start using your camcorder. However, even if the pre-installed rechargeable battery is not charged, the camcorder operation other than date recording will not be affected. Note on disposal/transfer the ownership of the camcorder (Models with internal memory) Even if you delete all movies and still images, or perform [Format] (p.

38), data on the internal memory may not be completely erased. It is recommended that □ [Setup] □ [Media you select Settings] □ [Format] □ [Empty] to prevent the recovery of your data. Others/Index How to charge the pre-installed rechargeable battery Connect your camcorder to a wall outlet (wall socket) using the AC Adaptor (models with an AC Adaptor) or attach the fully charged battery pack, and leave it with the LCD screen closed for more than 24 hours.

45 GB Specifications System Signal format: NTSC color, EIA standards (HDR-CX220/ CX230/CX280/CX290/PJ220/PJ230) PAL color, CCIR standards (HDR-CX220E/ CX230E/CX280E/CX290E/PJ220E/PJ230E) HD TV Movie recording format: AVCHD (AVCHD format Ver.



[You're reading an excerpt. Click here to read official SONY HANDYCAM HDR-CX290/B user guide](http://yourpdfguides.com/dref/5026449)  
<http://yourpdfguides.com/dref/5026449>



Furthermore, □ and □ are not mentioned in each case in this manual. Bottom Left Add further enjoyment with your PlayStation 3 by downloading the application for PlayStation 3 from PlayStation Store (where available.) The application for PlayStation 3 requires PlayStation Network account and application download. Accessible in areas where the PlayStation Store is available. Indicator Meaning MENU button (36) Self-timer recording (37) Wide Mode (37) Fader (37) [Face Detection] set to [Off] (37) [Smile Shutter] set to [Off] (37) Manual focus (37) Scene Selection (37) White Balance (37) SteadyShot off (37) Tele Macro (37) Destination (39) Intelligent Auto (face detection/scene detection/ camera-shake detection) (25) Meaning Slideshow Set Warning (41) Playback mode (26) Others/Index □ □ □ Center Indicator □ □ 49 GB Right Indicator 60i 720 Meaning Recording image quality (HD/MP4/STD), frame rate (60p/50p/60i/50i), recording mode (PS/FX/ FH/HQ/LP) and movie size (37) Remaining battery Recording/playback/ editing media (21) Counter (hour:minute: second) Estimated remaining recording time Approximate number of recordable photos and photo size (38) Playback folder Current playing movie or photo/Number of total recorded movies or photos Connection to the external media device (34) Meaning [Micref Level] low (37) [Wind Noise Reduct.] (37) Blt-in Zoom Mic (37) Low Lux (37) Exposure (37) Intelligent Auto (25) Data file name Protect (38) 60min 0:00:00 00min 9999 8.9M 100/112 Bottom Indicator 101-0005 □ □ □ Indicators and their positions are approximate and may differ from what you actually see. Some indicators may not appear, depending on your camcorder model.

50 GB Index A Attaching/Removing the battery pack.....

.....  
 .....

..18 AVCHD recording disc...

.....  
 .....

.11 . Install.....

.....  
 .....

.32 . Intelligent Auto...

.....  
 .....

25 T Tripod.....

.....  
 .....

.....17 Troubleshooting..

.....  
 .....

....40 . TV.....

.....  
 .....

....28 .

L Language.....

.....  
 .....

....10 LCD screen.....

.....  
 .....

.....24 B Battery pack.

.....  
.....  
.....  
.....

..18 . Beep.....

.....  
.....  
.....

.....  
.....  
.....

21 Built-in USB Cable.....

.....  
..19 U USB..

.....  
.....

.....  
.....  
.....  
.....

19 USB Adaptor Cable.....

.....  
.....

.35 USB connection support cable.....

.....  
.....  
.....  
.....

.....11 . M Mac..

.....  
.....  
.....

.....  
.....  
.....

.....31 Media select....

.....  
.....  
.....  
.....

21 Memory card.....

.....  
.....  
.....

..22 "Memory Stick PRO-HG Duo" media.....

.....  
.....  
.....

.....  
.....  
.....

.22 . "Memory Stick PRO Duo" media (Mark2)..

.....  
.....  
.....

.....  
.....  
.....22 "Memory Stick XC-HG Duo" media..

.....  
.....  
.....  
.....

.....  
.....  
.....22 . Menu lists..

.....  
.....

.....  
.....

.....  
.....  
.....37 Menus.....

.....  
.....  
.....  
.....

.....36 . C Care.....

.....  
.....  
.....

.....  
.....  
.....

.....42 Charging the battery pack.....

.....18 Charging the battery pack using your computer.....

.....  
.....  
.....

.....19 . Charging the battery using the AC adaptor.....

.....  
.....  
.....

.....19 Computer....

.....  
.....  
.....

.....32 Creating discs..

.....  
.....

.....34 W Warning indicators.

.....  
.....

.....41 Wind noise....

.....  
.....  
.....

.....37 Windows....

.....

.....  
.....  
.....  
.....  
.....  
*32 Z Zoom.....*

.....  
.....  
.....  
.....  
.....  
*.....25 D Data Code.....*

.....  
*..21 Date/Time...*  
.....  
.....

.....  
*...21 . Display items on the LCD screen.*  
.....

.....  
.....  
.....  
.....  
.....  
*...24 Dual Capture.....*

.....  
*.....24 N Notes on handling of your camcorder.....*  
.....  
.....  
.....

.....  
*..42 Others/Index P Parts and controls...*  
.....  
.....

.....  
*.....16 Playback....*  
.....  
.....  
.....

.....  
*.26 PlayMemories Home....*  
*. 11, 31, 32 PlayMemories Home Help Guide.....*

.....  
.....  
.....  
.....  
.....  
*11, 33 Projector.....*



