



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for SONY XPERIA E3. You'll find the answers to all your questions on the SONY XPERIA E3 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual SONY XPERIA E3
User guide SONY XPERIA E3
Operating instructions SONY XPERIA E3
Instructions for use SONY XPERIA E3
Instruction manual SONY XPERIA E3

SONY.

User guide

Xperia™ E3
D2202/D2203/D2206



[You're reading an excerpt. Click here to read official SONY XPERIA E3 user guide](http://yourpdfguides.com/dref/5742825)
<http://yourpdfguides.com/dref/5742825>

Manual abstract:

Smart apps and features that save you time.....

.....
.....
.....

.98 Controlling accessories and settings with Smart Connect.....

.....

98 Using your device as a fitness hub with ANT+™.....

.....

.....

....99 Using your device as a wallet.

.....
.....

.....

.....

.....

.....

.....

100 Travel and maps.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

...101 Using location services.....

.....

.....

.....

.....

.....

.....

.....

.....101 Google Maps™ and navigation.

.....

.....

.....

.....

.....

.....

.....

..102 Using data traffic when travelling.....

.....

.....

.....

.....

.....

..103 Airplane mode...

.....

.....

.....
.....
.....
.....

.....
.....
.....
.....

..103 Calendar and alarm clock.....

.....
.....
.....

.....
.....
.....
.....

104 Calendar.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.....104 Alarm and clock.

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

.105 Support and maintenance....

.....

.....
.....
.....
.....

.....
.....

....107 Support for your device.

.....
.....

.....
.....
.....
.....

.....
.....

....107 Computer tools.

.....

.....

.....

.....

.....

.....

.....

..a while for the device to start. @@Tap OK. until the options menu opens.

It may take a while for the device to shut down. Why do I need a Google™ account? Your Xperia™ device from Sony runs on the Android™ platform developed by Google™. A range of Google™ applications and services is available on your device when you purchase it, for example, Gmail™, Google Maps™, YouTube™ and Google Play™, the online store for downloading Android™ applications. To get the most out of these services, you need a Google™ account. For example, a Google™ account is mandatory if you want to: ••••Download and install applications from Google Play™. Synchronise email, contacts and the calendar. Chat with friends using the Hangouts™ application. Synchronise your browsing history and bookmarks. For more information about Android™ and Google™, go to www.sonymobile.com/support.

1 2 To set up a Google™ account on your device Find and tap Settings > Add account > Google. Follow the registration wizard to create a Google™ account, or sign in if you already have an account. You can also sign in to or create a Google™ account from the setup guide the first time you start your device. Or you can go online and create an account at www.google.com/accounts. 9 This is an Internet version of this publication. © Print only for private use. Charging your device The battery is partly charged when you buy the device.

You can still use your device while it is charging. Read more about the battery and how to improve the performance in Battery and power management on page 109. To charge your device 1 2 3 4 Plug the charger into a power outlet. Plug one end of the USB cable into the charger (or into the USB port of a computer). Plug the other end of the cable into the micro USB port on your device, with the USB symbol facing up.

The notification light illuminates when charging begins. When the device is fully charged, disconnect the cable from your device by pulling it straight outwards. Make sure not to bend the connector. If the battery is completely discharged, it may take a few minutes before the notification light illuminates and the charging icon appears. Battery notification light status Green Flashing red Orange The battery charge level is greater than 90% The battery is charging and the battery charge level is less than 15% The battery is charging and the battery charge level is less than 90% 10 This is an Internet version of this publication.

© Print only for private use. Learning the basics Using the touchscreen Tapping ••••Open or select an item. Mark or unmark a checkbox or option. Enter text using the on-screen keyboard. Touching and holding ••••Move an item. Activate an item-specific menu. Activate selection mode, for example, to select several items from a list. 11 This is an Internet version of this publication. © Print only for private use. Pinching and spreading •Zoom in or out on a web page, a photo or a map.

Swiping ••Scroll up or down a list. Scroll left or right, for example, between Home screen panes. 12 This is an Internet version of this publication. © Print only for private use. Flicking •Scroll quickly, for example, in a list or on a web page. You can stop the scrolling movement by tapping the screen. Locking and unlocking the screen When your device is on and left idle for a set period of time, the screen darkens to save battery power and locks automatically. This lock prevents unwanted actions on the touchscreen when you are not using it. When you buy your device, a basic screen swipe lock is already set. This means that you have to swipe in any direction from the middle of the screen to unlock it.

You can change the security settings later and add other kinds of locks. See Screen lock on page 37. •To activate the screen Briefly press the power key To unlock the screen . ••Place a finger on the screen and swipe up or down. To lock the screen When the screen is active, briefly press the power key . 13 This is an Internet version of this publication. © Print only for private use. Home screen The Home screen is the starting point for using your device. It's similar to the desktop on a computer screen. Your Home screen can have up to seven panes, which extend beyond the regular screen display width.

The number of Home screen panes is represented by a series of dots at the top of the Home screen. The highlighted dot shows the pane that you are currently in. •To go to the Home screen Press . To browse the Home screen Home screen panes You can add new panes to your Home screen (up to a maximum of seven panes) and delete panes. You can also set the pane that you want to use as the main Home screen pane. 1 2 To set a pane as the main Home screen pane Touch and hold an empty area on your Home screen until the device vibrates. Flick left or right to browse to the pane that you want to set as your main Home screen pane, then tap at the top corner of the pane. 14 This is an Internet version of this publication. © Print only for private use. 1 2 1 2 To add a pane to your Home screen Touch and hold an empty area on your Home screen until the device vibrates.

Flick left or right to browse the panes, then tap . To delete a pane from your Home screen Touch and hold an empty area on your Home screen until the device vibrates. Flick left or right to browse to the pane that you want to delete, then tap . Application screen The Application screen, which you open from the Home screen, contains the applications that come pre-installed on your device as well as applications that you download. 1 2 ••To view all applications on the Application screen From your Home screen, tap . Flick left or right on the Application screen. To open an application from the Application screen Flick left or right to find the application, and then tap the application. To open the Application screen menu When the Application screen is open, drag the left edge of the screen to the right. To move an application on the Application screen To open the Application screen menu, drag the left edge of the Application screen to the right. Make sure that Own order is selected under SHOW APPS.

Touch and hold the application until it magnifies and the device vibrates, then drag it to the new location. To add an application shortcut to the Home screen From the Application screen, touch and hold an application icon until the screen vibrates, then drag the icon to the top of the screen.



[You're reading an excerpt. Click here to read official SONY XPERIA E3 user guide](http://yourpdfguides.com/dref/5742825)
<http://yourpdfguides.com/dref/5742825>

The Home screen opens. Drag the icon to the desired location on the Home screen, then release your finger. To arrange applications on the Application screen To open the Application screen menu, drag the left edge of the Application screen to the right.

Select the desired option under SHOW APPS. 1 2 3 1 2 15 This is an Internet version of this publication. © Print only for private use. 1 2 3 1 2 3 To search for an application from the Application screen To open the Application screen menu, drag the left edge of the Application screen to the right. Tap Search apps.

Enter the name of the application that you want to search for. To uninstall an application from the Application screen To open the Application screen menu, drag the left edge of the Application screen to the right. Tap Uninstall. All uninstalleable applications are indicated by . Tap the application that you want to uninstall, then tap Uninstall. Navigating applications You can navigate between applications using the navigation keys, the favourites bar, the quick launch apps feature, and the recently used applications window, which lets you switch easily between all recently used applications. Some applications are to exit while others continue to run in the background or closed when you press pause. If the application is paused or runs in the background, you can continue where you left off the next time you open the application. 1 2 3 4 5 Recently used applications window – Open a recently used application Favourites bar – Open a shortcut for applications or widgets Task navigation key – Open the recently used applications window and the small apps bar Home navigation key – Exit an application and go back to the Home screen Back navigation key – Go back to the previous screen within an application or close the application ••• To open the recently used applications window Press . To close all the recently used applications Tap and then tap Close all.

To open a menu in an application While using the application, press . A menu is not available in all applications. 16 This is an Internet version of this publication. © Print only for private use. Shaking your device to open an application You can set up your device so that a selected application launches when you shake it. You can use this quick launch function for an application that you need to use quickly or frequently, for example, the phone dialer or a social networking service. To use the quick launch function 1 2 1 2 3 Press and hold down the power key , then shake the device. When the pre-selected application opens, release the power key. To set up the quick launch function From your Home screen, tap . Find and tap Settings > Personalisation > Motion > Shake to start app.

Select an application, then tap Done. Small apps A small app is a shortcut used for applications and widgets. You can get quick access to the small apps at any time using the favorites bar. A small app only takes up a small area of your screen, so you can interact with a small app and another application at the same time on the same screen. For example, you can have a web page open and then open the Calculator small app on top of it and perform calculations. You can download more small apps from Google Play™. 1 2 To open a small app To make the small apps bar appear, press Tap the small app that you want to open. . You can open several small apps at the same time. •To close a small app Tap on the small app window.

17 This is an Internet version of this publication. © Print only for private use. 1 2 To download a small app From the small apps bar, tap , then tap and tap . Search for the small app that you want to download, then follow the instructions to download it and complete the installation. To move a small app When the small app is open, touch and hold the top left corner of the small app, then move it to the desired location. To minimise a small app When the small app is open, touch and hold the top left corner of the small app, then drag it to the right edge or to the bottom edge of the screen. To rearrange the small apps in the small apps bar Touch and hold a small app and drag it to the desired position. To remove a small app from the small apps bar Touch and hold a small app, then drag it to . To restore a previously removed small app . Open the small apps bar, then tap Touch and hold the small app that you want to restore, then drag it into the small apps bar.

To add a widget as a small app To make the small apps bar appear, press . > > . Tap Select a widget. Enter a name for the widget, if desired, then tap OK. ••• 1 2 1 2 3 4 Widgets Widgets are small applications that you can use directly on your Home screen. They also function as shortcuts. For example, the Weather widget allows you to see basic weather information directly on your Home screen. But when you tap the widget, the full Weather application opens. You can download additional widgets from Google Play™. 1 2 To add a widget to the Home screen Touch and hold an empty area on your Home screen until the device vibrates, then tap Widgets.

Find and tap the widget that you want to add. 18 This is an Internet version of this publication. © Print only for private use. 1 2 3 •To resize a widget Touch and hold a widget until it magnifies and the device vibrates, then release the widget. If the widget can be resized, for example, the Calendar widget, then a highlighted frame and resizing dots appear.

Drag the dots inward or outward to shrink or expand the widget. To confirm the new size of the widget, tap anywhere on the Home screen. To move a widget Touch and hold the widget until it magnifies and the device vibrates, then drag it to the new location. To delete a widget Touch and hold the widget until it magnifies and the device vibrates, then drag it to . •Shortcuts and folders Use shortcuts and folders to manage your applications and keep your Home screen tidy.

1 2 Access a folder containing applications Access an application using a shortcut 1 2 3 To add a shortcut to your Home screen Touch and hold an empty area on your Home screen until the device vibrates and the customisation menu appears. In the customisation menu, tap Apps. Scroll through the list of applications and select an application. The selected application gets added to the Home screen. In step 3, alternatively, you can tap Shortcuts and then select an application from the list available. If you use this method to add shortcuts, some of the applications available allow you to add specific functionality to the shortcut. •To move an item on the Home screen Touch and hold the item until it magnifies and the device vibrates, then drag the item to the new location. To delete an item from the Home screen Touch and hold an item until it magnifies and the device vibrates, then drag the item to . •19 This is an Internet version of this publication.



[You're reading an excerpt. Click here to read official SONY XPERIA E3 user guide](http://yourpdfguides.com/dref/5742825)

<http://yourpdfguides.com/dref/5742825>

© Print only for private use.

• To create a folder on the Home screen Touch and hold an application icon or a shortcut until it magnifies and the device vibrates, then drag and drop it on top of another application icon or shortcut. To add items to a folder on the Home screen Touch and hold an item until it magnifies and the device vibrates, then drag the item to the folder. To rename a folder on the Home screen Tap the folder to open it. Tap the folder's title bar to show the Folder name field. Enter the new folder name and tap Done. • 1 2 3 Background and themes You can adapt the Home screen to your own style using wallpapers and different themes. You can also change the wallpaper on the lock screen. 1 2 1 2 To change your Home screen wallpaper Touch and hold an empty area on your Home screen until the device vibrates. Tap Wallpapers and select an option. To set a theme Touch and hold an empty area on your Home screen until the device vibrates.

Tap Themes, then select a theme. When you change a theme, the background also changes in some applications. 1 2 3 To change the wallpaper for the lock screen From your Home screen, tap . Find and tap Settings > Personalisation > Lock screen. Select an option, then follow the instructions to change your wallpaper.

Taking a screenshot You can capture still images of any screen on your device as a screenshot. Screenshots you take are automatically saved in Album. 20 This is an Internet version of this publication. © Print only for private use. 1 2 To take a screenshot Press and hold down the power key until a prompt window appears.

Tap You may also take the screenshot through pressing the power key and volume down key at the same time until you hear a clicking sound. • To view your screenshot Drag the status bar downwards, touch to view your screenshot. You may also view your screenshot by tapping the Album application from the Home screen. Status and notifications The icons in the status bar inform you of events such as new messages and calendar notifications, activities in progress such as file downloads, and status information such as battery level and signal strength. You can drag down the status bar to open the Notification panel and handle your notifications. To open or close the Notification panel ••• To take action on a notification Tap the notification. To dismiss a notification from the Notification panel Place your finger on a notification and flick left or right. To clear all notifications from the Notification panel Tap Clear. Notification light The notification light informs you about battery status and some other events. For example, a flashing white light means there is a new message or a missed call.

21 This is an Internet version of this publication. © Print only for private use. Icons in the status bar Status icons Signal strength No signal Roaming GPRS is available EDGE is available 3G is available Mobile data network is available Sending and downloading GPRS data Sending and downloading EDGE data Sending and downloading 3G data Sending and downloading mobile data Battery status The battery is charging STAMINA mode is activated Airplane mode is activated The Bluetooth® function is activated The SIM card is not inserted The microphone is muted The speakerphone is on Silent mode Vibrate mode An alarm is set GPS is activated Synchronisation is ongoing Problem with sign-in or synchronisation Your device is ready to connect to other ANT+™ capable devices Depending on your service provider, network and/or region, the functions or services represented by some icons in this list may not be available.

Notification icons The following notification icons may appear on your screen: New email message New text message or multimedia message New voicemail

22 This is an Internet version of this publication. © Print only for private use. Upcoming calendar event A song is playing The device is connected to a computer via a USB cable Warning message Error message Missed call Call ongoing Call on hold Call forwarding is turned on A Wi-Fi® connection is enabled and wireless networks are available Software updates are available Downloading data Uploading data More (undisplayed) notifications Application overview Use the Alarm and clock application to set various kinds of alarms. Use your web browser to navigate and view web pages, manage bookmarks, and manage text and images. Use the Calculator application to perform basic calculations. Use the Calendar application to keep track of your events and manage your appointments. Use the camera to take photos and record video clips.

Use the Contacts application to manage phone numbers, email address and other information related to your contacts. Access your downloaded applications.

Use the Email application to send and receive emails through both private and corporate accounts. Use the Facebook™ application to engage in social networking with friends, family members and colleagues around the world. Browse and listen to FM radio stations.

Use the Album application to view and to work with your photos and videos. Use the Gmail™ application to read, write and organise email messages. Search for information in your device and on the web. View your current location, find other locations, and calculate routes using Google Maps™. Go to Google Play™ to download free and paid applications for your device.

Use the Messaging application to send and receive text and multimedia messages. 23 This is an Internet version of this publication. © Print only for private use. Use the Movies application to play videos in your device and share content with your friends. Use the Walkman® application to organise and play music, audio books and podcasts. View news stories and weather forecasts. Make phone calls by dialling the number manually or by using the smart dial function.

Use the Video Unlimited application to rent and purchase videos. Optimise settings to suit your own requirements. Use the Hangouts™ application to chat with friends online.

Identify music tracks that you hear playing in your surroundings, and get artist, album and other info. Use YouTube™ to share and view videos from around the world. Use the Support application to access user support in the device. For example, you can access a User guide, troubleshooting information, plus tips and tricks. Download and install new applications and updates. Some applications are not supported by all networks and/or service providers in all areas. 24

This is an Internet version of this publication. © Print only for private use. Downloading applications Downloading applications from Google Play™ Google

Play™ is the official online Google store for downloading applications, games, music, movies and books. It includes both free and paid applications.

Before you start downloading from Google Play™, make sure that you have a working Internet connection, preferably over Wi-Fi® to limit data traffic charges.



[You're reading an excerpt. Click here to read official SONY XPERIA E3 user guide](http://yourpdfguides.com/dref/5742825)
<http://yourpdfguides.com/dref/5742825>

To use Google Play™, you need to have a Google™ account. Google Play™ may not be available in all countries or regions. 1 2 3 To download an application from Google Play™ Find and tap Play Store. Find an item you wish to download by browsing categories, or by using the search function. Tap the item to view its details, and follow the instructions to complete the installation. Some applications may need to access data, settings and various functions on your device in order to work properly. Only install and give permissions to applications that you trust. You can view the permissions granted to a downloaded application by tapping the application under Settings > Apps. Downloading applications from other sources When your device is set to allow downloads from sources other than Google Play™, you can download applications directly from other websites by following the relevant download instructions.

Installing applications of unknown or unreliable origin can damage your device. Only download applications from reliable sources. Contact the application provider if you have any questions or concerns. To allow the download of applications from other sources 1 2 3 Find and tap Settings > Security. Mark the Unknown sources checkbox. Tap OK. Some applications may need to access data, settings and various functions on your device in order to work properly. Only install and give permissions to applications you trust. You can view the permissions granted to a downloaded application by tapping the application under Settings > Apps. 25 This is an Internet version of this publication.

© Print only for private use. Internet and networks Browsing the web The Google Chrome™ web browser for Android™ devices comes pre-installed in most markets. Go to <http://support.google.com/chrome> and click the "Chrome for Mobile" link to get more detailed information about how to use this web browser.

1 2 3 4 To browse with Google Chrome™ From your Home screen, tap . Find and tap . If you are using Google Chrome™ for the first time, select to either sign in to a Google™ account or browse with Google Chrome™ anonymously. Enter a search term or web address in the search and address field, then tap Go on the keyboard. 1 2 3 4 5 6 Go to the homepage Search and address field Refresh the page Access browser tabs View help and options Go back a page in the browser history Internet and MMS settings To send multimedia messages, or to access the Internet when there is no available Wi-Fi® network, you must have a working mobile data connection with the correct Internet and MMS (Multimedia Messaging Service) settings.

Here are some tips: •••• For most mobile networks and operators, Internet and MMS settings come preinstalled on your device. You can then start using the Internet and send multimedia messages right away. In some cases, you get the option to download Internet and MMS settings the first time you turn on your device when a SIM card is inserted. It is also possible to download these settings later from the Settings menu. You can manually add, change or delete Internet and MMS settings on your device at any time.

Contact your network operator for detailed information. If you cannot access the Internet over a mobile network or if multimedia messaging is not working, even though the Internet and MMS settings have been downloaded 26 This is an Internet version of this publication. © Print only for private use. successfully to your device, refer to the troubleshooting tips for your device at www.sonymobile.com/support/ for network coverage, mobile data, and MMS issues. 1 2 3 To download Internet and MMS settings From your Home screen, tap . Find and tap

Settings > More... > Internet settings. Tap Accept. Once the settings have been downloaded successfully, in the status bar and mobile data is turned on automatically. appears If the settings cannot be downloaded to your device, check the signal strength of your mobile network. Move to an open location free from obstructions or get close to a window and then try again. 1 2 3 1 2 3 4 5 6 7 1 2 3 4 To check whether mobile data is turned on or off From your Home screen, tap . Find and tap Settings > More... > Mobile networks. Check whether the Mobile data traffic checkbox is marked or not.

To add Internet and MMS settings manually From your Home screen, tap . Find and tap Settings > More... > Mobile networks. Tap Access Point Names > . Tap Name and enter a name as desired. Tap APN and enter the access point name. Enter all other information as required. If you don't know what information is required, contact your network operator for more details. When you're done, tap , then tap Save. To view the downloaded Internet and MMS settings From your Home screen, tap . Find and tap Settings > More... > Mobile networks.

Tap Access Point Names. To view more details, tap any of the available items. If you have several available connections, the active network connection is indicated by a marked button . 1 2 3 4 To delete all Internet and MMS settings From your Home screen, tap . Find and tap Settings > More... > Mobile networks.

Tap Access Point Names, then tap . Tap Reset to default. All Internet and MMS settings are deleted. Wi-Fi® Use Wi-Fi® connections to surf the Internet, download applications, or send and receive emails. Once you have connected to a Wi-Fi® network, your device remembers the network and automatically connects to it the next time you come within range.

Some Wi-Fi® networks require you to log in to a web page before you can get access. Contact the relevant Wi-Fi® network administrator for more information. The signal strength of Wi-Fi® networks can differ. Moving closer to the Wi-Fi® access point increases the signal strength. Available Wi-Fi® networks may be open or secured: •• Open networks are indicated by next to the Wi-Fi® network name. Secured networks are indicated by next to the Wi-Fi® network name. Some Wi-Fi® networks do not show up in the list of available networks because they do not broadcast their network name (SSID). If you know the network name, you can add it manually to your list of available Wi-Fi® networks. 27 This is an Internet version of this publication. © Print only for private use.

1 2 To turn on Wi-Fi® Find and tap Settings. Drag the slider beside Wi-Fi to the right to turn on the Wi-Fi® function. It may take a few seconds before Wi-Fi® is enabled. 1 2 3 4 To connect to a Wi-Fi® network automatically From your Home screen, tap . Find and tap Settings. Tap Wi-Fi. All available Wi-Fi® networks are displayed. Tap a Wi-Fi® network to connect to it. For secured networks, enter the relevant password. is displayed in the status bar once you are connected.

To search for new available networks, tap , and then tap Scan. 1 2 3 4 5 6 7 8 To add a Wi-Fi® network manually From your Home screen, tap .



[You're reading an excerpt. Click here to read official SONY XPERIA E3 user guide](http://yourpdfguides.com/dref/5742825)

<http://yourpdfguides.com/dref/5742825>

Find and tap Settings > Wi-Fi. Tap . Enter the Network name (SSID) information.

To select a security type, tap the Security field. If required, enter a password. To edit some advanced options such as proxy and IP settings, mark the Show advanced options checkbox and then edit as desired. Tap Save. Contact your Wi-Fi® network administrator to get the network SSID and password.

Increasing Wi-Fi® signal strength There are a number of things you can do to increase the strength of a Wi-Fi® signal: ••• Move your device closer to the Wi-Fi® access point. Move the Wi-Fi® access point away from any potential obstructions or interference. Don't cover the Wi-Fi® antenna area of your device (the highlighted area in the illustration). **Wi-Fi® settings** When you are connected to a Wi-Fi® network or when there are Wi-Fi® networks available in your vicinity, it is possible to view the status of these networks. You can also enable your device to notify you whenever an open Wi-Fi® network is detected. If you are not connected to a Wi-Fi® network, your device uses a mobile data connection to access the Internet (if you have set up and enabled a mobile data connection on your device). By adding a Wi-Fi® sleep policy, you can specify when to switch from Wi-Fi® to mobile data. 1 2 3 4 5 1 2 To enable Wi-Fi® network notifications Turn on Wi-Fi®, if it is not already on.

Find and tap Settings > Wi-Fi. Press . Tap Advanced. Mark the Network notification checkbox. To view detailed information about a connected Wi-Fi® network Find and tap Settings > Wi-Fi. Tap the Wi-Fi® network that you are currently connected to. Detailed network information is displayed. To add a Wi-Fi® sleep policy Find and tap Settings > Wi-Fi. Press . Tap Advanced.

Tap Keep Wi-Fi on during sleep. Select an option. 1 2 3 4 5 **Sharing your mobile data connection** You can share your device's mobile data connection with a single computer using a USB cable. This process is called USB tethering. You can also share your device's data connection with up to eight other devices at once by turning your device into a portable Wi-Fi® hotspot.

When your device's mobile data connection is successfully shared, the sharing devices can use your device's data connection, for example, to surf the Internet, download applications, or send and receive emails. You may need to prepare your computer to establish a network connection via USB cable. Go to www.android.com/tether to get the most current information.

1 2 3 4 5 6 **To share your data connection using a USB cable** Deactivate all USB cable connections to your device. Using the USB cable that came with your device, connect your device to a computer. From your Home screen, tap . Find and tap Settings > More... > Tethering & portable hotspot. Mark the USB tethering checkbox, then tap OK if prompted. is displayed in the status bar once you are connected. To stop sharing your data connection, unmark the USB tethering checkbox or disconnect the USB cable. You cannot share your device's data connection and SD card over a USB cable at the same time. 1 2 3 4 5 6 7 8 9 **To use your device as a portable Wi-Fi® hotspot** From your Home screen, tap . Find and tap Settings > More... > Tethering & portable hotspot.

Tap Portable Wi-Fi hotspot settings > Configure Wi-Fi hotspot. Enter the Network name (SSID) information. To select a security type, tap the Security field. If required, enter a password. Tap Save. Tap and mark the Portable Wi-Fi hotspot checkbox. If prompted, tap OK to confirm. appears in the status bar once the portable Wi-Fi® hotspot is active. To stop sharing your data connection via Wi-Fi®, unmark the Portable Wi-Fi hotspot checkbox. 29 This is an Internet version of this publication.

© Print only for private use. 1 2 3 4 5 6 7 **To rename or secure your portable hotspot** From the Home screen, tap . Find and tap Settings > More... > Tethering & portable hotspot. Tap Portable Wi-Fi hotspot settings > Configure Wi-Fi hotspot. Enter the Network name (SSID) for the network.

To select a security type, tap the Security field. If required, enter a password. Tap Save. **Controlling data usage** You can keep track of the amount of data transferred to and from your device over your mobile data or Wi-Fi® connection during a given period. For example, you can view the amount of data used by individual applications.

For data transferred over your mobile data connection, you can also set data usage warnings and limits to avoid additional charges. Adjusting data usage settings can help you keep greater control over data usage but cannot guarantee the prevention of additional charges. 1 2 3 **To turn mobile data traffic on or off** From your Home screen, tap . Find and tap Settings > Data usage. Drag the slider beside Mobile data accordingly to turn mobile data traffic on or off.

When mobile data traffic is turned off, your device can still establish Wi-Fi® and Bluetooth® connections. 1 2 3 4 **To set a data usage warning** Make sure that mobile data traffic is turned on. From your Home screen, tap . Find and tap Settings > Data usage. To set the warning level, drag the warning line to the desired value.

You receive a warning notification when the amount of data traffic approaches the level you set. To set a mobile data usage limit Make sure that mobile data traffic is turned on. From your Home screen, tap . Find and tap Settings > Data usage. Mark the Set mobile data limit checkbox if it is not marked, then tap

OK. To set the mobile data usage limit, drag the corresponding line to the desired value. Once your mobile data usage reaches the set limit, mobile data traffic on your device gets turned off automatically. 1 2 3 4 5 1 2 3 4 5 **To control the mobile data usage of individual applications** From your Home screen, tap . Find and tap Settings > Data usage. Find and tap the desired application.

Mark the Restrict background data checkbox. To access more specific settings for the application (if available), tap View app settings and make the desired changes. The performance of individual applications may be affected if you change the related data usage settings. 30 This is an Internet version of this publication. © Print only for private use.

1 2 3 **To view data transferred via Wi-Fi®** Find and tap Settings > Data usage. Tap , then mark the Show Wi-Fi usage checkbox if it is not marked. Tap the Wi-Fi tab. **Selecting mobile networks** Your device automatically switches between mobile networks depending on which mobile networks are available where you are. You can also manually set your device to use a particular mobile network mode, for example, WCDMA or GSM.

1 2 3 4 1 2 3 4 **To select a network mode** From your Home screen, tap . Find and tap Settings > More... > Mobile networks.



[You're reading an excerpt. Click here to read official SONY XPERIA E3 user guide](http://yourpdfguides.com/dref/5742825)

<http://yourpdfguides.com/dref/5742825>

Tap Network Mode. Select a network mode. To select another network manually From your Home screen, tap . Find and tap Settings > More... > Mobile networks > Network operators. Tap Search mode > Manual. Select a network. If you select a network manually, your device will not search for other networks, even if you move out of range of the manually selected network. 1 2 3 To activate automatic network selection From your Home screen, tap .

Find and tap Settings > More... > Mobile networks > Network operators. Tap Search mode > Automatic. Virtual private networks (VPNs) Use your device to connect to virtual private networks (VPNs), which allow you to access resources inside a secured local network from a public network. For example, VPN connections are commonly used by corporations and educational institutions for users who need to access intranets and other internal services when they are outside of the internal network, for example, when they are travelling. VPN connections can be set up in many ways, depending on the network. Some networks may require you to transfer and install a security certificate on your device. For detailed information on how to set up a connection to your virtual private network, please contact the network administrator of your company or organisation. 1 2 3 4 5 1 2 3 4 1 2 To add a virtual private network Find and tap Settings > More... > VPN. Tap . Select the type of VPN to add.

Enter your VPN settings. Tap Save. To connect to a virtual private network Find and tap Settings > More... > VPN. In the list of available networks, tap the VPN that you want to connect to. Enter the required information. Tap Connect. To disconnect from a virtual private network Drag the status bar downwards. Tap the notification for the VPN connection to turn it off. 31 This is an Internet version of this publication. © Print only for private use.

Synchronising data on your device Synchronising with online accounts Synchronise your device with contacts, email, calendar events and other information from online accounts, for example, email accounts such as Gmail™ and Exchange ActiveSync, Facebook™, Flickr™ and Twitter™. You can synchronise data automatically for all accounts by activating the auto-sync function. Or you can synchronise each account manually. 1 2 3 To set up an online account for synchronisation From your Home screen, tap . Tap Settings > Add account, then select the account that you want to add. Follow the instructions to create an account, or sign in if you already have an account. To activate the auto-sync function From your Home screen, tap > Settings. Drag the slider beside Auto-sync to the right. To synchronise manually with an online account From your Home screen, tap > Settings. Under Accounts, select the account type, then tap the name of the account that you want to synchronise with.

A list of items that can be synchronised with the account appears . Mark the items that you want to synchronise. Tap , then tap Sync now. To remove an online account From your Home screen, tap > Settings. Under Accounts, select the account type, then tap the name of the account that you want to remove. Tap , then tap Remove account. Tap Remove account again to confirm. 1 2 1 2 3 4 1 2 3 4 Synchronising with Microsoft® Exchange ActiveSync® Using a Microsoft Exchange ActiveSync account, you can access your corporate email messages, calendar appointments and contacts directly on your device. After setup, you can find your information in the Email, Calendar and Contacts applications. 32 This is an Internet version of this publication.

© Print only for private use. 1 2 3 4 5 6 7 8 9 To set up an EAS account for synchronisation Make sure that you have your domain and server details, provided by your corporate network administrator, available. From your Home screen, tap . Tap Settings > Add account > Exchange ActiveSync. Enter your corporate email address and password.

Tap Next. Your device begins to retrieve your account information. If a failure occurs, enter the domain and server details for your account manually and then tap Next. Tap OK to allow your corporate server to control your device. Select what data you want to sync with your device, such as contacts and calendar entries.

If desired, activate the device administrator to allow your corporate server to control certain security features on your device. For example, you can allow your corporate server to set password rules and set storage encryption. When the setup is done, enter a name for the corporate account. When you change the login password for an EAS account on your computer, you have to log in again to the EAS account on your device. 1 2 3 To change the settings of an EAS account From your Home screen, tap . Tap Email, then tap . Tap Settings and select an EAS account, then change the settings of the EAS account as desired. To set a synchronisation interval for an EAS account From your Home screen, tap . Tap Email, then tap . Tap Settings and select an EAS account.

Tap Account check frequency > Check frequency and select an interval option. To remove an EAS account From your Home screen, tap > Settings. Under Accounts, tap Exchange ActiveSync, then select the EAS account that you want to remove. Tap , then tap Remove account. Tap Remove account again to confirm. 1 2 3 4 1 2 3 4 Synchronising with Outlook using a computer You can use the Calendar and Contacts applications within the PC Companion and the Sony Bridge for Mac computer programs to synchronise your device with the calendar and contacts from your Outlook account. For more information on how to install the PC Companion on a PC or the Sony Bridge for Mac application on an Apple® Mac® computer, see Computer tools on page 107. 1 2 3 To synchronise with your Outlook contacts using a computer Make sure that the PC Companion application is installed on the PC or the Sony Bridge for Mac application is installed on the Apple® Mac® computer. Computer: Open the PC Companion application or the Sony Bridge for Mac application. Click Start to start the Contacts and Contacts Sync applications and follow the on-screen instructions to synchronise your device with your Outlook contacts.

33 This is an Internet version of this publication. © Print only for private use. 1 2 3 To synchronise with your Outlook calendar using a computer Make sure that the PC Companion application is installed on the PC or the Sony Bridge for Mac application is installed on the Apple® Mac® computer. Computer: Open the PC Companion application or the Sony Bridge for Mac application. Click Start to start the Calendar and Calendar Sync applications and follow the on-screen instructions to synchronise your device with your Outlook calendar.

34 This is an Internet version of this publication. © Print only for private use. Basic settings Accessing settings View and change settings for your device from the Settings menu.



[You're reading an excerpt. Click here to read official SONY XPERIA E3 user guide](http://yourpdfguides.com/dref/5742825)
<http://yourpdfguides.com/dref/5742825>

The Settings menu is accessible from both the Application screen and the Quick settings panel. ••1 2 1 2 To open the device settings menu from the Application screen Tap Settings.

To open the Quick settings panel Using two fingers, drag the status bar downwards. To select which settings to display on the Quick settings panel Using two fingers, drag the status bar downwards, then tap Edit. Select the quick settings that you want to display. To rearrange the Quick settings panel Using two fingers, drag the status bar downwards, then tap Edit. beside a quick setting, then move it to the desired position. Touch and hold Sound, ringtone and volume You can adjust the ringtone volume for incoming calls and notifications as well as for music and video playback. You can also set your device to silent mode so that it doesn't ring when you're in a meeting. •••1 2 1 2 3 1 2 3 4 1 2 3 4 To adjust the ringtone volume with the volume key Press the volume key up or down. To adjust the media playing volume with the volume key When playing music or watching video, press the volume key up or down. To set your device to vibrate mode Press the volume key down until appears in the status bar.

To set your device to silent mode Press the volume key down until the device vibrates and appears in the status bar. Press the volume key down again. appears in the status bar. To set your device to vibrate and ring mode From your Home screen, tap . Find and tap Settings > Sound. Mark the Vibrate when ringing checkbox. To set a ringtone From your Home screen, tap . Find and tap Settings > Sound > Phone ringtone. Select a ringtone. Tap Done.

To select the notification sound From your Home screen, tap . Find and tap Settings > Sound > Notification sound. Select the sound to be played when notifications arrive. Tap Done. 35 This is an Internet version of this publication.

© Print only for private use. 1 2 3 To enable touch tones From your Home screen, tap . Find and tap Settings > Sound. Mark the Dial pad touch tones and Touch sounds checkboxes. SIM card protection You can lock and unlock each SIM card that you use in your device with a PIN (Personal Identity Number). When a SIM card is locked, the subscription linked to the card is protected against misuse, meaning that you have to enter a PIN every time you start your device. If you enter the PIN incorrectly more times than the maximum number of attempts allowed, your SIM card will become blocked. You then need to enter your PUK (Personal Unblocking Key) and a new PIN. Your PIN and PUK are supplied by your network operator. 1 2 3 4 1 2 3 4 5 1 2 3 To lock or unlock a SIM card From the Home screen, tap . Find and tap Settings > Security > Set up SIM card lock. Mark or unmark the Lock SIM card checkbox. Enter the SIM card PIN and tap OK. To change the SIM card PIN Find and tap Settings > Security > Set up SIM card lock. Tap Change SIM PIN.

Enter the old SIM card PIN and tap OK. Enter the new SIM card PIN and tap OK. Re-type the new SIM card PIN and tap OK. To unlock a blocked SIM card using the PUK code . Enter the PUK code and tap . Enter a new PIN code and tap Re-enter the new PIN code and tap . If you enter an incorrect PUK code too many times, you need to contact your network operator to get a new SIM card. Screen settings 1 2 3 4 To adjust the screen brightness From your Home screen, tap . Find and tap Settings > Display > Brightness. Unmark the Adapt to lighting conditions checkbox if it is marked.

Drag the slider to adjust the brightness. Lowering the brightness level increases battery performance. 1 2 3 To set the screen to vibrate on touch From your Home screen, tap . Find and tap Settings> Sound. Mark the Vibrate on touch checkbox.

The screen now vibrates when you tap soft keys and certain applications. To adjust the idle time before the screen turns off From your Home screen, tap . Find and tap Settings > Display > Sleep. Select an option. To turn off the screen quickly, briefly press the power key .

1 2 3 36 This is an Internet version of this publication. © Print only for private use. Screen lock There are several ways to lock the screen. The security level of each lock type is listed below in order of weakest to strongest: •••••Swipe – no protection, but you have quick access to the Home screen Face Unlock – unlocks your device when you look at it Unlock pattern – draw a simple pattern with your finger to unlock your device Unlock PIN – enter a numeric PIN of at least four digits to unlock your device Unlock password – enter an alpha-numeric password to unlock your device It is very important that you remember your screen unlock pattern, PIN or password. If you forget this information, it may not be possible to restore important data such as contacts and messages. 1 2 3 4 To set up the Face Unlock feature From your Home screen, tap > Settings > Security > Screen lock. Tap Face Unlock, then follow the instructions in your device to capture a photo of your face. After your face is successfully captured, tap Continue. Select a backup unlock method and follow the instructions in the device to complete the setup. For best results, capture your face in an indoor area that is well lit but not too bright, and hold the device at eye level.

1 2 To unlock the screen using the Face Unlock feature Activate the screen. Look at your device from the same angle you used to capture your Face Unlock photo. If the Face Unlock feature fails to recognise your face, you must use the backup unlock method to unlock the screen. 1 2 3 To create a screen lock pattern From your Home screen, tap . Find and tap Settings > Security > Screen lock > Pattern. Follow the instructions in your device. If your lock pattern is rejected five times in a row when you try to unlock your device, you must wait 30 seconds and then try again. 1 2 3 1 2 3 4 5 6 7 To change the screen lock pattern Find and tap Settings> Security > Screen lock. Draw your screen unlock pattern. Tap Pattern and follow the instructions in your device.

To create a screen unlock PIN From your Home screen, tap > Settings > Security > Screen lock > PIN. Enter a numeric PIN. If necessary, tap to minimise the keyboard. Tap Continue. Re-enter and confirm your PIN.

If necessary, tap to minimise the keyboard. Tap OK. 37 This is an Internet version of this publication. © Print only for private use. 1 2 3 4 5 6 7 1 2 3 To create a screen lock password From your Home screen, tap > Settings > Security > Screen lock > Password.

Enter a password. If necessary, tap to minimise the keyboard. Tap Continue. Re-enter and confirm your password. If necessary, tap to minimise the keyboard. Tap OK. To change screen lock type From your Home screen, tap . Find and tap Settings > Security > Screen lock. Follow the instructions in your device and select another screen lock type. Language settings You can select a default language for your device and change it again at a later time.



[You're reading an excerpt. Click here to read official SONY XPERIA E3 user guide](http://yourpdfguides.com/dref/5742825)

<http://yourpdfguides.com/dref/5742825>

You can also change the writing language for text input. See Keyboard settings on page 42. 1 2 3 To change the language Find and tap Settings > Language & input > Language. Select an option. Tap OK. If you select the wrong language and cannot read the menu texts, find and tap . Then select the text beside and select the first entry in the menu that opens. You can then select the language you want. Date and time You can change the date and time on your device. 1 2 3 4 5 1 2 3 4 5 6 1 2 3 4 To set the date manually Find and tap Settings > Date & time.

Unmark the Automatic date & time checkbox, if it is marked. Tap Set date. Adjust the date by scrolling up and down. Tap Set. To set the time manually Find and tap Settings > Date & time.

Unmark the Automatic date & time checkbox if it is marked. Tap Set time. Scroll up or down to adjust the hour and minute. If applicable, scroll up to change AM to PM, or vice versa. Tap Set.

To set the time zone Find and tap Settings > Date & time. Unmark the Automatic time zone checkbox, if it is marked. Tap Select time zone. Select an option.

Enhancing the sound output You can enhance the sound output that comes from the speakers in your device using features such as Clear Phase™ and xLOUD™ technology. 38 This is an Internet version of this publication. © Print only for private use. Using Clear Phase™ technology Use Clear Phase™ technology from Sony to automatically adjust the sound quality coming from your device's internal speakers and get a cleaner, more natural sound. 1 2 3 To enhance the speaker sound quality using Clear Phase™ From your Home screen, tap . Find and tap Settings > Sound.

Mark the Clear Phase™ checkbox. The activation of the Clear Phase™ feature has no effect on voice communication applications. Using xLOUD™ technology Use xLOUD™ audio filter technology from Sony to enhance the speaker volume without sacrificing quality. Get a more dynamic sound as you listen to your favourite songs. 1 2 3 To enhance the speaker volume using xLOUD™ From your Home screen, tap . Find and tap Settings > Sound. Mark the xLOUD™ checkbox. The activation of the xLOUD™ feature has no effect on voice communication applications. 39 This is an Internet version of this publication. © Print only for private use.

Typing text On-screen keyboard You can enter text with the on-screen QWERTY keyboard by tapping each letter individually, or you can use the Gesture input feature and slide your finger from letter to letter to form words. You can select up to three languages for text input. The keyboard detects the language that you are using and predicts the words for that language as you type. Some applications open the on-screen keyboard automatically, for example, email and text messaging applications. 1 Delete a character before the cursor.

2 Enter a carriage return or confirm text input. 3 Enter a space. 4 Personalise your keyboard. This key disappears after the keyboard is personalised. 5 Display numbers and symbols.

For even more symbols, tap 6 Switch between lower-case , upper-case access extra characters in the language. and caps . . For some languages, this key is used to •• To display the on-screen keyboard to enter text Tap a text entry field. To use the on-screen keyboard in landscape orientation When the on-screen keyboard is displayed, turn the device sideways. You may need to adjust the settings in some applications to enable landscape orientation. 1 2 To enter text character by character To enter a character visible on the keyboard, tap the character. To enter a character variant, touch and hold a regular keyboard character to get a list of available options, then select from the list. For example, to enter "é", touch and hold "e" until other options appear, then, while keeping your finger pressed on the keyboard, drag to and select "é". To enter a period After you enter a word, double-tap the space bar.

To enter text using the Gesture input function When the on-screen keyboard is displayed, slide your finger from letter to letter to trace the word that you want to write. After you finish entering a word, lift up your finger. A word suggestion appears based on the letters that you have traced. to see other options and if the word that you want does not appear, tap select accordingly. If the desired option does not appear, delete the entire word and trace it again, or enter the word by tapping each letter individually. • 1 2 3 40 This is an Internet version of this publication. © Print only for private use. 1 2 3 To change the Gesture input settings When the on-screen keyboard is displayed, tap . Tap , then tap Keyboard settings > Text input settings. To activate or deactivate the Gesture input function, mark or unmark the Gesture input checkbox.

To use the one-handed keyboard Open the on-screen keyboard in portrait mode, then tap . Tap , then tap One-handed keyboard. To move the one-handed keyboard to the left side or right side of the screen, or accordingly. tap To return to using the full on-screen keyboard, tap . 1 2 3 Entering text using voice input When you enter text, you can use the voice input function instead of typing the words.

Just speak the words that you want to enter. Voice input is an experimental technology from Google™, and is available for a number of languages and regions. 1 2 3 4 To enable voice input When you enter text using the on-screen keyboard, tap . Tap , then tap Keyboard settings. Mark the Google voice typing key checkbox.

Tap to save your settings. A microphone icon appears on your on-screen keyboard. To enter text using voice input Open the on-screen keyboard. Tap . When appears, speak to enter text. When you're finished, tap again. The suggested text appears. Edit the text manually if necessary. To make the keyboard appear and enter text manually, tap . 1 2 3 4 Editing text You can select, cut, copy and paste text as you write.

You can access the editing tools by double-tapping the entered The editing tools then become available via an application bar. Application bar 1 2 3 4 5 Close the application bar Select all text Cut text Copy text Paste text only appears when you have text saved on the clipboard. 41 This is an Internet version of this publication. © Print only for private use. 1 2 1 2 To select text Enter some text, then double-tap the text. The word you tap gets highlighted by tabs on both sides. Drag the tabs left or right to select more text. To edit text Enter some text, then double-tap the entered text to make the application bar appear. Select the text that you want to edit, then use the tools in the application bar to make your desired changes. Keyboard settings You can select settings for the on-screen keyboard, such as writing language and automatic correction.

1 2 3 4 1 2 3 To access the on-screen keyboard settings When you enter text using the on-screen keyboard, tap .



[You're reading an excerpt. Click here to read official SONY XPERIA E3 user guide](http://yourpdfguides.com/dref/5742825)

<http://yourpdfguides.com/dref/5742825>

Tap , then tap Keyboard settings and change the settings as desired. To add a writing language for text input, tap Writing languages and mark the relevant checkboxes. Tap OK to confirm. To display the Smiley key When you enter text using the on-screen keyboard, tap .

Tap , then tap Keyboard settings > Symbols and smileys. Mark the Smiley key checkbox. 42 This is an Internet version of this publication. © Print only for private use. Calling Making calls You can make a call by manually dialling a phone number, by tapping a number saved in your contacts list, or by tapping the phone number in your call log view.

You can also use the smart dial feature to quickly find numbers from your contacts list and call logs. To make a video call, you can use the Hangouts™ instant messaging and video chat application on your device. See Instant messaging and video chat on page 59. 1 2 3 4 5 6 7 8 9 Open your contacts list View your call log entries View your favourite contacts View all contact groups saved to your device Delete number Dialpad View more options Call button Hide or show the dialer 1 2 3 1 2 3 4 To make a call by dialling From your Home screen, tap . Find and tap Phone. Enter the number of the recipient and tap . To make a call using smart dial From your Home screen, tap . Find and tap Phone. Use the dialpad to enter letters or numbers that correspond to the contact you want to call. As you enter each letter or number, a list of possible matches appears.

Tap the contact you want to call. 43 This is an Internet version of this publication. © Print only for private use. 1 2 3 4 To make an international call From your Home screen, tap . Find and tap Phone. Touch and hold 0 until a “+” sign appears. Enter the country code, area code (without the initial zeros) and phone number, then tap . To add a direct dial number to your Home screen Touch and hold an empty area on your Home screen until the device vibrates and the customisation menu appears. In the customisation menu, tap Apps > Shortcuts. Scroll through the list of applications and select Direct dial.

Select the contact and the number that you want to use as the direct dial number. 1 2 3 4 Showing or hiding your phone number You can select to show or hide your phone number on call recipients' devices when you call them. 1 2 To show or hide your phone number From the Home screen, tap . Find and tap Settings > Call settings > Additional settings > Caller ID. Receiving calls To answer a call To decline a call • To mute the ringtone for an incoming call When you receive the call, press the volume key.

Using the answering machine You can use the answering machine application in your device to answer calls when you are busy or miss a call. You can enable the automatic answering function and determine how many seconds to wait before the calls get answered automatically. You can also manually route calls to the answering machine when you are too busy to answer them. And you can access messages left on your answering machine directly from your device.

Before using the answering machine, you must record a greeting message.

• To reject a call with the answering machine When an incoming call arrives, drag Response options upwards, then select Reject with Answering Machine. To record a greeting message for the answering machine From your Home screen, tap . Find and tap Settings > Call settings > Answering Machine > Greetings. Tap Record new greeting and follow the on-screen instructions. 1 2 3 44 This is an Internet version of this publication. © Print only for private use. 1 2 3 To enable automatic answering From your Home screen, tap . Find and tap Settings > Call settings > Answering Machine. Mark the Answering Machine checkbox. If you don't set a time delay for the automatic answering of calls, the default value is used.

1 2 3 4 5 1 2 3 To set a time delay for automatic answering From your Home screen, tap . Find and tap Settings > Call settings > Answering Machine. Tap Pick up after. Adjust the time by scrolling up and down. Tap Done. To listen to messages on the answering machine From your Home screen, tap . Find and tap Settings > Call settings > Answering Machine > Messages. Select the voice message that you want to listen to. You can also listen to answering machine messages directly from the call log by tapping . Rejecting a call with a text message You can reject a call with a text message.

When you reject a call with such a message, the message is automatically sent to the caller and stored in the Messaging conversation with the contact. You can select from a number of predefined messages available on your device, or you can create a new message. You can also create your own personalised messages by editing the predefined ones. 1 2 1 2 1 2 3 4 To reject a call with a text message When an incoming call arrives, drag Response options upwards, then tap Reject with message. Select a predefined message or tap and write a new message.

To reject a second call with a text message When you hear repeated beeps during a call, drag Response options upwards, then tap Reject with message. Select a predefined message or tap and write a new message. To edit the text message used to reject a call From your Home screen, tap . Find and tap Settings > Call settings > Reject call with message. Tap the message that you want to edit, then make the necessary changes.

Tap OK. 45 This is an Internet version of this publication. © Print only for private use. Ongoing calls 1 2 3 4 5 6 Open your contacts list Turn on the loudspeaker during a call Put the current call on hold or retrieve the call Enter numbers during a call Mute the microphone during a call End a call • • To change the ear speaker volume during a call Press the volume key up or down. To activate the screen during a call Briefly press . Using the call log In the call log, you can view missed calls 1 2 1 2 3 To view your missed calls When you have missed a call, downwards. Tap Missed call . , received calls and dialled calls . appears in the status bar. Drag the status bar To call a number from your call log From your Home screen, tap .

Find and tap Phone. The call log view appears on the upper part of the screen. To call a number directly, tap the number. To edit a number before calling, touch and hold the number, then tap Edit number before call. You can also call a number by tapping > Call back. 1 2 3 4 5 1 2 3 To add a number from the call log to your contacts From your Home screen, tap . Find and tap Phone. The call log view appears on the upper part of the screen. Touch and hold the number, then tap Add to Contacts. Tap the desired contact, or tap Create new contact.

Edit the contact details and tap Done. To hide the call log From your Home screen, tap Find and tap Phone. Tap > Hide call log . 46 This is an Internet version of this publication.

© Print only for private use. Forwarding calls You can forward calls, for example, to another phone number, or to an answering service.



[You're reading an excerpt. Click here to read official SONY XPERIA E3 user guide](http://yourpdfguides.com/dref/5742825)

<http://yourpdfguides.com/dref/5742825>