




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for TOSHIBA RAS-M10NKV-E. You'll find the answers to all your questions on the TOSHIBA RAS-M10NKV-E in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual TOSHIBA RAS-M10NKV-E
User guide TOSHIBA RAS-M10NKV-E
Operating instructions TOSHIBA RAS-M10NKV-E
Instructions for use TOSHIBA RAS-M10NKV-E
Instruction manual TOSHIBA RAS-M10NKV-E



[You're reading an excerpt. Click here to read official TOSHIBA RAS-M10NKV-E user guide](http://yourpdfguides.com/dref/3703876)
<http://yourpdfguides.com/dref/3703876>

Manual abstract:

Specifications 2. Construction Views 3. Wiring Diagram 4. Specifications of Electrical Parts (Indoor unit only) 5. Control Block Diagram (Indoor unit only) 6. Operation Description 7. Installation Procedure 8. How to Diagnose the trouble 9. How to Replace the main parts (Indoor unit only) 10. @@SVM-05019 1.

@@SVM-05019 2. CONSTRUCTION VIEWS Indoor Unit Front panel Air inlet Air filter Heat exchanger 790 218 275 60 Air outlet 48 6 Knock out system Knock out system 64 53 120 590 Hanger 80 Drain hose (0.54m) Hanger 320 Connecting pipe (0.43m) (Flare 6.35) Connecting pipe (0.33m) (For 10,13 series ; Flare 9.52 For 16 series ; Flare 12.7) 235 215 For stud bolt (8~10) For stud bolt (6) 620 235 215 Minimum distance to ceiling 65 or more Hanger 26 48 45 275 190 Minimum distance to ceiling Minimum distance to ceiling 45 170 or more 170 or more Hanger 90 150 160 160 Hanger 32 40 57 18 90 150 Installation plate outline Center line Wireless remote control 3 160 6 60 FILE NO. SVM-05019 3. WIRING DIAGRAM 3-1. Indoor Unit (For 10k & 13k) COLOR INDICATION BRW RED WHI YEL BLU BLK GRY PNK ORN GRN&YEL GRN : : : : : : : : : : BROWN RED WHITE YELLOW BLUE BLACK GRAY PINK ORANGE GREEN & YELLOW GREEN TERMINAL BLOCK 2 1 BLK W HI RED CN21 INDOOR OUTDOOR UNIT UNIT BLK BLK CN01 (BLU) CN24 CN23 HEAT EXCHANGER SENSOR CN03 (W HI) (TC) BLK BLK 11 22 LINE FILTER Power supply circuit 5 CN07 (W HI) +12 VDC +5 VDC FUSE THERMO SENSOR (TA) 11 22 T3.15A 250VAC F01 R04 3 Fan Motor Drive circuit BLU BLU BLU BLU BLU BLU BLU BLU BLU BLU 10 10 10 10 WHI 11 11 11 11 INFRARED RAYS RECEIVING AND INDICATING PARTS 1 2 3 4 5 6 7 8 9 CN25 (W HI) 1 2 3 4 5 6 7 8 9 CN13 (W HI) 11 22 33 44 55 W HI YEL YEL YEL YEL 11 22 33 44 55 1 2 3 4 5 6 7 8 9 1 2 3 4 5 6 7 8 9 LOUVER MOTOR CN11 123 123 CN10 5 5 3 3 BLK 1 1 RED 6 YEL GRY BRW MAIN P.C. BOARD WP-004 150°C 123456 12345 6 AC FAN MOTOR MCC-861 1 4 1234 HA JEM-A CN08 Simple Check for Failure Diagnosis Check Item Diagnosis Result 1 Check to see if the OPERATION indicator goes on OPERATION and off when the main switch or breaker is turned on. INDICATOR (Check the primary and secondary voltage of the transformer.) 2 Check the power supply voltage between 1 and 2. @@(15~60VDC) FUSE Check to see if the fuse blows out. @@@@ (Check the F01) Refer to the service data for the detailed failure diagnosis. 4 WHI FILE NO. SVM-05019 3-2.

Indoor Unit (For 16k) COLOR INDICATION BRW : RED : WHI : YEL : BLU : BLK : GRY : PNK : ORN : GRN&YEL : GRN : BROWN RED WHITE YELLOW BLUE BLACK GRAY PINK ORANGE GREEN & YELLOW GREEN TERMINAL BLOCK 2 BLK 123 WHI RED INDOOR OUTDOOR UNIT UNIT BLK BLK CN01 (BLU) CN24 CN23 CN21 HEAT EXCHANGER SENSOR CN03 (WHI) (TC) BLK BLK 11 22 6 CN10 (WHI) FAN MOTOR RED BLK WHI YEL BLU 11 FUSE THERMO SENSOR (TA) 11 22 T3.15A 250VAC F01 3 LINE FILTER DC5V DC12V 3 4 5 6 3 4 5 6 DC MOTOR CN13 (WHI) BLU BLU BLU BLU BLU BLU BLU BLU BLU BLU 10 10 10 10 WHI 11 11 11 11 INFRARED RAYS RECEIVING AND INDICATING PARTS 1 2 3 4 5 6 7 8 9 CN25 (WHI) 1 2 3 4 5 6 7 8 9 R05 DB01 R04 ~ ~ POWER SUPPLY CIRCUIT 5 CN07 (WHI) + + MAIN P.C. BOARD MCC-867or MCC-5014 C03 1 2 3 4 5 1 2 3 4 5 WHI YEL YEL YEL YEL 11 22 33 44 55 MCC-861 1 4 1234 HA JEM-A CN08 LOUVER MOTOR Simple Check for Failure Diagnosis Check Item Diagnosis Result 1 Check to see if the OPERATION indicator goes on OPERATION and off when the main switch or breaker is turned on. INDICATOR (Check the primary and secondary voltage of the transformer.) Check the power supply voltage between 1 and 2. @@(15 60VDC) 2 ~ 3 FUSE Check to see if the fuse blows out. 3.15A (Check the R04 of the varistor.) 4 Check the voltage at the No. 4 pin on CN13 connector DC5V of the infrared receiver. @@(Check the transformer and the power supply circuit of the rated voltage.) ~ Refer to the service data for the detailed failure diagnosis. 5 Check the voltage at the No.1 pin on CN10 DC325V connector.

(Check the DB01, R05 and C03.) (DC310 340V) 6 FILE NO. SVM-05019 4. SPECIFICATIONS OF ELECTRICAL PARTS RAS-M10NKV-E, RAS-M13NKV-E RAS-M10NKCV-E, RAS-M13NKCV-E No. 1 2 3 4 5 6 7 8 9 10 11 12 13 Parts name Fan motor (for indoor) Thermo. sensor (TA-sensor) AC-AC transformer (T01) Microcomputer Heat exchanger sensor (TC-sensor) Line filter (L01) Diode (DB01) Capacitor (C50) Fuse (F01) Regulator IC (IC08) Regulator IC (IC11) Varistor (R21, R109) Louver motor Type SKF-220-20-4A-1 ----- TT-10 Specifications AC Motor with 150°C thermo fuse 10 k at 25°C 187 - 276V, 6VA μ PD780024AGK ----- SS11V-06270 KBP06M 10 k at 25°C 27 μ H, AC 0.64A 1.5A, 420V LXV35VB2200MJ20 BET 3.15A 250VAC NJM7812 NJM7805 15G561K 24BYJ48 2200 μ F, 35V T3.15A, 250 V 12VDC, 1.5A max 5VDC, 1.5A max 560 V DC 12V RAS-M16NKV-E, RAS-M16NKCV-E No. 1 2 3 4 5 6 7 8 9 10 11 12 13 Parts name Fan motor (for indoor) Thermo. sensor (TA-sensor) DC-DC transformer (T01) Microcomputer Heat exchanger sensor (TC-sensor) Line filter (L01) Diode (DB01) Capacitor (C03) Fuse (F01) Power supply IC (IC01) Varistor (R21, R109) Resistor (R01) Louver motor Type ICF-340-30-2 ----- SWT-70 μ PD780024AGK ----- SS11V-06270 D3SBA60 KMH450VSSN120M25C FCU250V, 3.15A STR-L472 15G561K RF-5TK4R7 24BYJ48 560 V 4.

7, 5 W 12VDC Specifications DC 340 V, 30 W 10 k at 25°C DC 390 V, Secondary DC 15 V, 12 V, 7 V 10 k at 25°C 27mH, AC 0.6A 4A, 600 V 120 μ F, 450 V T3.15A, 250 V 6 FILE NO. SVM-05019 5. CONTROL BLOCK DIAGRAM 5-1. Indoor Unit Heat Exchanger Sensor Indoor Unit Control Panel M.C.U. Functions · Louver Control · 3-minute Delay at Restart for Compressor · Motor Revolution Control Infrared Rays Signal Receiver · Processing (Temperature Processing) · Timer Filter Sign Display Operation Display Timer Display Temperature Sensor Infrared Rays Initiallizing Circuit Clock Frequency Oscillator Circuit Fan Only Sign Display Indoor Fan Motor Power Supply Circuit Remote Control Outdoor unit ON/OFF Signal Louver ON/OFF Signal Noise Filter Louver Driver Louver Motor From Outdoor Unit Outdoor Unit REMOTE CONTROLLER RAS-M10NKV-E, RAS-M13NKV-E, RAS-M16NKV-E RAS-M10NKCV-E, RAS-M13NKCV-E, RAS-M16NKCV-E (Heat pump model) Infrared Rays (Cooling only model) Infrared Rays Remote Controller Operation () Remote Controller Operation () Operation Mode Selection AUTO, COOL, DRY, HEAT Thermo. Setting Fan Speed Selection ON TIMER Setting OFF TIMER Setting Louver AUTO Swing Louver Direction Setting ECONO.



[You're reading an excerpt. Click here to read official TOSHIBA RAS-M10NKV-E user guide](http://yourpdfguides.com/dref/3703876)

<http://yourpdfguides.com/dref/3703876>

Operation Mode Selection AUTO, COOL, DRY, FAN ONLY Thermo. Setting Fan Speed Selection ON TIMER Setting OFF TIMER Setting Louver AUTO Swing Louver Direction Setting ECONO. 7 FILE NO. SVM-05019 6. OPERATION DESCRIPTION 6-1.

Outline of Air Conditioner Control This air conditioner is a capacity-variable type air conditioner. The capacity proportional control compressor which can change the motor speed is mounted. The indoor unit motor drive circuit is mounted to the indoor unit. The compressor and the inverter to control outdoor unit motor are mounted to the outdoor unit. The entire air conditioner is mainly controlled by the indoor unit controller.

The indoor unit controller drives the indoor fan motor based upon command sent from the remote controller, and transfers the operation command to the outdoor unit controller. The outdoor unit controller receives operation command from the indoor unit side, and controls the outdoor fan and the pulse modulating valve. Besides, detecting revolution position of the compressor motor, the outdoor unit controller controls speed of the compressor motor by controlling output voltage of the inverter and switching timing of the supply power (current transfer timing) so that motors drive according to the operation command. And then, the outdoor unit controller transfers reversely the operating status information of the outdoor unit to control the indoor unit controller.

(2) Role of outdoor unit controller Receiving the operation command signal (Serial signal) from the indoor controller, the outdoor unit performs its role. · Compressor operation Operations followed control to judgment of · Operation control of serial signal from outdoor fan motor indoor side. · P.M.V. control · Detection of inverter input current and current release operation · Over-current detection and prevention operation to transistor module (Compressor stop function) · Compressor and outdoor fan stop function when serial signal is off (when the serial signal does not reach the board assembly of outdoor control by trouble of the signal system) · Transferring of operation information (Serial signal) from outdoor unit to indoor unit · Detection of outdoor temperature and operation revolution control · Defrost control in heating operation (Temp.

measurement by outdoor heat exchanger and control for 4-way valve and outdoor fan) (3) Contents of operation command signal (Serial signal) from indoor unit controller to outdoor unit controller The following three types of signals are sent from the indoor unit controller. · Operation mode set on the remote controller · Compressor revolution command signal defined by indoor temperature and set temperature (Correction along with variation of room temperature and correction of indoor heat exchanger temperature are added.) · For these two tyng to reduce the current on much power consumption of cooling/heating operation. Controlling starts from the time when input power has reached at a certain point. To be concrete, IGBT of the power factor improvement circuit is used, and the power factor is improved by keeping IGBT on for an arbitrary period to widen electro-angle of the input current. -9- FILE NO. SVM-05019 6-1-4. Prevent-Freezing Control The indoor heat exchanger sensor detects refrigerant vapor temperature in COOL/DRY operation. If the temperature is below the specified value, compressor motor speed is reduced so that operation is performed in temperature below the specified value to prevent-freezing of indoor heat exchanger. 6-1-6.

Louver Control (1) Vertical air flow louvers Positions of vertical air flow louvers are automatically controlled according to the operation status (AUTO, COOL, DRY, HEAT). Besides, positions of vertical air flow louvers can be arbitrarily set by pressing the [FIX] button. The louver position which has been set by the [FIX] button is stored in microcomputer, and the louver is automatically set at the stored position in the next operation. (2) Swing If the [SWING] button is pressed during running operation, vertical air flow louvers start swinging. When the [SWING] button is pressed again, swinging stops.

6-1-5. P. M. V. (Pulse Modulating Valve) Using P.

M.V., refrigerant flow of refrigeration cycle is varied for the optimum temperature. Controlling each unit separately by four P.M.V. corresponds to difference of pipe length, fan speed, and unit temperature. If an error occurs on cycle temperature when power source of the air conditioner has been turned on, and if start/stop times of the outdoor unit are 30 times, move the valve once until it hits on the stopper for positioning of the valve. In this case, ticktack sound may be heard. 6-1-7.

Indoor Fan Control The indoor fan is operated by motor speed non-step variable drive system mion can be effected thereafter simply by pushing [] button. · A cooling operation signal is transmitted to outdoor unit. · The indoor fan motor operates as shown in Fig.62-2 when [FAN] button is set to AUTO. · The motor operates with a constant air flow when the [FAN] button is set to LOW, LOW+, MED, MED+, or HIGH. · The outdoor unit controls the outdoor fan relay R01, R02 and R03, and the compressor motor speed according to the operation command signal sent from the indoor unit. (1) Cooling capacity control · The cooling capacity and room temperature are controlled by changing the compressor motor speed according to both the difference between the temperature detected by the room temperature sensor and the temperature set by [TEMP] button and also any change in room temperature. · When compressor has been activated or reactivated, it operates with Max. 33 rps for 2 minutes and with Max. 57 rps from 2 to 4 minutes passed.

· When room temperature is lower than set temperature and indoor fan motor is operated at fan speed L as shown in Fig. 6-2-2 while the outdoor unit stops. (2) Prevent-freezing control If temperature of indoor heat exchanger detected by the indoor heat exchanger sensor is 5°C or lower, compressor motor speed is gradually lowered to prevent freezing of the indoor heat exchanger. If temperature is 7°C or higher, return the operation to the above item (1). (3) Current release control The input current of compressor and outdoor fan motor (Precisely inverter main circuit control section) which occupy most of air conditioner input is detected by the outdoor current sensor, and compressor motor speed is gradually lowered so that current value does not exceed 11.

5A if current value exceeds 11.5A. When the current value lowers to 11.0A, return the operation to the above item (1). (Room temp.

) (Set temp.) °C +3 +2.5 +2 +1.5 +1 +0.5 0 0,5 M+ *1 *1 *1 L In normal operation Set temp. Current value NOTE : *1: Calculated from difference in motor speed of M+ and L, and controlled. Fig. 6-2-2 Setting of air flow [Air Flow AUTO] 14.



[You're reading an excerpt. Click here to read official TOSHIBA RAS-M10NKV-E user guide](http://yourpdfguides.com/dref/3703876)

<http://yourpdfguides.com/dref/3703876>

2 Comp. motor speed down 13.

7 Normal control Comp. motor speed keep Fig. 6-2-3 (4) Outdoor temperature release control The outdoor temperature release is controlled by changing the current release points 14.2 and 13.7 in the above item according to temperature detected by the outdoor temperature sensor. For example, if the outdoor temperature is 43°C, the value of current release points becomes 9.6A. - 12 - FILE NO. SVM-05019 (5) Limit for maximum compressor motor speed by indoor fan speed When outdoor temperature sensor detected 32°C or lower, and indoor heat exchanger sensor detected 17°C or lower, the maximum compressor motor speed is limited by the indoor fan speed. For example, when 1 unit only operates, the compressor motor speed is limited as described in the table below. Table 6-2-1 Air flow rate HIGH M+ MED L L UL SUL M10 (rps) 32 29 24 20 20 20 20 M13 (rps) 48 42 28 20 20 20 20 M16 (rps) 54 46 38 30 30 20 20 (6)

Louver control The vertical air flow louvers are automatically set to horizontal or cool memory position. When temperature of indoor heat exchanger becomes 5°C or lower by the prevent-freezing control and the compressor is turned off, the vertical air flow louvers close once and then return to the position of previous time. (7) Discharge temperature control The discharge temperature of refrigerant gas from the compressor is detected by the discharge temperature sensor, and controls operating compressor motor speed. 1) Control 1 (A zone) : Normal operation zone When TD detect value is 101°C or lower, the operation is performed with operating motor speed instructed by the serial signal. 2) Control 2 (B zone) : Slow-up zone of motor speed When TD detect value is 101°C or higher, operating motor speed is slowly up.

3) Control 3 (C zone) : Keep zone When TD detect value is 108°C or higher, operating motor speed is not changed if raising operation speed. 4) Control 4 (D zone) : Slow down zone of motor speed When TD detect value is 111°C or higher, operating motor speed is slowly down. 5) Control 5 (E zone) : Normal down of motor speed When TD detect value is 115°C or higher, operating motor speed is down. 6) Control 6 (F zone) : Operation stop zone If TD detect value exceeds 120°C during operation, stop the operation immediately. Then, restart the operation when TD detect value becomes 108°C or lower.

TD (°C) 120 115 111 Zone F E D Operation stop zone Normal down zone of motor speed Slow down of motor speed Release of motor speed 108 C Keep zone : Motor speed is not changed. 101 B Slow-up zone of motor speed A Normal operation zone Fig. 6-2-4 Compressor motor speed control 13 FILE NO. SVM-05019 (8) ECONO operation control When the [ECO] button is pushed, ECONO operation is performed by restraining air flow and compressor motor speed. The set temperature is changed also. 1) The set temperature increased 0.5°C per hour up to 2°C starting from the set temperature when ECONO has been received. 2) Indoor air flow is controlled between L+ and UL. The compressor motor speed in control as shown in Fig. 6-2-5 Fig.

6-2-5 (9) COMFORT SLEET operation control. When the [COMFORT SLEEP] button is pushed, the ECONO operation activate together with the timer OFF function. Each time of pressing [COMFORT SLEEP] button the off timer setting changes in the sequence of 1, 3, 5 or 9 hours. (10) Hi POWER operation control. When the [Hi POWER] button is pushed Hi Power operation is performed by change set temperature and air flow (display on the remote control does not change). 1) Changing of set temperature. Fig. 6-2-6 - 14 - FILE NO. SVM-05019 2) Changing of air flow (Fan setting : AUTO) When the Hi POWER is started, the fan of the indoor unit operates at higher air flow level than normal air flow AUTO (normal air flow AUTO is shown in Fig. 6-2-2).

Because of the difference between room temperature and set temperature are increased automatically. 3) Changing of air flow (Fan setting : One of 5 levels) When the Hi POWER is started, the fan of the indoor unit operates at higher consecutive air flow level. (Fan speed on the display of remote control does not change) 4) Changing of louver position If the room temperature is higher than setting temperature by 3.5 °C or more, the louver is automatically set to the maximum air flow position. If it is not, position of louver is not change.

When room temperature is reach to setting temperature. The louver moves back to set position. · The outdoor unit controls the outdoor fan relay R01, R02 and R03, and the compressor motor speed according to the operation command signal sent from the indoor unit. +2.5 (Room temp.

) (Set temp.) +2.0 +1.5 L *1 +1.0 SUL +0.5 0 0.5 Set temp. NOTE : *1 : Middle motor speed between L and SUL Fig. 6-2-7 Setting of air flow (11) Quiet operation control. When the [QUIET] button is pushed, the fan is restricted the revolution speed at L- level until the [QUIET] button is pushed once again (cancel QUIET operation).

Remarks : QUIET operation is appropriate to work with less cooling load condition. Because of the fan speed L- may cause not enough the cooling capacity.

6-2-3. DRY Operation (The Remote controller [MODE] Button is Set to the DRY Position) · Once the setting is made, the operation mode is memorized in the microcomputer so that the same operation can be effected thereafter simply by pushing [] button. · Dry operation signal is transmitted to outdoor unit. · The Cooling operation giving priority to dehumidifying, which restrains the indoor fan speed and compressor motor speed, is performed. · The indoor fan motor operates as shown in Fig. 6-2-7. (Fan speed is AUTO only.) (1) Dehumidifying-preferential Cooling capacity control · The cooling capacity and room temperature are controlled by changing the compressor motor speed according to both the difference between the temperature detected by the room temperature sensor and the temperature set by [TEMP] button and also any change in room temperature.

· When the air conditioner operates in Dry mode, the maximum compressor motor speed is restricted. M10 : Max. 20 rps M13 : Max. 20 rps M16 : Max. 22 rps While multiple indoor units operate, compressor motor speed is calculated in the outdoor unit to operate.

· When room temperature is lower than set temperature, indoor fan motor is operated at fan speed SUL as shown in Fig. 6-2-6 while the outdoor unit stops. · ECONO Hi POWER, QUIET and COMFORTSLEEP mode cannot be set. · Other controls than the above-mentioned controls are common to those of cooling operation. - 15 - FILE NO.

SVM-05019 6-2-4. Heating Operation Transferring of heating operation signal from indoor unit to outdoor unit starts. The indoor fan motor operates by the room temperature when selecting "AUTO" of "FAN" as shown in Fig.



[You're reading an excerpt. Click here to read official TOSHIBA RAS-M10NKV-E user guide](http://yourpdfguides.com/dref/3703876)

<http://yourpdfguides.com/dref/3703876>

6-2-8, and operates with a set air flow when selecting LOW to HIGH. However, to prevent cold draft, revolution speed of the fan is restricted by indoor heat exchanger when air flow is AUTO (Fig. 6-2-9) and starting of FAN Manual. (3) SUL : Super ultra low [In star ting and in stability] In star ting · Until 12 minutes passed after operation start FAN AUTO · When 12 to 25 minutes passed after operation start and room temp. is 3°C or lower than set temp. In stability · When 12 to 25 minutes passed after operation start and room temp. is higher than (set temp.

-3°C) · When 25 minutes or more passed after operation start · Room temp. > Set temp. -3.5°C [Basic control] Set temp. (Room temp.) - (Set temp.) 0 -0.5 -1 -1.5 -2 LOW FAN · Room temp. Manual Set temp. - 4°C *1 *2 M+ -5.

0 -5.5 [FAN AUTO] The outdoor unit controls the outdoor fan based upon the operation signal sent from the indoor unit, and also controls revolution speed of the compressor motor. The power coupler (IC20) for four-way valve is turned on, and turned off in defrost operation. (1) Heating capacity control

Calculate the difference between temperature detected by room temp. sensor every minute and the set temp.

set on "Temp. indicator" and variation amount of room temp. Then, obtain the correction amount of the command signal, and correct the current frequency command signal. (2) High-temp. release control If temperature of the indoor heat exchanger detected by the indoor heat exchanger sensor is 55°C or higher, compressor motor speed is gradually lowered to prevent over-temp.

rising of compressed pressure. If temperature becomes below 48°C, return to above item (1). (3) Current release control The input current of compressor and outdoor fan motor (Precisely inverter main circuit control section) which occupy most of air conditioner input is detected by the outdoor current sensor. The compressor motor speed is lowered gradually according to the range of TO (outside air temp.) if the input current exceeds the current value determined in each zone as shown in Fig. 6-2-10 so that the input current does not exceed the set value. In case that the current lowered by approx. 0.3A to 0.5A than each set value, return to above item (1).

HIGH *1, *2 : Approximate revolution speed of M+ and L to linear according to temperature. Fig. 6-2-8 Setting of air flow [Cold draft preventing control]

The upper limit of fan revolution speed is shown below. HIGH Approximate revolution speed of HIGH and SUL linear by Tc. 44 43 31 30 A+4 A-8 FAN

AUTO 33 32 20 19 A*2 A- 8 Starting of FAN Manual SUL*3 SUL (NOTE : *1) Stop Fig. 6-2-9 Cold draft preventing control NOTES : (1) Stops for 2 minutes after thermostat-OFF. (2) 24°C when the set temp. is 24°C or more Set temp. when the set temp. is below 24°C - 16 - FILE NO.

SVM-05019 Outside air temp. (°C) TO 16.0 15.5 11.0 10.

5 9.8A 10.3A 10.8A 3 Defrost operation has been already performed once. Fig.

6-2-10 (4) Defrost control 1) Detection of frost In heating operation, time duration while the compressor operates is counted, and defrost operation starts by any condition described below. a. The counted time is 28 minutes or more, and status that temperature of the outdoor heat exchanger detected by the outdoor heat exchanger is - 20°C or lower continued for 3 minutes or more. b. The counted time is 28 minutes or more, and status that temperature of the outdoor heat exchanger detected by the outdoor heat exchanger is - 8°C or lower and temperature lowered by 2.5 °C than the minimum value of the outdoor heat exchanger during 10 to 15-minutes count time continued for 3 minutes or more. c. The counted time is 34 minutes or more, and status that temperature of the outdoor heat exchanger detected by the outdoor heat exchanger is -5°C or lower and temperature lowered by 3.0 °C than the minimum value of the outdoor heat exchanger during 10 to 15 minutes count time continued for 3 minutes or more. d.

The counted time is 4 hours or more, and status that temperature of the outdoor heat exchanger detected by the outdoor heat exchanger is 0°C or lower and temperature lowered by 1.0 °C than the minimum value of the outdoor heat exchanger during 10 to 15 minutes count time continued for 3 minutes or more. e.

If the following three conditions are satisfied, defrost operation (Timer defrost) starts after heating operation for 48 minutes. 1 Setting on remote control, HEAT 2) Defrost operation Operation of the compressor is stopped once, turn off power coupler for four-way valve after 10 seconds, and then exchange the four-way valve. After 20 seconds, restart operation of the compressor. Turn off the outdoor fan just when the compressor stopped. If temperature of the indoor heat exchanger lowered than 38°C, stop the indoor fan. 3) Defrost reset Resetting operation from defrost to heating is performed when any one of the following conditions is satisfied. a.

Temperature of the outdoor heat exchanger rose to +8°C or higher. b. A status that temperature of the outdoor heat exchanger is +5°C or higher continued for 80 seconds. c. Defrost operation continued for 10 minutes.

In resetting defrost operation, the compressor stops for 50 seconds if defrost has started under condition a. to d. in item 1), but the compressor is reset to heating operation keeping operated if defrost has started under condition e. in item 1). (5) Louver control The vertical air flow louvers are automatically set to heating position or heat memory position.

When the compressor is turned off by hightemp. release control, the vertical air flow louvers close once and then return to the position of previous time. (6) ECONO operation control. When the [ECO] button is pushed, ECONO operation is performed by restraining air flow and compressor moter speed. 1) The indoor fan speed is controlled within Las maximum speed. 2) Compressor motor speed is controlled by the difference value of room temperature and set temperature as shown in Fig. 6-2-11 The different value of room temperature and set temperature are separated to A, B and C zone. Then compressor motor speed in each zone are controlled by different speed. (mode), HIGH (Fan), 30°C (temp.).

outside air temp. is 5°C or lower. 2 Room temp. is 19°C to 24°C, and - 17 - FILE NO. SVM-05019 After 30 minutes passed, the different value of room temperature and set temperature is separated zone again by more different value than before. Then compressor motor speed after 30 minute passed is lower than before by the same different value of room temperature and set temperature. Fig. 6-2-11 (7) COMFORT SLEEP operation control. When the [COMFORT SLEEP] button is pushed, the ECONO operation activate together with the timer OFF function. Each time of pressing [COMFORT SLEEP] button the off timer setting changes in the sequence of 1, 3, 5 or 9 hours.

(8) Hi POWER operation control.



[You're reading an excerpt. Click here to read official TOSHIBA RAS-M10NKV-E user guide](http://yourpdfguides.com/dref/3703876)

<http://yourpdfguides.com/dref/3703876>

When the [Hi POWER] button is pushed Hi Power operation is performed by changing setting temperature and air flow (display on the remote control does not change). 1) Changing of setting temperature. 2) Changing of air flow (Fan setting : AUTO) When the Hi POWER is started, the fan of the indoor unit operates at higher air flow level than normal air flow AUTO (normal air flow AUTO is shown in Fig. 6-2-8).

Because of the difference between room temperature and setting temperature are increased automatically. 3) Changing of air flow (Fan setting : One of 5 levels) When the Hi POWER is started, the fan of the indoor unit operates at higher consecutive air flow level. (Fan speed on the display of remote control does not change) (9) QUIET operation control. When the [QUIET] button is pushed, the fan is restricted the revolution speed at L- level until the [QUIET] button is pushed once again (cancel QUIET operation). Remarks : QUIET operation is appropriate to work with less heating load condition.

Because of the fan speed L- may cause not enough the heating capacity. Fig. 6-2-12 - 18 - FILE NO. SVM-05019 6-2-5. Auto Operation (1) As shown in Fig. 6-2-13, the operation mode (COOL, DRY, HEAT) is selected according to the outside temperature when the operation has started. The operation in Fan mode continues until an operation mode is selected. If the room temperature is 20°C or higher when "AUTO" operation started within 2 hours after "HEAT" operation had stopped. select an operation mode after Fan operation of ultra low fan. In AUTO operation, the set temperature of each operation can be corrected by the remote controller in the range of $T_s = \pm 5^\circ\text{C}$.

Outdoor temp. (°C) 32 Cool mode 22 Fan mode 20 Heat mode 6-3. Temporary Operation · Temporary Auto operation, existence of Auto Restart, and Temporary Cooling operation can be set by the [RESET] button of the indoor controller. RESET Powerful Cool mode [RESET] button OFF ON After pushing button for 3 seconds After pushing button for 10 seconds Fig. 6-3-1 Control Temporary Auto operation start Auto Restart control select Temporary Cooling operation start 6-3-1. Temporary Auto Operation Fig. 6-2-13 (2) After selecting the operation mode (COOL, DRY, HEAT), select an operation mode again when a status that the compressor was turned off by the room temperature or outside air temperature continues for 15 minutes. (3) After selecting DRY operation, a status that the room temperature is the set temp. - 2°C continues for 15 minutes, select an operation mode again. (4) Powerful Cool mode control When the outside temperature is above 32°C and indoor temperature is above 28°C, select Cool mode control.

In Cool mode, the air flow louver directs downward. When the room temperature gains access to the set temperature, it becomes cool memory position. · When the [RESET] button is pushed, the Auto operation with set temperature fixed at 24°C starts. Controlling is same as that of Auto operation by the remote controller. · When the [RESET] button is pushed again, the operation stops.

· During Temporary Auto operation, operation by the remote controller is accepted. · Using the Auto Restart function, the Temporary Auto operation starts when power failure is reset. 6-3-2. Temporary Cooling Operation · When the [RESET] button keeps pushed for 10 seconds, Cooling operation of which compressor motor speed and the indoor fan speed are fixed starts. Compressor motor speed : 24.

5 rps Indoor fan speed : Low · When the [RESET] button is pushed again, the operation stops. · Auto Restart function is unavailable. - 19 - FILE NO. SVM-05019 6-4. Auto Restart Function The indoor unit is equipped with an automatic restarting function which allows the unit to restart operating with the set operating conditions in the event of power supply being accidentally shut down. The operation will resume without warning three minutes after power is restored. This function is not set to work when shipped from the factory. Therefore it is necessary to set it to work. 6-4-1. How to set auto restart function To set the auto restart function, proceed as follows: The power supply to the unit must be on; the function will not set if the power is off.

Push the [RESET] button located in the center of the front panel continuously for three seconds. The unit receives the signal and beeps three times. The unit then restarts operating automatically in the event of power supply being accidentally shut down. When the unit is on standby (Not operating) Operation Push [RESET] button for more than three seconds. The unit is on standby. · The unit starts to operate. · 0 Motions The green lamp is on. After approx. three seconds, The lamp changes from green to orange. 3S RESET The unit beeps three times and continues to operate.

If the unit is not required to operate at this time, push [RESET] button once more or use the remote control to turn it off. When the unit is in operation Operation Push [RESET] button for more than three seconds. The unit is in operation. · The unit stops operating. · 0 Motions The green lamp is on. The green lamp is turned off. After approx. three seconds, 3S RESET The unit beeps three times If the unit is required to operate at this time, push [RESET] button once more or use the remote control to turn it on. · · · While this function is being set, if the unit is in operation, the orange lamp is on. This function can not be set if the timer operation has been selected.

When the unit is turned on by this function, the louver will not swing even though it was swinging automatically before shutting down. · While the filter check lamp is on, the [RESET] button has the function of filter reset button. - 20 - FILE NO. SVM-05019 6-4-2. How to cancel auto restart function To cancel auto restart function, proceed as follows: Repeat the setting procedure: the unit receives the signal and beeps three times. The unit will be required to be turned on with the remote control after the main power supply is turned off. When the unit is on standby (Not operating) Operation Push [RESET] button for more than three seconds. The unit is on standby. Motions · The unit starts to operate. The orange lamp is on.

· 0 After approx. three seconds, The lamp changes from orange to green. 3S RESET The unit beeps three times and continues to operate. · If the unit is not required to operate at this time, push [RESET] button once more or use the remote control to turn it off. When the unit is in operation Operation Push [RESET] button for more than three seconds. The unit is in operation. Motions The orange lamp is on. · The unit stops operating. The orange lamp is turned off. 0 · 3S After approx. three seconds, RESET The unit beeps three times If the unit is required to operate at this time, push [RESET] button once more or use the remote control to turn it on.



[You're reading an excerpt. Click here to read official TOSHIBA RAS-M10NKV-E user guide](http://yourpdfguides.com/dref/3703876)

<http://yourpdfguides.com/dref/3703876>

· While this function is being set, if the unit is in operation, the orange lamp is on. 6-5. Filter Check Lamp When the elapsed time reaches 1000 hours, the filter check lamp indicates. After cleaning the filters, turn off the filter check lamp.

6-5-1. How to turn off filter check lamp Push [RESET] button on the indoor unit. Note: If [RESET] button is pushed while the filter check lamp is not indicating, the indoor unit will start the Automatic Operation. 6-4-3. Power failure during timer operation When the unit is in Timer operation, if it is turned off because of power failure, the timer operation is cancelled.

Therefore, set the timer operation again. - 21 - FILE NO. SVM-05019 6-6. Remote control 6-6-1. Remote control and its functions 14 RAS-M10UKCV, RAS-M13UKCV, RAS-M16UKCV 1 2 3 3 4 5 6 7 8 9 10 11 12 13 Infrared signal emitter Transmits a signal to the indoor unit. START/STOP button [] Push the button to start operation. (A receiving beep is heard.) Push the button again to stop operation. (A receiving beep is heard.) If no receiving sound is heard from the indoor unit, push the button twice.

Mode select button [MODE] Push this button to select a mode. Each time you push the button, a mode is selected in a sequence that goes from A : Auto changeover control, : Cool, : Dry, : Heat, : Fan only, and back to A. (A receiving beep is heard.) Temperature button [TEMP.]

.The set temperature is increased up to 30°C. ...
....The set temperature is dropped down to 17°C.

(A receiving beep is heard.) Fan speed button [FAN] Push this button to select fan speed. When you select AUTO, the fan speed is automatically adjusted according to the room temperature. You can also manually select the desired fan speed from among five settings. , MED , (LOW , LOW+ MED+ , HIGH) (A receiving beep is heard.) Auto louver button [SWING] Push this button to swing the louver. (A receiving beep is heard.) Push the button again to stop the louver swinging. (A receiving beep is heard.) Set louver button [FIX] Push this button to adjust the air flow direction.

(A receiving beep is heard.) On timer button [ON] Push this button to set the ON timer. Off timer button [OFF] Push this button to set the OFF timer. Reserve button [SET] Push this button to reserve setting of time, ON timer or OFF timer. (A receiving beep is heard.) Cancel button [CLR] Push this button to cancel ON timer and OFF timer. (A receiving beep is heard.) Sleep timer button [SLEEP] Push this button to set the OFF timer. (1, 3, 5 or 9 hours) (A receiving beep is heard) High power button [Hi POWER] Push this button to start the high power operation. (A receiving beep is heard.

) 15 16 17 18 ECO timer button [ECO] Push this button to start the ECO operation. (A receiving beep is heard) Quiet button [QUIET] Push this button to start the quiet operation. (A receiving beep is heard) Comfort sleep button [COMFORT SLEET] Push this button to start the comfort sleep operation. OFF timer necessary to set together (1, 3, 5 or 9 hours). (A receiving beep is heard) PRESET button Push this button to operate the air conditioner according to settings memorized.

(A receiving beep is heard) Or push the button for more than 4 seconds to memorize the setting indicated on the remote control and mark is indicated.

Automatic operation button [AUTO] Push this button to operate the air conditioner automatically. (A receiving beep is heard.) 1 17 18 2 15 6 7 8 12 5 4 3 16 13 14 11 9 10 - 22 - FILE NO. SVM-05019 6-6-2.

Names and functions of indications on remote control r Display All indications, except for clock time indication, are indicated by push the [] button. 1 2 3 4 5 6 7 8 9 10 Transmission mark This transmission mark () indicates when the remote control transmits signals to the indoor unit. Mode display Indicates the current operation mode. 10 3 1 4 28 (AUTO : Automatic control, A : Auto changeover control, : Cool, : Dry, : Heat, : Fan only) Temperature display Indicates the temperature setting (17°C to 30°C). When you set the operating mode to : Fan only, no temperature setting is indicated. Louver operation display Indicates the louver operation. (: Fix, : Swing). FAN speed display Indicates the selected fan speed. AUTO or one of five fan speed levels (LOW , LOW+ , MED+ , HIGH , MED) 11 7 9 5 6 can be indicated. Indicates AUTO when the operating mode is either AUTO or : Dry.

· In the illustration, all indications TIMER and clock time display are indicated for explanation. The time set for timer operation or clock time is indicated. During operation, only the The present time is always indicated except for TIMER operation. relevant indications will be indicated on the remote control. Hi POWER display Indicates when the Hi POWER operation starts. Push the [Hi POWER] button to start and push it again to stop the operation. PRESET display Flashes for 4 seconds when the [PRESET] button is pushed and hold to memorize. mark is indicated when [PRESET] button is pushed than 4 seconds. Push another button to turn off the mark. ECO display Indicates when the ECO is in operation.

COMFORT SLEEP display Indicates when the COMFORT SLEEP is in operation. Each time you push the [COMFORT SLEEP] button, the display changes in the sequence of 1, 3, 5 or 9h. QUIET display Indicates when the QUIET is in operation. 11 - 23 - FILE NO. SVM-05019 7.

INSTALLATION PROCEDURE 7-1. Safety Cautions For general public use Power supply cord of parts of appliance for Outdoor use shall be more than polychloroprene sheathed flexible cord (design H07RN-F), or cord designation 245IEC66. (1.5 mm² or more) CAUTION New Refrigerant Air Conditioner Installation · THIS AIR CONDITIONER ADOPTS THE NEW HFC REFRIGERANT (R-410A) WHICH DOES NOT DESTROY OZONE LAYER. R-410A refrigerant is apt to be affected by impurity such as water, oxidizing membrane, and oils because pressure of R-410A refrigerant is approx.

1,6 times of refrigerant R-22. Accompanied with adoption of the new refrigerant, refrigerating machine oil has been also changed. Therefore, during installation work, be sure that water, dust, former refrigerant, or refrigerating machine oil does not enter into the refrigerating cycle or new-refrigerant air conditioner. @@@@ MAKE SURE ALL POWER SWITCHES ARE OFF. FAILURE TO DO SO MAY CAUSE ELECTRIC SHOCK. ·

CONNECT THE CONNECTING CABLE CORRECTLY. @@@@ FAILURE TO FOLLOW THIS INSTRUCTION CAN RESULT IN FIRE OR EXPLOSION. @@@@ IF AIR OR ANY OTHER GAS IS MIXED IN THE REFRIGERANT, THE GAS PRESSURE IN THE REFRIGERATION CYCLE BECOMES ABNORMALLY HIGH AND IT RESULTINGLY CAUSES BURST OF THE PIPE AND INJURIES ON PERSONS. · IN THE EVENT THAT THE REFRIGERANT GAS LEAKS OUT OF THE PIPE DURING THE INSTALLATION WORK, IMMEDIATELY LET FRESH AIR INTO THE ROOM. IF THE REFRIGERANT GAS IS HEATED BY FIRE OR SOMETHING ELSE, IT CAUSES GENERATION OF POISONOUS GAS.

WARNING · Never modify this unit by removing any of the safety guards or by by-passing any of the safety interlock switches.



[You're reading an excerpt. Click here to read official TOSHIBA RAS-M10NKV-E user guide](http://yourpdfguides.com/dref/3703876)

<http://yourpdfguides.com/dref/3703876>

@@Personal injury and property damage can result if the unit falls. @@And, make sure the equipment to be earthed. @@If you detect any damage, do not install the unit. @@Do not store in a wet basement or expose to rain or water. @@@@SVM-05019 7-1-1. @@@@When purchasing a charge hose, be sure to confirm the port size. @@The size of opposite sides of flare nuts have been increased. @@@Used when flare is made by using conventional flare tool. Connected to conventional vacuum pump.

@@@@@1/2, 5/8) Flare tool (clutch type) Gauge for projection adjustment Vacuum pump adapter Gas leakage detector · Incidentally, the "refrigerant cylinder" comes with the refrigerant designation (R-410A) and protector coating in the U.S.'s ARI specified rose color (ARI color code: PMS 507). · Also, the "charge port and packing for refrigerant cylinder" require 1/2 UNF 20 threads per inch corresponding to the charge hose's port size. 25
FILE NO. SVM-05019 7-2.

Installation Diagram of Indoor Units 65 mm or more 170 mm Hook or more 1 Installation plate For the rear left and left piping Wall Hook 170 mm or more Air filter Insert the cushion between the indoor unit and wall, and tilt the indoor unit for better operation. Shield pipe (Attach to the front panel.) Do not allow the drain hose to get slack. 5 Sasa-Zeolite plus filter 6 Bio-enzyme & Ginkgo filter Cut the piping hole sloped slightly 8 Pan head wood screw Make sure to run the drain hose sloped downward. 2 Wireless remote control 4 Remote control holder Before installing the wireless remote control · With the remote control cover open, load the batteries supplied correctly, observing their polarity.

The auxiliary piping can be connected the left, rear left, rear right, right, bottom right or bottom left. 2 Wireless remote control Cover Insulate the refrigerant pipes separately with insulation, not together. Right Rear right Rear left Left Bottom left Bottom right 3 Batteries 6 mm thick heat resisting polyethylene foam - 26 - FILE NO. SVM-05019 7-3-2. Accessory and installation parts Part No. Part name (Qty) Part No. Part name (Qty) Part No. Part name (Qty) 1 Installation plate x 1 4 Remote control holder x 1 7 Mounting screw 4 x 25 l x 6 2 Wireless remote control x 1 5 Sasa-Zeolite plus filter x 1 8 Pan head wood screw 3.1 x 16 l x 2 3 Battery x 2 6 Bio-enzyme & Ginkgo filter x 1 9 B Label x 1 B Others Name Owner's manual Installation manual This model is not equipped with an extension drain hose. Option : For the extension drain hose, use an optionally available RB-821SW or commercially available one.

27 FILE NO. SVM-05019 7-2-2. Installation Place · A place which provides the spaces around the indoor unit as shown in the above diagram. · A place where there is no obstacle near the air inlet and outlet. · A place which allows easy installation of the piping to the outdoor unit. · A place which allows the front panel to be opened. · The indoor unit shall be installed as top of the indoor unit comes to at least 2m height. Also it must be avoided to put anything on the top of the indoor unit. Mounting the Installation Plate For installation of the indoor unit, use the paper pattern on the back. Anchor bolt holes 62 82. 5 Hook 170 85 CAUTION · Direct sunlight to the indoor unit wireless receiver should be avoided. · The microprocessor in the indoor unit should not be too close to r-f noise sources. (For details, see the owner's manual.) 1 Hook Hook Thread Pipe hole Indoor unit Weight Pipe hole Installation plate 7 Mounting screw Fig. 7-2-3 Remote controller · A place where there are no obstacles such as a curtain that may block the signal from the indoor unit. · Do not install the remote control in a place exposed to direct sunlight or close to a heating source, such as a stove. · Keep the remote control at least 1 m apart from the nearest TV set or stereo equipment. (This is necessary to prevent image disturbances or noise interference.) · The location of the remote control should be determined as shown below. (Side view) (Top view) 5 m Indoor unit 5 45° 45° When the installation plate is directly mounted on the wall 1. Securely fit the installation plate onto the wall by screwing it in the upper and lower parts to hook up the indoor unit. 2. To mount the installation plate on a concrete wall with anchor bolts, utilize the anchor bolt holes as illustrated in the above figure. 3. Install the installation plate horizontally in the wall. CAUTION When installing the installation plate with a mounting screw, do not use the anchor bolt hole. @@@@7-2-1 7-2-3. @@@@holes in the wall. @@@7-2-2 1. @@@Electrical Work 1.

@@2. @@@@An approved circuit breaker or switches must used. (2) Connection with power supply plug : Attach power supply plug with power cord and plug it into wall outlet. An approved power supply cord and plug must be used. 7-2-6 Piping and Drain Hose Installation Piping and Drain Hose Forming * Since dewing results in a machine trouble, make sure to insulate both the connecting pipes. (Use polyethylene foam as insulating material.) Rear right Bottom left Left NOTE · Perform wiring works so as to allow a generous wiring capacity. Bottom right Right 7-2-5. Wiring Connection How to connect the connecting cable Wiring of the connecting cable can be carried out without removing the front panel. 1. Remove the air inlet grille. Open the air inlet grille upward and pull it toward you. 2. Remove the terminal cover and cord clamp. 3. Insert the connecting cable (according to the local cords) into the pipe hole on the wall. 4. Take out the connecting cable through the cable slot on the rear panel so that it protrudes about 15 cm from the front. 5. Insert the connecting cable fully into the terminal block and secure it tightly with screws. 6. Tightening torque : 1.2 N·m (0.12 kgf·m) 7. Secure the connecting cable with the cord clamp. 8. Fix the terminal cover, rear plate bushing and air inlet grille on the indoor unit. 1. Die-cutting Front panel slit Cut out the slit on the left or right side of the front panel for the left or right connection and the slit on the bottom left or right side of the front panel for the bottom left or right connection with a pair of nippers. 2.

Changing drain hose For left connection, left-bottom connection and rear-left connection's piping, it is necessary to change the drain hose and drain cap. How to remove the Drain Cap Clip drain cap by needle-nose plier, and pull out. CAUTION · Be sure to refer to the wiring system diagram labeled inside the front panel. · Check local electrical cords and also any specific wiring instructions or limitations.



[You're reading an excerpt. Click here to read official TOSHIBA RAS-M10NKV-E user guide](http://yourpdfguides.com/dref/3703876)
<http://yourpdfguides.com/dref/3703876>

How to install the Drain Hose Firmly insert drain hose connecting part until hitting on a heat insulator. Heat insulator How to fix the Drains Cap 1) Insert hexagonal wrench (4 mm) in a center head. 4 mm 2) Firmly insert drains cap. No gap Do not apply lubricating oil (refrigerant machine oil) when inserting the drain cap. Application causes deterioration and drain leakage of the plug. Insert a hexagon wrench (4 mm) NOTE · Use stranded wire only.

· Wire type : H07RN-F or more. Fig. 7-2-5 CAUTION Firmly insert the drain hose and drain cap; otherwise, water may leak. 29 Die-cutting Front panel slit

Fig. 7-2-6 Drain hose Fig.

7-2-7 Fig. 7-2-8 Fig. 7-2-9 Piping preparation Changing drain hose Rear left FILE NO. SVM-05019 In case of right or left piping · After scribing slits of the front panel with a knife or a making-off pin, cut them with a pair of nippers or an equivalent tool. Slit 7-2-6 Indoor Unit Fixing 1.

Pass the pipe through the hole in the wall, and hook the indoor unit on the installation plate at the upper hooks. 2. Swing the indoor unit to right and left to confirm that it is firmly hooked up on the installation plate. 3. While pressing the indoor unit onto the wall, hook it at the lower part on the installation plate. Pull the indoor unit toward you to confirm that it is firmly hooked up on the installation plate. Hook here 1 Fig. 7-2-10 In case of bottom right or bottom left piping · After scribing slits of the front panel with a knife or a making-off pin, cut them with a pair of nippers or an equivalent tool. 1 Installation plate 2 Slit Hook Press (unhook) Fig. 7-2-11 Fig.

7-2-14 · For detaching the indoor unit from the installation plate pull the indoor unit toward you while pushing its bottom up at the specified parts. Left-hand connection with piping Bend the connecting pipe so that it is laid within 43 mm above the wall surface. If the connecting pipe is laid exceeding 43 mm above the wall surface, the indoor unit may unstably be set on the wall. When bending the connecting pipe, make sure to use a spring bender so as not to crush the pipe. Bend the connection pipe within a radius of 30 mm (Ø6.35) 40 mm (Ø9.52). To connect the pipe after installation of the unit (figure) (To the forefront of flare) 270 mm 170 mm Push Push Fig. 7-2-15 Liquid side Gas side 7-2-7 Drainage 1. Run the drain hose sloped downwards.

NOTE Outward form of indoor unit 43 mm · Hole should be made at a slight downward slant on the outdoor side. Do not rise the drain hose. Do not form the drain hose into the waved shape. R30 or less (Ø6.35) R40 or less (Ø9.

52) (Use polisin (polyethylene core or the like for bending pipe.) ° 80 Use the handle of screwdriver, etc. 50 mm or more Fig. 7-2-12 NOTE If the pipe is bent incorrectly, the indoor unit may unstably be set on the wall. After passing the connecting pipe through the pipe hole, connect the connecting pipe to the auxiliary pipes and wrap the facing tape around them.

Do not put the drain hose end into water. Do not put the drain hose end in the drainage ditch. Fig. 7-2-16 2. Put water in the drain pan and make sure that the water is drained out of doors. 3. When connecting extension drain hose, insulate the connecting part of extension drain hose with shield pipe. Shield pipe

CAUTION · Bind the auxiliary pipes (two) and connecting cable with facing tape tightly. In case of leftward piping and rear-leftward piping, bind the auxiliary pipes (two) only with facing tape. Indoor unit Auxiliary pipes Connecting cable Installation plate Drain hose Inside the room Extension drain hose Fig.

7-2-17 CAUTION Fig. 7-2-13 Arrange the drain pipe for proper drainage from the unit. Improper drainage can result in dew-dropping. This air conditioner has the structure designed to drain water collected from dew, which forms on the back of the indoor unit, to the drain pan. Therefore, do not store the power cord and other parts at a height above the drain guide. Space for pipes Wall Drain guide · Carefully arrange pipes so that any pipe does not stick out of the rear plate of the indoor unit. · Carefully connect the auxiliary pipes and connecting pipes to each other and cut off the insulating tape wound on the connecting pipe to avoid double-taping at the joint, moreover, seal the joint with the vinyl tape, etc. · Since dewing results in a machine trouble, make sure to insulate both the connecting pipes. (Use polyethylene foam as insulating material.) · When bending a pipe, carefully do it not to crush it.

Fig. 7-2-18 30 FILE NO. SVM-05019 7-2-8. Setting of Remote Controller Selector Switch When two indoor units are installed in the separated rooms, there is no need to change the select switches. (1) Stop the operation of the air conditioner and turn off its main power supply.

(@@@) First open the horizontal louver and then remove the front panel from the back body by pulling it toward you. Remote Controller Selector Switch ·

When two indoor units are installed in the same room or adjacent two rooms, if operating a unit, two units may receive the remote controller signal simultaneously and operate. In this case, the operation can be preserved by setting either one indoor unit and remote controller to B setting (Both are set to A setting in factory shipment). · The remote control signal is not received when the settings of indoor unit and remote controller are different. · There is no relation between A setting/B setting and A room/B room when connecting the piping and cables.

Position of Remote Control Selector Switch 1. Setting of remote controller switch at the indoor unit side How to remove the front cabinet Fig. 7-2-20 How to mount the front panel Push the front panel back in and make sure all hook are locked. Adhesion of B label (When setting to [B]) Be sure to affix the B label on the front panel same as the below figure. Fig. 7-2-21 Fig. 7-2-19 31 FILE NO. SVM-05019 2. Setting of remote controller selector at the remote controller side [B] of the remote controller is displayed with liquid crystal only when it is set to [B]. There is no display of [A].

· Enter the batter. · Push the [CHK] button by something with thin edge. ([00] is displayed.) · If [MODE] button is pushed while pushing [CHK] button, the small [B] is displayed at the right of the setting temperature indication section. * To reset [A] setting, push the [MODE] button again while pushing the [CHK] button. 7-2-9. Check and Test Operation 1. Check the unit is firmly hooked up on the installation plate. 2. Check the connecting pipes tightened securely.

Confirm that there is no gas leakage. 3. Confirm that all connecting cables are secured and correct. 4. Check the pipes insulation.



[You're reading an excerpt. Click here to read official TOSHIBA RAS-M10NKV-E user guide](http://yourpdfguides.com/dref/3703876)

<http://yourpdfguides.com/dref/3703876>

5. Check the drainage. 6. Connection of the grounding wire. 7.

To switch the TEST RUN (COOL) mode, turn the switch on. To switch the TEST RUN (COOL) mode, press TEMPORARY button for 10 sec. (The beeper will make a short beep.) 3. Confirm the indoor unit can operate with the changed setting of the remote controller. RESET Hi POWER FILTER PAP TIMER Fig. 7-2-23 [MODE] button 8. Operate the unit at cooling operation mode for fifteen minutes or more. Measure the temperature of the intake and discharge air. Ensure the difference between the intake temperature and the discharge one is more, than 8°C.

NOTE: Three-minutes protection feature [CHK] button A protection feature prevents the air conditioner from being activated for about 3 minutes when it is restarted immediately after operation or when the power switch is turned on. 9. Check the remote controller operation. When finished the check and test operation, make sure to return to REMOTE CONTROLLER. (Push the temporary switch with once again.) 10. Explain to the customer on the correct usage of air conditioner simple layman's terms. * The above remote controller is one for cooling only model. 32 FILE NO. SVM-05019 8.

HOW TO DIAGNOSE THE TROUBLE The pulse modulating circuits are mounted to both indoor and outdoor units. Therefore, diagnose troubles according to the trouble diagnosis procedure as described below. (Refer to the check points in servicing written on the wiring diagrams attached to the indoor/outdoor units.) 8-1. First Confirmation 8-1-1.

Confirmation of Power Supply Confirm that the power breaker operates (ON) normally. 8-1-3. Operation Which is not a Trouble (Program Operation) For controlling the air conditioner, the program operations are built in the microcomputer as described in the following table. If a claim is made for running operation, check whether or not it meets to the contents in the following table. When it does, we inform you that it is not trouble of equipment, but it is indispensable for controlling and maintaining of air conditioner.

8-1-2. Confirmation of Power Voltage Confirm that power voltage is AC 220 - 240V ± 10%. If power voltage is not in this range, the unit may not operate normally. Table 8-1-1 No. 1 Operation of air conditioner When power breaker is turned "ON", the operation lamp (Green) of the indoor unit flashes.

Description The OPERATION lamp of the indoor unit flashes when power source is turned on. If [] button is operated once, flashing stops. (Flashes also in power failure) 2 Compressor may not operate even if the room temperature is within range of compressor-ON. The compressor does not operate while compressor restart delay timer (3-minutes timer) operates. The same phenomenon is found after power source has been turned on because 3-minutes timer operates.

The air flow indication is fixed to [AUTO]. 3 In DRY and ECONO. mode, FAN (air flow) display does not change even though FAN (air flow select) button is operated. Increasing of compressor motor speed stops approx. 30 seconds after operation started, and then compressor motor speed increases again approx. 30 seconds after. The set value of the remote control should be below the room temperature. 4 For smooth operation of the compressor, the compressor motor speed is restricted to Max. 33 rps for 2 minutes and Max. 57 rps for 2 minutes to 4 minutes, respectively after the operation has started.

If the set value is above the room temperature, Cooling operation is not performed. And check whether battery of the remote control is consumed or not. 5 8-2. Primary Judgment To diagnose the troubles, use the following methods. (1) Judgment by flashing LED of indoor unit (2) Self-diagnosis by service check remote controller (3) Judgment of trouble by every symptom Firstly use the method (1) for diagnosis.

Then, use the method (2) or (3) to diagnose the details of troubles. For any trouble occurred at the outdoor unit side, detailed diagnosis is possible by 5-serial LED on the inverter P board. .C. 33 FILE NO.

SVM-05019 8-3. Judgment by Flashing LED of Indoor Unit While the indoor unit monitors the operation status of the air conditioner, if the protective circuit operates, the contents of self-diagnosis are displayed with block on the indoor unit indication section. Table 8-3-1 Lamps A B C D E F G OPERATION lamp is blinking. (1Hz) OPERATION lamp is blinking. (5Hz) OPERATION lamp is blinking. (5Hz) OPERATION lamp is blinking. (5Hz) OPERATION lamp is blinking. (5Hz) OPERATION and TIMER lamps are blinking. (5Hz) OPERATION, TIMER and FAN ONLY lamps are blinking. OPERATION, TIMER and FAN ONLY lamps are blinking.

Self-diagnosis Power failure (when the power supply is turning on) Thermo sensor (TA) short or break Heat exchanger sensor (TC) short or break Indoor fan motor lock or failure Indoor P.C. board failure Wrong wiring of connecting cable · Gas shortage or other refrigerant cycle trouble · Heat exchanger sensor open, break or short · Overload relay or thermostat trouble of compressor Cycle failure H NOTES: (1) (2) (3) (4) The contents of items B and C and a part of item E are displayed when air conditioner operates. When item B and C, and item B and a part of item E occur concurrently, priority is given to the block of item B. The check codes can be confirmed on the remote controller for servicing. When connecting the changing kit, first-push priority control is executed.

The secondary operation lamp continues flashing. For details, refer to the section 10. Changing Kit. 34 FILE NO.

SVM-05019 8-4. Self-Diagnosis by Remote Control (Check Code) (1) If the lamps are indicated as shown B to G in Table 9-3-1, exchanger the self-diagnosis by the remote control. (2) When the remote control is set to the service mode, the indoor controller diagnoses the operation condition and indicate the information of the self-diagnosis on the display of the remote control with the check codes. If a fault is detected, all lamps on the indoor unit will blink at 5Hz and it will beep for 10 seconds (Pi, Pi, Pi..

..). The timer lamp usually blinks (5Hz) during the self-diagnosis. 8-4-1.

How to use remote control in service mode (1) Press [CHK] button with a tip of pencil to set the remote control to the service mode. · "00" is indicated on the display of the remote control. · The timer lamp on the indoor unit blinks continuously. (5 times per 1 sec.) (2) Press [TIMER 8] button. If there is no fault with a code, the indoor unit will beep once (Pi) and the display of the remote control will change as follows: 00 01 02 1d 1E 22 · Check the unit with all 35 check codes (00 to 22). as shown in Table 9-4-1. · Press [TIMER 9] button to change the check code backwards. If there is a fault, the indoor unit will beep for 10 seconds (Pi, Pi, Pi..

..). Note the check code on the display of the remote control. · 2-digits alphanumeric will be indicated on the display.



[You're reading an excerpt. Click here to read official TOSHIBA RAS-M10NKV-E user guide](http://yourpdfguides.com/dref/3703876)

<http://yourpdfguides.com/dref/3703876>