



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for WHIRLPOOL ART 483/4. You'll find the answers to all your questions on the WHIRLPOOL ART 483/4 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual WHIRLPOOL ART 483/4**  
**User guide WHIRLPOOL ART 483/4**  
**Operating instructions WHIRLPOOL ART 483/4**  
**Instructions for use WHIRLPOOL ART 483/4**  
**Instruction manual WHIRLPOOL ART 483/4**

## INSTRUCTIONS FOR USE

|   | Page |
|---|------|
| BEFORE USING THE APPLIANCE                            | 5    |
| SAFEGUARDING THE ENVIRONMENT                          | 5    |
| PRECAUTIONS AND GENERAL RECOMMENDATIONS               | 6    |
| FIRST USE   | 7    |
| CLEANING AND MAINTENANCE                              | 7    |
| IF THE APPLIANCE IS NOT GOING TO BE USED              | 7    |
| IN CASE OF POWER FAILURES                             | 7    |
| OPERATION OF THE REFRIGERATOR AND FREEZER COMPARTMENT | 7    |
| REFRIGERATOR COMPARTMENT                              | 8    |
| FREEZER COMPARTMENT                                   | 8    |
| DEFROSTING THE FREEZER COMPARTMENT                    | 8    |
| STORING FOOD  | 9    |
| TROUBLESHOOTING GUIDE                                 | 9    |
| AFTER-SALES SERVICE                                   | 9    |

- 4 -



[You're reading an excerpt. Click here to read official WHIRLPOOL ART 483/4 user guide](http://yourpdfguides.com/dref/4834890)  
<http://yourpdfguides.com/dref/4834890>

**Manual abstract:**

To ensure best use of your appliance, carefully read the operating instructions which contain a description of the product and useful advice. Keep these instructions for future reference. 1. After unpacking the appliance, make sure it is not damaged and that the door closes properly. Any damage must be reported to the dealer within 24 hours of delivery of the appliance. 2. Wait at least two hours before switching the appliance on, to ensure that the refrigerant circuit is fully efficient. 3. Installation and the electrical connection must be carried out by a qualified technician according to the manufacturer's instructions and in compliance with the local safety regulations. 4.

Clean the inside of the appliance before using it. For disposal, comply with the local regulations. Keep the packing materials (plastic bags, polystyrene parts, etc. The symbol on the appliance, or on the accompanying documents, indicates that this appliance should not be treated as domestic waste but must be taken to a special collection centre for the recycling of electrical and electronic equipment. information: This appliance does not contain CFCs.

The refrigerant circuit contains R134a (HFC) or R600a (HC) (see the rating plate inside the appliance). Appliances with Isobutane (R600a): isobutane is a natural gas without environmental impact, but is flammable. Therefore, make sure the refrigerant circuit pipes are not damaged. This product may contain Fluorinated Greenhouse Gases covered by the Kyoto Protocol; the refrigerant gas is inside a hermetically sealed system. refrigerant gas: R134a has a Global Warming Potential of (GWP) 1300.

Declaration of conformity This appliance has been designed for preserving food and is manufactured in compliance with Regulation (CE) No. 1935/2004. This appliance has been designed, manufactured and marketed in compliance with: - safety objectives of the Low Voltage Directive 2006/95/CE (which replaces 73/23/CEE and subsequent amendments); - the protection requirements of Directive EMC 2004/108/EC. Electrical safety of the appliance can only be guaranteed if it is correctly connected to an approved earthing system. Be careful not to damage the floors (e. g. Parquet) when moving the appliance. Make sure the appliance is not near a heat source. Keep the appliance ventilation openings free. The appliance may not work properly if it is left for a long time at a temperature outside the specified range.

(°F) SAFETY Do not store or use petrol, flammable liquids or gas in the vicinity of this or other electrical appliances. The fumes can cause fires or explosions. Do not use mechanical, electric or chemical means other than those recommended by the Manufacturer to speed up the defrost process. Do not use or place electrical devices inside the appliance compartments if they are not of the type expressly authorised by the Manufacturer. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. To avoid the risk of children becoming trapped and suffocating, do not allow them to play or hide inside the appliance. Do not swallow the contents (non-toxic) of the ice packs (in some models). Do not use single/multi adapters or extension cords. 6 FIRST USE Connect the appliance to the mains power supply. do not use abrasive detergents or tools.

IF THE APPLIANCE IS NOT GOING TO BE USED Disconnect the appliance from the power supply, remove all the food, defrost and clean. Leave the doors open enough for air to circulate inside the compartments. This will prevent the formation of mould and bad odours. IN CASE OF POWER FAILURES Keep the doors of the appliance closed. In this way the stored food will stay cold as long as possible.

Do not refreeze partially thawed food, consume it within 24 hours. OPERATION OF THE REFRIGERATOR AND FREEZER COMPARTMENT If the refrigerator compartment of your appliance is fitted with a thermostat box and an external panel, the temperature of both compartments is adjusted using the thermostat knob as shown in figure 1. Move the knob to the position to switch the whole appliance off. If in addition to the internal thermostat box your appliance also has an external control panel with an adjustment knob, the temperatures of the two compartments must be adjusted separately. The knob of the thermostat inside the refrigerator compartment is used for adjusting the temperature of the refrigerator compartment only (see fig.

To remove the light bulb turn anticlockwise as shown in figure 1. fan (if provided) The fan operates automatically. The fan ensures a more consistent distribution of the temperature inside the refrigerator compartment, with better preservation of food and reduction of excess humidity. Do not obstruct the suction zone with food. The fan is only active when the motor is in operation. Packed frozen foods can be stored for the period indicated on the packing. Fresh food can also be frozen, ensuring that any contact with already frozen food is avoided. The quantity of fresh food that can be frozen in a 24 hour period is given on the rating plate. Re-freezing of partially defrosted food is not recommended. This food should be consumed within 24 hours.

For further information on freezing fresh food, refer to the quick guide. Do not use sharp or pointed objects to detach the tray. the formation of frost is normal. The amount and rate at which frost accumulates depends on room conditions and how often the door is open. To defrost the unit, switch off the freezer compartment or the whole appliance, depending on the model, and remove all food products. Leave the freezer door open to allow the frost to melt. for appliances in fig. 2 only pull out the defrost water drain and place a container under the drain. When the operation is completed, replace the defrost water drain. Clean the inside of the freezer.

rinse and dry thoroughly. Switch the freezer compartment, or the whole appliance, back on and store the food inside. fig. 2 8 STORING FOOD Wrap food so that no water, moisture or condensate can enter; this will prevent odours or aromas going from one part to another in the refriger.



[You're reading an excerpt. Click here to read official WHIRLPOOL ART 483/4 user guide](http://yourpdfguides.com/dref/4834890)  
<http://yourpdfguides.com/dref/4834890>