



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HONEYWELL DT92A. You'll find the answers to all your questions on the HONEYWELL DT92A in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HONEYWELL DT92A User guide HONEYWELL DT92A Operating instructions HONEYWELL DT92A Instructions for use HONEYWELL DT92A Instruction manual HONEYWELL DT92A

Honeywell

DT92A Wireless Room Thermostat

User Guide / Guía del Usuario / Utilisation / Gebruikershandleiding / Bedienung / Guida per l'Utente / Használati Utasítás / Návod k Použití / Obsluga / Návod na Použitie

1 Room temperature / Indicación de temperatura ambiente / Lecture de la température ambiante / Ruimetemperatuurweergave / Raumtemperatur-istwert / Lettura temperatura ambiente / Aktuális helyiséghőmérséklet

22.5

2 Aktuális pokojová teplota / Odczyt temperatury / Izbová teplota

3 Set temperature, inquiry / Consulta de temperatura deseada / Lecture de la température demandée / Vrijzen van de ingestelde temperatuur / Ingestelde Temperatuur anvroegen / Intraqogazione temperatura impostata / Beállított hőmérséklet lekérdezése

22.5

4 Zabravení žádané teploty / Odczyt temperatury zadanej / Informácia o teplote

5 Set temperature, adjustment / Ajuste de temperatura deseada / Réglage de la température demandée / Wijzen van de ingestelde temperatuur / Ingestelde Temperatuur ändern / Modifica temperatura impostata / Kiválasztás / Nastavení žádané teploty / Ustawianie temperatury zadanej / Nastawienie požądowanej teploty

6 Switch ON/OFF (frost protection enabled) / Botón de encendido / apagado (protección antihielo activada) / Bouton Marche/Arrêt (avec protection anti-gel) / AAN/UIT-toets (vorstbeveiliging actief) / Schalter Ein / Aus (Frostschutz aktivieren) / Interruttore ON / OFF (protezione antielo abilitata) / K/I/B/E kapcsoló (fagyvédelem aktivizálása) / Sprináč Zapnutú/Vypnutú (aktivovaná protimrazová ochrana) / Włącz/Wyłącz (aktywna ochrona przeciwzamrażeniowa) / Sprináč Zapnutý/Vypnutý (aktivovaná protimrazová ochrana)

22.5

7 Heating demand indicator / Indicador de demanda de calefacción / Indicateur de demande de chauffage / Waarmtevraagsymbool / Anzeige Heizlastanforderung / Indicatore di richiesta riscaldamento / Hőigény jelzés / Symbol požadavku na spracutie kotla / Wskaźnik włączonogo palnika / Symbol požadavky na zopracutie kotla

20.0

8 Frost protection / Protección antihielo / Fonction de protection anti-gel / Vorstbeveiliging / Frostschutz / Protezione anti-gelo / Fagyvédelem / Protimrazová ochrana / Ochrona przeciwzamrażeniowa / Protimrazová ochrana

5.0

9 Fault indicator / Indicador de fallo / Indicateur d'usure de piles / Störungsymbol / Indicateur anomalie / Hiba jelzés

10 Low battery indicator / Indicador de pila agotada / Indicateur d'usure de piles / Symbol voor batteriewaarsning / Anzeige für Batteriewechsel / Indicazione cambio delle batterie / Kínarolt elem jelzés / Wskaźnik wyladowania baterii / Indicația vybitých batérii

20.0

11 RF communication / Comunicaciones RF / Communication RF / RF communicatie / Funk-Kommunikation / Comunicazione in RF / RF kommunikáció / RF komunikace / Komunikacja bezprzewodowa / Bezdrótová komunikácia

12 Loss of RF communications. The Relay Box operates in Failsafe mode, as set by Installer. / Pérdida de comunicaciones RF. El Módulo de Relé funciona en modo a prueba de fallos, como se ha establecido por el instalador. / Perte de communication RF. Le récepteur fonctionne sur son mode de sécurité, comme réglé dans les paramètres. / RF communicatieverlies. De ontvangermodule werkt in beveiligingsmode, zoals geselecteerd in het installatiemenu. / Verlust der Funk-Kommunikation. Die Relais-Box arbeitet im Fehler-Modus, wie im Installateur-Menü hinterlegt. / Perdita della comunicazione in RF. Il Modulo Relé funziona in modalità di sicurezza, come impostato dall'installatore. / RF kommunikáció elvesztése. A Reléegység a telepítő által beállított biztonságos módban üzemel. / Ztráta RF komunikace. Sprinací jednotka pracuje v protipouhčovém módu, tak jak je nastaven v instalačním režimu. / Usterka komunikacji bezprzewodowej. Moduł kolektory pracuje w trybie awaryjnym skonfigurowanym przez instalatora. / Strata spójności. Skrinka przimająca pracuje w bezpiecznym trybie, który był nastawiony w instalacyjnym móde

20.0

13 Heat/cold changer / Cambio calefacción/aire acondicionado / Chauffage/Réfrigérisement / Overschakeling warmte/kouelen / Wechsel heizen/kühlen / Cambiamento caldo/freddo / Hűtés/hűtés váltás / Změna topení/chlazení / Zmiana ogrzewania/chłodzenie / Zmena kúrenia a chladienia

HC = 1

20.0

20.0



You're reading an excerpt. [Click here to read official HONEYWELL DT92A user guide](http://yourpdfguides.com/dref/2938607)
<http://yourpdfguides.com/dref/2938607>

Manual abstract:

It works by sensing the air temperature, switching on the heating when the air temperature falls below the thermostat setting, and switching it off once this set temperature has been reached. Turning a room thermostat to a higher setting will not make the room heat up any faster. How quickly the room heats up depends on the design of the heating system, for example, the size of boiler and radiators. Neither does the setting affect how quickly the room cools down. Turning a room thermostat to a lower setting will result in the room being controlled at a lower temperature, and saves energy. the heating system will not work if a time switch or programmer has switched it off. @@@@ you won't have to adjust the thermostat further. @@@@ @@@@ @@@@ @@@@ @@@@ These intellectual and property rights may include patent applications, registered designs, unregistered designs, registered trade marks, unregistered trade marks and copyrights. Honeywell reserves the right to modify this document, product and functionality without notice. This document replaces any previously issued instructions and is only applicable to the product(s) described.

This product has been designed for applications as described within this document. @@@@.



[You're reading an excerpt. Click here to read official HONEYWELL DT92A user guide](http://yourpdfguides.com/dref/2938607)
<http://yourpdfguides.com/dref/2938607>