



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HONEYWELL DT92E. You'll find the answers to all your questions on the HONEYWELL DT92E in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HONEYWELL DT92E User guide HONEYWELL DT92E Operating instructions HONEYWELL DT92E Instructions for use HONEYWELL DT92E Instruction manual HONEYWELL DT92E

DT92E Wireless Room Thermostat with ECO energy saving feature

User Guide / Guía del Usuario / Utilisation / Gebruikershandleiding / Bediening / Guida per l'Utente / Használati Utasítás / Návod k Použití / Obaluga / Návod na Použitie

Room temperature
 1. Indicación de temperatura ambiente
 2. Lecture de la température ambiante
 3. Ruimtetemperatuurweergave
 4. Raumtemperatur-Anzeige
 5. Lettura temperatura ambiente
 6. Aktuális helyiség-hőmérséklet

Aktuální pokojová teplota
 7. Odczyt temperatury
 8. Izbová teplota

Set temperature, inquiry
 9. Consulta de temperatura deseada
 10. Lecture de la température demandée
 11. Uitkijken van de ingestelde temperatuur
 12. Ingestelde Temperatuur anvroegen
 13. Introgazione temperatura impostata
 14. Beállított hőmérséklet lekérdezése

Aktuální požadované teploty
 15. Zobrazení žádané teploty
 16. Odczyt temperatury zadanej
 17. Információ a teplota

Set temperature, adjustment
 18. Ajuste de temperatura deseada
 19. Réglage de la température demandée
 20. Wijzigen van de ingestelde temperatuur
 21. Ingestelde Temperatuur ändern
 22. Modifica temperatura impostata
 23. Kiválasztott hőmérséklet beállítás
 24. Nastawienie żądanej teploty
 25. Ustawianie temperatury zadanej
 26. Nastawienie požadowanej teploty

Zobrazení žádané teploty
 27. Zobrazení žádané teploty
 28. Odczyt temperatury zadanej
 29. Információ a teplota

Switch ON/OFF (frost protection enabled)
 30. Botón de encendido / apagado (protección antihielo activada)
 31. Bouton Marche/Arrêt (avec protection anti-gel)
 32. AAN/UIT-toets (vorstbeveiliging actief)
 33. Schalter Ein / Aus (Frostschutz aktivieren)
 34. Interruttore ON / OFF (protezione antielo abilitata)
 35. K/I/B/E kapcsoló (fagyvédelem aktivizálása)
 36. Spinač Zapnuto/Vypnuto (aktivovaná protimrazová ochrana)
 37. Włącz/Wyłącz (aktywna ochrona przeciwzamrażawcza)
 38. Spinač Zapnuto/Vypnuto (aktivovaná protimrazová ochrana)

Operating indicators / Indicadores de funcionamiento / Indicateurs de fonctionnement / Bedrijfsmodusymbolen / Betriebsanzeige / Indicatore di funzionamento / Kezelési útmutató / Stavové symboly / Wskaźniki pracy regulatora / Stavové symboly

Heating demand indicator
 39. Indicador de demanda de calefacción
 40. Indicateur de demande de chauffage
 41. Waarmtevraagingsymbool
 42. Anzeige Heizlastanforderung
 43. Indicatore di richiesta riscaldamento
 44. Hőigény jelzés
 45. Symbol požadavku na spracutie kotla
 46. Wskaźnik włączonego palnika
 47. Symbol požadavky na zapnutie kotla

Frost protection
 48. Protección antihielo
 49. Fonction de protection anti-gel
 50. Vorstbeveiliging
 51. Frostschutz
 52. Protezione anti-gelo
 53. Fagyvédelem
 54. Protimrazová ochrana
 55. Ochrona przeciwzamrażawcza
 56. Protimrazová ochrana

Faust indicator
 57. Indicador de fallo
 58. Indicateur de défaut
 59. Storingssymbool
 60. Störungsanzeige
 61. Indicatore anomalia
 62. Hiba jelzés

Low battery indicator
 63. Indicador de pila agotada
 64. Indicateur d'usure de piles
 65. Symbool voor batterijverloping
 66. Anzeige für Batteriewechsel
 67. Indicazione cambio delle batterie
 68. Kimerül elem jelzés
 69. Wskaźnik wyczerpania baterii
 70. Indicația vybitých batérií

Vyskyt poruchy
 71. Vyskyt poruchy
 72. Usterka
 73. Vyskyt poruchy

RF communication
 74. Comunicaciones RF
 75. Communication RF
 76. RF communicatie
 77. Funk-Kommunikation
 78. Comunicazione in RF
 79. RF kommunikáció
 80. RF komunikace
 81. Komunikacja bezprzewodowa
 82. Bezdrótová komunikácia

Loss of RF communications. The Relay Box operates in Failsafe mode, as set by Installer.
 83. Pérdida de comunicaciones RF. El Módulo de Relé funciona en modo a prueba de fallos, como se ha establecido por el instalador.
 84. Perte de communication RF. Le récepteur fonctionne sur son mode de sécurité, comme réglé dans les paramètres.
 85. Verlies der Funk-Communicatie. De ontvangermodule werkt in beveiligingsmodus, zoals geselecteerd in het installatiemenu.
 86. Perdita della comunicazione in RF. Il Modulo Relé funziona in modalità di sicurezza, come impostato dall'installatore.
 87. RF kommunikáció elvesztése. A Reléegység a telephő átal beállított biztonságos módban üzemel.
 88. Ztráta RF komunikace. Spínači jednotka pracuje v protipouhčovém módu, tak jak je nastaven v instalačním režimu.
 89. Usterka komunikacji bezprzewodowej. Moduł relajowy pracuje w trybie awaryjnym skonfigurowanym przez instalatora.
 90. Strata spojenia. Skrinka prímačka pracuje v bezpečnostnom režime, ktorý bol nastavený v inštaláčnom móde

Heat/cold changer
 91. Cambio calefacción/aire acondicionado
 92. Chauffage/Réfrigérant
 93. Overschakeling warmte/koulen
 94. Wechsel heizen/kühlen
 95. Cambiamento caldo/freddo
 96. Hűtés/hűtés váltás
 97. Změna topení/chlazení
 98. Zmiana ogrzewania/chłodzenia
 99. Zmena kúrenia a chladienia

1

2

3



You're reading an excerpt. [Click here to read official HONEYWELL DT92E user guide](http://yourpdfguides.com/dref/2938637)

Manual abstract:

Turning a room thermostat to a higher setting will not make the room heat up any faster. How quickly the room heats up depends on the design of the heating system, for example, the size of boiler and radiators. Neither does the setting affect how quickly the room cools down. Turning a room thermostat to a lower setting will result in the room being controlled at a lower temperature, and saves energy. the heating system will not work if a time switch or programmer has switched it off. The way to set and use your room thermostat is to find the lowest temperature setting that you are comfortable with, and then leave it alone to do its job. @@ you won't have to adjust the thermostat further. @@@@ Honeywell reserves the right to modify this document, product and functionality without notice. This document replaces any previously issued instructions and is only applicable to the product(s) described. This product has been designed for applications as described within this document. for use outside of the scope as described herein , refer to Honeywell for guidance. @@.



[You're reading an excerpt. Click here to read official HONEYWELL DT92E user guide](http://yourpdfguides.com/dref/2938637)
<http://yourpdfguides.com/dref/2938637>