



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for MIELE S6290 SILENCE. You'll find the answers to all your questions on the MIELE S6290 SILENCE in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual MIELE S6290 SILENCE
User guide MIELE S6290 SILENCE
Operating instructions MIELE S6290 SILENCE
Instructions for use MIELE S6290 SILENCE
Instruction manual MIELE S6290 SILENCE

Miele



de Gebrauchsanweisung Bodenstaubsauger
en Vacuum cleaner operating instructions
fr Mode d'emploi pour aspirateur traîneau
nl Gebruiksaanwijzing stofzuigers
it Istruzioni d'uso per aspirapolvere a traino

HS14

M.-Nr. 09 591 600



[You're reading an excerpt. Click here to read official MIELE S6290 SILENCE user guide](http://yourpdfguides.com/dref/5488038)
<http://yourpdfguides.com/dref/5488038>

Manual abstract:

.....
.....
.....
.....

..... 14 Ein- und Ausschalten .

.....
.....
.....

.....
.....
.....

..... 14 Saugleistung wählen

.....
.....
.....
.....

..... 14 Beim Saugen ..

.....
.....

.....
.....
.....
.....

..... 15 Abstellen, Transportieren und Aufbewahren Park-System für Saugpausen

.....
.....
.....

.....
.....

. 15 Park-System zur Aufbewahrung

.....
.....

..... 15 Wartung Wo bekomme ich Staubbeutel und Filter?

.....
.....
.....

..... 16 Welche Staubbeutel und Filter sind richtig?

.....
.....
.....

..... 16 Wann tausche ich den Staubbeutel aus?

.....
.....
.....

..... 17 Wie tausche ich den Staubbeutel aus?

.....
.....
.....

..... 17 Wann tausche ich den Motorschutzfilter aus? ..

z. B. Bohr- 6 de - Sicherheitshinweise und Warnungen ~ Schalten Sie den Staubsauger immer nach dem Gebrauch, vor jedem Zubehörwechsel und vor jeder Reinigung / Wartung aus. Ziehen Sie den Netzstecker aus der Steckdose. reinigen Sie ihn nur trocken oder mit einem leicht feuchten Tuch. ~ Tauchen Sie den Staubsauger niemals in Wasser und ~ Lassen Sie Reparaturen nur von einer von Miele autorisierten Fachkraft ausführen. Durch unsachgemäße Reparaturen können erhebliche Gefahren für den Benutzer entstehen. Sachgemäßer Gebrauch ~ Benutzen Sie den Staubsauger nicht ohne Staubbeutel, Motorschutzfilter und Abluftfilter. ~ Wenn kein Staubbeutel eingesetzt ist, kann der Staubraumdeckel nicht geschlossen werden. Wenden Sie keine Gewalt an.

~ Saugen Sie keine brennenden oder glühenden Gegenstände, wie z. B. Zigaretten oder scheinbar verloschene Asche bzw. Kohle, auf. ~ Saugen Sie keine Flüssigkeiten und keinen feuchten Schmutz auf.

Lassen Sie feucht gereinigte oder schampunierte Teppiche und Teppichböden vor dem Absaugen vollständig trocknen. Druckern oder Kopiergeräten verwendet wird, kann elektrisch leitfähig sein. ~ Saugen Sie keinen Tonerstaub auf. Toner, der z. B.

bei 7 de - Sicherheitshinweise und Warnungen ~ Saugen Sie keine leicht entflammaren oder explosiven Stoffe oder Gase auf und saugen Sie nicht an Orten, an denen solche Stoffe gelagert sind. dem Saugrohr, in Kopfnähe zu kommen. ~ Vermeiden Sie beim Saugen mit einer Saugdüse oder Zubehör ~ Fassen Sie beim Saugen mit einer Miele Turbobürste nicht in die laufende Bürstenwalze.



[You're reading an excerpt. Click here to read official MIELE S6290 SILENCE user guide](http://yourpdfguides.com/dref/5488038)

<http://yourpdfguides.com/dref/5488038>

~ Achten Sie beim Saugen mit dem Handgriff ohne auf~ Verwenden Sie nur Staubbeutel, Filter und Zubehör mit dem "Original Miele"-Logo. Nur dafür kann der Hersteller die Sicherheit gewährleisten. stecktes Zubehör darauf, dass der Handgriff nicht beschädigt ist. Miele haftet nicht für Schäden, die durch bestimmungswidrigen Gebrauch, falsche Bedienung und infolge von Nichtbeachtung der Sicherheitshinweise und Warnungen verursacht werden. 8 de - Ihr Beitrag zum Umweltschutz Entsorgung der Verkaufsverpackung Die Verpackung schützt den Staubsauger vor Transportschäden. Die Verpackungsmaterialien sind nach umweltverträglichen und entsorgungstechnischen Gesichtspunkten ausgewählt und deshalb recycelbar. Das Rückführen der Verpackung in den Materialkreislauf spart Rohstoffe und verringert das Abfallaufkommen.

Geben Sie die Verpackung zur Entsorgung in die dualen Systeme (z. B. gelber Sack / gelbe Tonne). Entsorgung des Altgerätes Entnehmen Sie vor der Entsorgung des Altgerätes den Staubbeutel und die eingesetzten Filter und geben Sie diese Teile in den Hausmüll. Elektrische und elektronische Altgeräte enthalten vielfach noch wertvolle Materialien. Sie enthalten aber auch schädliche Stoffe, die für ihre Funktion und Sicherheit notwendig waren. Im Restmüll oder bei falscher Behandlung können diese der menschlichen Gesundheit und der Umwelt schaden. Geben Sie Ihr Altgerät deshalb auf keinen Fall in den Restmüll. Entsorgung der Staubbeutel und der eingesetzten Filter Staubbeutel und Filter sind aus umweltverträglichen Materialien hergestellt. Die Filter können Sie über den normalen Hausmüll entsorgen.

Dies trifft auch auf den Staubbeutel zu, sofern er keinen im Hausmüll verbotenen Schmutz enthält. Nutzen Sie stattdessen die von Ihrem Wohnort eingerichtete Sammelstelle zur Rückgabe und Verwertung elektrischer und elektronischer Altgeräte. Informieren Sie sich gegebenenfalls bei Ihrem Händler. Bitte sorgen Sie dafür, dass Ihr Altgerät bis zum Abtransport kindersicher aufbewahrt wird. 9 de - Gerätebeschreibung 10 de - Gerätebeschreibung Die Abbildung zeigt die Maximalausstattung des Staubsaugers.

a Handgriff XXL * b Nebenluftsteller * c Entriegelungstasten d Dreiteiliges Teleskopsaugrohr * e Verstellknöpfe für Teleskopsaugrohr * f Entriegelungstaste für Staubraumdeckel g Bodendüse * h Tragegriff i Staubbeutel j Motorschutzfilter k Park-System zur Aufbewahrung (an beiden Seiten des Staubsaugers) l Abluftfilter * m Anschlusskabel n Fußtaste für automatische Kabelaufwicklung ! o Saugleistungswähler p Park-System für Saugpausen q Fußtaste Ein / Aus r Staubbeutel-Wechselanzeige s Saugstutzen t Saugschlauch u Zubehörhalter * je nach Modell sind diese Ausstattungsmerkmale in ihrer Ausführung unterschiedlich bzw. nicht vorhanden. 11 de Die in den Kapiteln angegebenen Abbildungen finden Sie auf den Ausklappseiten am Ende dieser Gebrauchsanweisung. Je nach Modell verfügt Ihr Staubsauger über eines der folgenden Teleskopsaugrohre. – zweiteiliges Teleskopsaugrohr – dreiteiliges Teleskopsaugrohr Zweiteiliges Teleskopsaugrohr einstellen (Abb.

5) Dieses Teleskopsaugrohr besteht aus zwei ineinander gesteckten Rohrteilen, die Sie auf die jeweils bequemste Länge auseinander ziehen können. ^ Drücken Sie den Verstellknopf und stellen Sie das Teleskopsaugrohr auf die gewünschte Länge ein. Dreiteiliges Teleskopsaugrohr einstellen (Abb. 6) Dieses Teleskopsaugrohr besteht aus drei ineinander gesteckten Rohrteilen. a Drücken Sie die Entriegelungstaste des unteren Rohrteils und ziehen Sie es bis zum deutlichen Einrasten hinaus. Drücken Sie diese Entriegelungstaste auch, wenn Sie das Rohrteil wieder einschieben möchten. Die Verriegelung rastet deutlich ein. b Drücken Sie den Verstellknopf und stellen Sie das Teleskopsaugrohr auf die gewünschte Länge ein. Bodendüse aufstecken (Abb. 7) ^ Stecken Sie die Bodendüse nach links und rechts drehend auf das Telesko.

Am Staubsauger sind den Leistungsstufen Symbole zugeordnet, die beispielhaft zeigen, wofür die jeweilige Leistungsstufe zu empfehlen ist. # - Gardinen, Textilien Anschlusskabel herausziehen (Abb. 14) ^ Ziehen Sie das Anschlusskabel bis zur gewünschten Länge heraus (max. ca. 6,5 m). ^ Stecken Sie den Netzstecker in die Steckdose. \$ - Polstermöbel, Kissen % - hochwertige Veloursteppiche, Brücken und Läufer * - energiesparendes tägliches Saugen bei geringer Geräuschkentwicklung (- Teppiche und Teppichböden aus Schlingenware) - Hartböden, stark verschmutzte Teppiche und Teppichböden ,Saugen Sie Treppen aus Sicherheitsgründen von unten nach oben ab. Gebrauch bei einer Betriebszeit von länger als 30 Minuten komplett herausziehen. Gefahr der Überhitzung und Schädigung. Aufrollen (Abb.

15) ^ Ziehen Sie den Netzstecker aus der Steckdose. ,Das Anschlusskabel müssen Sie ,Wenn Sie die Bodendüse Air- TeQ nutzen und Ihnen dabei die Schiebekraft zu hoch erscheint, so reduzieren Sie die Saugleistung, bis sich diese Bodendüse leicht schieben lässt. 14 de Drehregler (Abb. 17) ^ Drehen Sie den Saugleistungswähler auf die gewünschte Leistungsstufe. Nebenluftsteller öffnen (Abb.

18 + 19) Sie können die Saugleistung kurzzeitig reduzieren, z. B. um ein Festsaugen an textilen Bodenbelägen zu verhindern. ^ Öffnen Sie den Nebenluftsteller nur so weit, bis sich die Saugdüse leicht bewegen lässt. Dadurch verringert sich die Schiebekraft an der jeweils verwendeten Saugdüse.

Beim Saugen (Abb. 20) ^ Ziehen Sie den Staubsauger beim Saugen wie einen Schlitten hinter sich her. Sie können den Staubsauger auch aufrecht stehend benutzen, z. B. beim Absaugen von Treppen oder Gardinen. Abstellen, Transportieren und Aufbewahren Park-System für Saugpausen (Abb. 21) In kurzen Saugpausen können Sie das Saugrohr mit der Bodendüse bequem am Staubsauger abstellen. ^ Stecken Sie die Bodendüse mit dem Parkknochen in das Park-System. Befindet sich der Staubsauger hierbei auf einer schrägen Fläche, z. B.

auf einer Rampe, so schieben Sie die Rohrteile des Teleskopsaugrohres komplett ein. Park-System zur Aufbewahrung (Abb. 22 + 23) ,Schalten Sie den Staubsauger nach Gebrauch aus. Ziehen Sie den Netzstecker aus der Steckdose. ,Beim Saugen – vor allem von Feinstaub, wie z. B. Bohrstaub, Sand, Gips, Mehl usw. – kommt es naturgemäß zu elektrostatischen Aufladungen, die sich in bestimmten Situationen entladen können. Um die unangenehme Wirkung der elektrostatischen Entladungen zu vermeiden, ist an der Unterseite des Handgriffes eine Metalleinlage eingearbeitet. Achten Sie deshalb darauf, dass Ihre Hand diese Metalleinlage beim Saugen dauerhaft berührt.



[You're reading an excerpt. Click here to read official MIELE S6290](http://yourpdfguides.com/dref/5488038)

[SILENCE user guide](http://yourpdfguides.com/dref/5488038)

<http://yourpdfguides.com/dref/5488038>

^ Stellen Sie den Staubsauger aufrecht hin. Es ist hilfreich, die Rohrteile des Teleskopsaugrohres komplett einzuschieben. ^ Stecken Sie die Bodendüse mit dem Parknocken von oben in einen der beiden Saugrohrhalter. So können Sie den Staubsauger bequem tragen oder zum Aufbewahren abstellen. 15 de Ist Ihr Staubsauger mit einem Handgriff XXL ausgestattet, so haben Sie eine weitere Möglichkeit zur platzsparenden Aufbewahrung.

^ Trennen Sie anschließend den Handgriff XXL von dem eingesteckten Teleskopsaugrohr. ^ Wickeln Sie den Saugschlauch um das Teleskopsaugrohr und stecken Sie den Parknocken des Handgriffs XXL von oben in den zweiten Saugrohrhalter. ,Die Verwendung von Staubbeutel aus Papier oder papierähnlichen Materialien sowie von Staubbeuteln mit einer Halteplatte aus Pappe kann ebenso zu schwerwiegenden Schäden am Staubsauger führen und einen Verlust der Garantie nach sich ziehen wie der Einsatz von Staubbeuteln ohne "Original Miele"-Logo. Wo bekomme ich Staubbeutel und Filter? Original Miele Staubbeutel und Filter erhalten Sie bei Ihrem Fachhändler oder beim Miele Werkkundendienst sowie im Miele Onlineshop. *Wartung* ,Schalten Sie den Staubsauger vor jeder Wartung aus und ziehen Sie den Netzstecker aus der Steckdose.

Das Miele Filtersystem besteht aus drei Komponenten. – Staubbeutel – Motorschutzfilter – Abluftfilter Um die einwandfreie Saugleistung des Staubsaugers zu gewährleisten, müssen Sie diese Filter von Zeit zu Zeit austauschen. Verwenden Sie nur Staubbeutel, Filter und Zubehör mit dem "Original Miele"-Logo. Nur dann kann die Saugleistung des Staubsaugers optimal ausgenutzt und das bestmögliche Reinigungsergebnis erreicht werden. Welche Staubbeutel und Filter sind richtig? Original Miele Staubbeutel mit roter Halteplatte vom Typ F/J/M und Original Miele Filter erkennen Sie an dem "Original Miele"-Logo auf der Verpackung oder direkt auf dem Staubbeutel. In jeder Packung Miele Staubbeutel liegt zusätzlich ein Abluftfilter Air Clean und ein Motorschutzfilter. 16 de Möchten Sie Original Miele Abluftfilter einzeln nachkaufen, so nennen Sie Ihrem Fachhändler oder dem Miele Werkkundendienst die Modellbezeichnung Ihres Staubsaugers, damit Sie die richtigen Teile bekommen. Sie können diese Teile aber auch bequem im Miele Onlineshop bestellen. Wann tausche ich den Staubbeutel aus? (Abb. 24) Wenn die Farbskala das Sichtfenster der Staubbeutel-Wechselanzeige rot ausfüllt, müssen Sie den Staubbeutel austauschen.

Staubbeutel sind Einwegartikel. Entsorgen Sie volle Staubbeutel. Verwenden Sie diese nicht mehrfach. Verstopfte Poren reduzieren die Saugleistung des Staubsaugers. Zur Prüfung ^ Stecken Sie die Bodendüse auf. ^ Schalten Sie den Staubsauger ein und stellen Sie die maximale Saugleistung ein. ^ Heben Sie die Bodendüse ein Stück vom Fußboden ab. Funktion der Staubbeutel-Wechselanzeige Die Funktion der Anzeige ist auf Mischstaub ausgelegt: Staub, Haare, Fäden, Teppichfusseln, Sand usw. Wenn Sie viel Feinstaub saugen, wie z. B.

Bohrstaub, Sand, eventuell auch Gips oder Mehl, verstopfen die Poren des Staubbeutels sehr schnell. Die Anzeige wird dann bereits "voll" anzeigen, selbst wenn der Staubbeutel noch nicht voll ist. Er muss dann ausgetauscht werden. Saugen Sie viele Haare, Teppich-, Wollfusseln usw., so kann die Anzeige erst reagieren, wenn der Staubbeutel bereits prall gefüllt ist.

Wie tausche ich den Staubbeutel aus? (Abb. 25, 26 + 27) ^ Drücken Sie die Entriegelungstaste in der Griffmulde und klappen Sie den Staubraumdeckel bis zum Einrasten nach oben auf. Dabei schließt sich der Hygieneverschluss des Staubbeutels automatisch, sodass kein Staub entweichen kann. ^ Ziehen Sie den Staubbeutel an der Griffflasche aus der Aufnahme. ^ Stecken Sie den neuen Staubbeutel bis zum Anschlag in die rote Aufnahme.

Lassen Sie ihn dabei so zusammengefaltet, wie Sie ihn der Verpackung entnehmen. ^ Entfalten Sie den Staubbeutel im Staubraum so weit wie möglich. ^ Schließen Sie den Staubraumdeckel bis zum Einrasten der Verriegelung und achten Sie darauf, dass der Staubbeutel dabei nicht eingeklemmt wird. Eine Leerbetriebssperre verhindert das Schließen des Staubraumdeckels, wenn kein Staubbeutel eingesteckt ist. Keine Gewalt anwenden! 17 de Wann tausche ich den Motorschutzfilter aus? Immer dann, wenn Sie eine neue Packung Miele Staubbeutel anbrechen. In jeder neuen Packung Miele Staubbeutel liegt zusätzlich ein Motorschutzfilter. Wie tausche ich den Motorschutzfilter aus? (Abb. 28) ^ Öffnen Sie den Staubraumdeckel. ^ Ziehen Sie den Staubbeutel an der Griffflasche aus der Aufnahme. ^ Klappen Sie den Filterrahmen bis zum deutlichen Einrasten auf und nehmen Sie den verbrauchten Motorschutzfilter an der sauberen Hygienefläche heraus.

^ Setzen Sie einen neuen Motorschutzfilter ein. ^ Schließen Sie den Filterrahmen. ^ Stecken Sie den Staubbeutel bis zum Anschlag in die Aufnahme. ^ Schließen Sie den Staubraumdeckel bis zum Einrasten der Verriegelung und achten Sie darauf, dass der Staubbeutel dabei nicht eingeklemmt wird. Wann tausche ich den Abluftfilter aus? Je nach Modell ist serienmäßig einer der folgenden Abluftfilter eingesetzt (Abb. 29). a Air Clean Tauschen Sie diesen Abluftfilter immer dann, wenn Sie eine neue Packung Miele Staubbeutel anbrechen. In jeder Packung Miele Staubbeutel liegt zusätzlich ein Abluftfilter Air Clean. 18 b Active Air Clean SF-AAC 50 (schwarz) c Active HEPA SF-AH 50 (blau) Tauschen Sie diese Abluftfilter jeweils nach ca. einem Jahr. Den Zeitpunkt können Sie auf dem Abluftfilter notieren. Wie tausche ich den Abluftfilter Air Clean aus? (Abb. 30 + 31) Achten Sie darauf, dass immer nur ein Abluftfilter eingesetzt ist. ^ Öffnen Sie den Staubraumdeckel. ^ Drücken Sie die Entriegelung des Filtergitters zusammen und öffnen Sie das Filtergitter bis zum Einrasten.

^ Nehmen Sie den verbrauchten Abluftfilter Air Clean an einer der beiden sauberen Hygieneflächen heraus. ^ Legen Sie den neuen Abluftfilter Air Clean ein. Möchten Sie aber einen Abluftfilter Active Air Clean oder Active HEPA einsetzen, so beachten Sie dazu unbedingt das Kapitel "Abluftfilter umrüsten". ^ Schließen Sie das Filtergitter. ^ Schließen Sie den Staubraumdeckel.

de Wie tausche ich die Abluftfilter Active Air Clean und Active HEPA aus? (Abb. 32 und 33) Achten Sie darauf, dass immer nur ein Abluftfilter eingesetzt ist. ^ Öffnen Sie den Staubraumdeckel. ^ Heben Sie den Abluftfilter an und entnehmen Sie ihn. ^ Setzen Sie den neuen Abluftfilter ein und drücken Sie ihn nach unten. Möchten Sie aber einen Abluftfilter Air Clean einsetzen, so beachten Sie dazu unbedingt das Kapitel "Abluftfilter umrüsten". ^ Schließen Sie den Staubraumdeckel. Abluftfilter umrüsten Je nach Modell ist serienmäßig einer der folgenden Abluftfilter eingesetzt (Abb.



[You're reading an excerpt. Click here to read official MIELE S6290 SILENCE user guide](http://yourpdfguides.com/dref/5488038)
<http://yourpdfguides.com/dref/5488038>

29. a Air Clean b Active Air Clean SF-AAC 50 (schwarz) c Active HEPA SF-AH 50 (blau) Beim Umrüsten beachten I.

Wenn Sie anstelle des Abluftfilters a einen Abluftfilter b oder c einsetzen, so müssen Sie zusätzlich das Filtergitter herausnehmen und dafür den entsprechenden neuen Abluftfilter einsetzen. 2. Wenn Sie anstelle des Abluftfilters b oder c einen Abluftfilter a einsetzen, so müssen Sie diesen unbedingt in ein Filtergitter * einlegen (Abb. 31). * Filtergitter – siehe Kapitel "Nachkaufbares Zubehör" 19 Achten Sie darauf, dass immer nur ein Abluftfilter eingesetzt ist.

Wann tausche ich die Fadenheber aus? Die Fadenheber am Saugmund der Bodendüse sind austauschbar. Erneuern Sie die Fadenheber, wenn der Flor verschlissen ist. Wie tausche ich die Fadenheber aus? (Abb. 34 + 35) ^ Heben Sie die Fadenheber, z. B. mit einem Schlitz-Schraubendreher, aus den Einsteckschlitz. ^ Ersetzen Sie die Fadenheber durch neue. Polsterdüse SPD 10 (je nach Modell serienmäßig) (Abb. 36) a Entriegeln Sie die Fadenhebereinheit an beiden Seiten der Polsterdüse mit einer Münze. b Ersetzen Sie die Fadenhebereinheit durch eine neue und verriegeln Sie diese.

de Laufrolle der Bodendüse reinigen (Abb. 37) (nicht notwendig bei den Bodendüsen FiberTeQ und AirTeQ) a Entriegeln Sie die Rollenachse (Bajonetverschluss) mit einer Münze. b Drücken Sie die Rollenachse heraus und entnehmen Sie diese. c Entnehmen Sie die Laufrolle. ^ Entfernen Sie anschließend Fäden und Haare, setzen Sie die Laufrolle wieder ein und verriegeln Sie die Rollenachse.

Ersatzteile bekommen Sie beim Miele Fachhändler oder beim Miele Werkkundendienst. Pflege ,Schalten Sie den Staubsauger vor jeder Reinigung aus und ziehen Sie den Netzstecker aus der Steckdose. Staubsauger mit textiler Oberfläche Den Staubsauger können Sie mit dem Saugpinsel absaugen oder mit einem nebelfeuchten Tuch abwischen. Staubsauger und Zubehörteile Den Staubsauger und alle Zubehörteile aus Kunststoff können Sie mit einem handelsüblichen Kunststoffreiniger pflegen. ,Verwenden Sie keine Scheuer- mittel, keine Glas- oder Allzweckreiniger und keine ölhaltigen Pflegemittel! Staubraum Den Staubraum können Sie bei Bedarf mit einem zweiten Staubsauger, falls vorhanden, aussaugen oder einfach mit einem trockenen Staubtuch oder Saugpinsel reinigen. ,Tauchen Sie den Staubsauger niemals in Wasser! Feuchtigkeit im Staubsauger birgt die Gefahr eines elektrischen Schlages. 20 de Störungen Der Staubsauger schaltet selbsttätig ab. Ein Temperaturbegrenzer schaltet den Staubsauger aus, wenn er zu warm wird. Die Störung kann auftreten, wenn z. B.

sperriges Sauggut die Saugwege verstopft oder der Staubbeutel voll bzw. durch Feinstaub luftundurchlässig ist. Die Ursache dafür kann auch ein stark verschmutzter Motorschutzfilter oder Abluftfilter sein. Schalten Sie den Staubsauger dann aus (Fußtaste Ein / Aus s drücken) und ziehen Sie den Netzstecker aus der Steckdose. Nach Beseitigung der Ursache und einer Wartezeit von ca. 20 – 30 Minuten hat sich der Staubsauger so weit abgekühlt, dass Sie ihn wieder einschalten und benutzen können. Kundendienst Sollten Sie den Kundendienst benötigen, so wenden Sie sich bitte an – Ihren Miele Fachhändler oder – den Miele Werkkundendienst unter der Telefonnummer Deutschland 0800 - 22 44 666 Österreich 050 800 300 * (* österreichweit zum Ortstarif) Luxemburg (00352) 4 97 11-20/22 Schweiz 0 800 800 222 Garantiebedingungen Die Garantiezeit des Staubsaugers beträgt 2 Jahre. Nähere Angaben zu den Garantiebedingungen in Ihrem Land erhalten Sie unter der oben stehenden Telefonnummer. Garantiebedingungen in Schriftform können Sie dort ebenfalls anfordern. 21 de Nachkaufbares Zubehör Beachten Sie in erster Linie die Reinigungs- und Pflegeanweisung Ihres Bodenbelag-Herstellers.

Sie können diese und viele weitere Produkte im Internet bestellen. Bodenbürste Parquet (SBB Parquet-3) Mit Naturborsten zum Absaugen kratzempfindlicher Hartböden, wie z. B. Parkett. Bodenbürste Parquet Twister mit Drehgelenk (SBB 300-3) Zum Absaugen verschiedener Hartbodenflächen und kleiner Nischen.

Bodenbürste Parquet Twister XL mit Drehgelenk (SBB 400-3) Zum Absaugen großer Hartbodenflächen und kleiner Nischen. Sonstiges Zubehör Zubehörkoffer MicroSet (SMC 20) Zubehör für die Reinigung kleiner Gegenstände und schwer zugänglicher Stellen, wie z. B. Stereoanlagen, Tastaturen, Modellbau. Zubehörkoffer CarCare (SCC 10) Zubehör für die Innenreinigung von Kraftfahrzeugen.

Zubehörkoffer Cat&Dog (SCD 10) Zubehör für die Reinigung von Haushalten mit Haustieren. Zubehörkoffer HomeCare (SHC 10) Bodenbürste Hardfloor (SBB 235-3) Zum Absaugen strapazierfähiger Hartböden, wie z. B. Fliesen. Zubehör für die Reinigung von Wohnräumen. Sie erhalten sie aber auch bei Ihrem Miele Fachhändler oder über den Miele Werkkundendienst. Einzelne Modelle sind bereits serienmäßig mit einem oder mehreren der folgenden Zubehörteile ausgestattet. Bodendüsen / -bürsten Bodendüse Classic Allergotec (SBDH 285-3) Zur täglichen hygienischen Reinigung aller Bodenbeläge. Beim Saugen wird der Reinigungsfortschritt über ein Farbdisplay (Ampelanzeige) sichtbar. Turbobürste Turbo Comfort (STB 205-3) Zum Saugbürsten kurzfloriger textiler Bodenbeläge.

22 de Handturbobürste Turbo Mini Compact (STB 20) Zum Saugbürsten von Polstermöbeln, Matratzen oder Autositzen. Universalbürste (SUB 20) Zum Absaugen von Büchern, Regalböden und ähnlichem. Lamellen- / Heizkörperbürste (SHB 20) Zum Entstauben von Heizkörperrippen, schmalen Regalen oder Fugen. Matratzendüse (SMD 10) Zum bequemen Absaugen von Matratzen und Polstermöbeln und deren Fugen. Fugendüse, 300 mm (SFD 10) Extralange Fugendüse zum Aussaugen von Falten, Fugen und Ecken. Fugendüse, 560 mm (SFD 20) Flexible Fugendüse zum Aussaugen schwer zugänglicher Stellen. Polsterdüse, 190 mm (SPD 10) Extrabreite Polsterdüse zum Absaugen von Polstermöbeln, Matratzen und Kissen. Flexible Schlauchverlängerung (SFS 10) Zur Verlängerung des Saugschlauches um ca. 1,5 m. Hygieneverschluss mit Aktivkohle Vermindert den Austritt von Staub und Gerüchen bei abgenommenem Saugschlauch.

Filter Abluftfilter Active Air Clean (SF-AAC 50) Nimmt Gerüche auf, die durch den Schmutz im Staubbeutel entstehen. Abluftfilter Active HEPA (SF-AH 50) Ausgezeichneter Abluftfilter für reinste Ausblasluft. Besonders für Allergiker geeignet. Filtergitter Wird benötigt, wenn Sie anstelle eines Abluftfilters Active Air Clean oder Active HEPA einen Abluftfilter Air Clean einsetzen möchten.



You're reading an excerpt. Click here to read official MIELE S6290 SILENCE user guide

<http://yourpdfguides.com/dref/5488038>

23 en - Contents Warning and Safety instructions .

.....
.....

.....
.....
.....

25 Description of the appliance

.....
.....
.....
.....

30 Caring for our environment

.....
.....
.....

32 Preparing for use

.....
.....

.....
.....
.....

..... 33 Using the accessories supplied .

.....
.....
.....
.....

..... 34 Use

.....
.....
.....

.....
.....
.....
.....

..... 35 Unwinding the cable

.....
.....
.....

.....
.....
.....

... 35 Switching on and off

.....
.....
.....
.....

35 Adjusting the suction power

.....
.....
.....
.....
.....

. 35 During vacuuming

.
.
.
.

36 Setting down, transportation and storage.

.
.

. 36 Parking system for pauses in vacuuming .

.
.
.

36 Parking system for storage

.
.

.
.

. . 36 Maintenance

.
.
.
.

.
.

37 Purchasing new dustbags and filters

.
.

. . . . 37 Ordering the correct dustbags and filters .

.
.

.
.

37 When to change the dustbag

.
.
.
.

37 How to replace the dustbag

.
.
.

. 38 When to change the dust compartment filter (for motor protection)

.
.

. . 38 How to change the dust compartment filter

.
.
.

. 39 When to change the exhaust filter

.....
.....
.....
..... 39 How to replace the Air Clean filter ..

.....
.....
.....
.....
..... 39 How to replace an Active Air Clean filter or an Active HEPA filter.

.....
... 39 Replacing one type of exhaust filter with another ..
.....

.....
... 40 When to change the thread lifters ..
.....

.....
.....
.....
40 How to replace the thread lifters

.....
.....
.....
..... 40 Cleaning and care ..

.....
.....
.....
.....
.....
.....
.....
..... 41 Problem solving guide
.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
..... 41 After sales service

.....
.....
.....
.....
.....
.....
.....
..... 41 Guarantee ..
.....

.....
.....
.....
.....
.....
.....
.....
.....

.....
..... 42 Optional accessories ..
.....
.....
.....
.....

.....
..... 42 Electrical connection for the UK .

.....
.....
.....
.....

..... 44 Electrical connection AU, NZ
.....
.....
.....

.....
..... 44 24 en - Warning and Safety instructions This vacuum cleaner complies with statutory safety requirements.

Improper use can, however, lead to personal injury and damage to property. To avoid the risk of accidents and damage to the vacuum cleaner, please read these instructions carefully before using it for the first time. They contain important information on its safety, operation and maintenance. Keep these instructions in a safe place and ensure new users are familiar with the content. Pass them on to any future owner.

Always disconnect the vacuum cleaner from the mains supply when you have finished using it, before changing over accessories, as well as for maintenance work and cleaning. Switch it off at the wall socket and unplug it. Correct application ~ This vacuum cleaner is not designed for commercial use. It is intended for use in domestic households and similar working and residential environments. ~ The vacuum cleaner is not intended for outdoor use. ~ The vacuum cleaner must only be used for domestic household purposes to vacuum dry floor surfaces. Do not use on people or animals. Any other usage, modification or alteration is not supported by the manufacturer and could be dangerous. 25 en - Warning and Safety instructions ~ This appliance can only be used by people with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, if they are supervised whilst using it, or have been shown how to use it in a safe way and understand the hazards involved. Safety with children ~ Children under 8 years of age must be kept away from the appliance unless they are constantly supervised.

~ Children 8 years and older may only use the vacuum cleaner unsupervised if they have been shown how to use it in a safe way and recognise and understand the consequences of incorrect operation. appliance unsupervised. ~ Children must not be allowed to clean or maintain the ~ Please supervise children in the vicinity of the vacuum cleaner and do not let them play with it. Technical safety ~ Before using the vacuum cleaner, check for any visible signs of damage. Do not use a damaged appliance. ~ Ensure that the connection data on the data plate ~ The plug must be fitted with a 13 A fuse (UK). (voltage and frequency) match the mains electricity supply exactly. 26 en - Warning and Safety instructions ~ While the vacuum cleaner is under guarantee, repairs should only be undertaken by a service technician authorised by Miele. Otherwise the guarantee will be invalidated. ~ Do not pull or carry the appliance by the cable, and be careful not to damage the cable when withdrawing the plug from the socket.

Keep the cable away from sharp edges and do not let it be squashed, for example, under a door. Avoid running the vacuum cleaner over the cable. This could damage the cable, plug or socket. The appliance must not be used if any of these have suffered damage. If the cable is damaged it must be replaced together with a complete cable rewind.

For safety reasons this work must be done by the Miele Service Department or a Miele authorised service technician. sand, plaster, flour, talcum powder etc., electrostatic charges build up naturally. Under certain conditions these charges will be released. To avoid the unpleasant effects of these discharges, a metal inlay has been incorporated into the underside of the handle.

Please make sure that you keep your hand in constant contact with this metal strip during vacuuming. dry cloth or slightly damp cloth when disconnected from the mains supply. ~ Do not use the vacuum cleaner if the cable is damaged. ~ When vacuuming especially fine dust, e.g. sawdust, ~ Do not let the vacuum cleaner get wet. Clean only with a 27 en - Warning and Safety instructions ~ Repairs should only be carried out by a Miele authorised service technician. Repairs and other work by unqualified persons could be dangerous. Correct use ~ To avoid the risk of damage, do not use the vacuum ~ If the dustbag is not fitted correctly, the dust cleaner without the dustbag, dust compartment filter and exhaust filter in place. compartment cover does not normally close.

Do not force it. is still glowing e.g. cigarettes, ashes or coal, whether glowing or apparently extinguished. ~ Do not vacuum up anything which has been burning or ~ Do not vacuum up any water, liquid or damp dirt. Wait until any freshly cleaned or shampooed carpets or floor coverings are completely dry before attempting to vacuum. printers and photocopiers, can conduct electricity. ~ Do not vacuum toner dust. Toner, such as that used in ~ Do not vacuum up any inflammable or combustible matter or gases and do not vacuum in areas where such substances are stored.



You're reading an excerpt. Click here to read official MIELE S6290 SILENCE user guide
<http://yourpdfguides.com/dref/5488038>

used at head level to avoid the risk of injury, e.

g. to eyes and ears. ~ Floor attachments, accessories and tubes must not be 28 en - Warning and Safety instructions Accessories ~ To avoid the risk of injury when vacuuming with a Miele Turbobrush, do not touch the rotating roller brush. ~ It is not advisable to vacuum directly with the handle, i.e. without an accessory attached, as the rim could get damaged and you could hurt yourself on sharp edges. ~ Only use genuine dustbags, filters, accessories and optional accessories with the "Original Miele" logo on them. This will ensure optimum performance of the appliance throughout its life. Miele cannot be held liable for damage caused by incorrect use or operation or by non-compliance with these Warning and Safety instructions. 29 en - Description of the appliance 30 en - Description of the appliance The illustration shows the maximum number of features available on these Miele vacuum cleaners. a XXL handle * b Air inlet valve * c Release buttons d Telescopic or triscopic tube * e Release buttons for the telescopic / triscopic tube * f Dust compartment release catch g Floorhead * h Carrying handle i Dustbag j Dust compartment filter (for motor protection) k Parking attachment (on both sides of the vacuum cleaner) l Exhaust filter * m Mains cable n Foot switch for automatic cable rewind ! o Suction power selector p Parking system for pauses in vacuuming q On/Off foot control s r Dustbag change indicator s Connection socket t Suction hose u Accessories holder Those features marked * depend on model, and may vary or not be available on your model. 31 en - Caring for our environment Disposal of packing material The packaging is designed to protect the vacuum cleaner from damage during transportation. The packaging materials used are selected from materials which are environmentally friendly for disposal and should be recycled. Ensure that any plastic wrappings, bags, etc. are disposed of safely and kept out of the reach of babies and young children. Danger of suffocation. Disposing of your old appliance Before disposing of your old appliance remove the dustbag and all the filters and dispose of them with your normal household waste. Electrical and electronic appliances often contain materials which, if handled or disposed of incorrectly, could be potentially hazardous to human health and to the environment. They are, however, essential for the correct functioning of your appliance. Please do not therefore dispose of it with your household waste.

Disposing of the dustbag and filters These are made from environmentally friendly materials. The filters can be disposed of with the normal household waste. The dustbag can also be disposed of in this way if it has been used exclusively for general household dust. Please dispose of it at your local community waste collection/recycling centre, or contact your dealer for advice. Ensure that it presents no danger to children while being stored for disposal. 32 en The illustrations referred to in the text are shown on the fold-out pages at the end of these operating instructions. Adjusting the telescopic suction tube (dia. 5) One part of the telescopic tube is packed inside the other and can be adjusted to suit your height for comfortable vacuum cleaning. ^ Press the release button to release the tubes and adjust to the required height. Adjusting the triscopic suction tube (dia.

6) The triscopic tube has three sections. Two sections are packed together inside a third outer tube. a Press the release button to release the lower tube and pull it right out until it clicks. Press the button again when you want to retract the tube. The tube will click into place.

b Press the release button to release the tubes and adjust to the required height. Fitting the floorhead (dia. 7) ^ Push the suction tube into the floorhead and turn it clockwise or anti-clockwise until it clicks into position. ^ To release the floorhead from the suction tube, press the release button and pull the suction tube away from the floorhead. Preparing for use Attaching the suction hose (dia.

1) ^ Insert the hose connector into the socket on the vacuum cleaner until it clicks into position. To do this, line up the guides on the two pieces. Removing the suction hose (dia. 2) ^ Press the release buttons at the side of the hose connector and lift the hose from the socket. Connecting the handle to the suction hose (dia. 3) ^ Insert the suction hose into the handle until it clicks into position. Connecting the handle to the suction tube (dia. 4) ^ Insert the handle into the telescopic / triscopic suction tube until it clicks into position. To do this, line up the guides on the two pieces. ^ To release the handle from the suction tube, press the release button and pull the handle away from the tube.

Your vacuum cleaner is fitted with one of the following telescopic tubes, depending on the model: – Telescopic tube – Triscopic tube 33 en Fitting the floorhead (dia. 8, 9 + 10) The floorhead can be used for all normal cleaning of carpets and rugs. It can also be used with the brush protruding to vacuum hard flooring. For hard flooring, such as stone and parquet, we recommend using one of the special Miele floor brushes (see "Optional accessories"). It is important to observe the flooring manufacturer's cleaning and care instructions. Depending on model, the floorhead will have the following symbols: – ö and ä – % and) Vacuum carpets and rugs with the brush retracted: ^ Press the ö or % foot control. Clean hard flooring which is not susceptible to scratching with the brush protruding: ^ Press the ä or) foot control. Clean flooring which has deep crevices or grooves with the brush protruding. AirTeQ floorhead (dia. 10) This floorhead has been specially developed to achieve excellent cleaning results using low energy.

It has particularly low power consumption and high suction capability. Warning: If the suction power of the AirTeQ floorhead seems too high, reduce the suction until the floorhead is easier to manoeuvre (see "Use - regulating the suction"). Using the accessories supplied (dia. 11) The following accessories are supplied: a Dusting brush with natural bristles For cleaning skirting boards, ornate or carved objects. The head can be swivelled to adjust the angle.

b Upholstery nozzle For cleaning upholstery, mattresses, cushions, curtains, covers etc. c Crevice nozzle For cleaning in folds, crevices or corners. d Accessories holder for the above accessories (dia. 12) Symbols on the holder show where to attach the different accessories. ^ Attach the accessories holder to the suction hose where it joins the handle or to hose connector socket.

Make sure it clicks into position. Certain models are supplied as standard with the following accessories which are not illustrated on this page. – Classic Allergotec floorhead – Turbobrush These floorheads and brushes are supplied with their own operating instructions.



[You're reading an excerpt. Click here to read official MIELE S6290 SILENCE user guide](http://yourpdfguides.com/dref/5488038)

<http://yourpdfguides.com/dref/5488038>

34 en Floorhead (dia. 13) For general use and also for vacuuming stairs. Warning: For safety reasons when vacuuming stairs it is best to start at the bottom of the stairs and move upwards. Some models also have symbols on the controls. The symbols indicate the type of use the settings are suitable for. # - curtains, lightweight fabrics \$ - upholstery, cushions % - thick pile carpets, rugs and runners * - for daily energy-saving vacuuming (this setting is also very quiet) (- loop-pile carpets) - hard flooring and for intensive cleaning of carpets Warning: When using the AirTeQ floorhead, if the suction seems too high, reduce the suction until the floorhead is easier to manoeuvre. Rotary selector (dia.

17) ^ Turn the suction power selector manually to the suction power setting you require. Opening the air inlet valve (dia. 18 + 19) It is easy to reduce the suction power for a short time, e.g. to prevent rugs or other objects being sucked into the vacuum cleaner. ^ Open the air inlet valve far enough to reduce the suction power. The floorhead will be easier to manoeuvre. Close the valve when you are ready to use full power again. Use Unwinding the cable (dia. 14) ^

Pull the mains cable out to the required length (max. approx. 6.5 m). ^ Insert the plug in the socket correctly and switch on. Warning: If vacuuming for longer than 30 minutes, the mains cable must be pulled out to its fullest extent.

Otherwise there is a danger of overheating and damage. Rewinding the cable (dia. 15) ^ Switch the vacuum cleaner off at the wall socket and unplug it. ^ Press the rewind foot switch briefly. The cable will rewind automatically.

Switching on and off (dia. 16) ^ Press the On/Off foot control s. Adjusting the suction power The suction power can be regulated to suit the type of flooring being cleaned. Reducing the suction power reduces the amount of effort required to manoeuvre the floorhead. 35 en During vacuuming (dia. 20) ^ When vacuuming, pull the cleaner behind you on its wheels. You can stand it upright for vacuuming stairs and curtains etc. Warning: When vacuuming especially fine dust, e.g. sawdust, sand, plaster, flour, talcum powder etc.

electrostatic charges build up naturally. Under certain conditions these charges will be released. To avoid the unpleasant effects of these discharges, a metal inlay has been incorporated into the underside of the handle. Please make sure that you keep your hand in constant contact with this metal strip during vacuuming. Parking system for storage (dia. 22 + 23) Warning. Always disconnect the vacuum cleaner from the electrical supply when you have finished using it. Switch the vacuum cleaner off at the wall socket and unplug it. ^ Stand the vacuum cleaner upright when it is not being used and when it is being stored. Retract the telescopic tube fully.

^ Then slot the floorhead downwards into one of the parking attachments on the side of the vacuum cleaner. This makes the vacuum cleaner easier to carry or store. If your vacuum cleaner has an XXL handle, you can detach this so that the vacuum cleaner requires less storage space. ^ Detach the XXL handle from the retracted suction tube. ^ Wind the suction hose around the suction tube and then slot the XXL handle into the second parking attachment.

Setting down, transportation and storage Parking system for pauses in vacuuming (dia. 21) The parking system allows you to conveniently park the vacuum cleaner during pauses. ^ Slot the floorhead into the parking attachment at the back of the vacuum cleaner. If the vacuum cleaner is on a sloping surface, e.g. a ramp, retract the telescopic tube fully. 36 en Maintenance Warning: Always disconnect the vacuum cleaner from the electrical supply for maintenance work and for cleaning. Switch off at the wall socket and unplug it. The Miele filtration system consists of three filters which must be replaced from time to time to ensure that your vacuum cleaner performs efficiently. – Dustbag – Dust compartment filter (for motor protection) – Exhaust filter Only use genuine dustbags, filters, accessories and optional accessories with the "Original Miele" logo on them. Only this will ensure that the suction power of the vacuum cleaner is maintained, giving the best possible cleaning results. Purchasing new dustbags and filters Original Miele dustbags and filters can be ordered from your Miele retailer, from Miele or online at: Ordering the correct dustbags and filters Only use original Miele F/J/M dustbags with a red collar. Using any other dustbags will damage the vacuum cleaner. Original Miele dustbags are identified by the "Original Miele" logo on the packaging or directly on the dustbag. Warning: The use of dustbags made from paper or paper-based materials, or dustbags with a cardboard collar, or dustbags that do not carry the "Original Miele" logo, can seriously damage the vacuum cleaner and invalidate the warranty.

An Air Clean exhaust filter and a dust compartment filter are supplied with every packet of Miele dustbags. If you wish to purchase original Miele exhaust filters separately, please quote the model number of your appliance when ordering to ensure you get the correct items. When to change the dustbag (dia. 24) Change the dustbag when the colour marker in the dustbag change indicator fills the display, or sooner if it is no longer effective (see possible reasons for this below). 37 en Miele dustbags are disposable and designed for single use only. Dispose of the dustbag when it is full. Do not attempt to reuse as suction would be reduced. Checking the dustbag change indicator ^ Attach the standard floorhead to the suction tube. ^ Switch the vacuum cleaner on and select the maximum power setting. ^ Lift the floorhead off the floor a little.

How the dustbag change indicator works The dustbag change indicator is set for normal household dust. This generally contains a mixture of: dust, hair, threads, carpet fluff, grit etc. However, if the cleaner has been used to vacuum up fine dust, such as plaster, brick dust, cement or flour, the pores of the dustbag will become blocked very quickly. This affects the air permeability of the bag, and the marker will indicate that the bag is "full" even when it is not. If this happens you must still change the dustbag because suction power will be greatly reduced by blocked pores in the dustbag.

If, on the other hand, a large amount of hair and carpet fluff which typically contains a lot of air is vacuumed up, the indicator may fail to react even though the bag is full. You should still change it. Both these extremes can occur. How to replace the dustbag (dia. 25, 26 + 27) ^ Lift the release catch for the dust compartment lid and raise the lid as far as it will go.

The dustbag has a closing flap which closes automatically when the dust compartment lid is raised to prevent any dust escaping. ^ Pull the dustbag out by the grip on the collar. ^ Fit the new dustbag into the red holder as far as it will go. Leave it folded up when you take it out of the box.



[You're reading an excerpt. Click here to read official MIELE S6290](http://yourpdfguides.com/dref/5488038)

[SILENCE user guide](http://yourpdfguides.com/dref/5488038)

<http://yourpdfguides.com/dref/5488038>

^ It should be unfolded as far as possible in the dust compartment. ^ Close the dust compartment lid securely, making sure it clicks into position. Take care not to trap the dustbag when doing so. Warning: The lid will not close without a dustbag in place. Do not use force. When to change the dust compartment filter (for motor protection) Replace this filter every time you start a new packet of dustbags.

A dust compartment filter is supplied with every packet of Miele dustbags. 38 en How to change the dust compartment filter (dia. 28) ^ Open the dust compartment lid. ^ Pull the dustbag out by the grip on the collar. ^ Lift up the filter frame until it clicks and remove the old filter. Hold by the clean, unsoiled section to remove it. ^ Replace with a new dust compartment filter. ^ Close the filter frame. ^ Fit the dustbag into the holder as far as it will go. ^ Close the dust compartment lid securely, making sure it clicks into position.

Take care not to trap the dustbag when doing so. When to change the exhaust filter Depending on model, your vacuum cleaner will be fitted as standard with one of the following exhaust filters (dia. 29): a Air Clean Replace this filter every time you start a new packet of Miele dustbags. An Air Clean exhaust filter are supplied with every packet of Miele dustbags. b Active Air Clean SF-AAC 50 (black) c Active HEPA SF-AH 50 (blue) Change these types of filter approx. once a year. Make a note of the date on the filter. How to replace the Air Clean filter (dia. 30 + 31) Do not use more than one exhaust filter at a time. ^ Open the dust compartment lid.

^ Press the release catch on the filter grille and open the grille until it clicks. ^ Hold the used Air Clean filter by one of the clean, unsoiled sections. ^ Replace it with a new Air Clean filter. If you wish to replace the Air Clean filter with an Active Air Clean filter or with an Active HEPA filter, see "Replacing one type of exhaust filter with another". ^ Close the filter grille. ^ Close the dust compartment lid. How to replace an Active Air Clean filter or an Active HEPA filter (dia. 32 + 33) Do not use more than one exhaust filter at a time. ^ Open the dust compartment lid. ^ Lift the filter and remove it.

^ Replace with a new filter, and push it down into place. If you wish to use an Air Clean filter, see "Replacing one type of exhaust filter with another". ^ Close the dust compartment lid. 39 en Replacing one type of exhaust filter with another Depending on model, your vacuum cleaner will be fitted as standard with one of the following exhaust filters (dia. 29): a Air Clean b Active Air Clean SF-AAC 50 (black) c Active HEPA SF-AH 50 (blue) Please note: 1. If you wish to replace the Air Clean filter a with an Active Air Clean filter b or an Active HEPA filter c, it is essential that you remove the filter grille before fitting the new type of filter. 2. If you wish to replace the Active Air Clean filter b or the Active HEPA filter c with an Air Clean filter a, then it is essential that you also fit the filter grille *, see dia. 31. * Filter grille – see "Optional accessories".

Do not use more than one exhaust filter at a time. When to change the thread lifters The thread lifters on the suction inlet of the floorhead can be replaced. Check them from time to time and replace them if the pile has worn down. How to replace the thread lifters (dia. 34 + 35) ^ Use a suitable screwdriver to remove the thread lifters from the slots.

^ Fit new thread lifters. Upholstery nozzle SPD 10 (depending on model) (dia. 36) a Disengage the thread lifter unit at each side of the upholstery nozzle using a coin. b Fit a new thread lifter unit and lock into position. Cleaning the roller on the floorhead (dia.

37) (not necessary for FiberTeQ and AirTeQ floorheads) a Release the bearing (with bayonet fitting) using a coin. b Press the bearing out, and remove it. c Take out the roller. ^ Remove any threads and hair, replace the roller and refit the bearing. Replacement parts are available from your Miele retailer or from Miele (see back cover for contact details). 40 en Cleaning and care Warning: Always disconnect the vacuum cleaner from the electrical supply for maintenance work and for cleaning. Switch off at the wall socket and unplug it. Vacuum cleaners with textile velvet finish Clean the vacuum cleaner casing with the dusting brush or a slightly damp cloth. Vacuum cleaner and accessories External surfaces of the vacuum cleaner and of the accessories can be cleaned with a proprietary cleaner suitable for plastic. Warning: Do not use abrasive cleaning agents, glass cleaning agents, all-purpose cleaners or oil-based conditioning agents.

Dust compartment The dust compartment can, if necessary, be cleaned using a dry duster, brush or, if available, a second vacuum cleaner to vacuum the dust out. Warning: Do not let the vacuum cleaner get wet. If moisture gets into the appliance, there is a risk of electric shock. Problem solving guide The vacuum cleaner switches off automatically A temperature limiter switches the vacuum cleaner off automatically if it gets too hot. This can occur if, for instance, large articles block the suction tube or when the filter bag is full or contains particles of fine dust. A heavily soiled exhaust or dust compartment filter can also be the cause of overheating. Switch the vacuum cleaner off immediately using the On/Off foot control s. Disconnect it from the electricity supply. Switch it off at the wall socket and unplug it. After removing the cause, wait for approx.

20 - 30 minutes to allow the vacuum cleaner to cool down. It can then be switched on again. After sales service In the event of a fault that you cannot easily remedy, please contact – your Miele Dealer or – Miele (see back cover for contact details). Please note that telephone calls may be monitored or recorded for training purposes (UK only). 41 en Guarantee For information on the appliance guarantee specific to your country please contact Miele.

See back cover for contact details. In the U.K. your appliance is guaranteed for 2 years from the date of purchase. However, you must activate your cover by calling 0845 365 6640 or registering online at www.

miele.co.uk. Floorheads / brushes Classic Allergotec floorhead (SBDH 285-3) This floorhead is suitable for daily hygienic cleaning of all floor surfaces. The level of cleanliness of the floor shows in a colour "traffic light" display when vacuuming. Turbo Comfort Turbobrush (STB 205-3) This turbobrush is ideal for cleaning cut pile carpet. Hard floor brush (SBB 235-3) This brush is designed for use on hard flooring such as tiled or stone floors. Parquet floor brush (SBB Parquet-3) This brush has natural bristles and is designed for use on parquet floors and other surfaces which are susceptible to scratching such as laminate flooring. or from your retailer or Miele. Certain models are supplied as standard with one or more of the following accessories: Parquet Twister swivel-action floor brush (SBB 300-3) This brush is suitable for a variety of hard floor surfaces and has a swivel joint enabling it to get into awkward corners.



[You're reading an excerpt. Click here to read official MIELE S6290 SILENCE user guide](http://yourpdfguides.com/dref/5488038)
<http://yourpdfguides.com/dref/5488038>

Parquet Twister XL swivel-action floor brush (SBB 400-3) This brush is extra wide making it suitable for large areas of flooring and has a swivel joint enabling it to get into awkward corners. Optional accessories Please observe the flooring manufacturer's cleaning and care instructions. Miele accessories, including floorheads, filters and dustbags are available to order through your Miele retailer, Miele or online at: 42 en Other accessories MicroSet (SMC 20) This set is specially designed for cleaning small objects and difficult to reach areas (such as PC keyboards, stereo equipment, intricately carved furniture and ornaments, models etc). CarCare Set (SCC 10) For valeting the interior of cars. Cat&Dog Set (SCD 10) Especially for households with pets. HomeCare Set (SHC 10) Accessories for cleaning the living areas of your home. Hand Turbobrush Turbo Mini Compact (STB 20) For cleaning upholstery, mattresses, car seats etc. Universal brush (SUB 20) For dusting books, shelves, etc. Radiator brush (SHB 20) For cleaning radiators, narrow shelves and crevices. Mattress nozzle (SMD 10) For cleaning upholstery, mattresses, cushions, curtains, covers etc.

Crevice nozzle, 300 mm (SFD 10) Extra long crevice nozzle for cleaning in folds, crevices or corners. 43 Crevice nozzle, 560 mm (SFD 20) Flexible crevice nozzle for accessing awkward to reach areas. Upholstery nozzle, 190 mm (SPD 10) Extra wide nozzle for cleaning upholstery, mattresses, car seats etc. Flexible extension hose (SFS 10) For extending the suction hose by approx. 1.

5 m. Hygiene seal with active charcoal Helps prevent dust and odours escaping when the suction hose has been removed from the cleaner. Filters Active Air Clean exhaust filter SF-AAC 50 This filter absorbs odours from the dirt collected in the dustbag. Active HEPA filter (SF-AH 50) Excellent filtration level for very clean exhaust air. This filter is particularly suitable for allergy sufferers.

Filter grille The filter grille is required if you wish to fit an Air Clean filter instead of an Active Air Clean filter or an Active HEPA filter. en Electrical connection for the UK All electrical work should be carried out by a suitably qualified and competent person in strict accordance with current national and local safety regulations (BS 7671 in the UK). The voltage and frequency are given on the data plate located underneath the vacuum cleaner. Please ensure that these match the household mains supply. The fuse rating is quoted on the plug. The appliance is supplied with a cable and moulded plug ready for connection to a 230-240 V/50 Hz a.c. single phase supply. Non-rewireable plugs BS 1363 The fuse cover must be re-fitted when changing the fuse, and if the fuse cover is lost the plug must not be used until a suitable replacement is obtained. The colour of the correct replacement cover is that of the coloured insert in the base of the plug, or the colour that is embossed in words on the base of the plug, (as applicable to the design of plug fitted).

Replacement fuses should be ASTA approved to BS1362 and have the correct rating. Replacement fuses and fuse covers may be purchased from your local electrical supplier. Electrical connection AU, NZ All work should be carried out by a suitably qualified and competent person in strict accordance with national and local safety regulations. The voltage and rated load are given on the data plate located underneath the vacuum cleaner. Please ensure that these match the household mains supply. The fuse rating is quoted on the plug. The appliance is supplied with a cable and moulded plug ready for connection to a 230V/50Hz AC single phase supply. Test Marks Electrical safety C-Tick Mark Electrically suppressed according to AS/NZS 1044 44 fr - Table des matières Prescriptions de sécurité et mises en garde. . .

.....

.....

.....

.... 46 Description de l'appareil

.....

.....

.....

.....

.....

.. 50 Votre contribution à la protection de l'environnement ...

.....

..... 52 Avant utilisation

.....

.....

.....

.....

.....

.....

..... 53 Utilisation des accessoires fournis avec l'aspirateur

.....

.... 54 Utilisation .

.....

.....

.....

.....

.....

.....

..... 55 Débrancher le câble d'alimentation.

.....

.....

.....

.....
.....
55 Mise en marche et arrêt
.....

.....
.....
.....
.....
55 Sélection de la puissance d'aspiration
.....
.....
.....

. . . 55 En aspirant
.....
.....
.....

.....
.....
.....
.....
. 56 Transport et rangement . .
.....
.....
.....

.....
. . 56 Système Idéal Pause
.....
.....

.....
.....
.....
. 56 Entretien .

.....
.....
.....
.....
.....
.....
. 57 Où se procurer les sacs et les filtres ?

.....
.....
.....
. 57 Quels sacs à poussière et quels filtres choisir ? .

.....
.....
.....
. 57 Quand remplacer le sac à poussière ?

.....
.....
.....
. 57 Comment remplacer le sac à poussière ? .

.....
.....

.....
.....

58 Quand remplacer le filtre moteur ?

.....
.....
.....

..... 58 Comment remplacer le filtre moteur ?

.....
.....
.....

.....
58 Quand remplacer le filtre d'évacuation ?

.....
.....

.....
.. 59 Comment remplacer le filtre d'évacuation Air Clean ?

.....
.....

... 59 Comment remplacer les filtres Actif Air Clean et Actif HEPA ?

.....
.....

... 59 Changement d'équipement du filtre d'évacuation ..

.....

.....
.. 59 Quand remplacer les ramasse-fils ?

.....
.....

.....
.. 60 Comment remplacer le ramasse-fils ?

.....
.....

.....
.. 60 Entretien

.....
.....
.....
.....

.....
.. 60 Dysfonctionnements

.....
.....

.....
... 61 Service Après Vente

.....
.....
.....

.....
.... 61 Conditions de garantie

.....

.....
.....
.....
.....

... 61 Accessoires en option.

.....
.....
.....

.....
.....

... 61 45 fr - Prescriptions de sécurité et mises en garde Cet appareil répond aux réglementations de sécurité en vigueur. Une utilisation non conforme comporte des risques pour les personnes et l'appareil.

Lisez attentivement ce mode d'emploi avant d'utiliser l'aspirateur pour la première fois. Il vous apporte des indications importantes concernant la sécurité, l'utilisation et l'entretien de votre aspirateur. Vous vous protégez ainsi et évitez de détériorer votre aspirateur. Conservez ce mode d'emploi et remettez-le à un éventuel futur propriétaire. Utilisation conforme ~ Cet aspirateur est destiné à une utilisation à la maison ou de type domestique. rieur. ~ Cet aspirateur ne convient pas à une utilisation en exté~ N'utilisez l'aspirateur que dans le cadre domestique, pour aspirer des poussières sèches.



[You're reading an excerpt. Click here to read official MIELE S6290](#)

[SILENCE user guide](#)

<http://yourpdfguides.com/dref/5488038>