



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for PANASONIC DMR-BWT745EC. You'll find the answers to all your questions on the PANASONIC DMR-BWT745EC in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual PANASONIC DMR-BWT745EC
User guide PANASONIC DMR-BWT745EC
Operating instructions PANASONIC DMR-BWT745EC
Instructions for use PANASONIC DMR-BWT745EC
Instruction manual PANASONIC DMR-BWT745EC

Panasonic

Instrucciones de funcionamiento

Grabador Blu-Ray Disc™

Referencia **DMR-BWT745**

DMR-BWT640

DIGA
Blu-ray



Gracias por adquirir este producto.

Consulte estas instrucciones con atención antes de utilizar este producto y guárdelo para su uso futuro.

- Este grabador de discos Blu-ray puede utilizarse para ver y grabar solamente los canales abiertos. No permite recibir canales de TV de pago ni canales codificados.

Actualización de software (Firmware)



La tecnología Blu-ray Disc y los servicios de difusión siguen proporcionando nuevas funciones. A medida que evolucionan, será necesario actualizar el firmware para poder utilizar las últimas funciones. Para asegurarse de que se mantenga el firmware actualizado con la nueva tecnología, es muy importante instalar las actualizaciones más recientes para mantener el correcto funcionamiento de su unidad.

Para más información, consulte "Actualización de software (Firmware)" (p. 86) o <http://panasonic.jp/support/global/cs/> (Este sitio sólo está disponible en inglés).

IEC



[You're reading an excerpt. Click here to read official PANASONIC DMR-BWT745EC user guide](#)

<http://yourpdfguides.com/dref/5588322>

Manual abstract:

@@ Which recording would you like to stop ? Where do you want to start playback from ? , [HDD] Play Press OK to start playing from the selected chapter . ,
File Conversion Convert the selected title by changing its recording mode. Please select recording mode and other options, then press OK. , Automatic
Standby after Copy Off * 1, 3 Standby status can be changed if required. @@@@ Do not disconnect the AC mains lead. .



[You're reading an excerpt. Click here to read official PANASONIC
DMR-BWT745EC user guide
http://yourpdfguides.com/dref/5588322](http://yourpdfguides.com/dref/5588322)