Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ALPINE ICS-X7. You'll find the answers to all your questions on the ALPINE ICS-X7 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual ALPINE ICS-X7
User guide ALPINE ICS-X7
Operating instructions ALPINE ICS-X7
Instructions for use ALPINE ICS-X7
Instruction manual ALPINE ICS-X7

You're reading an excerpt. Click here to read official ALPINE ICS-X7 user guide
http://yourpdfguides.com/dref/5234241

Manual abstract:

SERIAL NUMBER: ISO SERIAL NUMBER: INSTALLATION DATE: INSTALLATION TECHNICIAN: PLACE OF PURCHASE: AL SE NL RU PL For details on all functions, refer to the Owner's Manual stored in the supplied CD-ROM. (As it is data CD, the CD cannot be used for playing back music and images on the player.) If required, an ALPINE dealer will readily provide you with a print out of the Owner's Manual contained in the CD-ROM. 1-EN ALPINE ICS-X7 68-21057Z37-A (EN) WARNING Gett DO NOT INSTALL IN LOCATIONS WHICH MIGHT HINDER VEHICLE OPERATION , SUCH AS THE STEERING WHEEL OR SHIFT LEVER. Doing so may obstruct forward vision or hamper movement etc. Failure to heed them can result in serious injury or death. dO NOT OPERATE ANY FUNCTION THAT TAKES YOUR ATTENTION AWAY FROM SAFELY DRIVING YOUR VEHICLE. Any function that requires your prolonged attention should only be performed after coming to a complete stop. Always stop the vehicle in a safe location before performing these functions. failure to do so may result in an accident.

Touch You can o e Comm CAUTION This symbol means important instructions. Failure to heed them can result in injury or material property damage. hALT USE IMMEDIATELY IF A PROBLEM APPEARS. Failure to do so may cause personal injury or damage to the product. @@@@Swallowing them may result in serious injury.

@@) can be dangerous and may result in an accident. @@To ensure safety, always contact the dealer where you purchased this product to have the work done. dO NOT DISASSEMBLE OR ALTER. Doing so may result in an accident, fire or electric shock. uSE SPECIFIED ACCESSORY PARTS AND INSTALL THEM SECURELY.

Be sure to use only the specified accessory parts. Use of other than designated parts may damage this unit internally, or may not securely install the unit in place. This may cause parts to become loose resulting in hazards or product failure. uSE ONLY IN CARS WITH A 12 VOLT NEGATIVE GROUND. (Check with your dealer if you are not sure. Route the cables and wiring away from moving parts (like the seat rails) or sharp or pointed edges. This will prevent crimping and damage to the wiring. If wiring passes through a hole in metal, use a rubber grommet to prevent the wire's insulation from being cut by the metal edge of the hole. a DO NOT BLOCK VENTS OR RADIATOR PANELS. Doing so may cause heat to build up inside and may result in fire.

Use for other than its designed application may result in fire, electric shock or other injury. b MAKE THE CORRECT CONNECTIONS. Failure to make the proper connections may result in fire or product damage. dO NOT INSTALL IN LOCATIONS WITH HIGH MOISTURE OR DUST. Avoid installing the unit in locations with high incidence of moisture or dust. Moisture or dust that penetrates into this unit may result in product failure. Never cut away cable insulation to supply power to other equipment. Doing so will exceed the current carrying capacity of the wire and result in fire or electric shock. dO NOT DAMAGE PIPE OR WIRING WHEN DRILLING HOLES. When drilling holes in the chassis for installation, take precautions so as not to contact, damage or obstruct pipes, fuel lines, tanks or electrical wiring.

Failure to take such precautions may result in fire. turnin DO NOT USE BOLTS OR NUTS IN THE BRAKE OR STEERING SYSTEMS TO MAKE GROUND CONNECTIONS. Bolts or nuts used for the brake or steering systems (or any other safety-related system), or tanks should NEVER be used for installations or ground connections. Using such parts could disable control of the vehicle and cause fire, etc. 1 2 Tu The Pre 2-EN ALPINE ICS-X7 68-21057Z37-A (EN) Owner's manual Touch operation , Location of Controls , Turning Power On or Off Getting Started DER EL OR etc.

, and Touch operation You can operate the system by using the touch panel on the screen. e Common onscreen buttons : Returns to the previous screen. Depending on the function, this button may cancel the operations performed on the screen. Ical skill here you HEM r than securely e resulting INCHED e seat rails) mage to the grommet dge of the A Home/C button Touch the Home button to call up Favorites. Press the Home button to call up the Home Screen. Press and hold for at least 5 seconds to turn the power off. Remote Sensor Point the remote control transmitter towards the remote sensor within a range of 2 metres. E (Media View) button • When not using the Navigation system: If appears on the screen, pressing the button will close the screen in the same way as touching [ ]. □ When using the Navigation system: Pressing toggles between the Navigation screen and Audio/Visual screen. F Media Control button 1/2/3 This action varies according to the Audio/Visual application. (Track Up/Down, PLAY/PAUSE, Fast reverse/Fast forward, etc) MUTE button Activating this function will instantly lower the volume level by 20 dB. SE NL RU PL B URE OR moisture esult in C D G Turning Power On or Off 1 2 Turn the ignition key to the ACC or ON position. The system is turned on. Press and hold the Home/C button for at least 5 seconds to turn the power off. 3-EN ALPINE ICS-X7 68-21057Z37-A (EN) Owner's manual Home Screen and Favorites Home Screen and Favorites You can easily switch to the application of your choice from the Home Screen or Favorites.

The Home Screen displays icons for applications usable with this unit. Favorites is a shortcut function that displays up to 4 icons on the screen you are using. The icon layout is customisable for your convenience. usin You can s touch. Home button Touch the Home button. press the Home button. Touch an application icon to switch to that application. Favorites Home Screen Sett Owner's manual Using the Media Control buttons Using the Media Control buttons For operations like moving up or down between songs, in addition to using the operation buttons displayed on the screen, you can also use the Media Control buttons on the unit itself. This allows you to press a Media Control button to select a song even if the main screen for the media is not being displayed. The operation of the Media Control buttons may change depending on the media you are using.

A guide will display on the screen to show which switch controls what function. 1 2 3 4 Pre To To To Guide display Media Control button 1 Media Control button 2 Media Control button 3 4-EN ALPINE ICS-X7 68-21057Z37-A (EN) ites Owner's manual Using the Media View button Using the Media View button een ons on You can switch between the Navigation screen and the main screen for the current media source with just one touch. eN DE . Media View button Press FR ES Media screen IT Owner's manual Date/Time Setting Setting the Time SE NL RU ttons yed on Control will 1 2 3 4 Press the Home button. Indicator Frequency display Band display iPod An iPod/i video-cap Audio Info area Decreases frequency Preset button Displays the preset stations with a short touch.

@@@@@@Audio mode ncy Displays the search screen Current song no.

[You're reading an excerpt. Click here to read official ALPINE ICS-X7 user guide](http://yourpdfguides.com/dref/5234241)
http://yourpdfguides.com/dref/5234241

The Albums search screen of the selected artist is displayed. @@ pL 5 6 Touch the desired album's name. All songs of the selected album are displayed. @@ touch the desired song's name.

The selected song is played back. @@@@@@Han Hands-fre Audio mode Displays the search screen Current song no. @@ hFT: Sets for use as a Hands Free Device. Both: Sets for use as both an Audio device and Hands Free Device. @@@@@@@@@@ touch [Set BLUETOOTH Device].

@@@@@@@@@@30 Sec skip The currently playing content jumps ahead 30 seconds. @@@@@@ 10-EN ALPINE ICS-X7 68-21057Z37-A (EN) Owner's manual MirrorLink™ (Optional) MirrorLink™ Operation (Optional) listening e ICS-X7. Play display MirrorLink is a standard for connecting provides for a connection between an ICS-X7 and a mobile phone. Using MirrorLink, you can display a displays mobile phone screen and allows you to operate your mobile phone applications via this unit. When using MirrorLink, we recommend that you connect your mobile phone via both USB and BLUETOOTH.

The screen for the selected mode is displayed. □ After connecting to a mobile phone that is compatible with this unit, application icons will appear on the Home screen. ng content conds. Io Setup us Station eviously ou can e currently ously ext Press the Media Control button to operate the unit. □ The functions of the Media Control button differ, depending on the mode. □ Operable modes on this unit may differ from operations on your mobile phone, depending on the connected mobile phone. □ In Navigation mode, you can operate the system by using the touch panel only. Urrent ntent 11-EN ALPINE ICS-X7 68-21057Z37-A (EN) Owner's manual Installation Installation • When making connections to the vehicle's electrical system, be aware of the factory installed components (e. Do not tap into these leads to provide power for this unit. When connecting the ICSX7 to the fuse box, make sure the fuse for the intended circuit of the ICS-X7 has the appropriate amperage.

Failure to do so may result in damage to the unit and/or the vehicle. When in doubt, consult your Alpine dealer. □ The Display must be completely retracted in the casing when installing. If it is not, problems may occur. 4 3 Remove the mounting sleeve from the main unit.

This unit Bracket keys (Included) 1 Install at an angle between horizontal and 30°. Note that installing at an angle outside of this range will result in a loss of performance and possibly damage. Wh the the he Mo un su un alr Co acc CO Hex Slide the unit into the mounting sleeve and secure it. mounting Sleeve (Included) Dashboard Rubber Cap (Included) 0 - 30° Bracket This unit Meta Mou Stra 2 Mounting the Microphone. For safe use, make sure of the following: • location is stabION Screen Size LCD Type Operation System Number of Picture Elements 7.

*(Power class 2) HFP (Hands-Free Profile) OPP (Object Push Profile) PBAP (Phone Book Access Profile) A2DP (Advanced Audio Distribution Profile) AVRCP (Audio/Video Remote Control Profile) • Windo or regis the Un • iPhone iTunes U. (800 × 3 × 480) Effective Number of Picture Elements 99% or more Illumination System LED • "Made electro specific has be perform operat and reg this acc perform FM TUNER SECTION Tuning Range Mono Usable Sensitivity 50 dB Quieting Sensitivity Alternate Channel Selectivity Signal-to-Noise Ratio Stereo Separation Capture Ratio 87. 008% (at 1 kHz) 95 dB (at 1 kHz) 100 dB 85 dB (at 1 kHz) • Due to continuous product improvement, specifications and design are subject to change without notice. This means that there is a possibility that 0. 01% of the pixels could be either always ON or OFF. □ "Supply private a licenc any co broadc other m intrane conten audio-o licence http://w • aha, th tradem Interna * Frequency response may differ depending on the encoder 16-EN ALPINE ICS-X7 68-21057Z37-A (EN) • Manufactured under licence from Dolby Laboratories. Dolby and the double-D symbol are trademarks of Dolby Laboratories. □ Windows Media, and the Windows logo are trademarks, ss 2)) ss Profile) or registered trademarks of Microsoft Corporation in the United States and/or other countries. □ iPhone, iPod, iPod classic, iPod nano, iPod touch, and iTunes are trademarks of Apple Inc. □ "Made for iPod," and "Made for iPhone," mean that an mote EN DE FR ES IT SE NL RU PL electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards.*

Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, or iPhone may affect wireless performance. □ DivX®, DivX Certified® and associated logos are trademarks of Rovi Corporation or its subsidiaries and are used under license. □ The BLUETOOTH® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. Mely fective re is a er always • "Supply of this product only conveys a licence for private,non-commercial use and does not convey a licence nor imply any right to use this product in any commercial (i. e. Revenue-generation) real time broadcasting (terrestrial, satellite, cable and/or any other media), broadcasting/streaming via internet, intranets and/or other networks or in other electronic content distribution systems, such as pay-audio or audio-on-demand applications. An independent licence for such use is required. For details, please visit http://www. mp3licensing.

Com" • aha, the Aha logo, and the Aha trade dress are trademarks or registered trademarks of HARMAN International Industries, used with permission. □ „Made for iPod" und „Made for iPhone" bedeuten, mote EN DE FR ES IT SE NL RU PL dass ein elektronisches Zubehör speziell für den Anschluss eines iPod bzw. EN DE FR ES IT SE NL RU PL • "Made for iPod", y "Made for iPhone", significa que un accesorio electrónico se ha diseñado exclusivamente para conectarse a un iPod o iPhone, respectivamente, y su cumplimiento de las normas de funcionamiento de Apple ha sido certificado por los programadores. Rispondere a una chiamata 1 X® are l'inizio o/Eseguire apido er almeno ione etuta ermata dio ermata play del file amento meno 2 Una chiamata in entrata fa partire la suoneria e un display di chiamata in entrata. @@@@@@@@Visning av illustration Går till början av nuvarande innehåll/Går till föregående innehåll Visning av stationslogotyp Aha informationsdisplay Mirr MirrorLin mobiltele När du 1 2 3 Try Try Skä • Visning av partnerlogotyp Går till början av nästa innehåll Visa Sökskärm Skärmen ändras till enkelt läge eller infoläge "Like" feedback "Dislike" feedback Tillbakaspolning 15 sekunder Den innehåll som spelas spolas tillbaka 15 sekunder.

[You're reading an excerpt. Click here to read official ALPINE ICS-X7 user guide](http://yourpdfguides.com/dref/5234241)
http://yourpdfguides.com/dref/5234241

Går till början av nästa innehåll Paus och Uppspelning Går till början av nuvarande innehåll/ Går till föregående innehåll Try • Mediak • Funktio mobilte • I navig • Tryck på [(Tillbaka)] på uppspelningsskärmen för att återgå till skärmen för val av inställd station. □ ”Made for iPod,” och ”Made for iPhone,” innebär att ett elektroniskt tillbehör har utvecklats specifikt för att anslutas till iPod respektive iPhone och har certifierats av utvecklaren så att de uppfyller de prestandakrav som Apple ställer. EN DE FR ES IT SE NL RU PL • “Made for iPod”, en “Made for iPhone”, betekenen dat een elektronische accessoire specifiek werd ontworopen om te worden aangesloten op een iPod of iPhone en gecertificeerd is door de ontwikkelaar om te beantwoorden aan de prestatienormen van Apple. EN DE FR ES IT SE NL RU PL • “Made for iPod” u “Made for iPhone” o3 WYŁĄCZNY DYSTRYBUTOR EN DE FR ES IT SE NL RU PL • Etykiety „Made for iPod” (przeznaczone dla odtwarzacza iPod) oraz „Made for iPhone” (przeznaczone dla telefonu iPhone) oznaczają, że urządzenie elektroniczne zostało zaprojektowane specjalnie pod kątem możliwości podłączenia do odtwarzacza iPod lub telefonu iPhone i zostało certyfikowane przez producenta jako spełniające standardy jakości firmy Apple. .

You're reading an excerpt. Click here to read official ALPINE ICS-X7 user guide
http://yourpdfguides.com/dref/5234241