Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for BRAUN CORDLESS STYLER. You'll find the answers to all your questions on the BRAUN CORDLESS STYLER in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual BRAUN CORDLESS STYLER**
**User guide BRAUN CORDLESS STYLER**
**Operating instructions BRAUN CORDLESS STYLER**
**Instructions for use BRAUN CORDLESS STYLER**
**Instruction manual BRAUN CORDLESS STYLER**

You're reading an excerpt. Click here to read official BRAUN CORDLESS STYLER user guide
http://yourpdfguides.com/dref/3274965

***Manual abstract:***

*We hope you thoroughly enjoy your new Braun appliance. Please read the use instructions carefully before usage. braun Cordless is the perfect styling solution for young , modern women. Its ability to curl, flick, wave, volumize and shape hair makes it the ultimate in styling freedom. @@@@Keep out of the reach of children. â· Do not allow the appliance to become wet. @@Do not start the appliance while it is in the hair in order to avoid damage to the hair. Keep away from flames (burning cigarettes as well). â· Use Braun energy cells only. When hot, do not place on surfaces which are not heat resistant. â· When using the steam function, be aware the steam is hot. When applying it to your hair, please use at a safe distance away from the scalp. â· Do not take apart, puncture or incinerate. The Braun Cordless should be used on dry hair only. A Energy supply / start switch Â«0Â» = off, Â«1Â» = energy supply, Â«startÂ» = starting heat up B Ready indicator dot C Ignition control window D Water reservoir for steam function E Tong F Â«openÂ» release button for handle G Small styling brush H Halfround shaping brush* I Big styling brush* J Protective heat resistant cover with safety lock *only available with C Pro S model Before use The energy supply must be switched off (switch (A) at position Â«0Â»).*

*Press the Â«openÂ» release button (F) and pull off the handle. Insert a Braun energy cell into the handle as shown in the illustration (arrows on energy cell pointing outward). Push the handle with the energy cell back onto the appliance until it snaps into place. The energy level in the cell can be checked through the window at the bottom of the appliance. Only use Braun energy cells.*

*These are available from the store where this appliance was pur9 Chased, as well as from authorised Braun Service Agents. @@E) Re-insert the water reservoir until it snaps into place. @@@@After the water has dried out the appliance will work normally again. @@ f) After approx. 2 to 3 minutes, the ready indicator dot (B) turns dark. @@@@@@@@@@@2 to 3 seconds (you will feel a click). @@@@ b) Wait 3 to 4 seconds. @@The styling attachments can be put on and off as shown. @@@@Cleaning Make sure the appliance is switched off and cold. always empty the water tank.*

*@@ never immerse the appliance in water. The round styling brush and the protective cover can be cleaned in warm, soapy water. Storage After use or cleaning, always place the protective cover (J) on the appliance. It is heat-resistant and can be placed on the product immediately after usage. The protective cover will ensure that the appliance does not turn on unintentionally. When travelling by air, please note that no more than one appliance may be carried by each crew member or passenger aboard an aircraft in checked luggage, if the protective cover is secured over the heating element. separate gas refills are not permitted. Subject to change without notice. this product conforms to the EMC-Directive 89/336/EEC. Please do not dispose of the product in the household waste at the end of its useful life.*

*Disposal can take place at Braun Service Centre or at appropriate collection points provided in your country. Within the guarantee period we will eliminate, free of charge, any defects in the appliance resulting from faults in materials or workmanship, either by repairing or replacing the complete appliance as we may choose. @@@@@@To obtain service within the guarantee period, hand in or send the complete appliance with your sales receipt to an authorised Braun Customer Service Centre. For UK only: This guarantee in no way affects your rights under statutory law. .*

You're reading an excerpt. Click here to read official BRAUN CORDLESS STYLER user guide
http://yourpdfguides.com/dref/3274965