Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HITACHI AX-M136I. You'll find the answers to all your questions on the HITACHI AX-M136I in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HITACHI AX-M136I
User guide HITACHI AX-M136I
Operating instructions HITACHI AX-M136I
Instructions for use HITACHI AX-M136I
Instruction manual HITACHI AX-M136I

Instruction Manual

HITACHI
Inspire the Next

AX-M136i

Micro Hi-Fi System with DAB Radio & Docking for iPod

Note: iPod is not included.

You're reading an excerpt. Click here to read official HITACHI AX-M136I user guide
http://yourpdfguides.com/dref/1273182

Manual abstract:

Please read these operating instructions before operating the unit. @@@@@@@@Don't look at the laser radiation district when the equipment is operating. The rating label is located on the base of the amplifier unit. Precautions This equipment has been designed and manufactured to meet international safety standards but, like any electrical equipment, care must be taken if you are to obtain the best results and safety is to be assured. .....

.....

.....

.....

..... DO read the operating instructions before you attempt to use the equipment. DO ensure that all electrical connections (including the mains plug, extension leads and interconnections between the pieces of equipment) are properly made and in accordance with the manufacturer's instructions. Switch off and withdraw the mains plug before making or changing connections.

@@@@@@@@Overheating will cause damage and shorten the life of the equipment. DON'T allow electrical equipment to be exposed to dripping or splashing, or objects filled with liquids, such as vases, to be placed on the equipment and don't handle the power cord with wet hands. DON'T place hot objects or naked flame sources such as lighted candles or nightlights on, or close to equipment. High temperatures can melt plastic and lead to fires. -1- DON'T use makeshift stands and NEVER fix legs with wood screws - to ensure complete safety always fit the manufacturer's approved stand or legs with the fixings provided according to the instructions.

DON'T listen to headphones at high volume, as such use can permanently damage your hearing. DON'T leave equipment switched on when it is unattended unless it is specifically stated that it is designed for unattended operation or has a standby mode. Switch off using the switch on the equipment and make sure that your family knows how to do this. Special arrangements may need to be made for infirm or handicapped people. DON'T continue to operate the equipment if you are in any doubt about it working normally, or if it is damaged in any way - switch off, withdraw the mains plug and consult your dealer.

.....

.....

.....

.....

... ABOVE ALL, NEVER let anyone especially children push anything into holes, slots or any other opening in the case - this could result in a fatal electrical shock. NEVER guess or take chances with electrical equipment of any kind...it is better to be safe than sorry! Correct Handling of Batteries Improper or incorrect use of batteries may cause corrosion or battery leakage, which could cause fire, personal injury or damage to property. Use only the types of the batteries which are indicated in this manual. Do not install new batteries with used ones.

Install the batteries correctly by following the polarity (+ and -) indications in the battery compartment. Do not dispose of the used batteries as domestic waste. Dispose of them in accordance with the local regulations. Small button cell batteries such as used in the remote handset for this unit are easily swallowed by young children and this can be dangerous. Keep loose button cells away from young children and make sure that the battery holder tray is secure in the remote control. Seek medical advice if you believe a cell has been swallowed. -2- Table of Contents Important Cautions ....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.. 1 For your safety ...

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....
.....
.....
.....

.....
.....
.....
.....

. 1 Precautions .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 1 Correct Handling of Batteries ....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
... 2 Package Contents .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 4 Product Overview .

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 5 The CD/MP3 Player .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.. 5 The Amplifier ...
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

.....
.....

.....
.....
.....
.....

.....
5 Remote Control Overview .....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.... 6 Installation of Battery .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 7 Connections ....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.. 8 Connecting the Antenna .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 8 Connecting the Speakers ..

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.. 8 Connecting Control Cable .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 8 Connecting the iPod Docking .....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

... 9 Connecting Auxiliary Equipment (AUX INPUT) .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.... 9 Connecting Auxiliary Equipment (LINE OUT) .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 9 Connecting the Headphones ...
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.....

..... 9 Connecting the AC Power Plug ....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 10 Turning the Power On and Off .

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
... 10 Setting the Clock ..
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
10 Sound Quality .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

. 11 Adjusting the Volume .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
11 Adjusting the super bass .....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.... 11 Control the Loudness .
.....
.....

.....
.....
.....
.....

.....
.....

.....
.....

.....
.....
.....
.....

.....
.....
.....
... 11 Preset Equalizer .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
. 11 Changing the Vacuum Fluorescent Display (VFD) Darkness ....
.....
.....

.....
.....
.....
.....

.....
.....
.... 11 Listening to Radio Broadcasts .
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.... 11 DAB Radio .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

11 FM Radio .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 13 Presetting Stations ...

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 13 To change the FM Reception Mode .

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 13 RDS (Radio Data System) Reception ....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

. 14 CD Operation .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
... 14 CD Playing ..
.....
.....

.....
.....
.....
.....

.....
.....
.....

.....

.....
.....
.....
.....

.....
.....
.....
.....

..... Direct Select track ...
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.... To Skip Search and Play .
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.. To Search .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.... Text Display During Playback .
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.... Program Play .
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.... Random Play (CD and MP3 discs) .....
.....
.....
.....

.....
.....
.....
.....

.....
.....

.....
.....

.....
.....
.....
. Playing the Beginning (Intro) of each Track .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.... Playing Repeatedly .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 14 14 14 14 14 15 15 15 15 MP3 Disc Playing .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
. 15 Playing Repeatedly ....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.. 16 Use the USB .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 16 Use the iPod portable player .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
... 17 Setting the Sleep Timer .....

.....
.....
.....
.....

.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
17 Setting the Daily on Timer .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
... 18 Disc Handling ..
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 19 Troubleshooting .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.....

.....
.....
.....
.....

... 20 Specifications .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.... @@@@You can connect your iPod portable player in the iPod docking.
Make sure the dock adaptor is compatible to your iPod. The CD Player iPod Portable Player iPod Docking Docking Cable Connecting Auxiliary Equipment (AUX INPUT) Connect the AUX INPUT sockets on this unit to the line output sockets on the auxiliary equipment as illustrated below. The CD Player Auxiliary equipment Connectuum Fluorescent Display (VFD). Preset Equalizer You can adjust the sound reproduced simply by choosing from 5 preset equalizers. @@@@@@@@@@@@@@2.
Press the Play/Pause button (BF) to confirm. @@@@@@@@Manual Tuning 1. @@2. @@3. @@@@@1. @@2. @@3. @@@@@@@4. @@@@The system will tune to the selected station automatically. @@@@@@@@@@@@2.

Press the Play/Pause button (BF) to confirm. @@@@@@Stations can be tuned in manually, automatically, or from preset memory storage. Caution: Before listening to the radio, please check that the FM antenna is correctly connected and adjusted for length and direction. Tuning in a Station 1. Repeatedly press the Function button (FUNCTION) on the front of the amplifier until FM Radio is displayed on the display screen, or press the Tuner Function button ( ) on the remote control. 2. Tune in a station using one of the following methods. Auto Tuning If you press the Intro/Scan button (INTRO/SCAN) button on the remote control, display will show "AUTOSCAN" and the auto tuning would start. Manual Tuning Repeatedly press the Tuning Backward/Forward buttons (- TUNING +) on the top of the CD player or press the D /C buttons on the remote control to change the frequency until you find the C station you want. Preset Tuning (Available only after the stations are preset) Repeatedly press the Preset Up/Down switch buttons (- PRESET +) on the top of the CD player or press the H/G buttons on the remote control to select the desired preset number.
Its band G and frequency are displayed on the Vacuum Fluorescent Display (VFD). Presetting Stations You can manually preset up to 20 FM stations. Tune in the desired station: 1. Press the Program button (PROG) on the remote control, the preset number will be displayed. 2.
Press the Preset Up/ Down switch buttons (- PRESET +) on the top of the CD player or the H /G buttons on the remote control to select the preset number. G - PRESET/H Decrease the preset number by 1 H PRESET +/G Increase the preset number by 1 G Note: If you select more than 20, the preset number will be changed to "1" automatically.

You're reading an excerpt. Click here to read official HITACHI AX-M136I user guide
http://yourpdfguides.com/dref/1273182

3. Press the Program button (PROG) again to store the station. The display will return to the broadcast frequency display.
4. Repeat above steps 1 to 3 for each station you want to store in memory with a preset number. Note: If the system is unplugged or if a power failure occurs, the preset stations will not be erased after stored. To change the FM Reception Mode Press the Mode button (MODE) to select the Auto or Mono channel to receive the best FM reception mode. - 13 - RDS (Radio Data System) Reception Many FM stations are broadcasting added data compatible with RDS. This radio set offers convenient functions using such data. Press the Display button (DISPLAY) on the remote control repeatedly to select the information that displayed as follows. PRG TYPE Program type identification signal. (Example: News, Rock, Classical music.) RADIO TEXT This displays the news of stations.

DATE/CLOCK This displays the current date and time, which is supplied by the radio station and should always be accurate. CD Operation CD Playing 1. Repeatedly press the Function button (FUNCTION) on the front of the amplifier or press the Disc Function button ( ) on the remote control. 2. Press the Open/Close button (K) to open the disc door and place the disc on the disc tray (with the printed side up). 3. Press the Open/Close button (K) to close the disc door, the unit will read the disc and play it automatically. Note: If in stop mode, please press the Play/Pause button (BF) to start playing the disc. 4. Press the Play/Pause button (BF) to pause the playing, press the button again to continue play.
5. Press the Stop button (L) to stop the disc playing. Direct Select track Load a disc, upon finishing reading the disc, you can select tracks by using number buttons (0-9, 10+) on the remote control and play. If the song number is less than 10, press the number buttons 0-9. @@@@@@Insert a disc and press the (STOP) when it starts playing.
2. Press the Program button (PROG), "01-P-01" appears. 3. @@4. @@5.
Repeat steps 3-4 to select and store all desired tracks. 6. Press the Play/Pause button (BF) to start programme play. 7. Press the Stop button (L) once to stop the programme play. Press the Stop button (L) twice to clear program. @@@@The playing time of each track is 10 seconds. @@@@@@@@You can use this function to repeat playing certain part of a track. When it is playing, press the repeat A-B button (A-B) on the remote control at the beginning of the content that needs repeat playing. Press the repeat A-B button (A-B) again at the end of the content that needs repeat playing.

The player will then repeatedly play between A and B until you press the repeat A-B button (A-B) again to cancel this function. The unit will then turn to normal playing mode. Note: A-B repeat function can only be used within the same track. MP3 Disc Playing When selecting tracks the player will automatically display the directory and track number. For example: track number 21 may be from directory 3, track 7. 1. Repeatedly press the Function button (FUNCTION) on the front of the amplifier until MP3 displays on the display screen, or press the Disc Function button ( ) on the remote control. 2. Press the Open/Close button (K) to open the disc door and place the MP3 disc on the disc tray. 3.
Press the Display button (DISPLAY) on the remote control, ID3 information (song title and artist) will be displayed or "NO ID3" if there is no ID3 information. Press this button again, and the directory, track and playing time will be displayed. 4. When playing MP3 discs, the current album and track will be displayed. 5.
Press the H, G buttons to select the previous/next track. When pressing the D, C buttons for a few seconds, it will search backward or search forward. - 15 - 6. Press the Album Up button (ALB+) or Album Down button (ALB-) on the remote control to select the next/previous directory, and play the first track of this directory. If the playing is stopped, press the Album Up button (ALB+) or Album Down button (ALB-) on the remote control to select the next/previous directory.
Then choose the track with the Next button (G) or Previous button (H). 7. Press the Play/Pause button (BF) to start play the disc. 8. Press the Stop button (L) to stop playing. Note: Play will continue to the final track when the selected tracks have been played. The first 2 digits of the display is the directory number, the next 3 digits is the track number and the remaining digits display the minutes and seconds. Playing Repeatedly ONE, DIR and ALL repeat play can be set by pressing the Mode button (MODE). First press : To repeat the same track, the words "TRK REP" blink. Second press : To repeat ALB (Album), the words "ALB REP" blink.

Third press : To repeat ALL (All directories and tracks), the words "ALB TRK REP" do not blink. Fourth press : To cancel the repeat playing, the word "REP" disappears. You can use this function to repeat playing certain part of a track. When it is playing, press the repeat A-B button (A-B) on the remote control at the beginning of the content that needs repeat playing. Press the repeat A-B button (A-B) again at the end of the content that needs repeat playing. Then the player will repeatedly play between A and B until you press the repeat A-B button (A-B) again to cancel the this function. The unit will then turn to normal playing mode. Note: A-B repeat function can only be used within the same track. Use the USB By connecting an USB mass storage device (including USB flash memory, USB flash players or memory cards) to this unit, you can enjoy the device's stored music through the powerful speakers of Hi-Fi system. 1. Insert the USB device's USB plug into the socket on the rear of unit. 2. Press the USB button on remote control or press the Function button (FUNCTION) on the panel of the amplifier to select the USB function. 3. The device's stored music will be played automatically.
4. When you store more one folders in the USB flash, use the Album Up button (ALB+) or Album Down button (ALB-) on the remote control to select the next/previous folder. Then choose the track with the Next button (G) or Previous button (H) to play the folder. For the devices with USB cables: 1. Insert one plug of the USB cable (not supplied) to the socket on the set.
2. Insert the other plug of the USB cable to the USB output terminal of the USB device. For the memory card: 1. Insert the memory card into a card reader (not supplied). 2. Use a USB cable (not supplied) to connect the card reader into the socket on the set. USB Storage Device Data Protection Always insert the USB device in the correct direction. Failure to do so may result in damage to the USB device and this product. - 16 - Do not remove the USB device while it is being accessed. Electrical interference and electrostatic discharges may cause the USB device to malfunction and suffer damage, resulting in data loss.

It is strongly recommended that any important data is backed up on a PC to protect against corruption, data loss or device malfunction.

[You're reading an excerpt. Click here to read official HITACHI AX-M136I user guide](http://yourpdfguides.com/dref/1273182)
http://yourpdfguides.com/dref/1273182

Please note that our company shall not accept any liability for damage or loss of stored data. Note: USB connection is not compatible with all hard drive models. Use the iPod portable player Correctly dock your iPod portable player in the docking. Make sure the dock adaptor is compatible. Press the iPod button (iPod/AUX) on the remote control or the Function button (FUNCTION) on the panel of the amplifier to select iPod source. Playback starts automatically. You can select available features (e.g. BF,G,H etc.

) during playback. In power on mode, directly dock your iPod portable player in the docking for charging. Note: For the purpose of saving power, recharging of your iPod or USB device is NOT SUPPORTED when the main set is in the STANDBY MODE. Setting the Sleep Timer Use the sleep timer to turn the system off after a certain number of minutes when it is playing. By setting the sleep timer, you can fall asleep to music and know that your system will turn off by itself rather than play all night.

1. Play a CD or tune in to the desired station. 2. To set the sleep timer press the Sleep button (SLEEP) on the remote control repeatedly, it changes the number of minutes shown on the display in this sequence: -10 20 ..

. 80 90 00 After setting the number of minutes for the sleep timer, the display will return to the display as before setting the sleep timer. The system is now set to turn off after the number of minutes you set. To confirm the sleep time When the Sleep button (SLEEP) on the remote control is pressed once, the remaining sleep time is displayed. Wait for a second until the display returns to the original display. To cancel the sleep timer setting Repeatedly press the Sleep button (SLEEP) on the remote control until the "00" is displayed. @@@@@@1. @@2. Set the hour with the Volume Down button (VOL-) or Volume Up button (VOL+). 3.

*Press the Timer button (TIMER) on the remote control, the minute indicator will blink. 4. Set the minute with the Volume Down button (VOL-) or Volume Up button (VOL+). 5. Press the Timer button (TIMER) on the remote control, the selected time is set. @@@@Caution: * You can set the daily timer only in standby mode. @@@@* The volume automatically comes on at level 12. To confirm the daily time When you press the Timer button (TIMER) on the remote control in standby mode, the daily time is displayed. Wait for a few seconds until the display returns to the time display. To cancel the daily timer setting Repeat the previous steps for setting the daily timer until "OFF" is displayed.*

Turning off the system also cancels the daily timer. - 18 - Disc Handling Handling Precautions · Hold the disc by the edges so the surface will not be soiled with fingerprints. (A) Fingerprints, dirt and scratches can cause skipping and distortion. · Do not write on the label side with a ball-point pen or other writing implements. · Do not use record cleaning sprays, benzine, thinner, static electricity prevention liquids or any other solvent.

· Be careful not to drop or bend the disc. · Do not install more than 1 disc on the disc tray. · Do not try to close the disc tray when the disc is not installed properly. · Be sure to store the disc in its exclusive case when not in use. If the surface is soiled (B) · Wipe gently with a soft, damp (water only) cloth.

· When wiping discs, always move the cloth from the center hole toward the outer edge. (If you wipe the discs using a circular motion, circular scratches are likely to occur, which will cause noise.) · If the disc is brought from a cold to a warm environment, moisture may form on the disc. Wipe the moisture off with a soft, dry, lint-free cloth before using the disc. Improper disc storage You can damage discs if you store them in the following places: · Areas exposed to direct sunlight. · Humid or dusty areas. · Areas directly exposed to a heat outlet or heating appliance. The disc formats can play in this unit: Audio CD, CD-R, CD-RW. - 19 - Troubleshooting If you are having a problem with your system, check this list for a possible solution before calling for service. If you cannot solve the problem from the hints given here, or the system has been physically damaged, call a qualified person, such as your dealer, for service.

Symptom No sound is heard Poor radio reception Possible Cause Connections are incorrect, or loose The antenna is disconnected The antenna is not properly extended and positioned The disc is dirty or scratched The disc is upside down The disc is dirty The path between the remote control and the sensor on the player is blocked The batteries have lost their charge The built-in microprocessor has malfunctioned due to external electrical interference Action Check all connections and make corrections Reconnect the antenna securely Extend antenna to the best reception position Clean or replace the disc Put the disc in with the label side up Remove disc from player, wipe with a clean cloth and re-insert. Remote the obstruction Replace the batteries Unplug the system then plug it back in The disc skips The disc does not play Unable to operate the remote control Operations are disabled - 20 - Specifications System Specification Power Requirements DAB Frequency Range (band III) FM Frequency Range Power Consumption Output Power THD Dimensions : : : : : : : ~ 230V/50Hz 174.928 - 239.200 MHz 87.5 - 108 MHz 60W (ECO Standby 0.7W) 45W × 2 1% (CD) 192(W) x 67(H) x 235(D) mm (Amplifier) 192(W) x 62(H) x 242(D) mm Speaker Specifications Impedance Input Power Dimensions The disc formats can play in this unit: Audio CD, CD-R, CD-RW. : : : 4 50W 128(W) x 205(H) x 205(D) mm 41006893 - 21 - The mark is in compliance with the Waste Electrical and Electronic Equipment Directive 2002/96/ EC (WEEE). The mark indicates the requirement NOT to dispose the equipment including any spent or discarded batteries as unsorted municipal waste, but use the return and collection systems available. If the batteries or accumulators included with this equipment, display the chemical symbol Hg, Cd, or Pb, then it means that the battery has a heavy metal content of more than 0.0005% Mercury, or more than 0.

002% Cadmium or more than, 0.004% Lead. Visit Partmaster.co.uk today for the easiest way to buy electrical spares and accessories.

With over 1 million spares and accessories available we can deliver direct to your door the very next day. Visit www.partmaster.co.uk or call 0870 6001 338 (UK customers only) Calls charged at National Rate.

If you require a replacement for any of the items listed below, please quote their corresponding part numbers: Replacement Part Part Number Remote control AXM136iP0001 Control cable AXM136iP0002 Speaker cable x 2 AXM136iP0003 DAB/FM Antenna AXM136iP0004 Stand AXM136iP0005 Instruction Manual AXM136iP0006 Addendum AXM136iP0007 iPod Docking AXM136iP0008A iPod Dock Adaptor (NANO) AXM136iP0008B iPod Dock Adaptor (MINI) AXM136iP0008C iPod Dock Adaptor (20GB+U2) AXM136iP0008D iPod Dock Adaptor (20GB+30GB) AXM136iP0008E iPod Dock Adaptor (40GB) AXM136iP0008F iPod Dock Adaptor (VIDEO 30GB) AXM136iP0008G iPod Dock Adaptor (VIDEO 60GB) AXM136iP0008H iPod Dock Adaptor (PHOTO 40GB/60GB) AXM136iP0008I - 22 - .

[You're reading an excerpt. Click here to read official HITACHI AX-M136I user guide](http://yourpdfguides.com/dref/1273182)
http://yourpdfguides.com/dref/1273182