Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HITACHI AX-M76. You'll find the answers to all your questions on the HITACHI AX-M76 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HITACHI AX-M76
User guide HITACHI AX-M76
Operating instructions HITACHI AX-M76
Instructions for use HITACHI AX-M76
Instruction manual HITACHI AX-M76

HITACHI
Inspire the Next

Instruction Manual

AX-M76

Micro Hi-Fi System

You're reading an excerpt. Click here to read official HITACHI AX-M76 user guide
http://yourpdfguides.com/dref/1273183

Manual abstract:

DO NOT cut off the mains plug from this equipment. If the plug fitted is not suitable for the power points in your home or the cable is too short to reach a power point, then obtain an appropriate safety approved extension lead or consult your dealer. Should it be necessary to change the mains plug, this must be carried out by a competent person, preferably a qualified electrician. If there is no alternative to cutting off the mains plug, ensure that you dispose of it immediately, having first removed the fuse, to avoid a possible shock hazard by inadvertent connection to the mains supply. IMPORTANT The wires in this mains lead are coloured in accordance with the following code: Blue : NEUTRAL Brown : LIVE As these colours may not correspond to the coloured markings identifying the terminals in your plug, proceed as follows: The wire coloured BLUE must be connected to the terminal marked with the letter N or coloured BLUE or BLACK. The wire coloured BROWN must be connected to the terminal marked with the letter L or coloured BROWN or RED. On no account connect either of these wires to the terminal marked E or by the earth symbol coloured green or green and yellow. E or Alternatively, this equipment may be supplied with a rewireable plug already fitted, which may be removed if not suitable and an alternative fitted in accordance with the preceding instructions. -1- Important Cautions Thank you for purchasing this system. Please read these operating instructions before operating the unit.
The operating instructions should be retained for future reference. For your safety CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER. NO USER SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED SERVICE PERSONNEL. Laser Product This product is equipped with low power laser equipment. For your own safety do not remove any covers or take the product apart.
Repair work must be carried out by qualified personnel. CLASS 1 LASER PRODUCT This symbol indicates that dangerous voltage constituting a risk of electric shock is present within this unit. This symbol indicates that there are important operating and maintenance instructions in the literature accompanying this unit. Caution: This product is equipped with low power laser equipment inside, for your safety, don't open the laser radiation protective equipment. Don't look at the laser radiation district when the equipment is operating.
The rating label is located on the base of the amplifier unit. Precautions This equipment has been designed and manufactured to meet international safety standards but, like any electrical equipment, care must be taken if you are to obtain the best results and safety is to be assured. .....

.....
.....
.....
..... DO read the operating instructions before you attempt to use the equipment. DO ensure that all electrical connections (including the mains plug, extension leads and interconnections between the pieces of equipment) are properly made and in accordance with the manufacturer's instructions. Switch off and withdraw the mains plug before making or changing connections. DO consult your dealer if you are ever in doubt about the installation, operation or safety of your equipment. DO be careful with glass panels or doors on equipment .

.....
.....
.....
.....

.. DON'T remove any fixed cover as this may expose dangerous voltages. DON'T obstruct the ventilation openings of the equipment with items such as newspapers, tablecloths, curtains, etc. Overheating will cause damage and shorten the life of the equipment. DON'T allow electrical equipment to be exposed to dripping or splashing, or objects filled with liquids, such as vases, to be placed on the equipment and don't handle the power cord with wet hands. -2- DON'T place hot objects or naked flame sources such as lighted candles or nightlights on, or close to equipment. High temperatures can melt plastic and lead to fires. DON'T use makeshift stands and NEVER fix legs with wood screws - to ensure complete safety always fit the manufacturer's approved stand or legs with the fixings provided according to the instructions. DON'T leave equipment switched on when it is unattended unless it is specifically stated that it is designed for unattended operation or has a standby mode.
Switch off using the switch on the equipment and make sure that your family knows how to do this. Special arrangements may need to be made for infirm or handicapped people. DON'T continue to operate the equipment if you are in any doubt about it working normally, or if it is damaged in any way - switch off, withdraw the mains plug and consult your dealer. ..
.....
.....

.....
.....
. ABOVE ALL, NEVER let anyone especially children push anything into holes, slots or any other opening in the case - this could result in a fatal electrical shock. NEVER guess or take chances with electrical equipment of any kind...
it is better to be safe than sorry! .....

.....
.....
.....
*... * * * The apparatus shall not be exposed to dripping or splashing and that no objects filled with liguids, such as vases, shall be placed on the apparatus. Plug is the disconnect device, and the disconnect device shall remain readily operable. Batteries shall not be exposed to excessive heat such as sunshine, fire or the like. Correct Handling of Batteries Improper or incorrect use of batteries may cause corrosion or battery leakage, which could cause fire, personal injury or damage to property. Use only the types of the batteries which are indicated in this manual. Do not install new batteries with used ones. Install the batteries correctly by following the polarity (+ and -) indications in the battery compartment.*

Do not dispose of the used batteries as domestic waste. Dispose of them in accordance with the local regulations. Small button cell batteries such ad used in the remote handset for this unit are easily swallowed by young children and this can be dangerous. Keep loose button cells away from young children and make sure that the battery holder tray is secure in the remote control. Seek medical advice if you believe a cell has been swallowed. -3- Table of Contents

IMPORTANT .....
.....
.....
....
....
.....
.....
....
....
.....
.....
....
....
.....
.....
....
....
.....
.....
.. 1 Important Cautions ....
....
.....
.....
....
....
.....
.....
....
....
.....
.....
....
....
.....
.....
.... 2 For your safety ..
....
.....
.....
....
....
.....
.....
....
....
.....
.....
....
....
.....
.....
....
....
.....

.....
..... 2 Precautions ..

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 2 Correct Handling of Batteries ....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.. 3 Package Contents ...
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
... 5 Control Locations ..
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 6 The CD Player .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... The Amplifier ...

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....

.....
.....
.....

.....
.....
.....
.....

.. The Remote Control .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... Replacing battery (lithium CR2025) into the remote control .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.. Connecting Connecting Connecting Connecting the Speakers ...
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

..... Auxiliary Equipment ...

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

Control Cable .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.... the AC Power Plug .
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.... 6 6 7 7 8 8 8 9 Connections .
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 8 Turning the Power On and Off .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
. 9 Sound Quality .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.... 9 Adjusting the Volume .....
.....
.....
.....

.....
.....

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... Adjusting the super bass ....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
. Control the Loudness ....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.. Preset Equalizer .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.. Changing the VFD Darkness .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
9 9 9 9 9 Listening to Radio Broadcasts .....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 10 Tuning in a Station .....

.....
.....
.....
.....

.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.... 10 Presetting Stations .
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.. 10 To change the FM Reception Mode ...
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 10 RDS (Radio Data System) Reception ..
.....
.....
.....

.....
.....
.....

.....

.....
.....
.....
.....

.....
... 11 CD Operation ..
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 11 CD Playing .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

. 11 To Skip Search or Search and Play .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 11 Program Play ...

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

12 Random Play (CD and MP3 discs) .

You're reading an excerpt. Click here to read official HITACHI AX-M76 user guide
http://yourpdfguides.com/dref/1273183

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 12 Playing the Beginning (Intro) of each Track ....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 12 Playing Repeatedly ..
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

12 MP3 Disc Playing .....
.....
.....
.....

.....
.....

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 12 Playing Repeatedly ....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 13 Use the USB ..

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
. 13 Setting the Clock Automatically ....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 13 Setting the Clock Manually .....

.VFD will not be illuminated. @@@@@@(see "Setting the clock" on page 14"). @@@@@@@@@@@@@@@@@@2. Select a station using one of the following methods. @@@@@@@@Tune in the desired station: 1. @@2. @@@@3. @@@@4. @@@@If a FM stereo broadcast is hard to receive or noisy, you can select MONO by pressing the mode button (MODE) and the "FM ST" will not displayed.
Reception will be improved, but you will lose any stereo effect. To restore the stereo effect, press the mode button (MODE) and the "FM ST" will be displayed. - 10 - RDS (Radio Data System) Reception Many FM stations are broadcasting added data compatible with RDS. This radio set offers convenient functions using such data. PS (Program Service Name) When an RDS station is received, the "RDS" and the name of that station will be displayed.
When RDS display button (DISPLAY) on the remote control is pressed during PS display, the CT is displayed for 3 seconds, then PS display returns. PTY (Program Type) Program type identification signal. (Example: News, Rock, Classical music.) CT (Clock Time System) The CT system may not properly operate in areas where RDS CT service is not available. Once CT service is received, the CT system keeps operating.
"RDS CLOCK" is displayed in areas where no CT services are available. Changing Display During PS display, press the RDS display button (DISPLAY) on the remote control repeatedly to select the CT, PTY or Frequency. They will be displayed for 3 seconds, then the PS display returns. CD Operation CD Playing 1. Repeatedly press the function button (FUNCTION) on the front of the product until "DISC" is displayed or press the CD function button ( ) on the remote control to select tuner function. 2. Press the open/close button (K) to open the disc door and place the disc on the disc tray (with the printed side up). 3. Press the open/close button (K) to close the disc door, the unit will read the disc and play it automatically. Note: If in stop mode, please press the play/pause button (BF) to start playing the disc.

4. Press the play/pause button (BF) to pause the playing, press the button again and it will be continue to play. 5. Press the stop button (L) to stop the disc playing. To Skip Search or Search and Play Press the previous/search backward button (H/D) on the front of the unit or previous button (H) on the remote control once or more to skip previous one or more tracks of the disc. Press and hold the previous/search backward button (H/D) on the front of the unit or search backward button (D) on the remote control to search for the position that you intend to start playing. Press the next/search forward button (G/C) on the front of the unit or next button (G) on the remote control once or more to skip forward one or more tracks of the disc. Press and hold the next/search forward button (G/C) on the front of the unit or search forward button (C) on the remote control to search for the position that you intend to start playing. - 11 - Program Play 1. Insert a disc and press L button when it starts playing.
2. Press the program button (PROG) on the remote control. 3. Press the H/D, G/C buttons on the front of the product or 0-9, 10+, G, H buttons on the remote control to select the desired track number and press the program button (PROG) to confirm your programme. 4.
Repeat above step 3 to finish your programming. 5. Press the BF button to start programme play. 6. Press the L button to stop the programme play.
NOTE: Random play will not shuffle the programmed music list. Random Play (CD and MP3 discs) The CD can be played randomly. Random play begins by pressing the random button (RANDOM) on the remote control in stop mode. Playing the Beginning (Intro) of each Track In stop mode, press the intro button (INTRO) on the remote control to play the beginning of each track consecutively. The playing time of each track is 10 seconds. When you hear the desired track, press the play/pause button twice. Playing Repeatedly * For CD disc, ONE and ALL repeat play can be set by pressing the mode button (MODE) repeatedly. First press : To repeat the same track over and over again, ("REP" will flash). Second press : To repeat all tracks on a disc and then play them again and again, ("REP" will stay lit). Third press : To cancel the repeat playing, ("REP" off).

You can use this function to enjoy the certain part of a disc which you like repeating. When it is playing, press the repeat A-B button (A-B) on the remote control at the beginning of the content that needs repeat playing. Press the repeat A-B button (A-B) again at the end of the content that needs repeat playing. Then the player will repeatedly play between A and B until you press the repeat A-B button (A-B) again to cancel the repeat paragraph the setting and turn to normal playing mode. NOTE: A-B repeat function can only be used within the same track. * MP3 Disc Playing When selecting tracks the player will automatically display the album and track number. For example: track number 21 may be from album 3, track 7. 1. Press the K button to open the disc door and place the MP3 disc on the disc tray. 2.
Press the CD display button (DISPLAY) on the remote control, ID3 information (song title and artist) will be displayed or "NO ID3" if there is no ID3 information. Press this button again, album, track and playing time will be displayed. 3. When playing MP3 discs, the current album and track will be displayed. 4.
Press the H/D, G/C button on the front of the product or H, G button on the remote control to select the previous/next track. When pressing the H/D, G/C button on the front of the product or D, C button on the remote control for a few seconds, it will search backward or search forward. - 12 - 5. Press the album up button (ALB+) or album down button (ALB-) on the remote control to select the next/previous album, and play the first track of this album. If playing has ended, press the album up button (ALB+) or album down button (ALB-) on the remote control to select the next/previous album.
Then choose the track with the H/D, G/C button on the front of the product or H, G button on the remote control. 6. Press the BF button to start playing the disc. 7. Press the L button to stop playback. Note: Play will continue to the final track when the selected tracks have been played. The first 2 digits of the display is the album number, the next 3 digits is the track number and the remaining digits display the minutes and seconds. Playing Repeatedly For MP3 disc, ONE, ALB and ALL repeat play can be set by pressing the mode button (MODE) repeatedly. - First press : To repeat the same track. - Second press : To repeat ALB (Album).

- Third press : To repeat ALL (All albums and tracks). - Fourth press : To cancel the repeat playing.

You're reading an excerpt. Click here to read official HITACHI AX-M76 user guide

http://yourpdfguides.com/dref/1273183

Note: The word ALB will appear on the display to indicate the albums stored on your MP3 disc. Use the USB By connecting an USB mass storage device (including USB flash memory, USB flash players or memory cards) to this unit, you can enjoy the device's stored music through the powerful speakers of Hi-Fi system. 1. Insert the USB device's USB plug into the socket on the front of unit. 2. Press the USB button on remote control or press the function select button on the CD player to select the USB function. 3. The device's stored music will be played automatically.

For the devices with USB cables: 1. Insert one plug of the USB cable (not supplied) to the socket on the set. 2. Insert the other plug of the USB cable to the USB output terminal of the USB device. For the memory card: 1.

Insert the memory card into a card reader (not supplied). 2. Use a USB cable (not supplied) to connect the card reader into the socket on the set. Setting the Clock Automatically Tune into a RDS station and wait for a few minutes. To confirm, press the clock button.

- 13 - Setting the Clock Manually The built-in clock shows the time on the display. 1. In standby mode, press the clock button (CLOCK) twice, the VFD will display SET CLOCK and the hour indicator will blink. 2. Set the hour with the VOL- or VOL+ button. 3. Press the clock button (CLOCK), minute indicator will blink. 4. Set the minute with the VOL- or VOL+ button. 5.

*Press the clock button (CLOCK), the built-in clock starts operating. Caution: * The operating time of every step shouldn't be longer than 10 seconds or it will return to the time display. * If there is a power failure or the systems power is turned off, the clock will lose its setting. Setting the Sleep Timer Use the sleep timer to turn the system off after a certain number of minutes when in play mode. By setting the sleep timer, you can fall asleep to music and know that your system will turn off by itself rather than play all night. 1. Play a CD or tune in to the desired station. 2. To set the sleep timer press the sleep/timer button (SLEEP/TIMER) on the remote control repeatedly, it changes the number of minutes shown on the display in this sequence: -10 20 ..*

. 80 90 00 After setting the number of minutes for the sleep timer, the display will return to the display as before setting the sleep timer. @@The display will show "zzz". @@Wait for a second until the display returns to the original display. @@@@When the setting timer is on, the timer indicator " " will be displayed.

But the clock must be correctly set for the timer to operate correctly. 1. In standby mode, press the sleep/timer button (SLEEP/TIMER) on the remote control, SET TIMER is displayed on the VFD and the hour indicator will blink. 2. Set the hour with the VOL- or VOL+ button.

*3. Press the sleep/timer button (SLEEP/TIMER) on the remote control, minute indicator will blink. 4. Set the minute with the VOL- or VOL+ button. 5. Press the sleep/timer button (SLEEP/TIMER) on the remote control, the selected time is set. Then set the daily timer to "ON" (daily timer set is in effect) or "OFF" (daily timer set is to cancel) by pressing the VOL- or VOL+ button. Caution: * You can set the daily timer only in standby mode. * The operating time of every step shouldn't be longer than 10 seconds or it will return to the time display. * Please select the sound source before turning into standby mode.*

e.g. CD, Radio. To confirm the daily time When you press the sleep/timer button (SLEEP/TIMER) on the remote control in standby mode, the daily time is displayed. Wait for a few seconds until the display returns to the time display. To cancel the daily timer setting In standby mode, repeatedly press the sleep/timer button (SLEEP/TIMER) until the "ON" is flashing. Press the VOL- button or VOL+ button to set the daily timer to "OFF". Press the Sleep/Timer button again to finish. Disconnecting the mains from the unit also cancels the daily timer. Disc Handling 1.

To keep the disc clean, please don't touch the disc's surface when you are holding it. You should hold the edge. (See fig. 1) 2. If the disc is dirty, it will affect the sound quality.

Please use a clean and soft cloth to wipe the disc from inside to outside. Don't wipe the disc in a circular direction. (See fig. 2) Fig.1 Fig.

2 3. 4. 5. 6. Don't stick paper on the disc. Don't put the disc in a place with direct sunshine or hot sources. Do not play any damaged discs in this player. When you have finished playing a CD, remove it from the CD player and store in its protector cover. - 15 - Troubleshooting If you are having a problem with your system, check this list for a possible solution before calling for service. If you cannot solve the problem from the hints given here, or the system has been physically damaged, call a qualified person, such as your dealer, for service.

Symptom No sound is heard Poor radio reception Possible Cause Connections are incorrect, or loose The antenna is disconnected The FM wire antenna is not properly extended and positioned The CD is dirty or scratched The CD is upside down The path between the remote control and the sensor on the CD player is blocked The batteries have lost their charge The built-in microprocessor has malfunctioned due to external electrical interference Action Check all connections and make corrections Reconnect the antenna securely Extend FM wire antenna to the best reception position Clean or replace the CD Put the CD in with the label side up Remove the obstruction The CD skips The CD does not play Unable to operate the remote control Operations are disabled Replace the batteries Unplug the system then plug it back in Specifications System Specification Power Requirements FM Tuning Range Power Consumption Output Power THD Dimensions Speaker Specifications Impedance Input Power Dimensions : : : : : : AC 230V/50Hz 87.5~108 MHz 60W (ECO standby 0.7W) 50W x 2 0.7% (CD) 218(W) x 85(H) x 235(D) mm (Amplifier) 218(W) x 85(H) x 235(D) mm 4 50W 161(W) x 250(H) x 220(D) mm : : : - 16 - The mark is in compliance with the Waste Electrical and Electronic Equipment Directive 2002/96/EC (WEEE). The mark indicates the requirement NOT to dispose the equipment including any spent or discarded batteries as unsorted municipal waste, but use the return and collection systems available. If the batteries or accumulators included with this equipment, display the chemical symbol Hg, Cd, or Pb, then it means that the battery has a heavy metal content of more than 0.0005% Mercury, or more than 0.002% Cadmium or more than, 0.004% Lead. Visit Partmaster.

co.uk today for the easiest way to buy electrical spares and accessories. With over 1 million spares and accessories available we can deliver direct to your door the very next day. Visit www.partmaster.

co.uk or call 0870 6001 338 (UK customers only) Calls charged at National Rate. If you require a replacement for any of the items listed below, please quote their corresponding part numbers: Replacement Part Part Number Remote control AXM76P0001 Instruction Manual AXM76P0002 Addendum AXM76P0003 Speaker leads x 2 AXM76P0004 Ribbon cable AXM76P0005 FM Antenna AXM76P0006 - 17 - 41006868 .

You're reading an excerpt. Click here to read official HITACHI AX-M76 user guide
http://yourpdfguides.com/dref/1273183