Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HITACHI KH337E. You'll find the answers to all your questions on the HITACHI KH337E in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HITACHI KH337E
User guide HITACHI KH337E
Operating instructions HITACHI KH337E
Instructions for use HITACHI KH337E
Instruction manual HITACHI KH337E

HITACHI
Inspire the Next

Instruction Manual

GB

KH337E

DAB+ FM Radio

You're reading an excerpt. Click here to read official HITACHI KH337E user guide
http://yourpdfguides.com/dref/4577810

Manual abstract:

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
10 Adjusting the Volume.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
. 10 DAB Operation.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
..11 DAB Auto Scan ...
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 11 Secondary Services....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.. 12 Manual Tuning...
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..... 12 Storing Stations...
.....

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 12 Recalling a Stored Station .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
... 12 Display Modes .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
... 13 FM Operation ..
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.14 Switching from DAB to FM Mode....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... 14 Auto Scan .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.... 14 Manual Scan.....

.....
.....
.....
.....

.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
... 14 Audio Mode..
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
... 14 Storing Stations..
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

. 14 Recalling a Stored Station .....
.....
.....

.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..... @@@@@@@Switch off and withdraw the mains plug before making or changing connections.

consult your dealer if you are ever in doubt about the installation, operation or safety of your equipment. be careful with glass panels or doors on equipment. route the mains lead so that it is not likely to be walked on, crushed, chafed, or subjected to excessive wear and tear or heat. remove any fixed cover as this may expose dangerous voltages. obstruct the ventilation openings of the equipment with items such as newspapers, tablecloths, curtains, etc. Overheating will cause damage and shorten the life of the equipment. allow electrical equipment to be exposed to dripping or splashing, or objects filled with liquids, such as vases, to be placed on the equipment. place hot objects or naked flame sources such as lighted candles or nightlights on, or close to equipment. High temperatures can melt plastic and lead to fires. use makeshift stands and NEVER fix legs with wood screws - to ensure complete safety always fit the manufacturer's approved stand or legs with the fixings provided according to the instructions.
use equipment such as personal stereos or radios so that you are distracted from the requirements of traffic safety. listen to headphones at high volume, as such use can permanently damage your hearing. leave equipment switched on when it is unattended unless it is specifically stated that is designed for unattended operation or has a stand-by mode. Switch off using the switch on the equipment and make sure that your family knows how to do this. Special arrangements may need to be made for infirm or handicapped people.
continue to operate the equipment if you are in any doubt about it working normally, or if it is damaged in any way – switch off, withdraw the mains plug and consult your dealer. GB DO DO DO DON'T DON'T DON'T DON'T DON'T DON'T DON'T DON'T ABOVE ALL – – NEVER let anyone especially children push anything into holes, slots or any other opening in the case – this could result in a fatal electric shock; NEVER guess or take chances with electrical equipment of any kind; it is better to be safe than sorry! 3 Used correctly, domestic batteries are a safe and dependable source of portable power. Problems can occur if they are misused or abused – resulting in leakage or, in extreme cases, fire or explosion. Here are some simple guidelines to safe battery use designed to eliminate any such problems. ALWAYS ALWAYS BATTERY SAFETY GUIDELINES ALWAYS Take care to fit your batteries correctly, observing the plus and minus marks on the battery and appliance.
@@@@@@They may leak, cause fire or even explode. @@Retain the manual. @@@@Damage Please inspect the unit for damage after unpacking. @@@@@@@@Temperature Avoid extreme degrees of temperature, either hot or cold. Place the unit well away from heat sources such as radiators or gas/ electric fires. Avoid exposure to direct sunlight and other sources of heat. Naked Flames Never place any type of candle or naked flame on the top of or near the unit. Moisture To reduce the risk of fire, electric shock or product damage, do not expose this unit to rain, moisture, dripping or splashing. No objects filled with liquids, such as vases, should be placed on the unit. If you spill any liquid into the unit, it can cause serious damage.

Switch it off at the mains immediately. Withdraw the mains plug and consult your dealer. Ventilation To prevent the risk of electric shock or fire hazard due to overheating, ensure that curtains and other materials do not obstruct the ventilation vents. Do not install or place this unit in a bookcase, built-in cabinet or in another confined space. Ensure the unit is well ventilated. Safety Always disconnect the unit from the mains supply before connecting/ disconnecting other devices or moving the unit. Unplug the unit from the mains socket before a lightning storm. Mains Cable Make sure the unit is not resting on top of the mains cable, as the weight of the unit may damage the mains cable and create a safety hazard. If the mains cable is damaged it must be replaced bndications in the battery compartment. Use only the types of the batteries which are indicated in this manual.
Do not install new batteries with used ones and do not mix different types of batteries. Do not dispose of the used batteries as domestic waste. Dispose of them in accordance with local regulations. If you are not going to use the unit for a long time, remove the batteries to avoid damage from battery leakage and corrosion. Due to the short battery life span of some alkaline batteries.
It is recommended to use rechargeable batteries. You will need to purchase a charger to charge the rechargeable batteries. This saves cost and is more environmentally friendly. 9 Mains Power Before using, connect the supplied power cable to the mains cable socket at the rear of the unit and to the mains socket. GB Connections Connecting to the Earphones Socket 1.
2. 3. Connect earphones (3.5mm stereo mini plug) to the earphones socket. Adjust the volume control to obtain the desired volume level. When the earphones are connected, the speakers will automatically mute. Avoid listening to sound excessive levels which could be harmful to your ear. Prolonged listening at full volume can damage the ears of the user. Basic Operation Powering ON/OFF Press the Press the STANDBY button to switch the unit on. STANDBY button again to switch the unit back to standby mode.

Disconnect the mains plug from the mains socket if you want to switch the unit off completely. Selecting Modes Press the DAB/FM button repeatedly to switch between modes (DAB or FM). Adjusting the Volume Adjust the volume to the desired level by turning the 10 VOLUME/SELECT control. DAB Operation If the unit is connected to the mains power and then switched on from standby for the first time, the unit will automatically enter into the DAB mode and perform auto scan function. During the scan the display will show "Scanning ..." together with a slide bar that indicates the progress of the scan and the amount of stations that have been found so far. Once the scgnals in your location. @@@@1.
The unit has two alarms. Press and hold the ALARM1/ ALARM2 button to set alarm 1 or alarm 2. @@@@The minute digits will flash. @@Turn the VOLUME/SELECT control to select DAB preset station. Press the TUNE/SELECT button to confirm.
Turn the VOLUME/SELECT control to select FM preset station. Press the TUNE/SELECT button to confirm. Turn the VOLUME/SELECT control to select Buzzer 1/2. Press the TUNE/SELECT button to confirm. @@Press the TUNE/SELECT button to confirm.

2. 3.

You're reading an excerpt. Click here to read official HITACHI KH337E user guide
http://yourpdfguides.com/dref/4577810

4. 5. 6. 7. Activating the Alarm Function 1. @@@@@@To stop the alarm sooner, press the STANDBY button. To check the alarm status, press the ALARM1 or ALARM2 button. @@To cancel this function, repeatedly press the ALARM1 or ALARM2 button until "Alarm Off" shows on the display.

Snooze Function (AC Operation Only) When the alarm has triggered, press the SNOOZE button to temporarily switch off the alarm for 5 minutes. The display will show "Zz" to indicate that snooze is on. Snooze function will continue for 1 hour from the set alarm time. If alarm 2 is due to go off within 1 hour of alarm 1, it will not activate until alarm 1 has been switched off. Sleep Function (AC Operation Only) This function allows you to program the unit to switch off by itself after a set period of time. 1. To activate the sleep function, press the SLEEP button repeatedly until the "Sleep Timer" shows on the display. The time will change in the below sequence on every press: 90 2. 80 70 60 30 10 When your desired sleep time appears in the display, release the button and the sleep function will be activated in two seconds. "S#" will show on the display (for example "S1" represents "10 minutes" sleep time).
When the sleep time counts to zero, the unit will go off. To put the sleep function off while the sleep timer is still counting down, press the SLEEP button once, "Sleep Off" will show on the display. @@@@@@@@This is resumed only when the factory reset has taken place. System Reset There may be times when you need to reset your unit back to the factory settings especially when you have moved house. If you experience reception problems you may want to reset and try again.
If you move to another part of the country and pick up the local and national DAB stations in that area, your previously tuned channels may no longer be available. 1. 2. 3. Press and hold the MENU button until the "Press SELECT to confirm reset" shows on the display.
Press the TUNE/SELECT button to start the system reset, "Restarting…" will show on the display. After the reset is complete, the unit will go to standby mode. Press the STANDBY button again to turn the unit on, the unit will then start scanning for DAB channels immediately. After the system reset, all the tuned stations, DAB & FM preset stations and alarm settings will be erased. 18 Maintenance Ensure to unplug the unit from the mains socket before cleaning. To clean the unit, wipe the case with a slightly moist, lint-free cloth. Do not use any cleaning fluids containing alcohol, ammonia or abrasives. @@Signal reception too low. Adjust the aerial or move the unit to a stronger signal location. Volume is too high.

Adjust the volume control. Weak signal. @@@@No DAB station. Poor reception. Adjust the position of the aerial. @@The unit will try to retune or perform a scan. Specifications Model Mains Supply Output Power Radio Frequency Range Dimension Weight KH337E AC 100 – 240V~ 50/60Hz DC 6V 1.5V(UM3) x 4 1.8W x 2 FM87.5 – 108 MHz DAB 174 – 240 MHz 246 (L) x 86.
5 (W) x 126 (H) mm 1.26kg Features and specifications are subject to change without notice. 19 Notes for battery disposal The batteries used with this product contain chemicals that are harmful to the environment. To preserve our environment, dispose of used batteries according to your local laws or regulations. Do not dispose of batteries with normal household waste.
For more information, please contact the local authority or your retailer where you purchased the product. The above mark is in compliance with the Waste Electrical and Electronic Equipment Directive 2002/96/EC (WEEE). The mark indicates the requirement NOT to dispose the equipment including any spent or discarded batteries as unsorted municipal waste, but use the return and collection systems available. If the batteries or accumulators included with this equipment display the chemical symbol Hg, Cd or Pb, then it means that the battery has a heavy metal content of more than 0.0005% Mercury, or more than 0.
002% Cadmium or more than, 0.004% Lead. In the unlikely event of a problem developing, please contact the store where you purchased your equipment. We continually strive to improve our products; specifications may change without prior notice. For advice on where to purchase accessories, please contact the store where you purchased your equipment. All trademarks are the property of their respective owners and all rights are acknowledged. Adr. c/o Solheimsveien 6-8, PB 153, NO 1471 Lørenskog, Norge (P.N. 227-3123AP-E13) .

You're reading an excerpt. Click here to read official HITACHI KH337E user guide
http://yourpdfguides.com/dref/4577810