Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for HOTPOINT ARXD 169. You'll find the answers to all your questions on the HOTPOINT ARXD 169 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual HOTPOINT ARXD 169
User guide HOTPOINT ARXD 169
Operating instructions HOTPOINT ARXD 169
Instructions for use HOTPOINT ARXD 169
Instruction manual HOTPOINT ARXD 169

Instructions for use

WASHING MACHINE

GB English,1
SE Svenska,13
FI Suomi,25
DK Dansk,37
NO Norsk,49

ARXD 169

Hotpoint ARISTON

GB

Contents

Installation, 2-3
Unpacking and levelling
Connecting the electricity and water supplies
The first wash cycle
Technical data

Description of the washing machine, 4-5
Control panel
Display

Running a wash cycle, 6

Wash cycles and functions, 7
Table of wash cycles
Wash functions

Detergents and laundry, 8
Detergent dispenser drawer
Preparing the laundry
Special wash cycles
Load balancing system

Precautions and tips, 9
General safety
Disposal
Opening the porthole door manually

Care and maintenance, 10
Cutting off the water or electricity supply
Cleaning the washing machine
Cleaning the detergent dispenser drawer
Caring for the door and drum of your appliance
Cleaning the pump
Checking the water inlet hose

Troubleshooting, 11

Service, 12

1

You're reading an excerpt. Click here to read official HOTPOINT ARXD 169 user guide
http://yourpdfguides.com/dref/4484034

Manual abstract:

Connecting the electricity and water supplies Connecting the water inlet hose Unpacking and levelling Unpacking 1. Remove the washing machine from its packaging. 2. Make sure that the washing machine has not been damaged during the transportation process. If it has been damaged, contact the retailer and do not proceed any further with the installation process. 3. Remove the 4 protective screws (used during transportation) and the rubber washer with the corresponding spacer, located on the rear part of the appliance (see figure). a 1. Insert seal A into the end of the inlet hose and screw the latter onto a cold water tap with a 3/4 gas threaded opening (see figure). Before performing the connection, allow the water to run freely until it is perfectly clear.
2. Connect the inlet hose to the washing machine by screwing it onto the corresponding water inlet of the appliance, which is situated on the top righthand side of the rear part of the appliance (see figure). 4. Close off the holes using the plastic plugs provided. 5.
Keep all the parts in a safe place: you will need them again if the washing machine needs to be moved to another location. 3. Make sure that the hose is not folded over or bent. □ Packaging materials should not be used as toys for children. Levelling □ The water pressure at the tap must fall within the values indicated in the Technical details table (see next page).
□ If the inlet hose is not long enough, contact a specialised shop or an authorised technician. □ Never use second-hand hoses. □ Use the ones supplied with the machine. 1. Install the washing machine on a flat sturdy floor, without resting it up against walls, furniture cabinets or anything else. 2. If the floor is not perfectly level, compensate for any unevenness by tightening or loosening the adjustable front feet (see figure); the angle of inclination, measured in relation to the worktop, must not exceed 2°. 2 Connecting the drain hose □ Do not use extension cords or multiple sockets. @@@@ warning! @@@@The free end of the hose should not be underwater. Once the appliance has been installed, and before you use it for the first time, run a wash cycle with .

Detergent and no laundry, using the wash cycle □ We advise against the use of hose extensions; if it is absolutely necessary, the extension must have the same diameter as the original hose and must not exceed 150 cm in length. electrical connections Technical data Model ARXD 169 width 59. 5 cm height 85 cm depth 53,5 cm from 1 to 6 kg please refer to the technical data plate fixed to the machine maximum pressure 1 MPa (10 bar) minimum pressure 0. 05 MPa (0. 5 bar) drum capacity 52 litres up to 1600 rotations per minute Before plugging the appliance into the electricity socket, make sure that: □ the socket is earthed and complies with all applicable laws; □ the socket is able to withstand the maximum power load of the appliance as indicated in the Technical data table (see opposite); □ the power supply voltage falls within the values indicated in the Technical data table (see opposite); □ the socket is compatible with the plug of the washing machine. If this is not the case, replace the socket or the plug. Dimensions Capacity Electrical connections Water connections Spin speed Energy rated programmes according to regulation EN 60456 programme (1st press of the button); temperature 60°C; using a load of 6 kg. This appliance conforms to the following EC Directives: - 89/336/EEC dated 03/05/89 (Electromagnetic Compatibility) and subsequent modifications - 2002/96/EC - 2006/95/EC (Low Voltage) □ The washing machine must not be installed outdoors, even in covered areas. It is extremely dangerous to leave the appliance exposed to rain, storms and other weather conditions. □ When the washing machine has been installed, the electricity socket must be within easy reach.
3 Description of the washing machine GB Control panel ON/OFF button CONTROL PANEL LOCK Button SPIN SPEED Button DISPLAY Detergent dispenser drawer MEMORY Button WASH CYCLE SELECTOR Buttons FUNCTION buttons START/ PAUSE button with indicator light DELAYED START Button TEMPERATURE Button Detergent dispenser drawer: used to dispense detergents and washing additives (see □Detergents and laundry□). ON/OFF button : press this briefly to switch the machine on or off. The START/PAUSE indicator light, which flashes slowly in a green colour shows that the machine is switched on. To switch off the washing machine during the wash cycle, press and hold the button for approximately 2 seconds; if the button is pressed briefly or accidentally the machine will not switch off. If the machine is switched off during a wash cycle, this wash cycle will be cancelled.
WASH CYCLE SELECTOR buttons: used to set the desired wash cycle (see "Table of wash cycles"). MEMORY button: press and hold the button to store a cycle with your own set of preferences in the memory of the machine. to recall a previously stored cycle , press the MEMO button. FUNCTION buttons: press the button to select the desired function. The corresponding indicator light on the display will switch on.
SPIN button : press to reduce or completely exclude the spin cycle - the value is indicated on the display. : press to decrease the TEMPERATURE button temperature: the value will be shown on the display. : to activate the CONTROL PANEL LOCK button control panel lock, press and hold the button for is approximately 2 seconds. When the symbol illuminated, the control panel is locked. This means it is possible to prevent wash cycles from being modified accidentally, especially where there are children in the home. To deactivate the control panel lock, press and hold the button for approximately 2 seconds. : press to set a delayed DELAYED START button start time for the selected wash cycle. The delay time will be shown on the display. @@@@@@If the is not illuminated, the door may be symbol opened. @@@@@@@@@@@@@@@@To prevent any damage from occurring, wait for the symbol to switch itself off before opening the appliance door.

: if the DELAYED START function has been activated, the door cannot be opened; pauses the machine by pressing the START/PAUSE button if you wish to open it. □ The first time the machine is switched on, you will be asked to select the language and the display will automatically show the language selection menu. To select the desired language press the TEMPERATURE and SPIN buttons; to confirm the selection press the CONTROL PANEL LOCK button. If you wish to select another language, press and hold the CONTROL PANEL LOCK + TEMPERATURE + SPIN buttons simultaneously for 5 seconds, then repeat the steps listed above. □ Press the button; the text WELCOME will appear on the display and the START/PAUSE indicator light will flash slowly in a green colour. Load the laundry, making sure you do not exceed the maximum load value indicated in the table of programmes on the following page. Pull out the detergent dispenser drawer and pour the detergent into the relevant compartments as described in "Detergents and laundry".

[You're reading an excerpt. Click here to read official HOTPOINT ARXD 169 user guide](http://yourpdfguides.com/dref/4484034)
http://yourpdfguides.com/dref/4484034

Press one of the WASH CYCLE SELECTOR buttons to select the required wash cycle; the name of the wash cycle will appear on the display. A temperature and spin speed is set for each wash cycle; these may be adjusted. The duration of the cycle will appear on the display.

Use the relevant buttons: □Modifying the temperature and/or spin speed. □ The machine automatically selects the maximum temperature and spin speed set for the selected wash cycle; these values cannot therefore be increased. The temperature can be decreased button, until the cold wash by pressing the "OFF" setting is reached. The spin speed may be button, progressively reduced by pressing the until it is completely excluded (the "OFF" setting). If these buttons are pressed again, the maximum values are restored.

setting a delayed start. To set a delayed start for the selected programme, press the corresponding button repeatedly until the required delay period has been reached. When this symbol lights up on the option is enabled, the display. To remove the delayed start function press the button until the text "OFF" appears on the display. □Modifying the cycle settings.

□ Press the button to enable the function; the indicator light corresponding to the button will switch on. □ Press the button again to disable the function; the indicator light will switch off. □ If the selected function is not compatible with another function which has been selected previously, the indicator light corresponding to the first function selected will flash and only the second function will be activated; the indicator light corresponding to the enabled function will remain lit. □ The functions may affect the recommended load value and/or the duration of the cycle. The corresponding indicator light will become green, remaining lit in a fixed manner, and the door will be locked (the DOOR LOCKED symbol will be on). During the wash cycle, the name of the phase in progress will appear on the display. @@□ It may not be used with the , , , and □Pump out□ programmes. @@@@: put the detergent in the relevant compartment. □ It cannot be used with the programmes. , , , , , □ It cannot be used with the programmes.

@@@@@@@@@@ 5 kg. @@@@@@To wash all silk Silk: use special wash cycle garments. @@@@@@@@ load 1 ,5 kg) and guarantees optimal performance. @@@@@@@@ compartment 3: Additives (fabric softeners , etc.) The fabric softener should not overflow the grid. @@ Empty all garment pockets and check the buttons. @@1 kg How much does your laundry weigh? @@@@@@@@@@@@@@@Remove the plug from the electrical socket. 2. Make sure the water level inside the machine is lower thash it onto the appliance. @@@@@@ gB Problem: The washing machine does not switch on. The wash cycle does not start. @@□ There is no power in the house. @@The ON/OFF button has not been pressed. The START/PAUSE button has not been pressed. The water tap has not been opened.

a delayed start has been set (see □Running a wash cycle□). The water inlet hose is not connected to the tap. the hose is bent. The water tap has not been opened. There is no water supply in the house.

The pressure is too low. The START/PAUSE button has not been pressed. The washing machine does not take in water (the text "NO WATER, CHECK SUPPLY" appears on the display). The washing machine continuously takes in and drains water. □ The drain hose is not fitted at a height between 65 and 100 cm from the floor (see □Installation□). □ The free end of the hose is under water (see □Installation□). □ The wall drainage system is not fitted with a breather pipe. If the problem persists even after these checks, turn off the water tap, switch the appliance off and contact the Assistance Service. If the dwelling is on one of the upper floors of a building, there may be problems relating to water drainage, causing the washing machine to fill with water and drain continuously. Special anti-draining valves are available in shops and help to avoid this inconvenience.

□ The wash cycle does not include draining: some wash cycles require the drain phase to be started manually (see □Wash cycles and functions□). □ The EASY IRON function has been activated: To complete the wash cycle, press the START/PAUSE button (see □Wash cycles and functions□). □ The drum was not unlocked correctly during installation (see □Installation□). □ Switch off the machine and unplug it, wait for approximately 1 minute and then switch it back on again. If the problem persists, contact the Technical Assistance Service. □ The detergent is not suitable for machine washing (it should display the text □for washing machines□ or □hand and machine wash□, or the like). Too much detergent was used. The washing machine does not drain or spin. The washing machine vibrates a lot during the spin cycle. the washing machine leaks.

The machine is locked and the display flashes, indicating an error code (e. There is too much foam. 11 Service GB Before calling for Assistance: □ Check whether you can solve the problem alone (see □Troubleshooting□); □ Restart the programme to check whether the problem has been solved; □ If this is not the case, contact an authorised Technical Assistance Centre using the telephone number provided on the guarantee certificate. □ Always request the assistance of authorised technicians. @@); □ the serial number (S/N).

@@@@@@For at slukke for vaskemaskinen under vask skal man holde tasten nede i længere tid, ca. Tast med kontrollampe for START/PAUSE: Når den grønne kontrollampe blinker langsomt, skal man trykke på tasten for at starte vasken. For at vælge det ønskede sprog skal man trykke på tasterne TEMPERATUR og CENTRIFUGERING, og for at bekræfte valget skal man trykke på tasten TASTELÅS. System til afbalancering af vasketøjet Inden centrifugeringen udfører tromlen nogle omdrejninger ved en hastighed, der er lidt højere end under vask, for at undgå vibrationer og for at fordele tøjet ligeligt. hvis tøjet efter gentagne forsøg stadig ikke af korrekt afbalanceret , foretager maskinen centrifugeringen ved en lavere hastighed end normalt. Hvis uligevægten er for stor, fordeler vaskemaskinen tøjet frem for at udføre centrifugeringen. @@@@@@@@@@Hurtigvask 30' (1° gang du trykker på knappen) : for å friske opp lett skitne plagg hurtig (egner seg ikke for ull, silke og klær som krever håndvask). Oppfriske Tøy 15min (2°gang du trykker på knappen) : for å friske opp lett skitne plagg hurtig (egner seg ikke for ull, silke og klær som krever håndvask). spesielle sykluser/ Minne Baby program: svært skitten kulørtvask. M Minne: med denne funksjonen kan du lagre hvilken som helst type vask Silke/Gardiner: for plagg i silke og viskose, pent undertøy 30° Ull: for ull, kashmir osv. For å bleke i løpet av en vaskesyklus hell i vaskemiddel og tøymykner som du ønsker å bruke, still inn ønsket vaskesyklus og aktiver funksjonen "Flekkfjerning".

You're reading an excerpt. Click here to read official HOTPOINT ARXD 169 user guide

http://yourpdfguides.com/dref/4484034

På slutten av en vaskesyklus vil maskinen sakte rotere trommelen for å forhindre at klærne krølles, for å avslutte syklusen trykkes START/PAUSE-knappen. □ Ikke bruk vaskemidler for håndvask, siden disse skaper for mye skum. Laste balansesystem Før hver sentrifugering roterer trommelen kontinuerlig ved en hastighet som er litt høyere enn vaskeroteringshastigheten for å unngå for mye vibrasjon før hver sentrifugering og fordele lasten jevnt. 00 04/2008 - Xerox Business Services Før du ringer for hjelp: □ Kontroller om du kan løse problemet selv (se □Feilsøking□); □ Start programmet på nytt for å kontrollere om problemet er løst; □ Hvis dette ikke er tilfelle, ta kontakt med et autorisert hjelpesenter ved bruk av telefonnumrene som finnes på garantibeviset.

.

You're reading an excerpt. Click here to read official HOTPOINT ARXD 169 user guide
http://yourpdfguides.com/dref/4484034