Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for TOSHIBA RL933. You'll find the answers to all your questions on the TOSHIBA RL933 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual TOSHIBA RL933
User guide TOSHIBA RL933
Operating instructions TOSHIBA RL933
Instructions for use TOSHIBA RL933
Instruction manual TOSHIBA RL933

TOSHIBA
Leading Innovation >>>

RL93* Digital Series
SL97* Digital Series
RL95* Digital Series

You're reading an excerpt. Click here to read official TOSHIBA RL933 user guide
http://yourpdfguides.com/dref/4249640

Manual abstract:

.....
.....
.....
.....

.....
.....
.... 8 Connecting an HDMI® device .
.....

.....
.....
.....
.....

.....
.....
9 To connect an HDMI device .....
.....

.....
.....
.....
.....

.... 9 HDMI's ARC (Audio Return Channel) feature .....
.....
.....
. 9 REGZA-LINK connection .....

.....
.....
.....
.....

.....
.....
.....
.....10 Connecting a computer .....

.....
.....
.....
.....

.....
.....
.....
.....11 To connect a PC to the RGB/PC terminal .

.....
.....
.....
..11 To connect a PC to the HDMI terminal .....

.....
.....
....11 Connecting a home network .
.....

.....
.....
.....
.....

.....
...12 To connect the TV to a home network - Wired ..
.....
....12 To connect the TV to a home network with an internet connection - Wireless .....

.....
.....
.12 Controls and input connections ....
.....

.....
.....
.....
.....

.....13 Switching on .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.13 Using the menu system .....

.....
.....
.....
.....

.....
.....
.13 Using the TV controls and connections ....
.....

.....
.13 MENU structure ....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.14 SETTING UP YOUR TV Startup Application .....
.....
.....
.....

.....
.....
.....
.....

.....
....15 Quick Setup .

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..15 Ant/Cable In (if available) .....
.....
.....
.....

.....
.....
.....
....17 Auto Tuning .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.18 ATV Manual Tuning ....
.....
.....

.....
.....
.....
.....

.....
.....
.....
....19 Tuning .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..19 Skip .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....20 Sorting positions ....

.....
.....
.....
.....

.....
.....
.....
.....

....21 DTV Manual Tuning .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.21 Manual Tuning ....
.....

.....
.....
.....
.....

.....
.....
.....
.....21 Manual Tuning for DVB-C ..

.....
.....
.....
.....

.....
.....
....22 DTV Settings .
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....

.....
22 Channels .....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....22 Standby Channel Update ..
.....
.....
.....

.....
.....
.....
.....

23 Location setting .....
.....
.....
.....

.....
.....
.....
.....

.....
23 Analogue switch-off .....
.....
.....

.....
.....
.....
.....

.....
23 CONTROLS AND FEATURES General controls .....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....24 Quick Menu .

.....
.....
.....
.....

.....
.....
.....

.....

.....
.....
..24 Selecting channels ...
.....

.....
.....
.....
.....

.....
.....
.....
.24 The Time Display analogue only .....

.....
.....
.....
....24 Stereo and Bilingual transmissions .....

.....
.....
.....
.....24 Sound controls ...

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
...25 Volume controls and sound mute ..
.....

.....
.....
.....
...25 Dual .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....25 Balance ....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..25 Bass, Treble .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.25 Voice Enhancement ....
.....
.....

.....
.....
.....
.....

.....
...25 Dynamic Bass Boost ..
.....
.....

.....
.....
.....
.....

.....
.....
25 Stable Sound® .....
.....

.....
.....
.....
.....

.....
.....
.....
.....25 Dynamic Range Control ..

.....
.....
.....
.....

.....
.....
.....
..25 Audio Level Offset .....

.....
.....

.....
.....

.....
.....
.....
.....26 TV Speakers On/Off ...

.....
.....
.....
.....

.....
.....
.....
.....

26 Headphone Settings .....
.....
.....
.....

.....
.....
.....
.....

.26 Audio Description .....
.....
.....
.....

.....
.....
.....
.....

.....26 Widescreen viewing ....
.....
.....
.....

.....
.....
.....
.....

.....
.....
..27 Picture controls ...
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....29 Picture Mode ...
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..29 Picture preferences .....

.....
.....
.....
.....

.....
.....
.....
.....29 Reset .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....29 ColourMaster ....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.29 Base Colour Adjustment ....
.....
.....

.....
.....
.....
.....

....30 Colour Temperature .....
.....
.....
.....

.....
.....
.....
.....

.....30 Auto Brightness Sensor .....

.....
.....
.....

.....
.....
.....
.....

30 Active Backlight Control .....
.....
.....
.....

.....
.....
.....
....30 Black/White Level .....

.....
.....
.....
.....

.....
.....
.....
.....

30 MPEG NR Noise Reduction .....
.....
.....
.....

.....
.....
.30 DNR Digital Noise Reduction ....
.....

.....
.....
.....
.....31 Cinema Mode ...

.....
.....
.....
.....

.....
.....
.....
.....

.....
.31 Resetting the advanced picture settings ....
.....
.....

...31 Automatic Format (Widescreen) .....
.....
.....
.....

.....
.31 4:3 Stretch ....
.....

.....

.....
.....
.....
.....

.....
.....
.....
.....

.31 Blue Screen .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
....31 Picture Position .
.....

.....
.....
.....
.....

.....
.....
.....
.....31 Picture still .

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
....31 Using your home network .
.....

.....
.....
.....
.....

.....
.....
...32 Setting up the Network ..
.....

.....
.....
.....
.....

.....
.....
.....
...33 Wireless Setup .....

.....
.....
.....
.....

.....
.....
.....
.....

.....33 Advanced Network Setup .....
.....
.....
.....

.....
.....
.....
.....35 DNS Setup .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
36 Network Connection Test .....
.....

.....
.....
.....
.....

.....36 Using the software keyboard ....
.....
.....
.....

.....
.....
.....
37 Network Device Setup .....

.....
.....
.....
.....

.....
.....
.....
.....37 External Control Setup ...

.....
.....

.....
.....

.....
.....
.....
....37 Device Name Setup .....

.....
.....
.....
.....

.....
.....
.....
.....38 Using Toshiba Places ....

.....
.....
.....
.....

.....
.....
.....
.....

.....38 Using YouTubeTM ....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
....39 Using Hybrid TV Standard (if available) .....

.....
.....
.....
.....39 Using the Media Player .

.....
.....
.....
.....

.....
.....
.....
.....

.....40 Basic operation .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.40 Viewing photo files (on a DLNA CERTIFIEDTM Server or USB device) ....
...41 Viewing movie files (on a DLNA CERTIFIEDTM Server or USB device) .....

43 Playing music files (on a DLNA CERTIFIEDTM Server or USB device) .....46 Other features ...
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

47 Panel Lock .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
47 The timers .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
47 Programme Timers digital only .....

.....
.....
.....
.....47 On Timer .....

.....
.....
.....
.....

.....
.....
.....
.....

.....

.....
...48 Sleep Timer ..
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....48 Energy Saving Settings ....
.....
.....
.....

.....
.....
.....
.....

.....
..49 Automatic Power Down ...
.....
.....

.....
.....
.....
.....

.....49 No Signal Power Down ....
.....
.....
.....

.....
.....
.....
.....

..49 2 Digital on-screen information .....
.....
.....
.....

.....
.....
.....
.....49 Information .....

.....
.....
.....
.....

.....
.....
.....
.....

.....
...49 Using EPG (Electronic Programme Guide) ..
.....

.....

.....
...50 Using Broadcast Guide ..
.....
.....

.....
.....
.....
.....

.....50 Genre selection/searching .
.....
.....
.....

.....
.....
.....
.....51 Using MediaGuide .

.....
.....
.....
.....

.....
.....
.....
.....

...51 MediaGuide screen .....
.....
.....
.....

.....
.....
.....
.....

.....51 Primary Navigation menu ....
.....
.....
.....

.....
.....
.....
.....51 Digital settings parental control ...

.....
.....
.....
.....

.....
.52 Parental PIN Setup ....
.....
.....

.....
.....
.....
.....

.....
.....
.52 Parental Setup ....
.....

.....
.....
.....
.....

.....
.....
.....
.....53 Network Lock .

.....
.....
.....
.....

.....
.....
.....
.....

.....
...53 Digital settings Channel Options ..
.....
.....

.....
.....
.....
.....53 Selecting favourite channels .....

.....
.....
.....
.....

.....
53 Favourite Channel Lists .....
.....
.....

.....
.....
.....
.....

.....53 Skip channels .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
54 Locking channels .....

.....
.....

.....
.....
.....
.....
.....
.....54 Digital settings other settings ...
.....
.....
.....
.....
.....
.....
54 Subtitles .....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
54 Audio languages .....
.....
.....
.....
.....
.....
.....
.....
...54 Common Interface ..
.....
.....
.....
.....
.....
.....
.....
..55 Software Upgrade and Licences .....
.....
.....
.....
.....
.....
.....
.....
55 Searching for New Software .....
.....
.....
.....
.....
.....
.....55 Network Upgrade ....

.....
.....
.....
.....

.....
.....
.....
.....

..55 Software Licences .....
.....
.....
.....

.....
.....
.....
.....

.....55 System Information and Reset TV ..
.....
.....
.....

.....
.....
.....
....56 System Information .....

.....
.....
.....
.....

.....
.....
.....
.....56 Reset TV ...

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..56 PC Settings .....

.....
.....
.....
.....

.....
.....
.....
.....

.....

.....
.....
.56 Horizontal and Vertical Position .....

.....
.....
.....
.....

56 Clock Phase .....
.....
.....
.....

.....
.....
.....
.....

.....
.....
...56 Sampling Clock ..
.....

.....
.....
.....
.....

.....
.....
.....
.....57 Reset .

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

57 Input selection and AV connections .....
.....
.....
.....

.....
.57 Input selection ....
.....
.....

.....
.....
.....
.....

.....
.....
.....

...57 Labeling video input sources .....

.....
.....
.....
.....

.....58 Digital Audio Output ...
.....
.....
.....

.....
.....
.....
.....

.....58 Using REGZA-LINK ...
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
..59 Enable REGZA-LINK .....

.....
.....
.....
.....

.....
.....
.....
.....59 TV Auto Power .....

.....
.....
.....
.....

.....
.....
.....
.....

.....59 Auto Standby ...
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.59 REGZA-LINK input source selection .....

.....
.....
.....
...59 REGZA-LINK one touch play .....

.....
.....
.....
.....

.....
60 REGZA-LINK system standby .....
.....
.....

.....
.....
.....
.....60 INFORMATION License Information .....

.....
.....
.....
.....

.....
.....
.....
.....

.....66 Information ...
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....68 Specifications and accessories .....
.....
.....
.....

.....
.....
.....
.....72 English TEXT SERVICES Text services .ipment. DO ensure that all electrical connections (including the mains plug, extension leads and interconnections between pieces of equipment) are properly made and in accordance with the manufacturers' instructions. @@WARNING: To prevent injuages generated by 4:3 broadcasts, text services, channel identification logos, computer displays, video games, on-screen menus, etc.

@@@@@@This is not a defect of the LCD TV and is not covered under the manufacturer's warranty. Regular use of other size modes (e.g.: Super Live) will prevent permanent retention. EXCLUSION CLAUSE Toshiba shall under no circumstances be liable for loss and/or damage to the product caused by: i) Fire; ii) Earthquake; iii) Accidental damage; iv) Intentional misuse of the product; v) Use of the product in improper conditions; vi) Loss and/or damage caused to the product whilst in the possession of a third party; vii) Any damage or loss caused as a result of the owner's failure and/or neglect to follow the instructions set out in the owner's manual; viii) Any loss or damage caused directly as a result of misuse or malfunction of the product when used simultaneously with associated equipment; Furthermore, under no circumstances shall Toshiba be liable for any consequential loss and/or damage including but not limited to the following: loss of profit, interruption of business, the loss of recorded data whether caused during normal operation or misuse of the product. 6 INSTALLING YOUR TV English The remote control Simple at-a-glance reference of your remote control. 16 To access the "TOSHIBA PLACES" Top Page When network is not connected, an error message will be displayed. 17 To access Media Player Menu 18 To call up text services 19 To access the analogue or digital Channel List 20 On-screen Menus 21 To display the digital on-screen Programme Guide 22 To page up, down, left or right 23 When using menus, the arrows move the

cursor on the screen up, down, left or right. Press OK to confirm your selection 24 To return to previous Menu 25 To exit menus and applications 26 When in TV mode: D Analogue time display When in Text mode: A To reveal concealed text B To hold a wanted page C To enlarge text display size D To select a page while viewing a normal picture During Playback: c To PLAY v To STOP W/w To PAUSE/STEP Z To SKIP-BACK CC To REWIND cc To FAST FORWARD z To SKIP-FORWARD 1 2 5 4 8 9 11 16 17 20 22 24 3 6 7 10 12 13 15 14 19 18 21 23 25 26 27 28 29 When using Programme Guide: Z 24 hours z +24 hours CC 1 page cc +1 page 27 Colour buttons: Text and interactive service control buttons 28 Picture still CT-90404 29 Not available for this TV 1 2 3 4 5 6 7 8 9 For On/Standby mode To select external input sources To select TV Mode (DTV Ant/DTV Cable/ATV) Selectable Picture Widescreen viewing Inserting batteries and effective range Remove the back cover to reveal the battery compartment and make sure the batteries are inserted the proper way. Suitable battery types for this remote are AA, IEC R6 1.

5V. Do not combine a used, old battery with a new one or mix battery types. Remove dead batteries immediately to prevent acid from leaking into the battery compartment. Dispose of them in accordance with instructions on page 67 of this manual.

You're reading an excerpt. Click here to read official TOSHIBA RL933 user guide
http://yourpdfguides.com/dref/4249640

Warning: Batteries must not be exposed to excessive heat such as sunshine, fire or the like.
The performance of the remote control will deteriorate beyond a distance of five metres or outside an angle of 30 degrees from the centre of the television. If the operating range becomes reduced, the batteries may need replacing. s Stereo/bilingual transmissions Digital Subtitles or Analogue TEXT Subtitle pages if available Number buttons Switch the Audio Description On/Off 10 To return to previous channel 11 To alter the TV volume 12 To display on-screen information To access the index page in Text mode 13 To mute the TV sound 14 To access Quick Menu 15 To change programme positions To change TEXT pages 7 CONNECTING YOUR TV English Connecting external equipment Before connecting any external equipment, turn off all main power switches. If there is no switch, remove the mains plug from the wall socket. ILLUSTRATION SHOWS 40RL933.
HDMI 3 INPUT HEADPHONE jack Power cord LAN port SCART (EXT 1) HDMI 1/2 INPUTS RGB/PC INPUT DIGITAL AUDIO OUTPUT (OPTICAL) Aerial Cable Media Recorder COMPONENT VIDEO/AUDIO INPUT VIDEO/AUDIO INPUT (Y/L/R) (EXT 2) Aerial cables:. . . . . .

. . . . . .
. . . . .
. . . . .
. . . . Connect the aerial to the socket on the rear of the television. If you use a decoder and/or a media recorder, it is essential that the aerial cable is connected through the decoder and/or through the media recorder to the television. SCART leads: . . . .

. . . . . .
. . . . .
. . . . .
. . . . . .

Connect the media recorder IN/OUT socket to the television. Connect the decoder TV socket to the television. Before running Auto Tuning, put your decoder and media recorder to Standby. The RCA sockets alongside the COMPONENT VIDEO INPUT sockets will accept L and R audio signals. When connecting the VIDEO/AUDIO devices, connect those cables to Y/L/R sockets. The Digital Audio Output socket enables the connection of a suitable surround sound system. NOTE: This output is always active. HDMI® (High-Definition Multimedia Interface) is for use with a DVD decoder or electrical equipment with digital audio and video output. For acceptable video or PC signal formats through the HDMI terminals, see page 69. NOTE: Although this television is able to connect to HDMI equipment, it is possible that some equipment may not operate correctly.
LAN port is used to connect the TV to your home network. This TV can play digital content stored on a DLNA CERTIFIEDTM product with server function. A wide variety of external equipment can be connected to the back of the television; therefore, the relevant owner's manuals for all additional equipment must be referred to for exact instructions. If the television automatically switches over to monitor external equipment, return to normal television by pressing the desired programme position button. To recall external equipment, press o to select between TV, EXT 1, EXT 2, HDMI 1, HDMI 2, HDMI 3 or PC.
When the external input mode is selected while viewing DTV mode, the SCART socket does not output video/audio signals. 8 CONNECTING YOUR TV English Connecting an HDMI® device The HDMI input on your television receives digital audio and uncompressed digital video from an HDMI source device. This input is designed to accept HDCP (High-Bandwidth Digital-Content Protection) programme material in digital form from EIA/CEA-861-D-compliant consumer electronic devices (such as a set-top box or DVD player with HDMI output). For acceptable video signal formats, see page 69. NOTE: Supported Audio format: Linear PCM, Dolby Digital (AC-3), sampling rate 32/44.
1/48kHz. HDMI's ARC (Audio Return Channel) feature This feature enables the audio signal of the TV to be sent to the AV amplifier via the HDMI cable. It will not be necessary to connect a cable from the audio output of the TV to the audio input of the AV amplifier to reproduce the audio received from the tuner of the TV through the AV amplifier. the back of your television AV amplifier that supports ARC To connect an HDMI device Connect an HDMI cable (type A connector) to the HDMI terminal. For proper operation, it is recommended that you use an HDMI cable with the HDMI Logo ( ). · If your HDMI connection is capable of 1080p and/or your television is capable of refresh rates greater than 50Hz, you will need a Category 2 cable. Conventional HDMI/DVI cable may not work properly with this model. · HDMI cable transfers both video and audio. Separate analogue audio cables are not required (see illustration). the back of your television HDMI cable HDMI cable HDMI device To view the HDMI device video, press the o button to select HDMI 1, HDMI 2 or HDMI 3 mode.

9 CONNECTING YOUR TV English REGZA-LINK connection You can control the basic functions of connected audio/video devices using the television's remote control if you connect a REGZA-LINK compatible AV amplifier or playback device. For an explanation of setup and operations, see pages 5960. the back of your television AV amplifier Playback device Playback device For the setup shown above, you will need three HDMI cables. NOTE: · If several devices are connected, the REGZA-LINK feature may not operate properly. · For proper operation, it is recommended that you use HDMI cables with the HDMI Logo ( ). · This function is available when one PC and one AV amplifier are connected separately. However, it may not operate properly if the PC is connected via the AV amplifier. Before controlling the device(s): · After completing the above connections, set the REGZALINK Setup menu as you desire (see page 59). · The connected devices must also be set. For details, see the operation manual for each device.
· The REGZA-LINK feature uses CEC technology as regulated by the HDMI standard. · This feature is limited to models incorporating Toshiba's REGZA-LINK. However, Toshiba is not liable for those operations. Refer to individual instruction manuals for compatibility information. 10 CONNECTING YOUR TV English Connecting a computer With either an RGB/PC or an HDMI connection, you can watch your computer's display on the television.
To connect a PC to the HDMI terminal When connecting a PC to the HDMI terminal on the television, use an HDMI-to-DVI adaptor cable. If connecting a PC with an HDMI terminal, use an HDMI cable (type A connector). the back of your television To connect a PC to the RGB/PC terminal When connecting a PC to the RGB/PC terminal on the television, use an analogue RGB (15-pin) computer cable. the back of your television Mini D-sub 15 pin connector Computer Computer HDMI-to-DVI adaptor cable For acceptable PC and video signal formats, see page 69. RGB PC cable (not supplied) NOTE: · The edges of the images may be hidden.
· If connecting a certain PC model with a unique PC signal, the PC signal may not be detected correctly. Conversion adaptor if required (not supplied) To use a PC, set the monitor output resolution on the PC before connecting it to the television.

[You're reading an excerpt. Click here to read official TOSHIBA RL933 user guide](http://yourpdfguides.com/dref/4249640)
http://yourpdfguides.com/dref/4249640

For acceptable PC signal formats, see page 68. To display the optimum picture, use the PC setting feature (see page 56). NOTE: · Some PC models cannot be connected to this television. · An adaptor is not needed for computers with a compatible mini D-sub15-pin terminal. · Depending on the DVD's title and the specifications of the PC on which you are playing the DVD-Video, some scenes may be skipped or you may not be able to pause during multi-angle scenes. · A band may appear at the edges of the screen or parts of the picture may be obscured. This is due to scaling of the picture by the set, it is not a malfunction. · When PC input mode is selected, some of the television's features will be unavailable e.

g. Colour System in the System Setup menu. · Some PC models may output unique signals that the television may be unable to detect (see page 68). · If connecting a certain PC model with a unique PC signal, the PC signal may not be detected correctly. 11 CONNECTING YOUR TV English Connecting a home network The LAN port allows your Toshiba TV to connect to your home network. You can use this revolutionary home entertainment networking system to access photo, video and audio files that are stored on a DLNA CERTIFIEDTM server and play/display them on your TV. NOTE: · If you connect to a shared network outside your home, it is advisable to use a router. Always use DLNA CERTIFIEDTM products in private network environments. Connect this TV to the same router as other DLNA CERTIFIEDTM products (server). · If you use a hub or switch to connect the TV to your home network, you may not be able to use the automatic setup and will have to manually set up the network address.
See page 35. · If you use a router with built-in DHCP functionality, use the automatic setup. Manual setup may not work. · If you connect the TV and PC directly, use a crossover LAN cable. To connect the TV to a home network with an internet connection - Wireless Please refer to "Wireless Setup" section on page 33.
the back of your television TOSHIBA Dual Band WLAN adaptor Access point (AP) Wireless LAN router Modem To connect the TV to a home network Wired the back of your television Computer Modem (if available) Router with Hub How to use this Dual Band Wireless LAN Adaptor · If this device is going to be operated in the frequency range of 5.15 GHz to 5.35 GHz, it is restricted to indoor use. · If this device is going to be operated for 802.11 b/g/n function in the frequency range of 2.
454 GHz to 2.4835 GHz in France, it is restricted to indoor use. · A general authorization is required for using this device outdoors or in public places in Italy. · This device is NOT ALLOWED to be used in the geographical area within a radius of 20km from the centre of Ny-Alesund in Norway. [1] [2] Server PC [2] [3] Cable or Phone jack [2] [1] Coaxial or telephone cable (depending on your modem type) [2] Standard LAN cable [3] Do NOT connect a phone jack directly to the TV's LAN port. 12 CONNECTING YOUR TV English Controls and input connections A wide variety of external equipment can be connected to the input sockets on the side of the television. While all the necessary adjustments and controls for the television are made using the remote control, the buttons on the television may be used for some functions. ILLUSTRATION SHOWS 40RL933. COMMON INTERFACE The Common Interface is for a Conditional Access Module (CAM). Contact a service provider.

The software updating of CI Plus CAM may be automatically executed. At this time, your Recording/Reminder programming will be canceled. Control panel USB port Media Player/Wireless LAN adaptor ready for a home network Ambient Light Sensor ORANGE LED Programme timer set (digital only) RED LED - Standby GREEN LED Power on Switching on If the RED LED is not lit, check that the mains plug is connected to the power supply and press 1 on the remote control; it may take a few moments. The GREEN LED will be lit. To put the television into Standby, press 1 on the remote control. To view the television, press 1 again. The picture may take a few seconds to appear. For energy saving: We recommend that you use the television with the factory settings. The factory settings are for energy saving. Unplugging the mains plug will cut energy use to zero for all televisions.
This is recommended when the television is not being used for a long time, e.g. when on holiday. Reducing the brightness of the screen will reduce energy use. Energy efficiency cuts energy consumption and thus saves money by reducing electricity bills.
NOTE: Putting the television into standby mode will reduce energy consumption, but will still draw some power. To use the option, press B and b on the remote control to move up and down and press C or c to select your desired setting. Using the TV controls and connections · To turn on or off the TV, press !. · To alter the volume, press + or . + and buttons operate as volume up/down as default.
· To alter the programme position, press p / o once and press u or U. · To select an external input, press and hold p / o until the Inputs window appears, and then press u or U to select the appropriate input source. The Media Player feature provides access to photo, movie and music files stored on a USB storage device that is connected via the USB port or on a network device. The USB port also has to be used with the "TOSHIBA Dual Band WLAN Adaptor WLM-20U2" in order to access a wireless network. You must use the TOSHIBA Wireless LAN device to ensure correct operation of this feature. This feature is available only when the "TOSHIBA Dual Band WLAN Adaptor" is used. Please always refer to the owner's manual of the equipment to be connected for full details. NOTE: · The USB socket has limited functionality and Toshiba can take no responsibility for damage to other connected equipment. · Interactive video games that involve shooting a "gun" at an on-screen target may not work with this TV. Using the menu system Press MENU on the remote control to display the menu.

The menu appears as a list of five topics. As each symbol is selected by pressing C or c on the remote control, its respective options will appear above. NOTE: The same menu is displayed in DTV (Digital TV) and ATV (Analogue TV) modes; however, where some items are not available in a mode, they will appear grayed out. 13 CONNECTING YOUR TV English MENU structure To open the main menu (illustration below) , press MENU on the remote control. Guide Genre Search Programme Timers Setup Function TV Programmes Media Player Connected TV 1st Layer Press MENU. TV Programmes Press C c / B. 2nd Layer Press C c. Press OK. 3rd Layer Press BbC c. Guide Genre Search Programme Timers Media Player Jump to Programme Guide (EPG) Jump to Genre Search Jump to Programme Timers USB Media Player Network Media Player Connected TV USB Media Player Menu Network Media Player Menu Toshiba Places Jump to Toshiba Places NOTE: This menu item is subject to change without notice.

[You're reading an excerpt. Click here to read official TOSHIBA RL933 user guide](http://yourpdfguides.com/dref/4249640)
http://yourpdfguides.com/dref/4249640

Function On Timer Sleep Timer Setup On Timer Menu Sleep Timer Menu Picture Sound Preferences System Setup Picture Menu Sound Menu Preferences Menu System Setup Menu 14 SETTING UP YOUR TV English Startup Application Before switching on the TV, make sure your decoder/media recorder, if applicable, is in standby. To set up the television, use the buttons on the remote control as detailed on page 7. h Press OK, and the Network Type screen will appear. Press C or c to select Wired or Wireless. Network Type Please select a network type.

Wired Quick Setup a Press the 1 button. The Menu Language screen will appear. This screen will appear the first time that the television is switched on and each time Reset TV is selected. Press B b C c to select the menu language and press OK. Highlight Country and press C or c to select.

The television is now set to tune the stations for your country. Quick Setup Country Primary Subtitle Language Secondary Subtitle Language Primary Audio Language Secondary Audio Language Germany German Turkish German English · When you select Wired (LAN cable connection), skip to step 12. · When you select Wireless (USB WLAN adaptor connection), follow step 9. NOTE: If the USB WLAN adaptor is not connected, Network Type screen does not display and skip to step 12. b c i Press OK, and the Wireless Setup screen will appear. Press C or c to select the Wireless Setup type. · Assisted Setup - follow step 10. Input the Security Key only. · Manual Setup, skip to step 11. Input the all settings.

Wireless Setup Please select a kind of wireless network. Assisted Setup NOTE: · The following display menus will differ slightly according to the country you selected. · If there is not a country that you want to select in the list, select Others. NOTE: EXIT is available during settings. j In step 9, when you select Assisted Setup; Press OK, and the Assisted Setup screen will appear. Press B or b to select the desired AP and press OK. NOTE: Check the MAC address on the label of the AP or in the manual, and select your AP. Press B or b to select Security Key and press OK. The Software Keyboard window will appear (page 37). Input the Security Key by using the Software Keyboard.

To save your setting, press the BLUE button. NOTE: · The Security Key must adhere to these conditions: - TKIP/AES: 8-63 ASCII or 64 Hex characters - WEP: 5 or 13 ASCII or 10 or 26 Hex characters · There is only one key ID to set for WEP encryption. Press B or b to highlight Done and press OK. NOTE: · If Network Name is not displayed, see Manual Setup below to set Network Name before pressing Done. · If BACK is pressed before Done is selected, settings are not saved.

When the message "Wireless configuration is complete." appears on screen, press OK. The screen will skip to step 12. d Press OK, and the Location screen will appear. Location To use the TV for displaying in a store showroom, please select [Store].

[Home] mode is recommended for normal use. Home e f Press C or c to select Home or Store. For normal home use, select Home. Press OK, and the AutoView screen will appear, press C or c to select Yes or No. AutoView AutoView mode automatically adjusts picture settings to suit ambient light conditions. Do you wish to enable AutoView mode? No g Press OK, and the Network Setup screen will appear. Press C or c to select Yes or No. Network Setup Do you want to configure network setup? Yes · When you select No, skip to step 15. 15 SETTING UP YOUR TV English k In step 9, when you select Manual Setup; Press OK, and the Manual Setup screen will appear. Press B or b to select Network Name and press OK.

The Software Keyboard window will appear (page 37). Input the Network Name by using the Software Keyboard. To save your setting, press the BLUE button. Press B or b to select Authentication and then press C or c to select Open System, Shared Key, WPAPSK or WPA2-PSK. Press B or b to select Encryption, and then press C or c to select None, WEP, TKIP or AES. NOTE: · Certain encryption types are only compatible with specific authentication types. - When Authentication is Open System, only WEP or None is compatible. - When Authentication is Shared Key, only WEP is compatible. - When Authentication is WPA-PSK or WPA2-PSK, only TKIP or AES is compatible. · When incompatible Authentication/Encryption pairings are detected, a warning message will be displayed, and no connection attempt will be made until the incompatibility is resolved.

· There is only one key ID to set for WEP encryption. Press B or b to select Security Key and press OK. Input the Security Key by using the Software Keyboard (page 37). To save your setting, press the BLUE button. This item is grayed out when Encryption is None.

When Encryption is WEP, Key ID setting is available. Press B or b to select Key ID and press C or c to select 1(default), 2, 3 or 4. Press B or b to select Done and press OK. When the message "Wireless configuration is complete." appears on screen, press OK.

NOTE: Settings are not saved if BACK is pressed before Done is selected. l The Advanced Network Setup screen will appear. When the DHCP function of the router connected with this TV is On, you can set Auto Setup to On or Off. (This should usually be set to On.) When the DHCP function of the router is Off, set Auto Setup to Off, and set the IP Address DNS address(es) manually. Advanced Network Setup IP Address Setup Auto Setup IP Address Subnet Mask Default Gateway On XXX . XXX . XXX . XXX XXX . XXX .

XXX . XXX XXX . XXX . XXX . XXX DNS Setup Auto Setup Primary DNS Address Secondary DNS Address MAC Address On XXX . XXX . XXX . XXX XXX . XXX . XXX .

XXX 00:11:22:33:44:55 Next You can view the fixed MAC address for the TV and for the Dual Band WLAN Adaptor, if one is installed. Press B or b to select Next. m Press OK, and Network Connection Test will start. A message will appear to indicate if the connection was successful or it could not be completed. Network connection was completed successfully.

OK @@Depending on the situation, YouTube may not be able to be used. To cancel the Network Connection Test: Press BACK while searching for the Internet connection. 16 SETTING UP YOUR TV English n Press OK. If your country supports Network Guide, The Guide Type screen will appear. Guide Type Please select Guide Type.

Broadcast Guide r s Press C or c to view the DTV (digital channel) or ATV (analogue channel) lists. Use B or b to move through the list to select a channel, and then press OK to view. In ATV mode, some areas may receive duplicate stations. There may not be a clear picture or the signal may be weak, so the station order can be changed using ATV Manual Tuning. REMEMBER: Press TV at any time to select between ATV and DTV modes. NOTE: The time will be set automatically by transmission but can be advanced or decreased by using Local Time Setting in the DTV Settings screen.

[You're reading an excerpt. Click here to read official TOSHIBA RL933 user guide](http://yourpdfguides.com/dref/4249640)
http://yourpdfguides.com/dref/4249640

PLEASE NOTE The Quick Setup menu can also be accessed at any time from the Setup / System Setup menu. Press C or c to select Broadcast Guide or MediaGuide. NOTE: If you select MediaGuide, it may take time to access the Guide screen depending on active channel numbers. o Press OK.

If the Ant/Cable In screen appears, press B or b to select Antenna or Cable, and then press OK to check ( ). Ant/Cable In Antenna Cable Next Ant/Cable In (if available) From this menu, you can set the RF input configuration. p Select Next and press OK. The Auto Tuning start up screen will appear with the option to select between DTV and ATV, DTV or ATV if available. Use C or c to select the appropriate mode. Press B or b to highlight Start Scan, and then press OK. The television will start to search for available DTV and/or ATV channels. The progress bar will indicate the scan status. You must allow the television to complete the search. Auto Tuning - Antenna Progress DTV Tune ATV Tune 3% Waiting.

.. Channel: C7 a b c Press MENU / C c to highlight Setup icon. Press B / C c to highlight System Setup icon and press OK. Press b to select Ant/Cable In and press C or c to select Antenna or Cable.

NOTE: When you attempt to change the Ant/Cable In setting, a warning message will appear followed by PIN entry (if PIN has been set) and a prompt for Auto Tuning. q Found 2 d When Ant/Cable In is set to Cable, the following setting options will be provided in the Auto Tuning screen. Press B or b to select an item and press C or c to select your desired option. Auto Tuning - Cable Tuning Mode Start Scan DTV Operator Selection Scan Type Start Frequency End Frequency Modulation Symbol Rate Network ID Others Quick Scan Auto Auto Auto Auto Auto DTV and ATV When the search is complete, the television will automatically select channel one. The Auto Tuning screen will display the total number of services found.

17 SETTING UP YOUR TV English With the exception of DTV Scan Type and DTV Modulation items, all of the following items will have 2 operating modes. The first is Auto where the values for each item are preset by the system. The second is an Input mode where you will be able to enter a single value in place of the pre-set value. If no channel is currently tuned and the Input state is chosen, a system default value will be shown. However, if a channel is currently tuned when the item is accessed, the value of the current channel will be displayed. c Press B or b to select Auto Tuning and press OK. System Setup Menu Language Country Ant/Cable In Auto Tuning ATV Manual Tuning DTV Manual Tuning DTV Settings Quick Setup English Germany Operator Selection: You can choose the Cable operator depending on the Country you set. DTV Scan Type: This item determines whether a Quick Scan or a Full Scan will be executed. The Quick Scan is a simplified version of the Full Scan that is designed to complete in less time. d Press C or c to select Yes and press OK.

Auto Tuning - Antenna Tuning Mode Start Scan DTV and ATV DTV Start Frequency: This sets the frequency from which the scan will begin. DTV End Frequency: This sets the frequency at which the scan will end. Press C or c to select DTV and ATV, DTV or ATV, if available, then highlight Start Scan and press OK to continue with the Auto Tuning. NOTE: If you have selected "Others" for the Country field in the System Setup menu, and selected a tuning mode other than "DTV" , choose the optimum ATV broadcasting system (B/G, I, D/K or L). The television will start to search for all available DTV and/or ATV services. You must allow the television to complete the search. When the search is complete, the Auto Tuning screen will display the services found. DTV Modulation: You can choose from five QAM modulation settings. DTV Symbol Rate: This is the baud rate (KS/s) of the scan. DTV Network ID: This is the Network ID to be utilized for the scan.

This item is grayed out when DTV Scan Type is set to "Full Scan". Auto Tuning NOTE: As new services are broadcast, it will be necessary to re-tune the television in order to view them. Auto Tuning will completely re-tune the television and can be used to update the channel list. It is recommended that Auto Tuning is run periodically to ensure that all new services are added. All current channels and settings, i.

e. locked channels, will be lost. e Press B or b to move through the list to select a channel and press OK to view. a b Press MENU / C c to highlight Setup icon. Press B / C c to highlight System Setup icon and press OK.

18 SETTING UP YOUR TV English ATV Manual Tuning Tuning The television can be tuned-in manually using ATV Manual Tuning. For example, you might use the feature if the television cannot be connected to a media recorder/decoder with a SCART lead or when you want to tune-in a station on another System. Use C and c to move across the screen and select any of the ATV Manual Tuning options. Then use B or b to adjust the settings. ATV Manual Tuning System 1 I A C 2 0 V C R a In the System Setup menu, press b to select ATV Manual Tuning and press OK. System Setup Menu Language Country Ant/Cable In Auto Tuning ATV Manual Tuning DTV Manual Tuning DTV Settings Quick Setup English Germany b Use B or b to select the desired position. We suggest Pos. 0 for a media recorder. ATV Manual Tuning Pos. Channel Station 12345678 1 9 1 2 3 4 5 6 7 8 C2 S10 C7 S40 C22 C25 C28 C30 Position The number to be pressed on the remote control to tune the channel.

System Specific to certain areas. Colour System Factory set to Auto, should only be changed if problems are experienced, i.e. NTSC input from external source. Skip Set Skip to On (8) or Off (() for the selected channel. See page 20. Signal Class The channel classification. Channel The channel number on which a station is being broadcast. Search Search up and down for a signal. Manual Fine Tuning Only used if interference/weak signal is experienced. See page 63. Station Station identification. Use the B b and C c buttons to enter up to seven characters. 2 3 Different Channel numbers may be displayed. 4 c d 5 6 Press OK to select.

If the channel chosen for the media recorder is set to skip, Skip should be removed before storing. Press c to select System and press B or b to change if required. ATV Manual Tuning System 1 I A C 2 0 7 8 e f Then press c to select Search. Press B or b to begin the search. The search symbol will flash. ATV Manual Tuning Search 1 I A C 2 0 9 To allocate a position on the television for a decoder and media recorder: turn the decoder on, insert a pre-recorded film in the media recorder, press PLAY and manually tune. 19 SETTING UP YOUR TV English g h Each signal will show on the television. If it is not your media recorder, press B or b again to restart the search. When your media recorder signal is found, press c to move along to Station.

[You're reading an excerpt. Click here to read official TOSHIBA RL933 user guide](http://yourpdfguides.com/dref/4249640)
http://yourpdfguides.com/dref/4249640

Use B, b, C and c to put in the required characters, e.g. VCR. ATV Manual Tuning Station 1 I A C 2 0 V C R Skip To prevent certain channels from being viewed, positions can be skipped. a b Select ATV Manual Tuning from the System Setup menu. Use B or b to highlight the position to be skipped and press OK to select.

ATV Manual Tuning Pos. Channel 1 2 3 4 5 6 7 Station i j k Press OK to save. Repeat for each position you want to tune. Press EXIT when you have finished. PLEASE NOTE This television has direct channel entry if the channel numbers are known. Select the ATV Manual Tuning screen in Step 3. Enter the Position number, the System, then C for standard (terrestrial) channels or S for cable channels and the Channel number. Press OK to save. C2 S10 C7 S40 C22 C25 C28 C30 ABC1 ABC1 8 c d Press c to select Skip. Use B or b to turn Skip on.

Press OK. 8 on the screen indicates a skipped position. ATV Manual Tuning Skip: On 1 I A C 2 0 e Press EXIT and repeat steps 1 through 4 to set other positions if necessary. Each position has to be individually selected. To turn Skip off, repeat the procedure for each position.

Skipped positions cannot be selected by PU and Pu or by the controls on the television but can still be accessed by the number buttons on the remote control. 20 SETTING UP YOUR TV English Sorting positions Channels may be moved and saved to the position of your choice. DTV Manual Tuning NOTE: This feature varies depending on the Ant/Cable In setting. a b Select ATV Manual Tuning from the System Setup menu. With the list of channels showing, use B or b to highlight the channel you want to move and press c.

ATV Manual Tuning Pos. Channel 2 3 4 5 1 6 7 8 Manual Tuning This feature is available for service engineers or can be used for direct channel entry if the multiplex channel is known. a Station Select DTV Manual Tuning from the System Setup menu and press OK. DTV Manual Tuning - Antenna S10 C7 S40 C22 C2 C25 C28 C30 ABC1 ABC1 Signal Strength Quality WEAK AVERAGE STRONG GOOD 67 842.0 MHz 8 MHz Channel Frequency Bandwidth Start Scan c d Use B or b to move through the list to your preferred position. As you do so, the other channels will move to make room. Press C to save your move. Repeat as necessary and press EXIT. b c Enter the multiplex number using the number buttons or use C or c to adjust the number up or down. Highlight Start Scan and press OK.

The television will automatically search for that multiplex. DTV Manual Tuning - Antenna 0 New Channels - Total 6 New Pos. Name Type 1 2 7 40 51 ABC ONE ABC TWO ABC THREE ABC NEWS 24 ABCi When the multiplex is found, any channels that are not currently in the channel list will be added and the channel information at the top of the screen will be updated. d Repeat as necessary. Press EXIT to finish. 21 SETTING UP YOUR TV English Manual Tuning for DVB-C When Ant/Cable In is set to Cable, DTV Manual Tuning items are as follows: Frequency input a specific frequency to be scanned Modulation choose from one of five QAM modulation options Symbol Rate input a specific baud rate (KS/s) to be used for the manual scan DTV Settings Channels The channel order may be changed to suit your personal preference. a b Select DTV Settings from the System Setup menu and press OK. Select Channels and press OK. DTV Settings Channels Subtitle and Audio Parental PIN Setup Parental Control Local Time Setting Standby Channel Update Common Interface c For your convenience, you can jump to specific places in the list by one of two methods. Channels Line No.

Pos. Name 1/10 Antenna TV 1 2 7 30 40 51 822 823 ABC ONE ABC TWO ABC THREE CABC Channel ABC NEWS 24 ABCi AA AC Line Number Jump -- Use the number buttons (0-9) to input the line number you want to select and press OK. It is also possible to change the Position number of a particular channel. Renumber -- Press the RED button to renumber the highlighted channel. Edit the channel number using the number buttons and press OK.

If the position number you input already exists, a confirmation window will appear. Pos. Name ABC ONE 22 SETTING UP YOUR TV English Move -- Press the GREEN button to activate the Move feature. Press the B or b buttons to select the channel you wish to move and press OK to check. If you wish to move multiple channels at once, select another channel and check in the same way.

Repeat as necessary. Once all desired channels have been checked, press the B or b buttons to place the focus at the position to which you wish to move the channels. The channels will be inserted above the highlighted channel. Press the GREEN button to execute the move. Channels Line No. Pos. Name 1/10 Analogue switch-off This is a digital television which is integrated to allow the use of both digital and analogue services. However, during the lifetime of this set it is very likely that analogue services will be switched off to allow for more new digital services. This 'switch-off' will happen in a number of phases, which will be advertised in your area well in advance. It is recommended that at each phase the television is re-tuned to ensure that existing and new digital services can be viewed without disruption.

Antenna TV 1 2 7 30 40 51 822 823 ABC ONE ABC TWO ABC THREE CABC Channel ABC NEWS 24 ABCi AA AC Position No. Sort -- Press the YELLOW button. A confirmation window will appear. Press C or c to select Yes and press OK. Your existing channel order will be lost. Do you wish to continue? Yes Standby Channel Update If the Standby Channel Update is set to On, when the TV is in standby mode, Digital Tuning is automatically executed and any new channels are saved. a b Select DTV Settings from the System Setup menu and press OK. Press b to select Standby Channel Update and press C or c to select On. Location setting You can select either Home or Store mode. Home is recommended for normal home use.

Select Store when using the television for displaying in a shop, etc. a b Select Location from the System Setup menu. Press C or c to select Home or Store. 23 CONTROLS AND FEATURES English General controls Quick Menu Quick Menu helps you access some options quickly, such as Picture Mode, Picture Size, More Information, Sleep Timer etc. Press QUICK to display the Quick Menu and use B or b to select the option.

Quick Menu Picture Mode Picture Size More Information Channel Options Sleep Timer Headphone Level Wireless Information 50 00:00 AutoView Super Live Selecting channels To select a channel, use the numbered buttons on the remote control. Channels can also be selected using PU and Pu. To display on-screen information such as channel, input mode or stereo/mono signal, press . Press again to cancel. The Time Display analogue only The time display facility allows the current (text service) time to be seen on the television screen.

[You're reading an excerpt. Click here to read official TOSHIBA RL933 user guide](http://yourpdfguides.com/dref/4249640)
http://yourpdfguides.com/dref/4249640

Press D whilst watching a normal television broadcast to see the time display from the broadcaster. It will remain on screen for about 5 seconds. NOTE: This display may not be available in some cases. Stereo and Bilingual transmissions For DTV programmes For stereo or dual mono broadcasts, press s and use C or c to select settings. Mode Display Description See page 29. See page 27. See page 50. See page 53. See page 48. See page 26.

See page 34. See page 51. See page 29. See page 25. See page 42. See page 42. See page 42. See page 43. See page 48. See page 26.
Stereo Dual mono Mono Multichannel Pressing c Stereo S Left S Right Dual 1 S Dual 2 S Dual NOTE: Quick Menu items are different depending on the current mode. Quick menu item example Mode When viewing a TV programme or pictures from the external input Quick menu item Picture Mode Picture Size More Information Channel Options Sleep Timer Headphone Level Wireless Information When using EPG USB Media Player (Photo Single View, Slide Show) Genre Colour Picture Sound Interval Time Repeat Background Music Play List Sleep Timer Headphone Level For multi-audio track broadcasts, press s repeatedly to change the audio language (see "Audio languages" on page 54). For ATV programmes If stereo or dual language broadcasts are transmitted, the word Stereo or Dual will appear on the screen each time channels are changed, disappearing after a few seconds. If the broadcast is not in stereo, the word Mono will appear. Stereo.
.. Press s to select Stereo or Mono. Bilingual..
. Bilingual transmissions are rare. If they are transmitted, the word Dual will be displayed. Choose the required programme number, and if the word Dual appears, press s to select Dual 1, Dual 2 or Mono. 24 CONTROLS AND FEATURES English Sound controls Volume controls and sound mute Volume Press 2+ or 2 to adjust the volume. Sound Mute Press once to turn the sound off and again to cancel. Voice Enhancement Voice Enhancement emphasises the frequency range of the speaker's voice, making it easier to catch what they are saying. a b In the Advanced Sound Settings menu, press B or b to select Voice Enhancement. Press C or c to select On or Off. Dual If a programme or film is being broadcast with a soundtrack in more than one language, the Dual feature allows selection between them.

Dynamic Bass Boost Dynamic Bass Boost enhances the depth of the sound on the TV speakers. The difference will only be noticeable on sound with strong bass. a b c Press MENU / C c to highlight Setup icon. Press B / C c to highlight Sound icon and press OK. Press B or b to select Dual and press C or c to choose between Dual 1 or Dual 2. Sound Dual Balance Advanced Sound Settings Stable Sound Dynamic Range Control Audio Level Offset TV Speakers Headphone Settings On Off On 0 Dual 1 a b In the Advanced Sound Settings menu, press B or b to select Dynamic Bass Boost. Press C or c to select the desired bass expansion level (Low, High or Off). Stable Sound® Stable Sound reduces the volume level differences between channels. It automatically remains on the same volume level when you change channels. a b In the Sound menu, press B or b to select Stable Sound.
Press C or c to select On or Off. Dynamic Range Control Balance a In the Sound menu, press B or b to select Balance and press C or c to emphasize left or right speaker balance. This feature allows control of audio compression for some digital TV programmes (MPEG-1 and MPEG-2 audio programmes are not supported). a b In the Sound menu, press B or b to select Dynamic Range Control. Press C or c to select On or Off.
Bass, Treble a b c In the Sound menu, press B or b to select Advanced Sound Settings and press OK. Press B or b to select Bass or Treble. Press C or c to change the setting. 25 CONTROLS AND FEATURES English Audio Level Offset Sometimes there can be large changes in volume when switching from a DTV 5.1ch to a DTV 2ch, an ATV channel, or an external input.
Using the Audio Level Offset feature reduces these volume differences. Headphone Settings This setting is used to set the sound output when headphones are connected. Speaker Link On Off Headphone Sound is output (2 ± is available.) Sound is output (Headphone level menu is available.) Speakers No sound Sound is output (2 ± is available.) a b c d Set the volume level usually used when watching a DTV 5.1ch programme. Tune to a channel which is DTV 2ch, ATV or an external input. In the Sound menu, press B or b to select Audio Level Offset and press OK. Press B or b to select an option, and then press C or c to adjust the volume level.

Audio Level Offset DTV 2ch ATV External Input -5 0 0 a b c In the Sound menu, press B or b to select Headphone Settings and press OK. Press B or b to select Speaker Link and press C or c to select On or Off. If you select Off, then highlight Headphone Level and use C or c to adjust the headphone sound. Headphone Settings Speaker Link Headphone Level 50 On NOTE: · The available item changes depending on the current input source. For example, while watching a DTV 2ch programme, only DTV 2ch is available and the other two items are grayed out in the menu. This allows you to easily adjust according to each condition. · When watching a DTV 5.1ch programme, this feature is not available. Audio Description Audio Description is an additional narrative sound track for visually impaired individuals to understand and enjoy the story line more fully. The letters AD will be displayed in the channel banner when programmes contain AD content.
TV Speakers On/Off This feature allows you to turn the TV speakers off when connecting the audio system. a b a b In the Sound menu, press B or b to select TV Speakers. Press C or c to select Off. In the Sound menu, press B or b to select Audio Description and press OK. Press B or b to select Audio Description and press C or c to select On.
Audio Description Audio Description Mixing Level 50 On To turn on the built-in speakers: Choose On in step 2. The AD button on the Remote can also be used to toggle the Audio Description feature between On and Off. c To adjust the level of the audio description sound to the main sound, highlight Mixing Level and press C or c. 26 CONTROLS AND FEATURES English Widescreen viewing Depending on the type of broadcast being transmitted, programmes can be viewed in a number of formats. Use this setting when watching a widescreen DVD, widescreen video tape or a 16:9 broadcast (when available). Due to the range of widescreen formats (16:9, 14:9, 20:9 etc.) black bars may be visible on the top and bottom of the screen. WIDE 4:3 Use this setting to view a true 4:3 broadcast. SUPER LIVE This setting will enlarge a 4:3 image to fit the screen by stretching the image horizontally and vertically, holding better proportions at the centre of the image. Some distortion may occur.

[You're reading an excerpt. Click here to read official TOSHIBA RL933 user guide](http://yourpdfguides.com/dref/4249640)
http://yourpdfguides.com/dref/4249640

CINEMA When watching `all sides panel format' films/video tapes, this setting will eliminate or reduce the black bars at all sides of the screen by zooming in and selecting the image without distortion. SUBTITLE When subtitles are included on a letterbox format broadcast, this setting will raise the picture to ensure that all the text is displayed. SUBTITLE 14:9 Use this setting when watching a 14:9 broadcast. 27 CONTROLS AND FEATURES English NATIVE This setting will show the picture without overscan, i.e.

WYSIWYG. PC NORMAL This setting will show the picture without overscan, i.e. WYSIWYG. This option is only available when watching a PC signal source via HDMI or PC terminal. PC WIDE This setting will show the picture without overscan or side panels. This option is only available when watching a PC signal source via HDMI or PC terminal. Dot by Dot "Dot by Dot" is a non-scaling display. Depending on the input signal format, the picture is displayed with side panels and/or bars at the top and bottom (e.g.
VGA input source). Press the button on the Remote to display the list of available widescreen formats. Press the button repeatedly to highlight the required format. The Quick Menu feature can also be used to select Picture Size. AV format Picture Size Wide 4:3 Super Live Cinema Subtitle 14:9 Native PC format Picture Size PC Normal PC Wide Dot by Dot Using the special functions to change the size of the displayed image (i.
e. changing the height/width ratio) for the purposes of public display or commercial gain may infringe on copyright laws. 28 CONTROLS AND FEATURES English Picture controls Most of the picture controls and functions are available in both digital and analogue modes. PLEASE NOTE: Features not available will be grayed out. Picture preferences You can customize current picture mode settings as desired.
For example, while selecting "Dynamic", if you change the following items, such as Backlight, Contrast, Brightness, Colour, Tint, Sharpness and the Advanced Picture Settings items, your new settings are saved for "Dynamic" picture mode. Picture Mode This television offers the choice of personalising the picture style. AutoView, Dynamic, Standard, Hollywood 1, Hollywood 2, Store, Game and PC are preset options and affect many features/settings within the television. NOTE: · Because the AutoView mode automatically adjusts picture settings based on ambient light conditions and input signal content, the Auto Brightness Sensor menu is grayed out when it is selected. · Store mode is only available when Location is set to Store. · Game mode is available in external input mode (other than aerial input). When you select Game mode, suitable widescreen formats will be selected. · PC mode is available in RGB/PC input mode or HDMI input mode. a b In the Picture menu, press B or b to select either Backlight, Contrast, Brightness, Colour, Tint or Sharpness and press OK. Press C or c to adjust the settings.

Reset This feature resets all picture settings to the factory settings except Picture Mode. a b In the Picture menu, press B or b to select Reset and press OK. A confirmation message will appear. Press C or c to select Yes and press OK. a b c Press MENU / C c to highlight Setup icon. Press B /C c to highlight Picture icon and press OK. Press B or b to select Picture Mode. Picture Picture Mode Reset Backlight Contrast Brightness Colour Tint Sharpness 100 100 0 0 0 0 Standard ColourMaster When ColourMaster is set to On, it allows the `Base Colour Adjustment' feature to become available. a b In the Picture menu, press B or b to select Advanced Picture Settings and press OK. Press b to select ColourMaster.
Advanced Picture Settings ColourMaster Base Colour Adjustment Colour Temperature Auto Brightness Sensor Active Backlight Control Black/White Level Noise Reduction Active Vision High Off Low Middle Off d Press C or c to select the picture mode you prefer and press OK. c Press C or c to select On or Off and press OK. The Picture Mode can also be selected using the q button on the remote control. NOTE: The picture mode you select affects the current input only. You can select a different picture mode for each input.
29 CONTROLS AND FEATURES English Base Colour Adjustment The Base Colour Adjustment feature allows the adjustment of individual colours to suit personal preference. This can be useful when using an external source. Auto Brightness Sensor When the Auto Brightness Sensor is activated, it will automatically optimise the backlighting levels to suit ambient light conditions. a b In the Advanced Picture Settings menu, press B or b to select Base Colour Adjustment and press OK. Press B or b to select an option and press c to move to the adjustment window.
Base Colour Adjustment Hue Saturation Brightness a b In the Advanced Picture Settings menu, press B or b to select Auto Brightness Sensor. Press C or c to select On or Off. Active Backlight Control 0 0 0 0 0 0 0 0 0 0 0 0 Red Green Blue Yellow Magenta Cyan Reset 0 0 0 0 0 0 When the Active Backlight Control feature is activated, it will control the backlighting levels depending on various scenes such as picture motion, bright scene or dark scene. a b In the Advanced Picture Settings menu, press B or b to select Active Backlight Control. Press C or c to select High, Low or Off. High: To control the backlighting levels depending on various scenes such as picture motion, bright scene or dark scene Low: To control the backlighting levels for dark scene c Press C or c to select Hue, Saturation or Brightness and press B or b to adjust the settings as required. Hue Red 0 Saturation 0 Brightness -1 Black/White Level Black/White Level increases the strength of dark areas of the picture to improve the definition. d Press BACK to return to the previous menu. To return to the factory settings, select Reset and press OK. a b In the Advanced Picture Settings menu, press B or b to select Black/White Level.

Press C or c to select High, Middle, Low or Off. Colour Temperature Colour Temperature increases the `warmth' or `coolness' of the picture by increasing the red or blue tint. MPEG NR Noise Reduction When watching a DVD, the compression may cause some words or picture elements to become distorted or pixelated. Using the MPEG NR feature reduces this effect by smoothing out the edges. a b c In the Advanced Picture Settings menu, press B or b to select Colour Temperature and press OK. Press B or b to select Colour Temperature and press C or c to select Cool, Natural or Warm to suit your preference. Press B or b to select Red Level, Green Level or Blue Level and press C or c to adjust the level. a b In the Advanced Picture Settings menu, press B or b to select Noise Reduction and press OK. Press b to select MPEG NR.

You're reading an excerpt. Click here to read official TOSHIBA RL933 user guide
http://yourpdfguides.com/dref/4249640

Noise Reduction MPEG NR Low Auto NOTE: To return the adjustments to the factory defaults, select Reset and press OK.
DNR c Press C or c to select Low, Middle, High or Off to suit your preference. 30 CONTROLS AND FEATURES English DNR Digital Noise Reduction DNR allows you to `soften' the screen representation of a weak signal to reduce the noise effect. 4:3 Stretch When 4:3 Stretch is activated, the size switching system changes 4:3 programmes into full screen picture. a b Select DNR from the Noise Reduction menu. Press C or c to select Low, Middle, High, Auto or Off. The differences may not always be noticeable (for the best result use lower settings as picture quality can be lost if the setting is too high). a b In the Preferences menu, press B or b to select Display Settings and press OK. Press B or b to select 4:3 Stretch and press C or c to select On or Off. Blue Screen When Blue Screen is selected, the screen will turn blue and the sound will be muted on analogue channels and external input modes when no signal is received. NOTE: Some external input sounds may not be muted.
Cinema Mode The frame rate of a movie film is generally 24 frames a second whereas the movie software such as DVD, etc. that you enjoy watching on television at home is 30 or 25 frames a second. The difference in frame rate may cause flickers while viewing the films on television; set the Cinema Mode to convert the signal to reproduce a smooth motion and picture quality. a b In the Preferences menu, press B or b to select Blue Screen. Press C or c to select On or Off. a b In the PICTURE menu, press b to select Advanced Picture Settings and press OK. Press b to select Cinema Mode and press C or c select from On or Off. Picture Position The picture position may be adjusted to suit personal preference and can be particularly useful for external inputs. NOTE: The Picture Position feature cannot be selected in the DTV mode. NOTE: When Picture Mode is set to Game or PC, this feature will be grayed out and automatically set to Off.

. Resetting the advanced picture settings This feature allows you to reset the current Advanced Picture Settings to the default values. a b In the Preferences menu, press B or b to select Display Settings and press OK. Press B or b to select Picture Position. Display Settings Auto Format 4:3 Stretch Picture Position PC Settings On Off a b In the Advanced Picture Settings menu, press B or b to select Reset. Press OK. Automatic Format (Widescreen) When this television receives a true Widescreen picture and Auto format is On, it will automatically be displayed in Widescreen format irrespective of the television's previous setting. c d Press OK to view the options available for the picture format that has been selected. Press B or b to select an option and press C or c to adjust the settings. The options differ depending on the currently selected widescreen format and the input signal.
Picture Position Horizontal Position Vertical Position 0 0 Reset a b c d Press MENU / C c to highlight Setup icon. Press B / C c to highlight Preferences icon and press OK. Press B or b to select Display Settings and press OK. Press B or b to select Auto Format and press C or c to select On or Off. Display Settings Auto Format 4:3 Stretch Picture Position PC Settings On Off To return to the original factory settings, select Reset in the Picture Position menu and press OK.
Picture still This feature is used to hold a still image on the screen. a Press r to hold an image on the screen, and press r again to cancel. 31 CONTROLS AND FEATURES English Using your home network This TV is a DLNA CERTIFIEDTM Player. This TV can play digital content stored on a DLNA CERTIFIEDTM product with server function. If you want to use this TV as a DLNA CERTIFIEDTM Player, you will have to configure the network on your TV (see page 12).
If you want to use your home network, you will have to configure the network on your TV. (see page 12) Change the network settings if necessary (see "Setting up the Network" on page 33). When using a wireless home network: Wireless Interoperability The TOSHIBA Dual Band WLAN Adaptor is designed to be interoperable with any wireless LAN product that is based on Direct Sequence Spread Spectrum (DSSS)/Orthogonal Frequency Division Multiplexing (OFDM) radio technology, and is compliant to: · The IEEE 802.11 Standard on Wireless LANs (Revision a/b/g/ n), as defined and approved by the Institute of Electrical and Electronics Engineers. · The TOSHIBA Dual Band WLAN Adaptor is intended for use with the RL93/SL97/RL95 series LCD TV's and should not be used with any other devices. Use of the WLAN Adaptor in other USB products may result in damage to the WLAN Adaptor and or the equipment. Such use will void any warranty that may otherwise apply, and TOSHIBA will have no liability for any damage that may result from such use. Wireless LAN and your Health Wireless LAN products, like other radio devices, emit radio frequency electromagnetic energy. The level of energy emitted by Wireless LAN devices, however, is far less than the electromagnetic energy emitted by wireless devices such as mobile phones. Because Wireless LAN products operate within the guidelines found in radio frequency safety standards and recommendations, TOSHIBA believes Wireless LAN is safe for use by consumers.

These standards and recommendations reflect the consensus of the scientific community and result from deliberations of panels and committees of scientists who continually review and interpret the extensive research literature. In some situations or environments, the use of Wireless LAN may be restricted by the proprietor of the building or responsible representatives of the organization. Such restrictions may apply in environments where the risk of interference to other devices or services is perceived or identified as harmful. If you are uncertain of the policy that applies to the use of wireless devices in a specific organization or environment, you are encouraged to ask for authorization to use the Wireless LAN device prior to turning on the equipment. This Dual Band Wireless LAN Adaptor may be operated in the following countries: AT BE CH CY CZ DE DK ES FI FR GB GR EE HU IT IE Austria Belgium Switzerland Cyprus Czech Republic Germany Denmark Spain Finland France United Kingdom Greece Estonia Hungary Italy Ireland IS LI LT LU LV MT NL NO PL PT SE SI SK BG RO TR Iceland Liechtenstein Lithuania Luxembourg Latvia Malta Netherlands Norway Poland Portugal Sweden Slovenia Slovakia Bulgaria Romania Turkey CAUTION BluetoothTM and Wireless LAN devices operate within the same radio frequency range and may interfere with one another. If you use BluetoothTM and Wireless LAN devices simultaneously, you may occasionally experience a less than optimal network performance or even lose your network connection.

You're reading an excerpt. Click here to read official TOSHIBA RL933 user guide
http://yourpdfguides.com/dref/4249640