



**Manual abstract:**

If your vehicle has an IR/solar reflective screen, the antenna should be fitted to another window, i. Clean and dry the internal area of the windscreen on which you want to install the antenna. 3. For optimum performance, install the antenna as near to the top of the windscreen as possible. The antenna must be installed between 4 cm and 10 cm from the vertical pillar (the closer the distance is to 10 cm, without affecting the view of the driver, the better the performance). See the positioning overview diagram for correct positioning. 4. @@ 5. @@ 6. @@ 7.

@@ 8. @@@@ Indd 1 Printed on 100% recycled paper 3/26/2012 4:35:59 PM Fitting instructions • Montageanleitungen • Instructions de montage • Istruzioni per il montaggio • Monteringsvejledning • Montage-instructies 1 Drop roof trim panel (A) - Nehmen Sie die Dach-Verkleidung ab (A) - Abaissez le panneau de garniture de la toiture (A) - Abbassare il pannello di rivestimento del tetto (A) - Dråbeformet tagpynteliste (A) - Laat de hemelbekleding naar beneden zakken (A) 2 Loosen vertical pillar trim panel (B) - Lösen Sie die Verkleidung am vertikalen Holm (B) - Desserrez le panneau de garniture du pilier vertical (B) - Staccare leggermente il pannello di rivestimento del montante verticale (B) - Løsn pyntelisterne på den lodrette dørstolpe (B) - Maak de bekleding van de voorruitstijl los (B) 3 Clean windscreen surface - Reinigen Sie die Oberfläche der Windschutzscheibe - Nettoyez la surface des essuies-glaces - Pulire il parabrezza - Rengør forruden - Reinig de voorruit 4 Pull blue tab to peel off antenna film backing (C) and attach to glass - Ziehen Sie das Klebeband ab und befestigen Sie die Antenne - Enlevez la couche protectrice de l'adhésif et collez l'antenne - Rimuovere l'adesivo e collegare l'antenna - Træk beskyttelsesfolien af klæbepuden, og fastgør antennen. - Verwijder de kleefstrip en bevestig de antenne 4 - 10 cm (B) (C) 5 Peel off the backing film (D) and stick the earth sheet to the metal roof panel (E) out of sight behind the trim/roof panel. Note: You do not have to scrape away any paint from the metal panel, simply stick the earth sheet over the metal panel. @@.



[You're reading an excerpt. Click here to read official ALPINE](http://yourpdfguides.com/dref/5234147)

[KAE-225DA user guide](http://yourpdfguides.com/dref/5234147)

<http://yourpdfguides.com/dref/5234147>