



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ACER ASPIRE 8930G. You'll find the answers to all your questions on the ACER ASPIRE 8930G in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual ACER ASPIRE 8930G**  
**User guide ACER ASPIRE 8930G**  
**Operating instructions ACER ASPIRE 8930G**  
**Instructions for use ACER ASPIRE 8930G**  
**Instruction manual ACER ASPIRE 8930G**

## Aspire 8930 Series

Quick Guide



[You're reading an excerpt. Click here to read official ACER ASPIRE 8930G user guide](http://yourpdfguides.com/dref/1115679)

<http://yourpdfguides.com/dref/1115679>

**Manual abstract:**

Acer Incorporated. All Rights Reserved. Aspire 8930 Series Quick Guide Original Issue: 07/2008 This company makes no representations or warranties, either express or implied, with respect to the contents hereof and specifically disclaims the implied warranties of merchantability or fitness for a particular purpose. @@Changes may be made periodically to the information in this publication without obligation to notify any person of such revisions or changes.

@@@Record the model number, serial number, purchase date and place of purchase information in the space provided below. The serial number and model number are recorded on the label affixed to your computer. All correspondence concerning your unit should include the serial number, model number and purchase information. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronically, mechanically, by photocopy, recording or otherwise, without the prior written permission of Acer Incorporated. Aspire 8930 Series Notebook  
PC Model number: \_\_\_\_\_ Serial number: \_\_\_\_\_ Date of purchase: \_\_\_\_\_  
Place of purchase: \_\_\_\_\_ Acer and the Acer logo are registered trademarks of Acer

Incorporated. @@poster helps you get started with setting up your computer.

@@@@@Such instances are marked in the text with language such as "only for certain models". The Quick Guide introduces you to the basic features and functions of your new computer. For more on how your computer can help you to be more productive, please refer to the AcerSystem User Guide. This guide contains detailed information on such subjects as system utilities, data recovery, expansion options and troubleshooting. @@@@Follow the instructions on the screen to complete the installation.

@@Also called Liquid-Crystal Display (LCD), displays computer output. Turns the computer on and off. @@@Comfortable support area for your hands when you use the computer. @@@Status indicators @@Web camera for video communication. @@Buttons for launching frequently used program.  
10 11 12 13 14 Acer Crystal Eye Empowering key Speakers Easy-launch button 6 English Closed front view # 1 2 Icon Item Speakers 6-in-1 card reader Description Front left, center and front right speakers deliver stereo audio output. Accepts Secure Digital (SD), MultiMediaCard (MMC), MultiMediaCard Plus (MMCplus), Memory Stick (MS), Memory Stick PRO (MS PRO), xD-Picture Card (xD). @@@Connects to a phone line. Connects to an Ethernet 10/100/1000based network. Connects to a display device (e.g., external monitor, LCD projector). Supports high definition digital video connections. Supports high definition digital video connections. Connects to USB 2.

0 devices (e.g., USB mouse, USB camera). Connects to USB 2.0 or eSATA devices (only for certain models). @@@Accepts audio line-in devices (e.g., audio CD player, stereo walkman). 8 English Right view # 1 2 3 4 5 6 7 Icon Item ExpressCard/54 slot Optical drive Optical disk access indicator Optical drive eject button Emergency eject hole 2 USB 2.0 ports TV-in port Description Accepts one ExpressCard/54 module.

Internal optical drive; accepts CDs or DVDs. Lights up when the optical drive is active. Ejects the optical disk from the drive. Ejects the optical drive tray when the computer is turned off. Connect to USB 2.

0 devices (e.g., USB mouse, USB camera). Accepts input signals from analog/ digital TV-tuner devices (only for certain models). 8 Kensington lock slot Connects to a Kensingtoncompatible computer security lock.

9 Base view English # 1 2 3 Icon Item Hard disk bay Memory compartment Ventilation slots and cooling fan Description Houses the computer's hard disk (secured with screws). Houses the computer's main memory. Enable the computer to stay cool, even after prolonged use. Note: Do not cover or obstruct the opening of the fan. 4 Battery bay Houses the computer's battery pack. 5 Battery release latch Releases the battery for removal. 6 Battery lock Locks the battery in position. 10 English Acer CineDash media console Acer CineDash media console is a touch-sensitive entertainment interface that features an ultra-smooth surface, inviting to the touch. Total media control including instant access to Acer Arcade™ Deluxe - provides a new, exciting way to launch and control entertainment. @@Function button: Perform selected function 2.

View image fullscreen 2. Watch video fullscreen 2. Perform movie menu function Select previous menu item 2. @@Stop slideshow 2. @@Stop playing video fullscreen 2. Stop playing music Jump to next video and play fullscreen Select previous menu item Select next menu item Play/pause movie Stop movie Select previous item Select next item Play/pause music Stop playing music 12 Next Jump to next chapter/title and play fullscreen Jump to and play next track 13 Forward Fast forward\* 1.2x, 1.4x, 2x, 4x, 8x, 16x, 32x Rewind\* 1x, 2x, 4x, 8x, 16x, 32x Jump to previous video and play fullscreen Jump to previous chapter/title and play fullscreen Jump forward 5 sec and keep playing Jump back 5 sec and keep playing Jump to and play previous track 14 Rewind N/A 15 Previous Jump to previous image in slideshow 16 Vol Up/ down Increase/decrease volume Note: \* depends on file format 12 English Power subsystem & environment Power subsystem Environment . . . . . ACPI 3.0 71 W 4800 mAh 3-pin 90 W AC adapter ENERGY STAR® 4.0 Temperature: · Operating: 5 °C to 35 °C · Non-operating: -20 °C to 65 °C Humidity (non-condensing): · Operating: 20% to 80% · Non-operating: 20% to 80% English 13 .



[You're reading an excerpt. Click here to read official ACER ASPIRE 8930G user guide](http://yourpdfguides.com/dref/1115679)  
<http://yourpdfguides.com/dref/1115679>