



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ACER ASPIRE E5-511. You'll find the answers to all your questions on the ACER ASPIRE E5-511 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual ACER ASPIRE E5-511
User guide ACER ASPIRE E5-511
Operating instructions ACER ASPIRE E5-511
Instructions for use ACER ASPIRE E5-511
Instruction manual ACER ASPIRE E5-511

Technical Documentation of (EU) No 617/2013

Product type	Notebook computer	
	A	B
Product category	Acer Italy s.r.l., Via Lepetit, 40, 20020 Lainate (MI) Italy	
Manufacturer name, address	Via Lepetit, 40, 20020 Lainate (MI) Italy	
Product model number	Aspire E5-511	
Year of manufacture	2014	
E _{rec} allowance with capability adjustments when discrete graphics cards are disabled (from 1 July 2014)	37.6 kWh/year	49.6 kWh/year
E _{rec} allowance with capability adjustments when discrete graphics cards are enabled (from 1 July 2014)	Not applicable	61.6 kWh/year
E _{rec} allowance with capability adjustments when discrete graphics cards are disabled (from 1 January 2016)	28.6 kWh/year	37.6 kWh/year
E _{rec} allowance with capability adjustments when discrete graphics cards are enabled (from 1 January 2016)	Not applicable	49.6 kWh/year
Whether all discrete graphics card are enabled during the test	Not applicable	No
Whether switchable graphics mode with UMA is driving the display during the test	Not applicable	Yes
E _{rec} of highest power-demanding configuration	17.25 kWh/year	16.71 kWh/year
Idle state power demand	6.48 Watt	7.93 Watt
Sleep mode power demand	0.74 Watt	0.54 Watt
Sleep mode with WOL enabled power demand	0.7 Watt	0.54 Watt
Off mode power demand	0.42 Watt	0.26 Watt
Off mode with WOL enabled power	0.37 Watt	0.26 Watt
Maximum power demand	Not applicable	Not applicable
Internal power supply (IPS) efficiency at 10 %, 20 %, 50 % and 100 % of rated output power	Not applicable	Not applicable
External power supply's (EPS) average active efficiency	86.46%	87.20%
Noise levels (the declared A-weighted sound power level, L _{WA}) of idle mode	2.9 B	2.9 B



[You're reading an excerpt. Click here to read official ACER ASPIRE E5-511 user guide](#)

<http://yourpdfguides.com/dref/5669014>

Manual abstract:

6 kWh/year adjustments when discrete graphics cards Not applicable are enabled (from 1 January 2016) Whether all discrete graphics card are Not applicable enabled during the test Whether switchable graphics mode with Not applicable UMA is driving the display during the test ETEC of highest power-demanding 17. 74 Watt Sleep mode with WOL enabled power 0. 7 Watt demand Off mode power demand 0. 42 Watt Off mode with WOL enabled power 0.

@@@9 B 400 cycles 2~ 8 GB 1 piece 0 piece 0 piece 0 piece Not applicable No 0 mg 2~ 8 GB 1 piece 0 piece 0 piece 1 piece G1 No 2.

@@@@@Determination of the declared noise emission values. @@ installation and operating instructions; 6. @@Method for determination of sound power levels of equipment under essentially free-field conditions over a reflecting plane; Annex C. 15 Equipment category: personal computers and workstations. @@@ENERGY STAR® Program Requirements Sequence of events required to reach the Product Specification for Computers, mode where the equipment automatically Eligibility Criteria Version 6.

@@.



[You're reading an excerpt. Click here to read official ACER ASPIRE E5-511 user guide](http://yourpdfguides.com/dref/5669014)

<http://yourpdfguides.com/dref/5669014>