




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for AEG-ELECTROLUX CYCLONE XL. You'll find the answers to all your questions on the AEG-ELECTROLUX CYCLONE XL in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual AEG-ELECTROLUX CYCLONE XL
User guide AEG-ELECTROLUX CYCLONE XL
Operating instructions AEG-ELECTROLUX CYCLONE XL
Instructions for use AEG-ELECTROLUX CYCLONE XL
Instruction manual AEG-ELECTROLUX CYCLONE XL



[You're reading an excerpt. Click here to read official AEG-ELECTROLUX CYCLONE XL user guide](http://yourpdfguides.com/dref/3659908)
<http://yourpdfguides.com/dref/3659908>

Manual abstract:

Note: Do not use the turbo nozzle on skin rugs or carpet fringes. to avoid damaging the carpet , do not keep the nozzle stationary whilst the brush is rotating. Do not pass the nozzle across electric cables, and be sure to switch off the vacuum cleaner immediately after use. The vacuum cleaner stops automatically if the nozzle, tube, hose or filters become blocked and when the dust container is full. In such cases, disconnect from mains and allow to cool for 0-0 minutes.

*@@Use a cleaning strip or similar to clear the tubes and hose. Hose handle could be dismantled from hose if cleaning is needed. @@@@Be sure to frequently clean the combination floor nozzle. * Press each wheel-hub and draw away the wheels. Remove dust-balls, hair or other objects that may be entangled.*

@@By snipping them away with scissors. Use the hose handle to clean the nozzle. @@By snipping them away with scissors. Use the hose handle to clean the nozzle. @@@This product is designed with the environment in mind.

@@@Close attention is necessary when used near children. The appliance is not intended for use by young children and infirm persons without supervison. The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. @@@.



[You're reading an excerpt. Click here to read official AEG-ELECTROLUX CYCLONE XL user guide](http://yourpdfguides.com/dref/3659908)

<http://yourpdfguides.com/dref/3659908>