



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for AEG-ELECTROLUX EWF16589W. You'll find the answers to all your questions on the AEG-ELECTROLUX EWF16589W in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual AEG-ELECTROLUX EWF16589W**  
**User guide AEG-ELECTROLUX EWF16589W**  
**Operating instructions AEG-ELECTROLUX EWF16589W**  
**Instructions for use AEG-ELECTROLUX EWF16589W**  
**Instruction manual AEG-ELECTROLUX EWF16589W**



[You're reading an excerpt. Click here to read official AEG-ELECTROLUX EWF16589W user guide](http://yourpdfguides.com/dref/5112118)  
<http://yourpdfguides.com/dref/5112118>

**Manual abstract:**

@@Maksimumstemperaturerne er 95° C for bomuld, 60° C for syntetiske stoffer, 40° C for sarte stoffer, uld og stoffer, der skal håndvaskes 30° C for silke. Maksimumhastighederne er: •for bomuld: 1600 o/m; •for syntetiske stoffer, håndvask og uld: 900 o/m. @@@Maskinen foretager desuden 6 skylninger i stedet for 3 ved bomuld og 4 skylninger i stedet for 3 ved syntetisk vask. @@@@Der er vand på gulvet: Der er anvendt for meget eller et uegnet vaskemiddel (danner for meget skum). @@@@Denne lov gælder for skader på andre ting og for personskafer, som skyldes fejl ved selve det installerede produkt. @@.



[You're reading an excerpt. Click here to read official AEG-ELECTROLUX EWF16589W user guide](http://yourpdfguides.com/dref/5112118)  
<http://yourpdfguides.com/dref/5112118>