



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ALPINE CDE-W235BT. You'll find the answers to all your questions on the ALPINE CDE-W235BT in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual ALPINE CDE-W235BT
User guide ALPINE CDE-W235BT
Operating instructions ALPINE CDE-W235BT
Instructions for use ALPINE CDE-W235BT
Instruction manual ALPINE CDE-W235BT

FOR CAR USE ONLY/NUR FÜR AUTOMOBILGEBRAUCH/POUR APPLICATION AUTOMOBILE UNIQUEMENT/PARA USO EN AUTOMÓVILES/SOLO PER L'UTILIZZO IN AUTOMOBILE/ENDAST FÖR BILBRUK/ALLEEN VOOR GEBRUIK IN DE AUTO/ТОЛЬКО ДЛЯ ИСПОЛЬЗОВАНИЯ В АВТОМОБИЛЯХ/DO UŻYCIA TYLKO W SAMOCHODZIE/I/A XPHZH MONO ZE AYTOKINHTO

ALPINE
2-DIN CD RECEIVER WITH ADVANCED BLUETOOTH
CDE-W235BT
2-DIN CD RECEIVER WITH USB AND iPod/iPhone CONTROLLER
CDE-W233R

Bluetooth
iPod iPhone
NORIEA
Bluetooth
iTunes
iPod/iPhone
(CDE-W233BT only)

QUICK REFERENCE GUIDE
Kurzanleitung
GUIDE DE RÉFÉRENCE RAPIDE
GUÍA DE REFERENCIA RÁPIDA
GUIDA RAPIDA
SHABBGUIDE
ΣΗΛΕΤΑΡΤΟΕΔΟ
КРАТКОЕ СПРАВОЧНОЕ РУКОВОДСТВО
SKRÓCZONA INSTRUKCJA DLA UŻYTKOWNIKA
ΟΔΗΓΟΣ ΓΡΗΓΟΡΗΣ ΑΝΑΦΟΡΑΣ

EN
DE
FR
ES
IT
SE
NL
RU
PL
GR

ALPINE ELECTRONICS MARKETING, INC.
1-18 Nishi Gotanda,
Shinagawa-ku,
Tokyo 141-0031, Japan
Phone 03-5466-8211

ALPINE ELECTRONICS OF AMERICA, INC.
19145 Gaemency Plaza, Torrance,
California 90501, U.S.A.
Phone 1-800-ALPINE-1 (1-800-257-4031)

ALPINE ELECTRONICS OF CANADA, INC.
777 Superfund Road, Toronto,
Ontario M2J 2S9, Canada
Phone 1-800-ALPINE-1 (1-800-257-4031)

ALPINE ELECTRONICS OF AUSTRALIA PT. LTD.
101-102 Princess Highway Hillman,
Victoria 3180, Australia
Phone 03-470 7-12 00

ALPINE ELECTRONICS GMBH
Wilhelm-Wagenfeld-Str. 1-3, 89310 Mindchen, Germany
Phone 089-32 42 640

ALPINE ELECTRONICS OF U.K. LTD.
Alpine House
Fitchamstead Highway, Coventry CV4 9TW, U.K.
Phone 0870-33 33 703

ALPINE ELECTRONICS FRANCES A.R.L.
(RCS PONTOISE S 08 101 280)
80, Rue de la Salle Ebolle, Z.I. Paris Nord II,
B.P. 50106, 95105 Rosny-Charles de Gaulle
Cedex, France
Phone 01-48139389

ALPINE BALIA S.p.A.
Viale C. Colombo 8, 30100 Treviso
Sul Naviglio (VA), Italy
Phone 02-494701

ALPINE ELECTRONICS DE ESPAÑA, S.A.
Paseo de Garmena 32, Pabellón 32,
01013 Miraflores (Alcalá) MADRID, Spain
Phone 9-45-203588

ALPINE ELECTRONICS (BE) N.V. GMBH
Lauvennesteenweg 110-110L,
15010 Zaventem, Belgium
Phone 02-272-13 13

YAMAGATA (Wuxi) Co., Ltd.
Block 28-25, Changjiang Nanfu, WND, Jiangsu, China

Designed by ALPINE Japan
Printed in China (P)
08-21627-229-A



[You're reading an excerpt. Click here to read official ALPINE CDE-W235BT user guide](http://yourpdfguides.com/dref/5234440)
<http://yourpdfguides.com/dref/5234440>

Manual abstract:

(As it is data CD, the CD cannot be used for playing back music and images on the player.) If required, an ALPINE dealer will readily provide you with a print out of the Owner's Manual contained in the CD-ROM. 34 1 **IMPORTANT** Please record the serial number of your unit in the space provided below and keep it as a permanent record. Book Page 2 Friday, November 18, 2011 2:40 PM **WARNING** This symbol means important instructions. Failure to heed them can result in serious injury or death. **DO NOT OPERATE ANY FUNCTION THAT TAKES YOUR ATTENTION AWAY FROM SAFELY DRIVING YOUR VEHICLE.** Any function that requires your prolonged attention should only be performed after coming to a complete stop. Always stop the vehicle in a safe location before performing these functions. Excessive volume levels that obscure sounds such as emergency vehicle sirens or road warning signals (train crossings, etc.) can be dangerous and may result in an accident.

Doing so may result in an accident, fire or electric shock. **USE ONLY IN CARS WITH A 12 VOLT NEGATIVE GROUND.** (Check with your dealer if you are not sure. Swallowing them may result in serious injury. Doing so may cause heat to build up inside and may result in fire.

Use for other than its designed application may result in fire, electric shock or other injury. Doing so may result in personal injury or damage to the product. @@Never cut away cable insulation to supply power to other equipment. @@@@Failure to take such precautions may result in fire. @@Using such parts could disable control of the vehicle and cause fire etc.

Doing so may obstruct forward vision or hamper movement etc. Book Page 4 Friday, November 18, 2011 2:40 PM **CAUTION** This symbol means important instructions. Failure to heed them can result in injury or material property damage. **HALT USE IMMEDIATELY IF A PROBLEM APPEARS.** Failure to do so may cause personal injury or damage to the product. Return it to your authorized Alpine dealer or the nearest Alpine Service Center for repairing. The wiring and installation of this unit requires special technical skill and experience. To ensure safety, always contact the dealer where you purchased this product to have the work done. Be sure to use only the specified accessory parts. Use of other than designated parts may damage this unit internally or may not securely install the unit in place.

This may cause parts to become loose resulting in hazards or product failure. Route the cables and wiring away from moving parts (like the seat rails) or sharp or pointed edges. This will prevent crimping and damage to the wiring. If wiring passes through a hole in metal, use a rubber grommet to prevent the wire's insulation from being cut by the metal edge of the hole. Avoid installing the unit in locations with high incidence of moisture or dust. Moisture or dust that penetrates into this unit may result in product failure. Book Page 5 Friday, November 18, 2011 2:40 PM Getting Started / Vorbereitungen / Mise en route English Deutsch Français Turning Power On Press any button (except on. Press and hold SOURCE/ for at least 2 seconds to turn off the unit. Changing the Source TUNER DISC BT AUDIO*2 TUNER USB AUDIO/IPOD*1 AUXILIARY*3 Wechseln der Tonquelle TUNER DISC BT AUDIO*2 TUNER USB AUDIO/IPOD*1 AUXILIARY*3 Changement de source TUNER DISC BT AUDIO*2 TUNER USB AUDIO/IPOD*1 AUXILIARY*3 *1 Only when the iPod/iPhone is connected. Book Page 6 Friday, November 18, 2011 2:40 PM Adjusting Volume Einstellen der Lautstärke Réglage du volume Displaying the Text The display will change every time the button is pressed.

Book Page 7 Friday, November 18, 2011 2:40 PM Radio English Deutsch Français Recalling the TUNER Mode 1 Select the TUNER mode. 3 Press and hold for at least 2 seconds. The tuner will automatically seek and store 6 strong stations in the selected band. @@@@ (Random Play) : The tracks are played back in random sequence. (CD) : Only files in a folder are played back in random sequence.

@@@@: Only files in a folder are repeatedly played back. @@@@@@: All songs in the USB Memory are played back in random sequence. : Only files in a folder are repeatedly played back. @@@@@@ Turn the ignition OFF then ON to complete the setup process. @3 Select the desired name or telephone number.

@@@@@ * This message depends on the voice tag prestored in the mobile phone. Book Page 19 Friday, November 18, 2011 2:40 PM • You can perform this operation only when a voice dial compatible mobile phone is connected. If the mobile phone is not compatible with the voice dial, "NO SUPPORT" is displayed for 2 seconds. □ The Voice Dial function performance depends on the recognition range of the mobile phone and mounting location of the microphone. Please pay attention when the microphone is mounted. □ If a called person that you say is not found, "NO CALL" is displayed for 2 seconds. □ Voice dial operation depends on the function of the mobile phone. For details, refer to the Owner's Manual of the mobile phone. Book Page 20 Friday, November 18, 2011 2:40 PM iPod/iPhone (Optional) / iPod/iPhone (Option) / iPod/iPhone (en option) English An iPod/iPhone can be connected to this unit by using the Interface cable for iPod/ iPhone (included with iPod/iPhone). Recalling the iPod Mode Select the IPOD mode.

Book Page 21 Friday, November 18, 2011 2:40 PM Selecting the desired song Press and release or to skip to the beginning of the current song or the next song. Press and hold or to fast backward or fast forward through the current song.) (Shuffle Albums): Album shuffle playback plays back all songs in order, then randomly selects the next album. (Shuffle Songs): Song shuffle randomly plays back songs within a selected category (playlist, album, etc. Book Page 22 Friday, November 18, 2011 2:40 PM Random Play Shuffle All 1 Press /ENTER to activate the search selection mode. 2 Turn the Rotary encoder to select SHUFFLEALL, and then press /ENTER. : Shuffle ALL plays all songs in the iPod/iPhone randomly. Repeat Play : Only a song is repeatedly played back.

Book Page 23 Friday, November 18, 2011 2:40 PM Searching for a desired Song (iPod/iPhone) / Suche nach einem gewünschten Titel (iPod/iPhone) / Recherche d'un morceau souhaité (iPod/iPhone) Hierarchy 1/Hierarchie 1/Hiérarchie 1 Playlist/Playlist/Liste d'écoute Artist/Interpret/Artiste Album/Album/Album Song/Titel/Morceau Podcast/Podcast/Podcast Genre/Genre/Genre Composer/Komponist/Compositeur Audiobook/Audiobook/Livre parlé Hierarchy 2/Hierarchie 2/Hiérarchie 2 Song/Titel/Morceau Album/Album/Album Song/Titel/Morceau — Episode/Episode/Épisode Artist/Interpret/Artiste Album/Album/Album — Hierarchy 3/Hierarchie 3/Hiérarchie 3 — — — Album/Album/Album Song/Titel/Morceau — Hierarchy 4/Hierarchie 4/Hiérarchie 4 — — — — Song/Titel/Morceau — — — — English Deutsch Français 1 Activate the search selection mode.



[You're reading an excerpt. Click here to read official ALPINE CDE-W235BT user guide](http://yourpdfguides.com/dref/5234440)
<http://yourpdfguides.com/dref/5234440>

Book Page 24 Friday, November 18, 2011 2:40 PM Select the desired search mode.

2 PLAYLIST/ARTIST/ALBUM/SONG/ PODCAST/GENRE/COMPOSER/ AUDIOBOOK •The display of search mode list varies depending on the setting of IPOD LIST. Song Search mode: The selected song is played back. Others Search mode: Proceeds to the next hierarchy level. @@ □ When search is made during M. Play, the M.

@@@@@At the same time, if there is an adjustment request from RDS, the time will be adjusted automatically by RDS data. Book Page 30 Friday, November 18, 2011 2:40 PM •iPhone, iPod, iPod classic, iPod nano, and iPod touch are trademarks of Apple Inc. □ “Made for iPod,” and “Made for iPhone,” mean that an electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod, or iPhone may affect wireless performance.

□ Windows Media, and the Windows logo are trademarks, or registered tra.



[You're reading an excerpt. Click here to read official ALPINE CDE-W235BT user guide](#)

<http://yourpdfguides.com/dref/5234440>