



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ALPINE INE-W925R. You'll find the answers to all your questions on the ALPINE INE-W925R in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual ALPINE INE-W925R  
User guide ALPINE INE-W925R  
Operating instructions ALPINE INE-W925R  
Instructions for use ALPINE INE-W925R  
Instruction manual ALPINE INE-W925R

FOR CAR USE ONLY / AUF FÜR AUTOMOBIL GEBRAUCH / POUR APPLICATION AUTOMOBILE UNIQUEMENT / PARA USO EN AUTOMOVILES / SOLO PER L'UTILIZZO IN AUTOMOBILI / ENDEST FOR BLIBRUK / ALLEEN VOOR GEBRUIK IN DE AUTO / ТОЛЬКО ДЛЯ ИСПОЛЬЗОВАНИЯ В АВТОМОБИЛЯХ / КОДО UZYCIA TYLKO W SAMOCHODZIE / ΑΛΗΚΗΝ ΜΟΝΟ ΣΕ ΑΥΤΟΚΙΝΗΤΟ

**AUDIO/VISUAL SECTION**

**ALPINE**

**ADVANCED NAVI STATION  
INE-W925R**

QUICK REFERENCE GUIDE  
Kurzanleitung  
GUIDE DE RÉFÉRENCE RAPIDE  
GUÍA DE REFERENCIA RÁPIDA  
GUIDA RAPIDA  
SNABBGUIDE  
SNELSTARTGIDS  
КРАТКОЕ СПРАВЧОНОЕ РУКОВОДСТВО  
SKRÓCZONA INSTRUKCJA DLA UŻYTKOWNIKA  
ΟΔΗΓΟΣ ΓΡΗΓΟΡΗΣ ΑΝΑΦΩΡΑΣ

**DIVX MP3 AAC**

EN  
DE  
FR  
ES  
IT  
SE  
NL  
RU  
PL  
GR



[You're reading an excerpt. Click here to read official ALPINE INE-W925R user guide](http://yourpdfguides.com/dref/5234430)  
<http://yourpdfguides.com/dref/5234430>

**Manual abstract:**

**SERIAL NUMBER: ISO SERIAL NUMBER: INSTALLATION DATE: INSTALLATION TECHNICIAN: PLACE OF PURCHASE: AL SE NL RU PL GR** For details on all functions, refer to the Owner's Manual stored in the supplied CD-ROM. (As it is data CD, the CD cannot be used for playing back music and images on the player.) If required, an ALPINE dealer will readily provide you with a print out of the Owner's Manual contained in the CD-ROM. 1-EN ALPINE INE-W925R QRG 68-21057Z83-A (EN) WARNING Gett DO NOT INSTALL IN LOCATIONS WHICH MIGHT HINDER VEHICLE OPERATION, SUCH AS THE STEERING WHEEL OR GEARSHIFT. Doing so may obstruct forward vision or hamper movement etc. Failure to heed them can result in serious injury or death. DO NOT OPERATE ANY FUNCTION THAT TAKES YOUR ATTENTION AWAY FROM SAFELY DRIVING YOUR VEHICLE. Any function that requires your prolonged attention should only be performed after coming to a complete stop. Always stop the vehicle in a safe location before performing these functions. This product is not a substitute for your personal judgment.

Any route suggestions by this system should never supersede any local traffic regulations or your personal judgment or knowledge of safe driving practice. locatio KEEP SMALL OBJECTS SUCH AS SCREWS OUT OF THE REACH OF CHILDREN. Swallowing them may result in serious injury. @@) can be dangerous and may result in an accident. @@ HALT USE IMMEDIATELY IF A PROBLEM APPEARS.

Failure to do so may cause personal injury or damage to the product. @@ DO NOT DISASSEMBLE OR ALTER. Doing so may result in an accident, fire or electric shock. USE ONLY IN CARS WITH A 12 VOLT NEGATIVE GROUND. (Check with your dealer if you are not sure.

@@To ensure safety, always contact the dealer where you purchased this product to have the work done. Doing so may cause heat to build up inside and may result in fire. USE SPECIFIED ACCESSORY PARTS AND INSTALL THEM SECURELY. Be sure to use only the specified accessory parts. Use of other than designated parts may damage this unit internally, or may not securely install the unit in place. This may cause parts to become loose resulting in hazards or product failure. USE THIS PRODUCT FOR MOBILE 12V APPLICATIONS. Use for other than its designed application may result in fire, electric shock or other injury. c DO NOT PLACE HANDS, FINGERS OR FOREIGN OBJECTS IN INSERTION SLOTS OR GAPS. Doing so may result in personal injury or damage to the product.

aRRANGE THE WIRING SO IT IS NOT CRIMPED OR PINCHED BY A SHARP METAL EDGE. Route the cables and wiring away from moving parts (like the seat rails) or sharp or pointed edges. This will prevent crimping and damage to the wiring. If wiring passes through a hole in metal, use a rubber grommet to prevent the wire's insulation from being cut by the metal edge of the hole. MAKE THE CORRECT CONNECTIONS. Failure to make the proper connections may result in fire or product damage. Avoid installing the unit in locations with high incidence of moisture or dust. Moisture or dust that penetrates into this unit may result in product failure. DO NOT SPLICE INTO ELECTRICAL CABLES. Never cut away cable insulation to supply power to other equipment.

Doing so will exceed the current carrying capacity of the wire and result in fire or electric shock. KEEP FINGERS AWAY WHILE THE MOTORIZED FRONT PANEL OR MOVING MONITOR IS IN MOTION. Failure to do so may result in personal injury or damage to the product. f DO NOT DAMAGE PIPE OR WIRING WHEN DRILLING HOLES. When drilling holes in the chassis for installation, take precautions so as not to contact, damage or obstruct pipes, fuel lines, tanks or electrical wiring.

Failure to take such precautions may result in fire. dO NOT USE BOLTS OR NUTS IN THE BRAKE OR STEERING SYSTEMS TO MAKE GROUND CONNECTIONS. Bolts or nuts used for the brake or steering systems (or any other safety-related system), or tanks should NEVER be used for installations or ground connections. Using such parts could disable control of the vehicle and cause fire, etc. 2-EN ALPINE INE-W925R QRG 68-21057Z83-A (EN) Owner's manual Touch operation, Location of Controls, Turning Power On or Off Getting Started DER EL OR etc.

, and Touch operation You can operate the system by using the touch panel on the screen. e Common onscreen buttons : : Returns to the previous screen.

Depending on the function, this button may cancel the operations performed on the screen. Ical skill here you IT A B (Release) button Use this button to remove the front panel. Remote Sensor Point the remote control transmitter towards the remote sensor within a range of 2 meters. (My Favorites) button The My Favorites screen for registered User 1 is displayed. Press and hold this button at least 3 seconds to switch to User 2. (MAP) button Recalls the navigation map screen. (PHONE) button Recalls the Telephone Menu screen. When a hands-free phone is connected, press and hold for at least 3 seconds to switch to the call history screen.

(AUDIO) button Displays the Audio/Visual screen. If the Audio/Visual screen is already displayed, changes the source. Press and hold AUDIO for at least 3 seconds to activate the "Setting the Balance/Fader/Subwoofer" mode. H I G Rotary encoder/MUTE/C button Adjust the volume by turning to the left or right. press to activate /deactivate the mute mode. Press and hold for at least 3 seconds to turn the power off. HEM r than securely e resulting SE NL RU PL GR C

INCHED e seat rails) mage to the grommet dge of the D E URE OR moisture esult in NT PANEL F he product. 3-EN ALPINE INE-W925R QRG 68-21057Z83-A (EN) Turning Power On or Off 1 2 Abo Turn the ignition key to the ACC or ON position. The system is turned on. @@ audio/Visu \*1 During Dual S You can s To switch position.

@@ @@@@ @@@@ @@@@ The screens will switch positions when you remove your finger. @@ Configure the User 1 and User 2 settings for each user. Preset butt Displays the short touch. The user name input screen for the first user is displayed. @@ In this case, the users will not be switched automatically.

@@ The system starts searching for BLUETOOTH devices. When the search is completed, the BLUETOOTH Device List is displayed. @@@@ @@@@ Press and hold the (My Favorites) button for at least 3 seconds. the My Favorites user guide is displayed. Repeat steps 2 through 6 to register USER 2.

Preset butt Displays the short touch. @@@@ @@@@ The following is an example of the DVD-VIDEO operation screen. @@@@ @@@@ /Total song no. @@ The Albums search screen of the selected artist is displayed. @@@@ All songs of the selected album are displayed. Touching [p] of the desired album will play back all songs of the selected album. acks Touch the desired song's name. The selected song is played back. □ Touching [p] of "ALL" will play back all songs in the list. 9-EN ALPINE INE-W925R QRG 68-21057Z83-A (EN) Owner's manual USB Memory (Optional) USB Memory Operation (Optional) You can play back music files (MP3/WMA/AAC) and video files (DivX®) stored in a USB memory device on the internal player of this system.



[You're reading an excerpt. Click here to read official ALPINE INE-W925R user guide](http://yourpdfguides.com/dref/5234430)

<http://yourpdfguides.com/dref/5234430>

Refer to the "MP3/WMA/AAC Operation" (page 7) for information on music. Finds the beginning of the current file/Finds a previous file within one second after playback starts/Fastreverses when touched for at least 2 seconds Finds the beginning of next file/Fast-forwards when touched for at least 2 seconds How to compa 1 To DivX® information display Elapsed time Displays the search screen Pause and Playback Repeat Playback Stop Playback Finds beginning of previous folder Finds beginning of next folder Changes operation button Displays the search screen 2 3 4 To To To "O Switches Audio Tracks Changes operation button Switches Subtitles 5 6 To To 7 To The 10-EN ALPINE INE-W925R QRG 68-21057Z83-A (EN) al) Owner's manual BLUETOOTH Setting, BLUETOOTH Operation Hands-Free Phone Control the Hands-free calls are possible when using an HFP (Hands-Free Profile) compatible mobile phone with the INEW925R. how to connect to a BLUETOOTH compatible device (Pairing) otal file no. Ing of wards r at least 8 Touch [Audio] or [Hands-free] of the device you want to connect from the list. □ 9 When the device registration is complete, a message appears and the devicused individually. □ If the switched power (ignition) lead of the INE-W925R is connected directly to the positive (+) post of the vehicle's battery, the INE-W925R draws some current (several hundred milliamperes) even when its switch is placed in the OFF position, and the battery may be discharged. 13-EN ALPINE INE-W925R QRG 68-21057Z83-A (EN) Owner's manual Connections Connections 1/2 Antenna ISO Antenna Plug Conne GPS Antenna (Included) iPod/iPhone (Sold separately) Connection kit KCU-461iV (Sold separately) Nokia Phone (Sold separately) iPod VIDEO AV extension cable (Included with KCU-461iV) USB Memory (Sold separately) USB extension cable (Included) Nokia Phone connection kit KCU-230NK (Sold separately) REMOTE TURN-ON (Blue/White) REVERSE (Orange/White) PARKING BRAKE (Yellow/Blue) To amplifier or equalizer To plus side of the back lamp signal lead of the car To the parking brake signal lead To power antenna IGNITION (Red) GND (Black) POWER ANT (Blue) BATTERY (Yellow) 10A (Green) Rear left (Green/Black) (White) Front left (White/Black) (Gray/Black) Front right (Gray) (Violet/Black) (Violet) Rear right Speakers Ignition key Battery 14-EN ALPINE INE-W925R QRG 68-21057Z83-A (EN) Connections 2/2 REMOTE OUT (Brown) REMOTE IN (Brown) SPEED SENSOR (Green/White) CAMERA1 To remote input lead To remote output lead To the vehicle speed pause line To Front/Rear camera To Rear/Other camera EN DE FR ES IT CAMERA2 4P Connector (Not Used) To steering remote control interface box To DAB antenna Microphone (Included) Connect this to the optional Vehicle Display Interface box car (Yellow) (Red) (White) (Yellow) (Red) (White) To Audio Input terminals (R, L) To Audio Output terminals (R, L) To Video Output terminal SE NL RU PL GR To Video Input terminal Rear Left Amplifier Rear Right Front Left Amplifier Front Right Amplifier Subwoofers 15-EN ALPINE INE-W925R QRG 68-21057Z83-A (EN) Owner's manual Specifications Specifications MONITOR SECTION Screen Size LCD Type Operation System Number of Picture Elements 6. 1" Transparent type TN LCD TFT active matrix Total Harmonic Distortion Dynamic Range Channel Separation Signal system Horizontal resolution Video output level Video S/N ratio Audio S/N ratio 0. 008% (at 1 kHz) 95 dB (at 1 kHz) 85 dB (at 1 kHz) NTSC/PAL 500 lines or greater 1Vp-p (75 ohms) DVD: 60 dB 100 dB • This ite that is proper engine • Manufa Dolby a Dolby 1,152,000 pcs. (800 × 3 × 480) Effective Number of Picture Elements 99% or more Illumination System LED • Windo or regis the Un PICKUP Wave length DVD: 666 nm CD: 785 nm CLASS II • iPhone iTunes U. 2 V/10k ohms • The BL tradem use of licence • "MPEG Fraunh • "Supply private a licenc any co broadc other m intrane conten audio-o licence http://w ©1993-20 Portions © Reserved. 5 mm \* Frequency response may differ depending on the encoder CD/DVD SECTION Frequency Response Wow & Flutter (% WRMS) 5 – 20,000 Hz (±1 dB) Below measurable limits • Due to continuous product improvement, specifications and design are subject to change without notice. This means that there is a possibility that 0. 01% of the pixels could be either always ON or OFF. Patents and other intellectual property rights of Rovi Corporation.

Dolby and the double-D symbol are trademarks of Dolby Laboratories. □ Windows Media, and the Windows logo are trademarks, or registered trademarks of Microsoft Corporation in the United States and/or other countries. EN DE FR ES IT SE NL RU PL GR • iPhone, iPod, iPod classic, iPod nano, iPod touch, and iTunes are trademarks of Apple Inc. □ "Made for iPod," and "Made for iPhone," mean that an electronic accessory has been designed to connect specifically to iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.

Please note that the use of this accessory with iPod, or iPhone may affect wireless performance. □ DivX®, DivX Certified® and associated logos are mote trademarks of Rovi Corporation or its subsidiaries and are used under license. □ The BLUETOOTH® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. □ • "Supply of this product only conveys a licence for private,non-commercial use and does not convey a licence nor imply any right to use this product in any commercial (i. e. Revenue-generation) real time broadcasting (terrestrial, satellite, cable and/or any other media), broadcasting/streaming via internet, intranets and/or other networks or in other electronic content distribution systems, such as pay-audio or audio-on-demand applications. An independent licence for such use is required. For details, please visit http://www. □ „Made for iPod“ und „Made for iPhone“ bedeuten, dass ein elektronisches Zubehör speziell für den Anschluss eines iPod bzw. □ "Made for iPod", y "Made for iPhone", significa que un otencia 2) perfil perfil ss Profile, nda) de e audio) mote control accesorio electrónico se ha diseñado exclusivamente para conectarse a un iPod o iPhone, respectivamente, y su cumplimiento de las normas de funcionamiento de Apple ha sido certificado por los programadores.

□ "Made for iPod," e "Made for iPhone," significano che un accessorio elettronico è stato progettato per essere collegato specificatamente a un iPod o a un iPhone, rispettivamente, e ha la certificazione dallo sviluppatore di soddisfare gli standard di prestazione di Apple.



[You're reading an excerpt. Click here to read official ALPINE INE-W925R user guide](http://yourpdfguides.com/dref/5234430)  
<http://yourpdfguides.com/dref/5234430>

Användandet av andra delar än som är avsedda för denna apparat kan leda till att apparaten skadas invändigt eller till ostadig montering på grund av lossnande delar. /Totalt antal låtar Slumpvis uppspelning Söskärmen visas Förfluten tid Paus och Uppspelning Upprepad spelning MP3/WMA/AAC informationsdisplay Går till början av nästa fil/Snabbspolar framåt om du pekar på knappen längre än 2 sekunder Anv En iPod/i ansluter e Ljudlåg Visning av Går till börj fil/Går till f om du pek inom en se uppspelnin Snabbspol på knappe Aktuellt låt Söskärme Förfluten t Paus och U Hittar början av föregående mapp Hittar början av nästa mapp Söskärmen visas Går till börj Artist/Albu Användarhandledning DVD Ikon för dir DVD-funktion När du pekar på dvd-uppspelningsskärmen, visas funktionsskärmen DVD. nedan visas ett exempel på en DVDVIDEO-funktionsskärm. @@@@ Styr Du kan ri handsfree Videoläge Går till början av nuvarande fil/Går till föregående fil om du pekar på knappen inom en sekund efter uppspelningsstarten/ Snabbspolar bakåt om du pekar på knappen längre än 2 sekunder DivX® informationsdisplay Förfluten tid Söskärmen visas Paus och Uppspelning Upprepad spelning Nuvarande filnr. □ "Made for iPod," och "Made for iPhone," innebär att ett elektroniskt tillbehör har utvecklats specifikt för att anslutas till iPod respektive iPhone och har certifierats av utvecklaren så att de uppfyller de prestandakrav som Apple ställer. □ "Made for iPod", en "Made for iPhone", betecknen dat een elektronische accessoire specifiek werd ontworopen om te worden aangesloten op een iPod of iPhone en gecertificeerd is door de ontwikkelaar om te beantwoorden aan de prestatienormen van Apple. □ "Made for iPod" u "Made for iPhone" o3 □ Etykiety „Made for iPod" (przeznaczone dla odtwarzacza iPod) oraz „Made for iPhone" (przeznaczone dla telefonu iPhone) oznaczają, że urządzenie elektroniczne zostało zaprojektowane specjalnie pod kątem możliwości podłączenia do odtwarzacza iPod lub telefonu iPhone i zostało certyfikowane przez producenta jako spełniające standardy jakości firmy Apple. □ "Made for iPod," και "Made for iPhone," ση .



[You're reading an excerpt. Click here to read official ALPINE INE-W925R user guide](http://yourpdfguides.com/dref/5234430)  
<http://yourpdfguides.com/dref/5234430>