



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ALPINE TME-M780. You'll find the answers to all your questions on the ALPINE TME-M780 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual ALPINE TME-M780
User guide ALPINE TME-M780
Operating instructions ALPINE TME-M780
Instructions for use ALPINE TME-M780
Instruction manual ALPINE TME-M780



TME-M780

7.0-INCH WIDE VGA LCD MONITOR WITH
BLACK BOX FOR REAR SEAT ENTERTAINMENT

TME-M780EM

EXTRA MONITOR FOR TME-M780

- OWNER'S MANUAL
Please read before using this equipment.
- BEDIENUNGSANLEITUNG
Lesen Sie diese Bedienungsanleitung bitte vor Gebrauch des Gerätes.
- MODE D'EMPLOI
Veuillez lire avant d'utiliser cet appareil.
- MANUAL DE OPERACIÓN
Léalo antes de utilizar este equipo.
- ISTRUZIONI PER L'USO
Si prega di leggere prima di utilizzare l'attrezzatura.
- ANVÄNDARHÄNDBOK
Innan du använder utrustningen bör du läsa igenom denna användarhandledning.

EN

DE

FR

ES

IT

SE

ALPINE ELECTRONICS, INC. Tokyo office: 1-18-1001, Ohtaera, Shinagawa-ku, Tokyo 141-8501, Japan Tel.: (33) 3494-1101	ALPINE ELECTRONICS OF AUSTRALIA PTY. LTD. 6-8 Farnley Road, Brisbane Region, Victoria 3173, Australia Tel.: (03) 8769-0000	ALPINE ELECTRONICS FRANCE S.A.S. (RCS) PROVISEUR 388 100 280 98, Rue De La Belle Étoile, Z.I. Paris Nord II, B.P. 10019, F-93066, Puteaux, Cedex De Gaulle, France Tel.: 01-48-60-89-88
ALPINE ELECTRONICS OF AMERICA, INC. 10445 Gateway Plaza, Torrance, California 90501, U.S.A. Tel.: 1-800-ALPINE1 (1-800-257-4811)	ALPINE ELECTRONICS GMBH Frankfurter Ring 177-80807 Munich, Germany Tel.: 089-32-42-640	ALPINE ELECTRONICS OF U.K., LTD. 13 Tanners Drive, Blandford, Milton Keynes MK43 9BZ, U.K. Tel.: 01908-611598
ALPINE ELECTRONICS OF CANADA, INC. Suite 203, 7500 Woodbine Ave. Markham, Ontario L3R 9Z9, Canada Tel.: 1-800-ALPINE1 (1-800-257-4811)	ALPINE ITALIA S.p.A. Via G. Odorico 8, 20098, Tezzano S/N Naviglio, MI, Italy Tel.: 02-4847481	ALPINE ELECTRONICS OF ESPAÑA, S.A. Paseo Duquesa 96, Pedreña 33, 01013 Vitoria (Álava) Auto. 133, Spain Tel.: 34-41-826588
	ALPINE ELECTRONICS DE BELGIË GMBH Louvain-la-Neuve 110-08, 1990 Zaventem, Belgium Tel.: 02-728-1314	



[You're reading an excerpt. Click here to read official ALPINE TME-M780 user guide](http://yourpdfguides.com/dref/1080474)
<http://yourpdfguides.com/dref/1080474>

Manual abstract:

0-INCH WIDE VGA LCD MONITOR WITH BLACK BOX FOR REAR SEAT ENTERTAINMENT EN DE TME-M780EM EXTRA MONITOR FOR TME-M780
· OWNER'S MANUAL Please read before using this equipment. · BEDIENUNGSANLEITUNG Lesen Sie diese Bedienungsanleitung bitte vor Gebrauch des
Gerätes. · MODE D'EMPLOI Veuillez lire avant d'utiliser cet appareil. · MANUAL DE OPERACIÓN Léalo antes de utilizar este equipo. · ISTRUZIONI PER
L'USO Si prega di leggere prima di utilizzare l'attrezzatura. · ANVÄNDARHANDLEDNING Innan du använder utrustningen bör du läsa igenom denna
användarhandledning. FR ES IT ALPINE ELECTRONICS, INC. Tokyo office: 1-1-8 Nishi Gotanda, Shinagawa-ku, Tokyo 141-8501, Japan Tel.: (03)

3494-1101 ALPINE ELECTRONICS OF AMERICA, INC. 19145 Gramercy Place, Torrance, California 90501, U.

S.A. Tel.: 1-800-ALPINE-1 (1-800-257-4631) ALPINE ELECTRONICS OF CANADA, INC. Suite 203, 7300 Warden Ave.

Markham, Ontario L3R 9Z6, Canada Tel.: 1-800-ALPINE-1 (1-800-257-4631) ALPINE ELECTRONICS OF AUSTRALIA PTY. LTD. 6-8 Fiveways
Boulevard Keysborough, Victoria 3173, Australia Tel.: (03) 9769-0000 ALPINE ELECTRONICS GmbH Frankfurter Ring 117 80807 Munich, Germany Tel.
: 089-32 42 640 ALPINE ITALIA S.p.A. Via C. @@ (RCS PONTOISE B 338 101 280) 98, Rue De La Belle Etoile, Z.I. Paris Nord II B.P. @@13 Tanners

Drive, Blakelands, Milton Keynes MK14 5BU, U.K.

Tel.: 01908-61 15 56 ALPINE ELECTRONICS DE ESPAÑA, S.A. Portal De Gamarra 36, Pabellón 32 01013 Vitoria (Alava)-Apdo. @@2 CAUTION

.....

.....

.....

.....

.....

.....

..... 3 PRECAUTIONS

.....

.....

.....

.....

..... @@8 Caution

.....

.....

.....

.....

.....

.....

.....

..... 8 Precautions ..

.....

.....

.....

.....

.....

.....

.....

.... 9 Installation

.....

.....

.....

.....

.....

.....

..... 10 Connections ..

.....

.....

.....

.....

.....

.....

.....

11 Basic Operation Screen Display ON/OFF

.....

.....

.....

..... 4 Adjusting the Volume

.....

.....

.....

.....

..... 4 Switching the Source ...

.....

.....

.....

.....

.....

... 4 Switching the display mode ..

.....

.....

.....

.... 5 Adjusting .

.....

.....

.....

.....

.....

.....

.....

.... 5 Other Useful Feature Remote Control Sensor .

.....

.....

.....

.....

..... 6 Information In Case of Difficulty ...

.....

.....

.....

.....

..... 7 Specifications .

.....

.....

.....

.....

.....

.....

.....

.. 7 1-EN WARNING WARNING This symbol means important instructions. Failure to heed them can result in serious injury or death. DO NOT WATCH VIDEO WHILE DRIVING. Watching the video may distract the driver from looking ahead of the vehicle and cause an accident. DO NOT OPERATE ANY FUNCTION THAT TAKES YOUR ATTENTION AWAY FROM SAFELY DRIVING YOUR VEHICLE. Any function that requires your prolonged attention should only be performed after coming to a complete stop. Always stop the vehicle in a safe location before performing these functions. Failure to do so may result in an accident.

INSTALL THE PRODUCT CORRECTLY SO THAT THE DRIVER CANNOT WATCH TV/VIDEO UNLESS THE VEHICLE IS STOPPED AND THE EMERGENCY BRAKE IS APPLIED. It is dangerous (and illegal in many states) for the driver to watch TV/Video while driving a vehicle. Installing this product incorrectly enables the driver to watch TV/Video while driving. This may cause a distraction, preventing the driver from looking ahead, thus causing an accident. The driver or other people could be severely injured.

KEEP THE VOLUME AT A LEVEL WHERE YOU CAN STILL HEAR OUTSIDE NOISE WHILE DRIVING. Failure to do so may result in an accident.

MINIMIZE DISPLAY VIEWING WHILE DRIVING. Viewing the display may distract the driver from looking ahead of the vehicle and cause an accident. **DO NOT DISASSEMBLE OR ALTER.**

Doing so may result in an accident, fire or electric shock. **USE THIS PRODUCT FOR MOBILE 12V APPLICATIONS.** Use for other than its designed application may result in fire, electric shock or other injury. **KEEP SMALL OBJECTS SUCH AS BATTERY OUT OF THE REACH OF CHILDREN.** Swallowing them may result in serious injury. If swallowed, consult a physician immediately. **USE THE CORRECT AMPERE RATING WHEN REPLACING FUSES.** Failure to do so may result in fire or electric shock. **2-EN CAUTION** This symbol means important instructions. Failure to heed them can result in injury or material property damage.

PRECAUTIONS Temperature Be sure the temperature inside the vehicle is between +45°C (+113°F) and 0°C (+32°F) before turning your unit on. **HALT USE IMMEDIATELY IF A PROBLEM APPEARS.** Failure to do so may cause personal injury or damage to the product. Return it to your authorized Alpine dealer or the nearest Alpine Service Centre for repairing. **Fuse Replacement** When replacing the fuse(s), the replacement must be of the same amperage as shown on the fuse holder. If the fuse(s) blows more than once, carefully check all electrical connections for shorted circuitry. Also have your vehicle's voltage regulator checked. **Maintenance** If you have problems, do not attempt to repair the unit yourself. @@This is an effect peculiar to LCD technology and is normal. @@@@To turn off the POWER, press the POWER button again.

@@@This is an effect peculiar to LCD technology and is normal. @@@@Adjustment screen will appear. Press the DISP button and select the mode to be adjusted. or button. Adjust by pressing the DISP or : Selects the mode.

@@@@@@@@@@@@@@@@This guide will help you isolate the problem if the unit is at fault. @@- Turn the ignition on. - No fuse or blown fuse. - Check the cause and replace the fuse. - Incorrect connections.

- Check connection and remedy. - Vehicle's battery is weak. @@- Adjust the brightness. @@@@Adjustment screen will appear. Press the DISP button and select the mode to be adjusted. or button. Adjust by pressing the DISP or : Selects the mode. - Protective circuit is on because of high temperature. @@@@Its effective pixel ratio is over 99.99%. @@- Check each control. Spots or dotted lines/stripes appear.

- Caused by neon signs, high-voltage power lines, CB transmitter, other vehicle's ignition plugs, etc. - Change the location of your vehicle. Unit does not operate. - Monitor's power is not turned on. - Turn on the monitor's power. **7-EN Installation and Connections** Before installing or connecting the unit, please read the following and pages 2 and 3 of this manual thoroughly for proper use. **DO NOT DAMAGE PIPE OR WIRING WHEN DRILLING HOLES.** When drilling holes in the chassis for installation, take precautions so as not to contact, damage or obstruct pipes, fuel lines, tanks or electrical wiring. Failure to take such precautions may result in fire. **Warning MAKE THE CORRECT CONNECTIONS.**

Failure to make the proper connections may result in fire or product damage. **DO NOT INSTALL THE MONITOR NEAR THE PASSENGER SEAT AIR BAG.** If the unit is not installed correctly the air bag may not function correctly and when triggered the air bag may cause the monitor to spring upwards causing an accident and injuries. **USE ONLY IN CARS WITH A 12 VOLT NEGATIVE GROUND.** (Check with your dealer if you are not sure.)

) Failure to do so may result in fire, etc. **BEFORE WIRING, DISCONNECT THE CABLE FROM THE NEGATIVE BATTERY TERMINAL.** Failure to do so may result in electric shock or injury due to electrical shorts. **Caution HAVE THE WIRING AND INSTALLATION DONE BY EXPERTS.** The wiring and installation of this unit requires special technical skill and experience.

To ensure safety, always contact the dealer where you purchased this product to have the work e the unit on the location chosen for installation.



[You're reading an excerpt. Click here to read official ALPINE TME-M780 user guide](http://yourpdfguides.com/dref/1080474)
<http://yourpdfguides.com/dref/1080474>

2. Mark the screw locations using the unit as a template. 3. Drill a hole less than 3 mm in diameter. **WARNING** When you are drilling a hole in the car body, be careful not to damage pipes, tanks or electrical wiring etc.. It might cause an accident or a fire. 4. Firmly attach the unit using 4 of the supplied selftapping screws (M4 x 15).

Self-tapping screws (M4 x 15) 10-EN Connections Make connections correctly. Improper connections may cause a fire or operation failure. Basic connection TME-M780 TME-M780EM Monitor 1 Monitor 2 11-EN Installation and Connections ACC power lead (Red) To ACC power lead powered when engine key position is ACC. Parking brake lead (Yellow/Blue) Connect this lead to the parking brake lead powered when parking brake is pulled. Remote control output lead (White/Brown) To remote control input lead of ALPINE products used in the system. Ground lead (Black) Connect the lead to a good chassis ground on the vehicle. Make sure the connection is made to bare metal and is securely fastened using the sheet metal screw provided. Fuse (7.5A) Headphones (sold separately) Main monitor Extra monitor Connection cable AUX3 Selection S/W Audio input connectors (AUX 1) Use these connectors to input the audio signals from a DVD player, TV tuner etc. Video input connector (AUX 1) Use this connector to input the video signals from a DVD player, TV tuner etc. Audio input connectors (AUX 2) Use these connectors to input the audio signals from a DVD player, TV tuner etc. Video input connectors (AUX 2) Use this connector to input the video signals from a DVD player, TV tuner etc. If If AUX3 SELECTION S/W "IN" position Audio input / output connectors (AUX 3) Use these connectors to input the audio signals from a DVD player, TV tuner etc. @@@@ To prevent external noise from entering the audio system. @@ - Keep the battery power leads as far away from other leads as possible.

· Connect the ground lead securely to a bare metal spot (remove the coating if necessary) of the car chassis. · If you add an optional noise suppressor, connect it as far away from the unit as possible. Your Alpine dealer carries various Alpine noise suppressors, contact them for further information. · Your Alpine dealer knows best about noise prevention measures so consult your dealer for further information. 12-EN .



[You're reading an excerpt. Click here to read official ALPINE TME-M780 user guide](http://yourpdfguides.com/dref/1080474)

<http://yourpdfguides.com/dref/1080474>