




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ALPINE TUE-T012. You'll find the answers to all your questions on the ALPINE TUE-T012 in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual ALPINE TUE-T012 User guide ALPINE TUE-T012 Operating instructions ALPINE TUE-T012 Instructions for use ALPINE TUE-T012 Instruction manual ALPINE TUE-T012



You're reading an excerpt. [Click here to read official ALPINE TUE-T012 user guide](http://yourpdfguides.com/dref/5199582)
<http://yourpdfguides.com/dref/5199582>

Manual abstract:

The serial number plate is located on the bottom of the unit. □ – ••••• Be sure to disconnect the cable from the (–) battery post before installing your TUE-T012. This will reduce any chance of damage to the unit in case of a short-circuit. When replacing a blown fuse, make sure to replace it with one of the same value. Be sure to connect the color coded leads according to the diagram. Incorrect connections may cause the unit to malfunction or damage the vehicle's electrical system. This unit is designed for 12 VDC, negative ground systems. Make sure your vehicle has this type of electrical system before connecting the power cable. When making connections to the car's electrical system, be aware of the factory installed components (e. Do not tap into these leads to provide power for this unit.

When connecting the TUE-T012 to the fuse box, make sure the fuse for the intended circuit of the TUE-T012 has the appropriate amperage. Failure to do so may result in damage to the unit and/or the vehicle. When in doubt, consult your ALPINE dealer. Poi iniziate l'installazione seguendo uno dei seguenti procedimenti: Installation Installation des TV TUNERS Instalación Instalación del SINTONIZADOR DE TV This TV TUNER can be placed inside the trunk, on the kick panel of the front passenger's seat or underdash. @@@@ Make sure you have all the necessary parts and tools.

@@@@ 2. @@ Do not cover the serial number. 3. @@ 4. Remove the protective strip from the other side of the Velcro pad.

5. Press the unit onto its mounting location. @@ Peel off the base paper and put on the antenna. Clean dirty of the mounting locations, and then put on the antenna. @@@@ 1/ To prevent external noise from entering the audio system. @@@@ @@@@ @@@@ @@@@ @@@@ Your Alpine dealer knows best about noise prevention measures so consult your dealer for further information. 1 2 3 1 Audio Interrupt Lead (Pink/Black) 2 Guide control input lead (White/Green) Connect the lead to the guide control output lead of the ALPINE navigation unit. 3 Display control input lead (Yellow/Red) Connect the lead to the display control input lead of the ALPINE navigation unit. 4 Dimmer input lead (White/Blue) To dimmer lead powered when position lamp switch is on. 4 5 6 9 7 5 Parking brake lead (Yellow/Blue) Connect this lead to the parking brake lead powered when parking brake is pulled.

6 Remote control output lead (White/ Brown) To remote control input lead of ALPINE product used in combination. 7 ACC power lead (Red) To ACC power lead powered when engine key position is ACC. 8 Ground lead (Black) Connect the lead to a good chassis ground on the vehicle. @@ fuse Parking brake aux. @@@@.



[You're reading an excerpt. Click here to read official ALPINE TUE-T012 user guide](#)

<http://yourpdfguides.com/dref/5199582>