



# Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ALPINE TUE-T150DV. You'll find the answers to all your questions on the ALPINE TUE-T150DV in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

**User manual ALPINE TUE-T150DV**  
**User guide ALPINE TUE-T150DV**  
**Operating instructions ALPINE TUE-T150DV**  
**Instructions for use ALPINE TUE-T150DV**  
**Instruction manual ALPINE TUE-T150DV**

ENGLISH

EN

**Contents**

**Operating Instructions**

**WARNING**

**WARNING** ..... 4  
**CAUTION** ..... 4  
**PRECAUTIONS** ..... 5  
**SAFETY** ..... 5  
**Controls on remote control** ..... 6

**Basic Operations**

Getting Started ..... 7  
Installation ..... 8, 9  
STB Setup ..... 10, 11, 12  
Viewer's Preference ..... 13  
Signal Strength ..... 13  
About Box ..... 13  
Hot Keys ..... 14, 15, 16, 17

**Information**

OSD Structure ..... 18

**Installation & Connections**

**WARNING** ..... 19  
**CAUTION** ..... 19  
**PRECAUTIONS** ..... 20  
Installation ..... 20  
**Connections & System Wiring** ..... 21  
**Specifications** ..... 22

3-EN



[You're reading an excerpt. Click here to read official ALPINE TUE-T150DV user guide](http://yourpdfguides.com/dref/1080422)  
<http://yourpdfguides.com/dref/1080422>

*Manual abstract:*

.....  
.....  
.....  
.....

.....  
.....  
... 4 CAUTION ..  
.....

.....  
.....  
.....  
.....

..... 4 PRECAUTIONS ..

.....  
.....  
.....

.....  
.....

.... 5 SAFETY .

.....  
.....

.....  
.....  
.....

.. 5 Controls on remote control ...

.....  
.....

.... 6 Basic Operations Getting Started .....

.....  
.....  
.....

.....  
.....

7 Installation .....

.....  
.....

.....  
.....

..... 8, 9 STB Setup ...

.....  
.....  
.....  
.....

.... 10, 11, 12 Viewer's Preference .....

.....  
.....  
.....

..... 13 Signal Strength ...

.....  
.....  
.....





frequencies. If this search is unsuccessful the TUE-T150DV will request the user to choose whether to accept this information is sent by the broadcast.

If swallowed, consult a physician immediately. DO NOT INSTALL IN LOCATIONS WHICH MIGHT HINDER VEHICLE OPERATION, SUCH AS THE STEERING WHEEL OR GEARSHIFT. Doing so may obstruct forward vision or hamper movement etc. and results in serious accident. 19-EN 1-EN Precautions Be sure to disconnect the cable from the (-) battery post before installing your TUE-T150DV. This will reduce any chance of damage to the unit in case of a shortcircuit. · Be sure to connect the color coded leads according to the diagram. Incorrect connections may cause the unit to malfunction or damage the vehicle's electrical system. · When making connections to the car's electrical system, be aware of the factory installed components (e.g. on-board computer). Do not tap into these leads to provide power for this unit. When connecting the TUE-T150DV to the fuse box, make sure the fuse for the intended circuit of the TUE-T150DV has the appropriate amperage. Failure to do so may result in damage to the unit and/or the vehicle. When in doubt, consult your ALPINE dealer.

· The TUE-T150DV uses female RCA-type jacks for connection to other units (e.g. amplifier) having RCA connectors. You may need an adaptor to connect other units. If so, please contact your authorized ALPINE dealer for assistance.

Installation Installing TV TUNER This TV TUNER can be placed inside the trunk, on the kick panel of the front passenger's seat or underdash. However, to avoid unnecessary signal wiring, it is better to mount the TV TUNER as close as possible to the Display. DO NOT MOUNT THE UNIT IN LOCATIONS THAT WILL BE IN THE VICINITY OF MOISTURE OR EXTREME HEAT (such as the engine compartment). 20-EN 20-EN Installation and Connections Connections and System Wiring Diagram MOBILE MEDIA STATION IVA-W200Ri EN iPod 9 MENU RDS POWER SOURCE TA AUX IN VIDEO 4 5 1 POWER KCE-415i VIDEO INTERFACE ADAPTER S-VIDEO C.VIDEO R AUDIO L OUTPUT LEFT IPOD RIGHT C.VIDEO S-VIDEO FRONT VIDEO CAMERA IN S-VIDEO 6 ANTENNA INPUT 7 1 Red Black White/Brown 12 17 15 POWER 2 8 2 3 EXT. REMOTE EYE INPUT RESET MODE POWER SUPPLY DIGITAL TV-TUNER UNITTUE-T150DV Yellow Red Yellow/Blue Orange/White White/Brown White/Brown Blue Black 11 ACC BATT 10 12 13 15 16 17 18 14 1 2 3 Antenna input socket (F-plug/female) with integrated 5V/30mA power supply. 9 External IR sensor Connect to a live terminal in the fuse block connecting to the car battery (bypassing the ignition switch). Reset button Mode switches for starting software download and erasing the EEPROM -Selecting the video output format (factory default is PAL): 1. Turn TUE-T150DV on 2.

Set both DIP switches to down position 3. Select the video system by pressing the RESET button PAL NTSC SECAM 10 Battery lead (yellow) 11 Fuse holder (3.0A) 12 Switched power lead (Ignition) (red) 13 Parking brake lead (yellow/blue) 12 Connect to an accessory terminal in the fuse block. 12 4. Set both DIP switches to up position! 1. Turn TUE-T150DV on 2. Switch DIP1 to the up position and DIP2 to the down position 3. Press the RESET button and wait for 10 sec. until the deletion is finished 4. Set both DIP switches to up position! 5.

Press once again the RESET button -Erasing the EEPROM (reset to factory default): 12 Connect to parking brake or metallic body or chassis of the car. 14 Reverse Lead (orange/white) Use when connecting a rear view camera. Connect to a Reverse gear activated 12 volt signal. @@@@ @@@@19145 Gramercy Place, Torrance, California 90501, U.S.

A. Phone 1-800-ALPINE-1 (1-800-257-4631) ALPINE ELECTRONICS OF AUSTRALIA PTY. LTD. 161-165 Princes Highway, Hallam Victoria 3803, Australia Phone 03-8787-1200 ALPINE ELECTRONICS GmbH Frankfurter Ring 117 80807 München, Germany Tel. 089-3242640 ALPINE ELECTRONICS OF U.

K. LTD. Alpine House Fletchamstead Highway, Coventry CV4 9TW, U.K. Phone 0870-33 33 763 ALPINE ELECTRONICS FRANCE S.A.R.L. (RCS PONTOISE B 338 101 280) 98, Rue de la Belle Etoile, Z.I.

Paris Nord II, B.P. 50016, 95945 Roissy Charles de Gaulle Cedex, France Phone 01-48638989 ALPINE ITALIA S.p.A. Viale C. Colombo 8, 20090 Trezzano Sul Naviglio (MI), Italy Phone 02-484781 ALPINE ELECTRONICS DE ESPAÑA, S.A. Portal de Gamarra 36, Pabellón, 32 01013 Vitoria (Alava)-APDO 133, Spain Phone 945-283588 22-EN 22-EN ALPINE ELECTRONICS (Benelux) GmbH Leuvensesteenweg 510-B6 1930 Zaventem, Belgium Tel. 02-7251315 .



[You're reading an excerpt. Click here to read official ALPINE TUE-T150DV user guide](http://yourpdfguides.com/dref/1080422)  
<http://yourpdfguides.com/dref/1080422>