



Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ASUS FONEPAD NOTE 6 (ME560CG-1A023A) BLANC. You'll find the answers to all your questions on the ASUS FONEPAD NOTE 6 (ME560CG-1A023A) BLANC in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual ASUS FONEPAD NOTE 6 (ME560CG-1A023A) BLANC

User guide ASUS FONEPAD NOTE 6 (ME560CG-1A023A) BLANC

Operating instructions ASUS FONEPAD NOTE 6 (ME560CG-1A023A) BLANC

Instructions for use ASUS FONEPAD NOTE 6 (ME560CG-1A023A) BLANC

Instruction manual ASUS FONEPAD NOTE 6 (ME560CG-1A023A) BLANC

ASUS Fonepad
**IN SEARCH OF
INCREDIBLE**

USER MANUAL

ASUS

E8376



[You're reading an excerpt. Click here to read official ASUS FONEPAD NOTE 6 \(ME560CG-1A023A\) BLANC user guide](http://yourpdfguides.com/dref/5526370)
<http://yourpdfguides.com/dref/5526370>

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 8 *Charging your batteries...*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.... 8 *Using your ASUS Fonepad.*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

. 8 *Airplane Precautions....*

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..... 8 *Package contents.*

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

.... 9 Chapter 1: Hardware Setup Getting to know your ASUS Fonepad.

.....

.....
.....
.....
.....

.....
.....
.....

.....12 Front view..

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.....12 Rear view .

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

.....
.....

.14 Inside the side compartment.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....17 Chapter 2: Using your ASUS Fonepad Setting up your ASUS Fonepad....

.....
.....
.....

.....
.....
.....

.....
.....

..20 Installing a micro SIM card...

.....
.....
.....
.....

.....
.....
.....

.....
.....

..20 Installing a microSD card...

.....
.....
.....
.....

.....
.....
.....

.....
.....
.....

21 Charging your ASUS Fonepad.....

.....
.....
.....

.....
.....
.....
.....

.....
...22 Turning your ASUS Fonepad on..

.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

...24 Gestures for the ASUS Fonepad.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

...25 Chapter 3: Working with Android™ Starting up for the first time.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

32 Android™ lock screen.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

33 Unlocking your device.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....34 Entering the camera mode..

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....34 Adding a wallpaper on the lock screen...

.....
.....
.....
.....
.....
.....
.....
.....
.....

...35 Adding a widget on the lock screen..

.....
.....
.....
.....
.....
.....
.....
.....
.....

.....35 K00G □ Entering Google Now.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....

...36 Home Screen.....

.....
.....
.....

.....

.....
.....
.....

.....

.....
.....
.....

.....

.....
.....
.....

38 Screen views.....

.....
.....
.....

.....

.....
.....
.....

.....

.....
.....
.....

.....

.....
.....
.....

.....39 Locking the screen orientation...

.....

.....
.....
.....

.....

.....
.....
.....

.....

.....
.....
.....

...40 Using the call features..

.....

.....

.....
.....
.....

.....

.....
.....
.....

.....

.....
.....
.....
.....41 Making calls...

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.....41 Setting up your contacts.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.....41 Connecting to the world..

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

..42 Connecting to mobile networks.....

.....
.....
.....

.....
.....
.....
.....

.....
.....

.....
.....
.....
.....

...54 ASUS Quick Setting.....

.....
.....

.....
.....
.....

.....
.....
.....

.....
.....

..54 Turning your ASUS Fonepad off...

.....

.....
.....
.....

.....
.....
.....

.....56 Putting your ASUS Fonepad to sleep...

.....
.....

.....
.....
.....

.....
.....

..56 Chapter 4: Pre-installed Apps Featured pre-installed apps...

.....

.....
.....
.....

.....
.....
.....

.....
.....

58 Play Music.....

.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

.58 Camera

.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

...60 □ ASUS Fonepad E-Manual Gallery ..

.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

64 Email Gmail Maps

.....
.....
.....
.....

.....
.....

.....
.....
.....
.....73 MyLibrary ..

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

75 SuperNote.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

.80 AudioWizard.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....86 App Locker..

.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.....87 Widgets ..

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

90 ASUS Battery.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....

.....91 Appendices EC Declaration of Conformity....

.....
.....
.....
.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
..96 ASUS Recycling/Takeback Services...

.....
.....

.....
.....
.....
.....

.....
.....
.....

.....96 Coating notice....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

....96 Driving safely.

.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
....96 Electronic devices.

.....
.....

.....
.....

.....
.....

.....
.....
.....

.....
.....
.....

.97 Other medical devices.....

.....
.....

.....
.....
.....

.....
.....
.....

.....97 Vehicles .

.....
.....

.....
.....

.....
.....

.....
.....

.97 Posted facilities....

.....

.....
.....

.....
.....

.....
.....

..98 Magnetic media.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

..98 Other Safety Guidelines.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....98 Proper disposal...

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

.....

depending on the ambient light condition. K00G 13 Rear view Stylus pen The bundled stylus pen allows you to input commands on your ASUS Fonepad. With your stylus pen, you can make selections, draw or sketch on the touch screen panel of your ASUS Fonepad. 14 ASUS Fonepad E-Manual Volume button The volume button allows you to increase or decrease the volume level of your ASUS Fonepad. In addition, you can also do any of the following using the volume button: q Press and hold the volume down button to activate Vibrate Mode. q Press and hold the volume up button to show and adjust the music, message alert, and time alarm volumes. q When in Vibrate mode, press the volume down button once to switch to Silent Mode. Power button Press the power button for about two (2) seconds to turn your ASUS Fonepad on or wake it up from standby mode. To turn your ASUS Fonepad off, press the power button for about (2) seconds and when prompted, tap Power Off then tap OK.

To lock your ASUS Fonepad or put it to standby mode, press and quickly release the power button. In the event that your ASUS Fonepad becomes unresponsive, press and hold the power button for about four (4) seconds to force it to shut down. IMPORTANT! • When your ASUS Fonepad is inactive for fifteen (15) seconds, it will automatically go to standby mode. • Forcing the system to restart may result to data loss. We strongly recommend that you back up your data regularly. Rear camera This built-in rear camera allows you to take high-definition pictures or record high-definition videos using your ASUS Fonepad. K00G 15 Speaker/Headset port This port allows you to connect your ASUS Fonepad to amplified speakers or a headset. IMPORTANT! This port does not support an external microphone. Side compartment The side compartment contains the micro SIM (Subscriber Identity Module) card slot and microSD card slot. NOTE: Refer to section Inside the side compartment for the features inside the side compartment. Micro USB 2.0 port Use the micro USB (Universal Serial Bus) 2.0 port to charge the battery pack or supply power to your ASUS Fonepad. This port also allows you to transfer data from your computer to your ASUS Fonepad and vice-versa. NOTE: When you connect your ASUS Fonepad to the USB port on your computer, your ASUS Fonepad will be charged only when it is in sleep mode (screen off) or turned off.

Microphone The built-in microphone can be used for video conferencing, voice narrations or simple audio recordings. 16 ASUS Fonepad E-Manual Inside the side compartment Micro SIM card slot The ASUS Fonepad comes with a built-in micro SIM (Subscriber Identity Module) card slot that supports GSM and WCDMA network bands. NOTE: Refer to section Installing a micro SIM card for more details. MicroSD card slot The ASUS Fonepad comes with a built-in memory card reader slot that supports microSD, microSDHC and microSDXC card formats. NOTE: Refer to section Installing a microSD card for more details.

K00G 17 18 ASUS Fonepad E-Manual Chapter 2: Using your ASUS Fonepad Chapter 2: Using your ASUS Fonepad K00G 19 Setting up your ASUS Fonepad Installing a micro SIM card Before you can make calls, send text messages or connect to a mobile broadband network using your ASUS Fonepad, you need to install a micro SIM (Subscriber Identity Module) card.



[You're reading an excerpt. Click here to read official ASUS FONEPAD NOTE 6 \(ME560CG-1A023A\) BLANC user guide](http://yourpdfguides.com/dref/5526370)

To install a micro SIM card: 1. Open the side compartment cover of your ASUS Fonepad. 2. Insert the micro SIM card to the micro SIM card slot with its metal contacts facing up, as shown. Metal contacts 3. Close the side compartment cover securely in place. 20 ASUS Fonepad E-Manual Installing a microSD card To install a microSD card: 1. Open the side compartment cover of your Fonepad. 2.

Insert the microSD card to the microSD card slot with its metal contacts facing up, as shown. Metal contacts 3. Close the side compartment cover securely in place. K00G 21 Charging your ASUS Fonepad To charge your ASUS Fonepad: Connect the micro USB cable to the power adapter. Plug the micro USB connector into your ASUS Fonepad. Plug the power adapter into a grounded power outlet. Charge your ASUS Fonepad for eight (8) hours before using it in battery mode for the first time. 22 ASUS Fonepad E-Manual IMPORTANT! • Use only the bundled power adapter and micro USB cable to charge your ASUS Fonepad. Using a different power adapter may damage your ASUS Fonepad. • Peel the protective film off from the power adapter and micro USB cable before charging the ASUS Fonepad to prevent risk or injury.

- Ensure that you plug the power adapter to the correct power outlet with the correct input rating. The output voltage of this adapter is DC 5.2V, 1.35A. • When using your ASUS Fonepad while plugged-in to a power outlet, the grounded power outlet must be near to the unit and easily accessible.
- Do not place objects on top of your ASUS Fonepad. NOTES: • Your ASUS Fonepad can be charged via the USB port on the computer only when it is in sleep mode (screen off) or turned off. • Charging through a USB port of a computer may take a longer time to complete. • If your computer does not provide enough power for charging your ASUS Fonepad, charge your ASUS Fonepad via the grounded power outlet instead. K00G 23 Turning your ASUS Fonepad on To turn your ASUS Fonepad on, press the power button for about two (2) seconds.

24 ASUS Fonepad E-Manual Gestures for the ASUS Fonepad Using the touch screen panel, the following gestures can be done to navigate, interact with, and launch the exclusive features included with your ASUS Fonepad. Drag/Tap and hold/Long press q To move an app, tap and hold the app and drag it to a new location. q To delete an app from the main screen, tap and hold the app and drag it up to the top side of the screen. . q To capture a screen image, tap and hold NOTE: To enable this setting, go to > ASUS Customized Setting then tick Capture screenshots by holding the Recent Apps Key. Settings K00G 25 Tap/touch q Tap an app to launch it. q In the File Manager app, tap to select and open a file. 26 ASUS Fonepad E-Manual Zoom out Bring together your two fingers on the touch panel to zoom out an image in Gallery, Maps, or Places. K00G 27 Zoom in Spread apart your two fingers on the touch panel to zoom in an image in Gallery, Maps, or Places. 28 ASUS Fonepad E-Manual Swipe Swipe your finger to the left or to the right on the touch panel display to switch between screens or to flip through the pages of an e-book or a gallery of images.

K00G 29 30 ASUS Fonepad E-Manual Chapter 3: Working with Android™ Chapter 3: Working with Android™ K00G 31 Starting up for the first time When you turn on your ASUS Fonepad for the first time, a series of steps appear to guide you in configuring the basic settings of your Android™ operating system.

NOTE: If a micro SIM card is already installed, your ASUS Fonepad may prompt you for the PIN code before you can set the basic settings. Refer to the micro SIM card's documentation for the PIN code, or ask the service provider for information. To start your ASUS Fonepad for the first time: 1. Turn your ASUS Fonepad on. 2. Choose a language, then tap . . 3. Select an input method or keyboard format, then tap Internet, then tap . 4. Select a type of network (mobile carrier or Wi-Fi or both) to connect to the 5. From the list of available Wi-Fi networks, tap a network name then tap To skip connecting to a network, tap . . NOTE: Some Wi-Fi networks may prompt you to key in a passcode. 6. Select the type of data synchronization, then tap . 7. Follow the onscreen instructions to configure the following items: q Google Account q Google location and services 8. Set the local date and time, then tap 9.

Tick the checkbox I understand then tap 10. Tap or . . to enter Home screen. 11. On the Home Screen, tap OK to start navigating your ASUS Fonepad. 32 ASUS Fonepad E-Manual Android™ lock screen Time, date, and weather panel Lock icon Google Now launcher K00G 33 Unlocking your device Tap and drag to . Entering the camera mode Swipe the lock screen from right to left to view the Camera shortcut and launch the Camera app. 34 ASUS Fonepad E-Manual Adding a wallpaper on the lock screen Swipe the lock screen from left to right to view the wallpaper and widget panel, then tap and select a wallpaper from Gallery or Wallpapers. Adding a widget on the lock screen Swipe the lock screen from left to right to view the wallpaper and widget panel, then tap and select a widget.

K00G 35 Entering Google Now Tap on the system bar then drag it to Google icon. 36 ASUS Fonepad E-Manual Google Now Google Now is your ASUS Fonepad's personal assistant, giving you instant updates on weather conditions, nearby restaurants, flight schedules, scheduled appointments, and other related information based from your web history, synced calendars and reminders. K00G 37 Home Screen Notification area and Settings Open Google Text search Open Google Voice search Tap to set up the location, date, and time alarm Shortcuts Open All Apps screen Shortcuts System bar Return to the previous screen Display recent apps Return to Home Screen 38 ASUS Fonepad E-Manual Screen views The built-in gravity-sensor of your ASUS Fonepad enables automatic screen rotations depending on how you hold it. You can quickly switch between a landscape or portrait view by steering your ASUS Fonepad to the left or to the right. NOTE: When in Home Screen, the orientation is in portrait mode only. Landscape view Portrait view K00G 39 Locking the screen orientation By default, your ASUS Fonepad screen automatically changes its orientation from portrait mode to landscape mode or vice-versa, depending on the way you hold your device. You can disable the auto-rotate screen function by following these steps: 1. Tap 2. Tap Settings on the Home Screen to open All Apps screen. > Accessibility then tap Auto-rotate screen to deselect.

NOTE: You can also enable or disable this function from the ASUS Quick Settings. Refer to section Settings for more details. 40 ASUS Fonepad E-Manual Using the call features Making calls To make a call: 1. Tap Phone on the Home Screen. to dial. to end the call. 2. Tap the keys to key in the number you wish to call.



[You're reading an excerpt. Click here to read official ASUS FONEPAD NOTE 6 \(ME560CG-1A023A\) BLANC user guide](http://yourpdfguides.com/dref/5526370)
<http://yourpdfguides.com/dref/5526370>

3. Tap 4.

Tap Setting up your contacts To set up your contacts, you can do any of the following: q From the Home Screen, tap People > then select Create a new contact. Follow the screen instructions to add a new contact. q Import your contacts from your micro SIM card into your ASUS Fonepad. To import your contacts from your micro SIM card: 1. Install the micro SIM card into your ASUS Fonepad. 2. From the Home Screen, tap People to launch the People app. 3. Tap then tap > Manage contacts. 4.

Tap Import/export > Import from SIM card then tap to select the contacts that you wish to import to your ASUS Fonepad. 5. When done, tap . K00G 41 Connecting to the world Connecting to mobile networks After installing the SIM card, you are ready to use your ASUS Fonepad to make/ receive calls or transmit/receive data. Different countries or regions may have different mobile networks available and you may have to configure your ASUS Fonepad to access these networks. To configure your mobile networks setting: 1. Do any of the following to go to the Settings screen: q Tap to go to the All Apps screen then tap Settings . q Swipe your finger down from the top of the screen to go to ASUS Quick Settings then tap . 2. From the Settings screen, tap More. .. then tap Mobile networks. NOTE: Refer to section Settings for more details about ASUS Quick Settings. IMPORTANT! If your ASUS Fonepad does not connect to a network, contact your mobile network carrier for assistance.

Connecting to Wi-Fi networks Wi-Fi wireless networking technology allows you to exchange data wirelessly over a network. To use Wi-Fi, enable the Wi-Fi feature in your ASUS Fonepad and connect to a wireless network. Some wireless networks are secured with a key or protected with digital certificates and requires additional steps to set up; others are open and you can easily connect to them. NOTE: Turn Wi-Fi off when you are not using it to help save battery power. To enable Wi-Fi and connect to a Wi-Fi network: 1.

Tap to go to the All Apps screen then tap Settings . 2. Slide the Wi-Fi switch to ON. When enabled, your ASUS Fonepad scans for available Wi-Fi networks. 42 ASUS Fonepad E-Manual 3. Tap a network name to connect to it. If the network is secured or protected, you are prompted to key in a password or key in other credentials. NOTE: If your ASUS Fonepad finds a network that you have connected to previously, it automatically connects to it. Using Bluetooth Enabling or disabling Bluetooth in your device Bluetooth is a wireless standard used for exchanging data over short distances. Bluetooth exists in many products, such as smartphones, computers, tablet devices, and headsets.

Bluetooth is very useful when transferring data between two or more devices that are near each other. The first time you connect to a Bluetooth device, you must pair it with your ASUS Fonepad. NOTE: Turn Bluetooth off when you are not using it to help save battery power. To enable or disable Bluetooth in your ASUS Fonepad, you can do any of the following: q Tap to go to the All Apps screen then tap Settings . Slide the Bluetooth switch to ON q Slide down the Notification area to display ASUS Quick Settings panel then tap . K00G 43 Pairing your ASUS Fonepad with a Bluetooth device Before you can connect to a Bluetooth device, you must first pair your ASUS Fonepad to that device. The devices stay paired, unless you remove the paired connection between them. To pair your ASUS Fonepad to a device: 1. Tap to go to the All Apps screen then tap Settings . Slide the Bluetooth switch to ON.

2. Tap Bluetooth to display all available Bluetooth devices within range. NOTES: • If the device you want to pair with is not in the list, ensure that its Bluetooth feature is turned ON and set as Discoverable. • See the technical documentation that came with the device to learn how to turn its Bluetooth ON and how to set it to discoverable. 3.

If your ASUS Fonepad has finished scanning before your Bluetooth device is ready, tap SEARCH FOR DEVICES. 4. In the list of available devices, tap the Bluetooth device that you want to pair with. Follow the succeeding screen instructions to complete the pairing. If necessary, refer to the technical documentation that came with the device.

Connecting your ASUS Fonepad to a Bluetooth device To connect to a Bluetooth device: 1. Tap to go to the All Apps screen then tap Settings After you have paired your ASUS Fonepad to a Bluetooth device, you can easily reconnect to it manually, after it is back in range. . Slide the Bluetooth switch to ON. 2. In the list of PAIRED DEVICES, tap the name of the paired device. 44 ASUS Fonepad E-Manual Unpairing and configuring a Bluetooth device To unpair or configure a Bluetooth device: 1. Tap to go to the All Apps screen then tap Settings . Slide the Bluetooth switch to ON. beside the connected Bluetooth device that you 2.

Tap Bluetooth then tap want to unpair or configure. 3. From Paired Bluetooth device screen, you can do any of the following: q Tap Unpair to unpair the device. q Tap Rename to rename the Bluetooth device. q Tap any of the listed profiles to enable or disable a profile. 4. Tap to go back to previous screen. K00G 45 Managing Apps Creating app shortcuts Get easy access to some of your favorite applications by creating app shortcuts on your Home Screen. To create app shortcuts: 1. Tap to go to the All Apps screen.

2. From the All Apps screen, tap and hold the app's icon then drag it to the Home Screen. Removing an app from the Home Screen Free up space for new app shortcuts by removing existing app shortcuts on your Home Screen. To remove app shortcuts: 1. Tap and hold an app until the X Remove appears on top of the screen.

2. Drag the app to X Remove to remove it from the Home Screen. 46 ASUS Fonepad E-Manual Viewing app info You can view the detailed app information while creating a shortcut for the app. While holding an app on the All Apps screen, the display switches to Home Screen and the App info appears on the top of the Home Screen display. Drag the app to App info to display its detailed information.

K00G 47 Creating app folder You can create folders to organize shortcuts on your Home Screen. To create an app folder: 1. On the Home Screen, tap and drag an app or shortcut onto another app until a transparent square appears. NOTES: • The created folder is shown in a transparent square. • You can add multiple apps in your folder. 2. Tap the folder and tap Unnamed Folder to rename the folder. 48 ASUS Fonepad E-Manual Viewing apps under the Recents screen The Recents screen allows you to view a list of app shortcuts based from your recently launched apps. Using the Recents screen, you can easily go back to or switch between the apps you recently launched. To access the Recents screen: 1.

Tap on the system bar. 2. A list shows up to display all of your recently launched apps. Tap on the app you want to launch. 3. To remove an app from the list, swipe the app to the left or right.



[You're reading an excerpt. Click here to read official ASUS FONEPAD NOTE 6 \(ME560CG-1A023A\) BLANC user guide](http://yourpdfguides.com/dref/5526370)
<http://yourpdfguides.com/dref/5526370>

Tap Highlight to mark a word or phrase. b. Tap Note to record a word or phrase.

c. Tap Text to Speech to listen to the selected word or phrase. d. Tap Copy to copy the selected word or phrase and paste it to a text app. e. Tap Share to share a phrase then select an app that you want for sharing. f. Tap Translation to see the translation of the selected phrase. K00G 79 SuperNote SuperNote is an easy-to-use app that lets you take notes, doodle, capture and insert photos, and record sounds and videos for a more interactive experience. You can also share your notebooks via your ASUS WebStorage account.

To launch SuperNote, tap SuperNote on the Home Screen. SuperNote main screen Tap to view by type Tap to select and lock, delete, or export notebooks as PDF or SuperNote formats Tap to open advanced settings Tap to import, search, or show locked notebooks Tap to sort notebooks Tap to log-in to your ASUS WebStorage account and sync your notebooks Tap to add a new notebook All your notebooks 80 ASUS Fonepad E-Manual Creating a new notebook To create a new notebook: 1. Tap Add a new Notebook. 2. Name the file and select Pad or Phone for page size.

3. Select a template. The new note page appears instantly. K00G 81 SuperNote Notebook interface Save Return path Notebook tool bar Search Add page Settings Previous page Page size Mode settings Next page Page number NOTE: The mode settings and notebook tool bar change when you tap mode, or mode. mode, 82 ASUS Fonepad E-Manual Customizing your notebook SuperNote allows you to be creative with your notebooks.

From the tool bar, you can select several tools that lets you customize your notebooks. NOTE: The settings of the tool bar may vary depending on the mode that you selected. To customize your notebook: 1. In the SuperNote main screen, tap the notebook that you want to customize. 2. Tap any of the icons on the toolbar to start editing your notebook. NOTES: • For mode, tap on the notebook tool bar then tap for penmanship guidelines when necessary. • For • For mode, tap mode, tap to select text color and weight. to select brush stroke, color, opacity, and weight K00G 83 SuperNote Read-only mode To enable the read-only mode, tap then tap Read only. Tap to enable Edit mode Renaming your notebook To rename your notebook: 1.

In the SuperNote main screen, tap and hold the notebook file then tap Rename. 2. Key in the the filename then tap OK. 84 ASUS Fonepad E-Manual Hiding your notebook To hide your notebook: 1. In the SuperNote main screen, tap and hold the notebook file then tap Lock to hide. 2. Key in your password then tap OK. NOTES: • You will be prompted to key in a new password when you hide your notebook for the first time. • To view the hidden notebooks on the main screen, tap locked notebook. then tap Show Deleting your notebook To delete your notebook: 1.

In the SuperNote main screen, tap and hold the notebook file then tap Delete. 2. Tap Delete to confirm deletion of the notebook. K00G 85 AudioWizard AudioWizard allows you to customize the sound modes of your ASUS Fonepad for a clearer audio output that fits the actual usage scenarios. To launch Audio Wizard, tap on the Home Screen then tap AudioWizard .

Preset modes Tap to confirm mode selection Using AudioWizard To use AudioWizard: 1. In the AudioWizard window, tap the sound mode that you want to activate. 2. Tap OK to save the selected sound mode and exit the AudioWizard window. 86 ASUS Fonepad E-Manual App Locker App Locker is a security app that prevents selected apps and files from being opened.

Using App Locker To use App Locker: 1. On the Home Screen, tap then tap . App Locker 2. Tap Start, set up your password then tap OK. 3. Tap OK to proceed to the App Locker screen. K00G 87 App Locker screen Move the slider to the right to enable the App Locker and activate the app list. Tap this to configure the settings of App Locker. Tap to open App Locker or File Protection Tap the apps that you want to lock or tap the locked app to unlock it. NOTES: • The apps that you locked appear as locked icons on the Home Screen.

• App Locker prompts you to key in your password every time you launch a locked app. 88 ASUS Fonepad E-Manual File Protection screen Tool bar File type tabs Protected files list Using File Protection To use File Protection: 1. Tap File Protection then tap to open File Manager app. . The files that 2. Tap to select the files that you want to protect, then tap you want to protect appear on the File Protection screen. K00G 89 Widgets Widgets are mini apps that allow you to conveniently access useful and fun applications on your ASUS Fonepad's Home Screen. To view widgets, tap on the Home Screen then tap WIDGETS. Displaying a widget on the Home Screen From the Widgets screen, swipe your finger to the left or to the right to select a widget. Tap and hold the selected widget, then drag it to the Home Screen.

IMPORTANT! • You may be prompted to perform additional tasks such as registration or activation before you can use a selected widget. • If there is not enough space on the screen to place the widget, the widget will not be added to the screen. Removing a widget from the Home Screen From the Home Screen, tap and hold the widget until X Remove appears. Without lifting your finger, drag the widget to X Remove to remove the widget from your Home Screen. Removes the widget from the Home Screen 90 ASUS Fonepad E-Manual ASUS Battery ASUS Battery is a special widget designed to show the battery status of your ASUS Fonepad and its connected accessories by percentage and color.

To view ASUS Battery widget, tap on the Home Screen then tap WIDGETS. Displaying the ASUS Battery widget on the Home Screen From the Widgets screen, swipe your finger to the left or to the right to look for ASUS Battery widget. Tap and hold the widget, then drag it to the Home Screen. NOTE: You can also view your ASUS Fonepad's battery status in ASUS Quick Setting and notification area. For more details, refer to sections ASUS Quick Setting and Notification panel.

K00G 91 92 ASUS Fonepad E-Manual Appendices Appendices K00G 93 EC Declaration of Conformity This product is compliant with the regulations of the R&TTE Directive 1999/5/EC. The Declaration of Conformity can be downloaded from <http://support.asus.com>. Prevention of Hearing Loss To prevent possible hearing damage, do not listen at high volume levels for long periods. À pleine puissance, l'écoute prolongée du baladeur peut endommager l'oreille de l'utilisateur. For France, as required by French Article L. 5232-1, this device is tested to comply with the Sound pressure requirement in NF EN 50332-2:200 and NF EN 50332-1:2003 standards. CE Mark Warning CE marking for devices with wireless LAN/ Bluetooth This equipment complies with the requirements of Directive 1999/5/EC of the European Parliament and Commission from 9 March, 1999 governing Radio and Telecommunications Equipment and mutual recognition of conformity.



[You're reading an excerpt. Click here to read official ASUS FONEPAD NOTE 6 \(ME560CG-1A023A\) BLANC user guide](http://yourpdfguides.com/dref/5526370)
<http://yourpdfguides.com/dref/5526370>

The highest CE SAR values for the device are as follows: • 0.

347 W/Kg (Body/GSM 900) • 0.905 W/Kg (Head/WLAN 2.4GHz) 94 ASUS Fonepad E-Manual ASUS ME560CG CE SAR values Equipment class DTS NII Mode / Band WLAN 2.4GHz Test position Scale SAR10g (W/Kg) 0.905 0.085 0.101 0.028 0.086 0.029 0.449 0.347 0.349 0.255 0.246 0.

216 0.229 0.206 PCB Head Body (1.5 cm gap) Head WLAN 5.3GHz Body (1.

5 cm gap) Head WLAN 5.6GHz Body (1.5 cm gap) Head GSM900 Body (1.5 cm gap) Head GSM1800 Body (1.5 cm gap) Head WCDMA Band I Body (1.5 cm gap) Head WCDMA Band VIII Body (1.5 cm gap) RF Exposure information (SAR) - CE This device meets the EU requirements (1999/519/EC) on the limitation of exposure of the general public to electromagnetic fields by way of health protection. The limits are part of extensive recommendations for the protection of the general public. These recommendations have been developed and checked by independent scientific organizations through regular and thorough evaluations of scientific studies. The unit of measurement for the European Council's recommended limit for mobile devices is the "Specific Absorption Rate" (SAR), and the SAR limit is 2.

0 W/Kg averaged over 10 gram of body tissue. It meets the requirements of the International Commission on Non-Ionizing Radiation Protection (ICNIRP). For next-to-body operation, this device has been tested and meets the ICNIRP exposure guidelines and the European Standard EN 62311 and EN 62209-2.

SAR is measured with the device directly contacted to the body while transmitting at the highest certified output power level in all frequency bands of the mobile device. K00G 95 Power Safety Requirement Products with electrical current ratings up to 6A and weighing more than 3Kg must use approved power cords greater than or equal to: H05VV-F, 3G, 0.75mm² or H05VV-F, 2G, 0.75mm². Regional notice for Singapore This ASUS product complies with IDA Standards. ASUS Recycling/Takeback Services ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for you to be able to responsibly recycle our products, batteries, other components as well as the packaging materials.

Please go to <http://csr.asus.com/english/Takeback.htm> for detailed recycling information in different regions. Coating notice IMPORTANT! To provide electrical insulation and maintain electrical safety, a coating is applied to insulate the device except on the areas where the I/O ports are located.

Driving safely Never use this device while driving. It is an offence, that while driving, to hold the device or cradle it in your neck at any point, during the setup, making or taking text message or any other data related mobile communication. Use of fully installed car kits are still permitted, as are the use of alternate handsfree accessories. In the interest of safety, we would recommend the use of a cradle while using any form of handsfree accessory. While driving, we recommend that you use voicemail wherever possible, and that you listen to your messages when you are not in the car.

If you must make a handsfree call when driving, keep it brief. Do not place objects, including both installed or portable wireless equipment, in the area over the airbag or in the airbag deployment area. An airbag inflates with great force. If the airbag inflates, serious injury could result. 96 ASUS Fonepad E-Manual Electronic devices Most modern electronic equipment is shielded from RF energy. However, certain electronic equipment may not be shielded against the RF signals from your device. Pacemakers The Health Industry Manufacturers' Association recommends that a minimum separation of six (6") inches be maintained between a phone and a pacemaker to avoid potential interference with the pacemaker. @@@@ • Do not carry your device in your breast pocket. @@@@ In the event of such interference, call ASUS Customer Service to discuss alternatives. Other medical devices If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from external RF energy.

Your physician may be able to assist you in obtaining this information. Turn your device off in healthcare facilities when any regulations posted in these areas instruct you to do so. Hospitals or healthcare facilities may be using equipment that could be sensitive to external RF energy. Vehicles RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles. Check with the manufacturer or its representative regarding your vehicle.

You should also consult the manufacturer of any equipment added to your vehicle. K00G 97 Posted facilities Turn your device off where posted notices so require. Magnetic media Magnetic fields generated by mobile devices may damage data on magnetic storage media, such as credit cards, computer discs or tapes. Do not place your device next to such media. You should never expose your device to strong magnetic fields as this may cause temporary malfunction. Other Safety Guidelines Aircraft Regulations prohibit using your mobile device while onboard an aircraft. Switch off your device before boarding an aircraft or turn off the wireless connections. Blasting areas To avoid interfering with blasting operations, turn your device off when in a 'blasting area' or in areas posted: "Turn off two-way radio." Obey all signs and instructions. Potentially explosive environments Turn your device off when in any area with a potentially explosive environment and obey all signs and instructions.

Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Areas with a potentially explosive environment are often, but not always, clearly marked. They include fuelling areas such as gas stations, below decks on boats, fuel or chemical transfer or storage facilities, vehicles using liquified petroleum gas (such as propane or butane), areas where the air contains chemicals or articles, such as grain, dust, or metal powders, and any other area where you would normally be advised to turn off your vehicle's engine. Choking Keep your away from children as the SIM card and other small parts present a choking hazard. 98 ASUS Fonepad E-Manual Proper disposal Risk of explosion if battery is replaced by an incorrect type.

Dispose of used batteries according to the instructions. DO NOT throw the battery in municipal waste. The symbol of the crossed out wheeled bin indicates that the battery should not be placed in municipal waste. DO NOT throw the ASUS Fonepad in municipal waste. This product has been designed to enable proper reuse of parts and recycling. The symbol of the crossed out wheeled bin indicates that the product (electrical, electronic equipment and mercury-containing button cell battery) should not be placed in municipal waste. Check local regulations for disposal of electronic products. DO NOT throw the ASUS Fonepad in fire.



[You're reading an excerpt. Click here to read official ASUS FONEPAD NOTE 6 \(ME560CG-1A023A\) BLANC user guide http://yourpdfguides.com/dref/5526370](http://yourpdfguides.com/dref/5526370)

DO NOT short circuit the contacts. DO NOT disassemble the ASUS Fonepad.

Model name: K00G (ME560CG) Manufacturer: Address: Authorized representative in Europe: Address: ASUSTeK Computer Inc. 4F, No.150, LI-TE RD., PEITOU, TAIPEI 112, TAIWAN ASUS Computer GmbH HARKORT STR. 21-23, 40880 RATINGEN, GERMANY K00G 99 EC Declaration of Conformity We, the undersigned, Manufacturer: Country: Address, City: Authorized representative in Europe: ASUSTeK COMPUTER INC. TAIWAN 4F, No. 150, LI-TE Rd., PEITOU, TAIPEI 112, TAIWAN ASUS COMPUTER GmbH GERMANY Address, City: Country: HARKORT STR. 21-23, 40880 RATINGEN declare the following apparatus: Product name : Model name : 2004/108/EC-EMC Directive EN 55022:2010 EN 61000-3-2:A2:2009 Asus Fonepad K00G conform with the essential requirements of the following directives: EN 55024:2010 EN 61000-3-3:2008 1999/5/EC-R &TTE Directive 2006/95/EC-LVD Directive EN

*60950-1 / A12:2011 EN 300 328 V1.7.
I(2006-10) EN 300 440-1 V1.6.1(2010-08) EN 300 440-2 V1.4.1(2010-08) EN 301 511 V9.
0.2(2003-03) EN 301 908-1 V5.2.1(2011-05) EN 301 908-2 V5.2.*

I(2011-07) EN 301 908-13 V5.2.1(2011-05) EN 301 893 V1.6.1(2011-11) EN 62209-1(2006-07) EN 62209-2(2010-06) EN 62479:2010 EN 62311:2008 EN 301 489-1 V1.9.2(2011-09) EN 301 489-3 V1.4.1(2002-08) EN 301 489-7 V1.3.

I(2005-11) EN 301 489-17 V2.2.1(2012-09) EN 301 489-24 V1.5.1(2010-10) EN 302 291-1 V1.1.1(2005-07) EN 302 291-2 V1.1.1(2005-07) EN 50332-1(2000-03) EN 50332-2(2003-12) EN 50360 (2001-07) EN 50360/A1 (2012-03) EN 60065:2002 / A12:2011 Regulation (EC) No. 278/2009 2009/125/EC-ErP Directive Regulation (EC) No.

1275/2008 Regulation (EC) No. 642/2009 2011/65/EU-RoHS Directive CE marking Ver. 130208 0560 (EC conformity marking) Position : CEO Name : Jerry Shen Declaration Date: 16/09/2013 Year to begin affixing CE marking:2013 Signature : _____ 100 ASUS Fonepad E-Manual K00G 101 support.asus.com 102 ASUS Fonepad E-Manual .



[You're reading an excerpt. Click here to read official ASUS FONEPAD NOTE 6 \(ME560CG-1A023A\) BLANC user guide](http://yourpdfguides.com/dref/5526370)
<http://yourpdfguides.com/dref/5526370>