




Your PDF Guides

You can read the recommendations in the user guide, the technical guide or the installation guide for ASUS PADFONE. You'll find the answers to all your questions on the ASUS PADFONE in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

User manual ASUS PADFONE
User guide ASUS PADFONE
Operating instructions ASUS PADFONE
Instructions for use ASUS PADFONE
Instruction manual ASUS PADFONE



[You're reading an excerpt. Click here to read official ASUS PADFONE user guide](http://yourpdfguides.com/dref/4350720)
<http://yourpdfguides.com/dref/4350720>

.....
.....
.....
.....
.....
..19 Screen Views.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

...20 Touch Panel Control.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

...20 Chapter 3: Using your PadFone Station Dock Features.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....23 Left side features.....

.....
.....
.....
.....
.....
.....
.....
.....
.....
.....

.....
23 Right side features.....

.....
.....

.....
.....
.....

.....
.....
.....

.....
...23 Top view features..

.....
.....

.....
.....
.....

.....
.....
.....

.....
.....

...24 Chapter 4: Using apps and widgets Using apps on the PadFone..

.....

.....
.....
.....

.....
.....

...28 Launching apps..

.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....28 Messaging.....

.....
.....
.....

.....

.....
.....
.....

.....
28 Surfing the web.

.....
.....

.....
.....
.....

.....
.....
.....

.....
.....

..29 □ Using apps on the PadFone Station. ..

.....

.....
.....
.....

....42 Managing Apps.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

..42 Task Manager...

.....
.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....
.....
.....
...55 Gallery

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
..56 Camera ...

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.60 Email

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

62 Gmail

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....

.....
.....
.....
.....

.....64 MyLibrary .

.....
.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....66 Places and Maps

.....
.....
.....

.....
.....
.....

.....
.....

.....69 Polaris® Office . .

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....70 MyNet

.....
.....

.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....
.....74 MyCloud

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....78 App Locker ...
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....88 SuperNote

.....
.....
.....
.....

.....
.....
.....
.....

.....
.....
.....
.....

.....89 Watch Calendar ..

.....
.....
.....
.....

.....
.....
.....
.....

98 Managing notifications.....

.....
.....
.....

.....
.....
.....

..29 Searching your PadFone or web...

.....
.....
.....
.....

.....
.....
.....

.....32 Taking pictures..

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....32 Watch Calendar ...

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....
..33 MyCloud ...

.....
.....

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....34 SuperNote .

.....
.....
.....

.....
.....
.....

.....
.....
.....

.....
...35 Using PadFone widgets. .

.....
.....

.....
.....
.....

.....
.....
.....

95 Using PadFone Station widgets.....

.....
.....
.....

.....
...97 Chapter 5: Accessory Using your PadFone Stylus Headset..

.....
.....

.....
.....
.....

.....99 Charging your PadFone Stylus Headset..

.....
.....

Quick Start Guide for instructions on installing the SIM card, installing an SD card, installing the battery, and charging your device.

The first time you turn on your PadFone, you'll see the Welcome screen. Touch the menu to choose your preferred language and touch Next Step. Follow the succeeding instructions to set up your PadFone. NOTE: You can skip some of the steps and set them up later. □ Navigating your PadFone After you finish setting up your PadFone, the Home Screen appears. At the bottom of your Home Screen, you'll find three navigation icons return to a previous page, or launch a recent app. Icon Description , , . These icons, which are always available on the system bar, allow you to instantly jump back to the Home Screen, Allows you to go back to the previous screen, until you are in the Home Screen. Opens your Home Screen. Opens a thumbnail list of your most recent apps.

To launch an app, touch the thumbnail image. If you wish to remove a thumbnail app, swipe it to the left or right. □ Touching and typing Use your fingers to launch apps, move icons, select menu items, press buttons, type on the onscreen keyboard, and perform other useful gestures on the PadFone touchscreen. To key in or type something, touch the part where you need to type and the onscreen keyboard will pop up. The following table describes more useful gestures. Gesture Pinch Drag Touch and hold Swipe or slide Double-tap Description Place two fingers on the screen and spread them apart to zoom in and bring them together to zoom out. This gesture can be used in selected apps, including Maps, Gallery, and Browser. Touch and hold an icon or item then, without lifting your finger, move your finger on the screen to move the icon or item. Touch and hold an item until an action occurs. Quickly move your finger across the screen in one sweeping motion.

Quickly tap twice on the screen to zoom. □ Making calls 1. Touch To make a call: on the Home Screen or touch to go to the All apps screen. 2. Touch the keys to key in the number you wish to call.

3. Touch 4. Touch to dial. to end the call. Setting up your contacts list To set up your contacts, you can do any of the following: • Touch then select Create a new contact.

Follow the succeeding screen instructions to add a new contact. • Import your contacts from your SIM card into your PadFone. To import your contacts from your SIM card: 1. Installk Settings, refer to the section Managing notifications in Chapter 4. to go to the All apps screen then touch Settings . . Swipe your finger down from the top of the screen to go to ASUS Quick Settings then 2. Slide the Wi-Fi switch to ON. When enabled, your PadFone scans for available Wi-Fi IMPORTANT: If your PadFone finds a network that you have connected to previously, it automatically connects to it. 13 Using Bluetooth Enabling or disabling Bluetooth in your device Bluetooth is a wireless standard used for exchanging data over short distances.

Bluetooth exists in many products, such as smartphones, computers, tablet devices, and headsets. Bluetooth is very useful when transferring data between two or more devices that are near each other. The first time you connect to a Bluetooth device, you must pair it with your PadFone. TIP: Turn OFF Bluetooth in your PadFone when you're not u the e-mail inbox folder. Notification area & Settings 19 Screen Views The screen view rotates automatically when you hold the tablet horizontally to vertically, and vice versa. To enable/ disable Auto-rotate screen, go to Settings > Display. Landscape view Portrait view Touch Panel Control Single-tapping • Single-tapping the touch panel allows you to select a desired item or launch an app.



[You're reading an excerpt. Click here to read official ASUS](http://yourpdfguides.com/dref/4350720)

[PADFONE user guide](http://yourpdfguides.com/dref/4350720)

<http://yourpdfguides.com/dref/4350720>

• Single-tapping in the File Manager allows you to open, select, copy, cut, delete, or edit the files. 20 Touching and holding • Touch and hold an application to drag and drop it or its shortcut to another Home Screen page. • Touch and hold the Recent Apps Key to capture screen images. To enable Screenshot, go to Settings > ASUS customized setting. • Touch and hold a file in the Gallery to enter selection mode. Zooming images Spread apart or bring two fingers together to zoom in or out an image in Gallery, Maps, or Places. Flipping through pages Use one finger to flip back and forth between home screens, through different images in the Gallery or pages in MyLibrary and SuperNote. Inputting, inserting, selecting, and copying text When the PadFone Station is not docked, the onscreen keyboard appears when tapping on any text insertion bars or word processors. On Google Text Search on the upper left corner, type in the web browser bar to search the web and your tablet, or to launch apps. 21 After typing in Google Text Search, touch on the text you have just entered and you will see an insertion point. To move the insertion point, drag or touch the space you would like to insert a letter or a word. Double-tap or hold the text to cut or copy the selected text. You can move the selection tab to expand or reduce the range of the selected text.

Touch and hold the desired text on the web page and a tool bar appears on the top. You can copy, share, select, find, or search on the web. 22 Using your PadFone Station Dock battery life and turn it into a traditional notebook. IMPORTANT: • Dock your PadFone Station installed with your PadFone into your PadFone Station Dock to increase its 3 Before you start, ensure that you have read all the safety information and operating instructions in the Important Notices bundled with your PadFone to prevent injury or damage to your device. Refer to your PadFone Station Dock Quick Start Guide for instructions on using your PadFone and PadFone Station with the PadFone Station Dock. Features Left side features 1 2 3 Right side features 4 3 23 Top view features 5 Backspace Tab Caps Lock Enter Shift Shift Fn PgUp Ctrl Fn Alt Ctrl Home PgDp End 6 7 24 1 40-pin USB connector Insert the power adapter into this port to supply power to your PadFone Station Dock and charge the internal battery pack. To prevent damage to your PadFone Station Dock and battery pack, always use the bundled power adapter. 2 Battery charge indicator (dual-color) With AC adapter: ••• Green: Battery power is between 95% and 100%. Orange: Battery power is less than 95%. Orange Blinking: Battery power is less than 10%.

Orange Blinking Quickly: Battery power is less than 3%. Orange Blinking Quickly: Battery power is less than 3%. Without AC adapter and with PadFone Station: • IMPORTANT: Ensure to connect the power charger when the indicator starts blinking. 3 USB Port (2.0) The USB (Universal Serial Bus) port is compatible with USB 2.0 or USB 1.1 devices such as keyboards, pointing devices, flash disk drive and hard disk drives. 4 Memory card slot The PadStation Dock has a built-in high-speed memory card reader that can conveniently read from and write to flash memory cards. 5 Latch Move the latch to the left to release the PadFone Station from the PadFone Station Dock. 25 6 Keyboard The keyboard provides comfortable key travel, which is the depth that the keys can be pressed to reliably enter the characters, and palm rest for both hands.

NOTE: The keyboard varies with country or region. 7 Touchpad and buttons The touchpad with its buttons is a pointing device that provides the same functions as a desktop mouse. Special Keyboard Functions Some special keys on your ASUS PadFone Station Dock's keyboard have standalone functions and some must be used with the function key. NOTE: The locations of the special keys vary with models but the functions remain the same. Icon Returns to the previous page.

Description Toggles the internal wireless LAN ON or OFF. Toggles the internal Bluetooth ON or OFF. Toggles the touchpad ON or OFF. PgUp Fn Decreases the display brightness Home PgUp PgDp End 26 Fn Fn Increases the display brightness PgUp Home PgDp End Home PgDp End Icon Description Toggles the ambient light sensor ON or OFF Captures the desktop image. Initiates the web browser.

Opens the Settings screen. PgUp Returns to the previous track when playing music. Home PgUp PgDp End Starts playing music from your playlist. Resumes or pauses the current music playing. PgDp Home End PgUp Fast forward or skip to the next track during the music playing. PgDp Home End PgUp Mutes the speaker. Home PgUp PgDp End Decreases the speaker volume. PgDp Home PgUp End Increases the speaker volume. PgDp Home End PgUp Locks the PadFone Station and put it into sleep mode. PgDp Home End PgUp Home PgUp Fn Home PgUp PgDp End Press <Fn> and the arrow keys to scroll up and down or scroll to the start and end in a document or web page.

Home PgUp PgDp PgDp End End Home PgUp PgDp End Home PgUp PgDp End 27 Home PgDp End Using apps and widgets NOTES: • PadFone and PadFone Station are purchased separately. You can seamlessly use applications between your PadFone and PadFone Station. 4 Some downloaded applications may work on your PadFone but may not work on your PadFone Station, and vice versa. Using apps on the PadFone Launching apps Touch to display all your apps. The main apps screen is where you can see all your apps. From • Touch an icon to launch an app. • Swipe the screen to display more apps. • Drag an app icon into the Home Screen. • See apps compatible with the PadFone Station. • Explore widgets.

• Get more apps from the Play Store. the main apps screen you can: Messaging Touch to compose and send a message. 28 Surfing the web Touch to launch the browser and surf the web. Managing notifications Notifications alerts you about new messages, calendar events, media service connections, PC sync information, alarms, and more. Enable the ASUS Quick Setting app to see more and do more from your Notifications area.

NOTES: • If ASUS Quick Setting is not enabled, go to the All Apps screen, touch customized setting and enable Use ASUS Quick Setting. then select ASUS Depending on your sound settings, you will also hear a sound at the same time a notification icon is displayed on the top left of your screen - everytime a new notification arrives. To see your notifications, swipe your finger down from the top of the screen. 29 ASUS Quick Setting Touch to get into Settings screen Touch to dismiss all notifications Touch to toggle performance mode Swipe sideways to see more options Touch to enable Auto screen brightness setting Touch to toggle between Outdoor mode and Normal mode Touch to respond to a notification or swipe sideways to dismiss See more ASUS Quick Settings options below: Icon Allows you to select your preferred mode Description Performance mode: Maximizes the system's performance.



[You're reading an excerpt. Click here to read official ASUS](http://yourpdfguides.com/dref/4350720)

[PADFONE user guide](http://yourpdfguides.com/dref/4350720)

<http://yourpdfguides.com/dref/4350720>

Balanced mode (Default mode): Balances the system's performance and power usage.

Power-saving mode: Energy saving mode 30 Icon Description Touch to enable or disable the auto-rotate screen feature. Touch to enable or disable the Wi-Fi connection. Touch to enable or disable the Bluetooth connection. Touch to enable or disable the sound. Touch to enable or disable the auto-sync feature. Touch to enable or disable the GPS function. Touch to enable or disable the airplane mode. Touch to enable or disable the scanning of available wireless network. 31 Searching your PadFone or web Use the Google Search bar at the top of your Home Screen to help you find anything that you need from your PadFone or from the web. To start searching, you can do either of the following: • Touch on the search bar then key in your search item.

As you key in your search item, Google lists suggestions that may match your search, touch a suggestion to search for it immediately or touch the arrow beside it to add the term into the search field. • Touch then when prompted to Speak now, speak clearly the item you're searching. Taking pictures Use the camera app, taking pictures and videos with your PadFone is fun and easy. The camera app works with two cameras, one 0.3 megapixel camera at the front of your device and one 8 megapixel camera at the rear. The front camera allows you take pictures and videos, while the rear camera allows you to take high resolution pictures and videos. The rear camera also allows you to take pictures in Panorama mode, where you can pan across a subject to create a single picture. You can view your pictures and videos in the Gallery app. To start taking pictures or video, go to the All Apps screen and touch or . 32 Watch

Calendar Watch Calendar allows you to add, edit, and delete an event or appointment and sync it through your Gmail account.

Add new event Tap to view events Edit an event Delete an event Event information To launch Watch Calendar: 1. Touch to go to the All apps screen then touch Watch Calendar . . 2. To add an event or appointment, touch touch + and select a file from the Gallery.

4. Touch Done. 5. To edit the selected event, touch 3. Key in the event name, date and time, location and description of the event.

To attach a file, . Touch to delete the selected event. 33 MyCloud MyCloud is a convenient app to access your cloud contents and synchronize them with your PadFone, remotely control your computer, and access asus@vibe, ASUS one-stop digital entertainment site. To launch MyCloud, touch to go to the All apps screen then touch MyCloud . Touch to view other MyCloud services Touch to access your media files Touch to remotely control your computer Log in using your existing account Touch to access asus@vibe Create a free account IMPORTANT: •••To synchronize your files between your PadFone and computer, download the latest ASUS Pad PC Suite from <http://eee.asus.com/eeepad> •To remotely control your computer using your PadFone, download and install Splashtop® Streamer on your computer or PadFone Station. Download Splashtop® Streamer from www.splashtop.com/streamer 34 SuperNote SuperNote is a convenient app used for writing and painting on your PadFone.

You can take notes, send instant messages, draw sketches, create e-cards with audio recordings or diaries with video, and a lot more. To launch SuperNote, touch to go to the All apps screen then touch SuperNote . All your notebooks Add new notebook All your notebooks and paintbooks Setting, Backup, Restore and Import Notebook 35 Using SuperNote To create a new notebook: 1. Touch . 2. Key in a name for the file and choose the page size: For Pad or For Phone.

3. Select a page color and line style, then touch OK. 4. Touch the newly-created notebook to open and write on the page.

The following screen describes the SuperNote screen features. New page Goes back to SuperNote's main page Delete page Settings Backspace Space Return Previous page Page number Next page 36 Using the SuperNote Notebook SuperNote Notebook is designed to allow you to scribble and doodle on your PadFone continuously regardless of page lines. The app automatically adjusts the scribbled note to fit into the page lines. To use the Scribble or Keyboard feature: 1. Touch and select the Scribble mode or Keyboard mode to write or use the onscreen keyboard to key in your notes.

To use the Keyboard mode, simply touch the keys on the onscreen keyboard to key in your notes. ••To use the Scribble mode, follow these steps: In Scribble mode, touch to select a color and stroke weight to customize strokes. Touch to set a spot for the text cursor, then scribble on the tablet. @@@@and select Doodle. to select the stroke weight and color.

@@@@@@@@@@@@The original app will remain in your All apps screen. @@@@@@@@@@You can find detailed information and manage your apps from the Recent Apps list. 1. Touch the Recent Apps icon at the lower left corner of the Home Screen. 2. Swipe up or down the list to view Recent Apps. Swipe a recent app to the left or right to remove from the list. 3. Touch and hold a recent app to display the menu. Select to remove app from list or display app information.

45 Task Manager ASUS widget displays a list of currently running utilities and applications and their usages in percentages on your PadFone.

@@@@@5. Tap beside each running app to close the app. @@@@@@@@@@If you don't have a Google account, please create one. To access the Play Store: 1. Touch to go to the All apps screen. @@@@@@@@@@There are two ways to go to the Settings screen.

@@@@@@@@@@@@Using the Tool bar options, you can upload, delete, or share selected albums online. Tool bar Album details Share the selected album through ASUS Webstorage, Bluetooth®, Picasa®, Google+®, or Gmail® Delete or cancel the selected album 57 Sharing, deleting, and editing images Touch an image in the Gallery and use the tool bar on the upper right corner to share, delete, or edit a selected image. Tool bar Album details Share the selected album through ASUS Webstorage, Bluetooth®, Picasa®, Google+®, or Gmail® Delete or cancel the selected album Check the image information, and edit the selected image CAUTION! 58 You cannot restore a deleted file.

Gallery widget The Photo Gallery widget allows immediate access to your favorite photos or albums right from the Home Screen. @3. Touch and hold Photo Gallery until the gallery widget box moves to the Home Screen and displays the Choose images menu box. 4. Choose the album or image that you wish to place as a widget on the Home Screen.

59 Camera Touch Camera from the All apps screen to take pictures, record videos, or create panoramic images. You can use the front camera or the back camera to take pictures or record videos. The image and video files are saved to Gallery. Camera mode Zoom in Mode switch Capture button Camera switch Albums Zoom out Flash 60 Video mode Effects Video mode White balance Record button Settings Panoramic mode Capture button Captured range

Panoramic image 61 Email Email allows you to add several e-mail accounts and conveniently browse and manage your e-mails.



[You're reading an excerpt. Click here to read official ASUS PADFONE user guide](http://yourpdfguides.com/dref/4350720)
<http://yourpdfguides.com/dref/4350720>

NOTES: ••The devices must be connected to the same wireless network while enabling My Desktop. My Desktop will not work if the devices are connected via 3G network. 85 Setting up Internet Discovery for My Desktop On your computer: 1. Download and activate Splashtop Streamer from the ASUS support site. 2. Go to Network in Splashtop Remote Streamer.

3. Key in your Google credentials in the Email and Password fields then click Sign in. On your PadFone Station: Go to Settings and enter your Google account in Internet discovery. Your device will automatically detect your computer. 86 asus@vibe asus@vibe is a one-stop entertainment platform that serves as a value-added service for all ASUS products. With asus@vibe, you can access or download a wealth of exciting and engaging digital content such as music, videos, games, magazines, and e-books. You can also tune into your favorite radio stations and stream live TV anytime and anywhere. **NOTES:** •Log in with your ASUS Access account to enjoy the multimedia content in asus@vibe. •The contents on asus@vibe may vary with country or region. 1.

From the All apps screen, touch asus@vibe. 2. Login by using your account. 3. Scroll and select your desired disc or radio station. 87 App Locker App Locker allows you to password-protect your apps. To use App Locker: 1. From the All apps screen, touch on App Locker. 2. Set up your password.

3. Tick the apps you would like to lock. 4. Activate App Locker from Settings on the upper right corner. **NOTES:** ••Locked apps will have lock icons on the Home Screen. You will be asked for your password everytime you access the locked apps. 88 SuperNote SuperNote is a convenient app used for writing and painting on your PadFone Station. You can take notes, send instant messages, draw sketches, create e-cards with audio recordings or diaries with video, and lots more. All your notebooks and paintbooks Delete, copy, move, import or export pages View books Sort by page or last modified Setting, backup, restore Pages and contents 89 Using SuperNote To create a new notebook: 1. Touch + New Notebook on the left panel of the SuperNote main page.

2. Key in a name for the file and choose the page size: For Pad or For Phone. 3. Select a page color and line style, then touch OK. 4. Touch the return path on the upper left for an overall view of the books and note pages. 5. On the upper right, touch Share to share by bluetooth, e-mail, webstorage, short messages social networks, or online gallery. Read Only Bookmarks Goes back to SuperNote's main page New page Delete page New page Settings Share and Export Page Scroll Space Backspace Return Previous page Next page Page number 90 Using the SuperNote Notebook SuperNote Notebook is designed to allow you to scribble and doodle on your PadFone Station continuously regardless of page lines. The app automatically adjusts the scribbled note to fit into the page lines.

1. Choose Scribble mode or Keyboard mode to enter your notes. 2. In Scribble mode, select Color and Stroke weight to customize strokes. 3. Touch to set a spot for the text cursor, then scribble on the tablet. The app automatically adjusts the scribbled note to fit into the page lines. 4. Touch the Baseline function for penmanship guidelines, if necessary. 91 5. Touch Insert to make annotations, create time stamps, insert photos, drawings from paintbook, picture from gallery, voice, video, or other text and picture file. 6. Insert a new page in the notebook or delete to discard unwanted pages. 7. Touch Read Only to enable Read Only mode to view and flip through the note pages and avoid entering unnecessary marks on the pages. 8. Touch Undo to delete changes. Touch Redo to keep the changes. Insert/ Delete page Redo/ Undo Scroll lock 92 9. You can do the following to use the Doodle feature: •••••Touch Brush to select the stroke type.

Touch Stroke to select the stroke weight. Touch Color to select a color from the color palette. Touch Select to move, scale, rotate, delete, or edit the selected area. SuperNote automatically saves and sorts the files by date in /sdcard/supernote. 93 Watch Calendar Watch Calendar allows you to add, edit and delete an event or appointment and sync it through your Gmail account. 1. From the All apps screen, touch Watch Calendar. 2. To add an event or appointment, touch New Event. 3.

Key in the event name, date and time, location and description of the event. You can also attach a file by touching + then selecting a file from the Gallery. 4. Touch Done. To edit an event, touch the event name and touch Edit.

Touch Delete to delete the selected event. 94 Using PadFone widgets Adding widgets Widgets are useful and fun applications that brings information and services conveniently to your Home Screen at-a-glance. @@@@To use Task Manager, swipe your screen to the right. Shows number of running apps Shows cache size status Touch to close app Touch to close all running apps Additional options: •To resize Task Manager, touch and hold anywhere on the app until the resize border appears. Touch and drag the sizing handle to adjust to your preferred screen size.

You can do this to create additional room for more apps. •To remove Task Manager, touch and hold the app until X Remove appears, then without lifting your finger, drag the app into X Remove. 96 Using PadFone Station widgets Adding widgets Use widgets to conveniently access useful and fun applications on your PadFone Station's Home Screen. @@@@The more battery power, the brighter the color. @@@@The battery status of the PadFone and PadFone Station Dock are shown separately. When battery is low, the battery icon turns from blue to red with an exclamation mark. There will also be a warning sound to notify you when the battery is running low. 98 Accessory Using your PadFone Stylus Headset incoming calls to your PadFone.

IMPORTANT: ••5 Use your PadFone Stylus Headset to turn your PadFone Station into a virtual sketchpad and answer Before you start, ensure that you have read all the safety information and operating instructions in the Important Notices bundled with your PadFone to prevent injury or damage to your device. Refer to your PadFone Stylus Headset Quick Start Guide for instructions on using your PadFone/ PadFone Station with the PadFone Stylus Headset.

Speaker Multi-function button Volume up (+) Volume down (-) Micro USB port Microphone Pen clip LED (red/blue light) **NOTE:** Refer to the table on the next page for the descriptions of the LED colors. 99 LED Color Solid blue Slow blue pulse Solid red Description / Status Fully charged Power on, paired and connected Charging mode Quick blue flash Red flash Incoming call or while taking a call Power on and not in pairing mode Establishing the pairing mode Quick red and blue flash 100 Charging your PadFone Stylus Headset We strongly recommend that you charge the battery fully before turning your device on.



[You're reading an excerpt. Click here to read official ASUS](http://yourpdfguides.com/dref/4350720)

[PADFONE user guide](http://yourpdfguides.com/dref/4350720)

<http://yourpdfguides.com/dref/4350720>

3 4 1 2 CAUTION! Double-check the connections and ensure that the power plug is securely attached to the USB charger to prevent overheating and damage to the cables, adapter, or device. NOTES: ••Use the power plug and USB charger that came with your PadFone to charge your PadFone Stylus Headset. The input voltage range between the wall outlet and the power adapter is AC 100V-240V. The output voltage through the micro-USB cable is DC 5V, 2A. 101 Turning your PadFone Stylus Headset on or off To turn your PadFone Stylus Headset on: Press the multi-function button for about 2 seconds. When you turn it on for the first time, the LED quickly flashes red and blue alternately to indicate that it is in the pairing mode and is discoverable by other Bluetooth devices. To turn your PadFone Stylus Headset off: Press the multi-function button for about 3 seconds until the LED turns red. Multi-function button LED (red/blue light) 102 Pairing and connecting devices To pair and connect your devices: 1.

Ensure that the Bluetooth function in your PadFone Station or Bluetooth mobile device is turned on. NOTES: •• For details on turning the Bluetooth function on in your PadFone Station, refer to its user manual that you can download from the ASUS website at support.asus.com For details on turning the Bluetooth function on in your Bluetooth mobile device, refer to the documentation that came with your Bluetooth mobile device. 3.

Press and hold the multi-function button for 5 seconds where the LED quickly flashes red and blue alternately, indicating that your PadFone Stylus Headset is ready to be paired with your PadFone Station. If the LED behaves differently, do the following: a) Press and hold the multi-function button for 3 seconds to turn your PadFone Stylus Headset off. b) Press and hold the multi-function button for 5 seconds to turn your PadFone Stylus Headset on again and enter the pairing mode. 4. To pair your PadFone Stylus Headset with your PadFone Station, go to the All apps screen, touch Stylus Headset and follow the onscreen instructions to complete the pairing process.

NOTE: For details on pairing your Bluetooth mobile device with another device, refer to the documentation that came with your Bluetooth mobile device. 103 Making calls To make a call: 1. Ensure that the devices are paired and connected. 2. From your PadFone Station, touch on the Home Screen or go to the All apps screen. 3. From your contacts list, touch the number you wish to call. 4. Touch to dial. 5.

Use your PadFone Stylus Headset to talk to the person on the other line. Press the volume button to adjust the volume. on your PadFone Station to end the call. 6. Press the multi-function button on your PadFone Stylus Headset or touch Answering calls To answer a call: 1. Ensure that the devices are paired and connected. 2. Press the multi-function button to answer the call. Your PadFone Stylus Headset vibrates or the LED flashes blue to indicate that you have an incoming call. 3.

Talk on your PadFone Stylus Headset as you would on your PadFone or mobile device. Press the volume button to adjust the volume. indicate that the call has ended. NOTES: ••4. Press the multi-function button to end the call.

Your PadFone Stylus Headset vibrates to For clearer audio, keep the pen clip oriented towards the PadFone Station. Do not bend or damage the pen clip. Refrain from touching the pen clip while talking on your PadFone Stylus Headset to avoid any signal interference. 104 105 106 .



[You're reading an excerpt. Click here to read official ASUS](http://yourpdfguides.com/dref/4350720)

[PADFONE user guide](http://yourpdfguides.com/dref/4350720)

<http://yourpdfguides.com/dref/4350720>